

xRAN Front Haul

Software Architecture Specification v21.03

March 2021

Revision 8.0

Intel Confidential



You may not use or facilitate the use of this document in connection with any infringement or other legal analysis concerning Intel products described herein. You agree to grant Intel a non-exclusive, royalty-free license to any patent claim thereafter drafted, which includes subject matter disclosed herein.

Statements in this document that refer to future plans or expectations are forward-looking statements. These statements are based on current expectations and involve many risks and uncertainties that could cause actual results to differ materially from those expressed or implied in such statements. For more information on the factors that could cause actual results to differ materially, see our most recent earnings release and SEC filings at www.intc.com.

Intel technologies' features and benefits depend on system configuration and may require enabled hardware, software, or service activation. Learn more at intel.com, or from the OEM or retailer.

No license (express or implied, by estoppel or otherwise) to any intellectual property rights is granted by this document.

The products described may contain design defects or errors known as errata, which may cause the product to deviate from published specifications. Currently characterized errata are available on request.

Copies of documents which have an order number and are referenced in this document may be obtained by calling 1-800-548-4725 or visiting www.intel.com/design/literature.htm.

Tests document the performance of components on a particular test, in specific systems. Differences in hardware, software, or configuration will affect actual performance. Consult other sources of information to evaluate performance as you consider your purchase. For more complete information about performance and benchmark results, visit www.intel.com/performance.

Intel does not control or audit third-party benchmark data or the web sites referenced in this document. You should visit the referenced web site and confirm whether referenced data are accurate.

Intel technologies may require enabled hardware, software, or service activation.

No product or component can be absolutely secure.

Your costs and results may vary.

Intel, the Intel logo, and other Intel marks are trademarks of Intel Corporation or its subsidiaries.

Other names and brands may be claimed as the property of others.

© 2019-2021, Intel Corporation. All rights reserved.



Contents

1.0	Intro	duction	10		
	1.1	Scope	10		
	1.2	Intended Audience			
	1.3	Terminology			
	1.4	Reference Documents			
2.0	Assur	mptions, Dependencies, and Constraints	14		
	2.1	Assumptions	14		
	2.2	Requirements			
	2.3	Dependencies			
	2.4	Constraints			
3.0	Archi	tecture Overview	16		
	3.1	Introduction	16		
	3.2	5G NR L1 Application Threads	17		
	3.3	Sample Application Thread Model			
	3.4	Functional Split			
	3.5	Data Flow			
	3.6	Timing, Latency, and Synchronization to GPS			
	3.7	Virtualization and Container-Based Usage2			
4.0	Trans	sport Layer and O-RAN Fronthaul Protocol Implementation	24		
	4.1	Introduction			
	4.2	Supported Feature Set	25		
	4.3	Transport Layer			
	4.4	U-plane	37		
		4.4.1 Radio Application Header			
		4.4.2 Data Section Application Data Header			
		4.4.3 Data Payload			
	4.5	C-plane			
		4.5.1 Ethernet Header			
		4.5.2 eCPRI Header			
		4.5.4 Section Type 0 Structure			
		4.5.5 Section Type 0 Structure			
		4.5.6 Section Type 3 Structure			
		4.5.7 Section Type 5 Structure			
		4.5.8 Section Type 6 Structure	46		
5.0	xRAN Library Design		47		
	5.1	General Introduction			
	5.2	Initialization and Close			
		5.2.1 Configuration			
		5.2.2 Start/Stop			
		5.2.3 Data Exchange	52		



		5.2.4 C-plane Information Settings	52
	5.3	Memory Management	53
		5.3.1 External Interface Memory	54
	5.4	xRAN Specific Functionality	56
		5.4.1 External API	
		5.4.2 C-plane	
		5.4.3 U-plane	
	5.5	Supporting Code	
		5.5.1 Timing	
		5.5.3 xRAN Ethernet	
		5.5.4 xRAN Ethdi	
		5.5.5 O-RAN One Way Delay Measurements	70
		5.5.6 Mlog Usage	71
6.0	Samp	le Application	72
Appe	ndix A	Setup Configuration	75
	A.1	Setup Configuration	75
	A.2	Prerequisites	76
	A.3	Configuration of System	80
	A.4	Install and Configure Sample Application	83
	A.4.1	Install and Configure FlexRAN 5G NR L1 Application	84
	A.4.2	Configure FlexRAN 5G NR L1 Application for multiple O-RUs with multiple nu	merologies 103
	A.4.3	Install and Configure FlexRAN 5G NR L1 Application for Massive - MIMO	103
Appe	ndix B	PTP Configuration	143
	B.1	PTP Synchronization	143
	B.1.1	PTP for Linux* Requirements	143
	B.1.2	ptp4l	144
	B.1.3	phc2sys	144
	B.1.4	Configuration C3	145
	B.1.5	Support in xRAN Library	149
Appe	ndix C	eCPRI DDP Profile for Columbiaville (Experimental Feature)	150
	C.1	Introduction	150
	C.2	Software/Firmware Requirements	150
	C.3	DDP Package Setup	150
	C.3.1	Wireless Edge DDP Package	151
	C.3.2	Option 1: ice Linux Base Driver	151
	C.3.3	Option 2: DPDK Driver Only	152



	C.3.4	Loading DDP Package to a Specific Intel Ethernet 800 Series Device	152
	C.3.5	For kernel driver:	153
	C.3.6	If using only DPDK driver:	153
	C.4	O-RAN Front haul eCPRI	154
	C.4.1	Limitations	155
	C.5	RTE Flow API	155
	C.5.1	RTE Flow Rule Validation	156
	C.5.2	RTE Flow Rule Creation	156
	C.5.3	RTE Flow Rule Destruction	156
	C.5.4	RTE Flow Flush	
	C.5.5	RTE Flow Query	
	C.6	RTE Flow Rules	
	C.6.1	Attributes	
	C.6.2	Pattern items	
	C.6.3	Matching Patterns	
	C.6.4	Route to specific Queue id based on ecpriRtcid/ecpriPcid	
Figur	es		
Figure 1.		Architecture Block Diagram	
Figure 2.		5G NR L1app Threads	
Figure 3.		Sample Application Threads	
Figure 4.		eNB/gNB Architecture with O-DU and RU Functional Split	
Figure 5. Figure 6.		Data Flows	
Figure 7.		C-plane and U-plane Packet Exchange	
Figure 8.		O-RAN Fronthaul Process	
Figure 9.		Configuration C1	24
Figure 10).	Configuration C3	25
Figure 11		Native Ethernet Frame with VLAN	
Figure 12		eCPRI Header Field Definitions	
Figure 13		ecpri one-way delay measurement message	
Figure 14 Figure 15		Bit Allocations of ecpriRtcid/ecpriPcid O-RAN Packet Components	
Figure 16		Radio Application Header	
Figure 17		Data Section Application Data Header	
Figure 18		Data Payload	
Figure 19		Radio Application Common Header	42
Figure 20).	Section Type 0 Structure	42
Figure 21		Section Type 1 Structure	43
Figure 22		Section Type 3 Structure	
Figure 23	l.	Section Type 5 Structure	45
			xRAN Front Haul



Figure 24.	Section Type 6 Structure	46
Figure 25.	Illustration of xRAN Sublayers	50
Figure 26.	Sample Application	72
Figure 27.	Setup for O-RAN Testing	75
Figure 28.	Setup for O-RAN Testing with PHY and Configuration C3	75
Figure 29.	Setup for O-RAN Testing with PHY and Configuration C3 for Massive MIMOMIMO	76
Figure 30.	O-RAN FH VNF	155
Tables		
Table 1.	Terminology	10
Table 2.	Reference Documents	12
Table 3.	Supported Data Flow	20
Table 4.	Front Haul Interface Latency (numerology 3 - mmWave)	21
Table 5.	Front Haul Interface Latency (numerology 0 - Sub6)	22
Table 6.	Front Haul Interface Latency (numerology 1 - Sub6)	22
Table 7.	O-RAN Mandatory and Optional Feature Support	25
Table 8.	Levels of Validation	26
Table 9.	Section Types	41
Table 10.	struct xran_cp_header_params - Common Radio Application HeaderHeader	57
Table 11.	struct xran_cp_header_params - Section Specific Parameters	58
Table 12.	Parameters for Sections	59
Table 13.	Patterns & Input Sets for Flow Director and RSS (DPDK 21.02)	155
Table 14.	Example RTE FLOW Item Types	158
Table 15.	RTE FLOW Actions	162
Table 16.	Pattern Items to match eCPRI packet with a Specific Physical Channel ID (pc_id)	162
Table 17.	QUEUE action for given queue id	163



Revision History

Revision Number	Description	Revision Date
8.0	Updated for the FlexRAN Software Release v21.03 with the following changes: Revised Section 1.3 Revised Table 8 in Section 4.2 Revised Section 6 Added Appendix C with eCPRI DDP for Columbiaville	March 2021
7.0	Updated for the FlexRAN Software Release v20.11 with the following changes: Revised Section 1.4 Revised Section 3.7 Revised Table 8 in Section 4.2 Revised Section 5.5.3, xRAN Ethernet Revised Appendix A.2, A.3	November 2020
6.0	Updated for the FlexRAN Software Release v20.08 with the following changes: Revised Section 2.1, software version number Revised Section 2.4, Category B Support Revised Section 4.1 Note Revised Table 7 and Table 8 Revised Section 4.5.5 Note Revised Section 5.0 Revised Section 5.2.4, C-plane c Revised Section 5.3.1, External Interface memory Revised Section 5.4.2.1, Step 1, Step 2, and Step 3 Revised Table 11 Revised Section 5.4.3, U-plane Revised Section 6.0, 1 Cell Sub6 100MHz TDD (Category B) Replaced Figure 28 Revised Appendix A.1, A.2, A3, A4	August 2020
5.0	 Updated for the FlexRAN software release v20.04 Updated Table 1, Terminology Table and Table 2, Reference Documents Revised Section 2.1, Assumptions Revised Section 2.3, Dependencies DPDK v19.11 Revised Section 2.3, Constraints Revised Section 3.1, Introduction Revised Section 4.1, Introduction Revised Table 7 and Table 8 Revised Section 4.3 	April 2020



Revision Number	Description	Revision Date
	 Revised Section 4.4.2 and Section 4.4.3 Revised Section 4.5, C-Plane 	
	 Revised Section 5.0, xRAN Library Design code Revised Section 5.2.1, Configuration 	
	Revised Section 5.2.4, C-Plane Information Settings code and text	
	 Revised Section 5.4.1, External API Revised Section 5.4.2.1.1, API and Data Structures Revised Section 5.4.3, U-Plane 	
	Revised Section 6.0, Sample Application Revised Appendix A.2. Prerequisites	
	 Revised Appendix A3, Configuration of System Revised Appendix A4, Install and Configure Sample Application 	
	Revised Appendix A5, Install and Configure FlexRAN 5G NR L1 Application	
4.0	Updated for the FlexRAN software release v20.02	February 2020
3.0	Updated for the FlexRAN software release v19.10	October 2019
2.0	Updated for the FlexRAN software release v19.06	July 2019
1.0	Initial release	April 2019



1.0 Introduction

This document describes the design of the Open Radio Access Network (O-RAN) Fronthaul interface system architecture supporting Fifth Generation New Radio (5G NR) and Long-Term Evolution (LTE). In this document, Extensible Radio Access Network (xRAN) refers to the software library implementing the O-RAN Fronthaul interface according to O-RAN Fronthaul Working Group Control, User and Synchronization Plane Specification (refer to Table 2).

1.1 Scope

This document provides a description of xRAN library design and implementation.

1.2 Intended Audience

The intended audience for this document is software engineers and system architects who design and develop 5G systems using the O-RAN Fronthaul interface, according to O-RAN Fronthaul Working Group Control, User, and Synchronization Plane Specification (refer to <u>Table 2</u>).

1.3 Terminology

Table 1. Terminology

Term	Description
5G NR	Fifth Generation New Radio
ACS	Access Control system
API	Application Programming Interface
вом	Bill of Materials
СР	Cyclic Prefix
DDP	Dynamic Device Personalization
DPDK	Data Plane Development Kit
eAxC	Extended Antenna Carrier
eCPRI	Enhanced Common Public Radio Interface
eNB	Enode B
ETH	Ethernet
FCS	Frame Check Sequence
FEC	Forward Error Correction
FFT	Fast Fourier Transform
FH	Front Haul
gNB	Next-generation NodeB also named as Base Station
GNSS	Global Navigation Satellite System



Term	Description	
GPS	Global Positioning System	
HARQ	Hybrid Automatic Repeat Request	
HW	Hardware	
IFG	Interframe Gap	
IFFT	Inverse Fast Fourier Transform	
loT	Inter-Operability Testing	
IQ	In-band and Quadrature	
LAA	License Assisted Access	
LTE	Long Term Evolution	
MAC	Media Access Control	
MEC	Mobile Edge Computing	
M-Plane	Management Plane	
mmWave	Millimeter Wave	
NIC	Network Interface Controller	
O-DU	O-RAN Distributed Unit: a logical node hosting RLC/MAC/High-PHY layers based on a lower layer functional split.	
O-RU	O-RAN Radio Unit: a logical node hosting Low-PHY layer and RF processing based on a lower layer functional split. This is similar to 3GPP's "TRP" or "RRH" but more specific in including the Low-PHY layer (FFT/IFFT, PRACH extraction).	
OWD	One Way Delay	
PDCCH	Physical Downlink Control Channel	
PDSCH	Physical Downlink Shared Channel	
PHC	Physical Hardware Clock	
PHP	Hypetext Preprocessor	
PMD	Poll Mode Driver	
POSIX	Portable Operating System Interface	
PRACH	Physical Random Access Channel	
PRB	Physical Resource Block	
PRTC	Protected Real Time Clock	
PUCCH	Physical Uplink Control Channel	
PUSCH	Physical Uplink Shared Channel	
PTP	Precision Time Protocol	
RA	Random Access	
RAN	Radio Access Network	
RB	Resource Block	
RE	Resource Element	
RLC	Radio Link Control	



Term	Description
RoE	Radio over Ethernet
RT	Real Time
RTE	Real Time Environment
RSS	Receive Side Scaling
RU	Radio Unit
SR-IOV	Single Root Input/Output Virtualization
SW	Software
SyncE	Synchronous Ethernet
TDD	Time Division Duplex
ToS	Top of the Second
TSC	Time Stamp Counter
TTI	Transmission Time Interval
UE	User Equipment
UL	Uplink
VF	Virtual Function
VIM	Virtual Infrastructure Manager
VLAN	Virtual Local Area Network
VM	Virtual Machine
WLS	Wireless Subsystem Interface
xRAN	Extensible Radio Access Network

1.4 Reference Documents

Table 2. Reference Documents

Document	Document No./Location
FlexRAN Reference Solution Software Release Notes	575822
FlexRAN Reference Solution L1 XML Configuration User Guide	571741
FlexRAN Reference Solution LTE eNB L2-L1 Application Programming Interface [API] Specification	571742
FlexRAN Reference Solution L2-L1 nFAPI Specification	576423
FlexRAN and Mobile Edge Compute (MEC) Platform Setup Guide	575891
FlexRAN 5G NR Reference Solution RefPHY (Doxygen).	603577



Document	Document No./Location
Intel® Ethernet Controller E810 Dynamic Device Personalization (DDP) Technology Guide	617015
3GPP* specification series	https://www.3gpp.org/dynareport/SpecList.htm?release=Rel- 15&tech=3&ts=1&tr=1
Wolf Pass Server Documentation	https://ark.intel.com/products/codename/80739/Wolf-Pass
Intel® C++ Compiler in Intel® Parallel Studio XE	https://software.intel.com/en-us/c-compilers/ipsxe
DPDK documentation	http://dpdk.org/doc/guides/
O-RAN Fronthaul Working Group Control, User and Synchronization Plane Specification (ORAN- WG4.CUS.0-v04.00)	https://www.o-ran.org/ specifications
ORAN Specification	https://www.o-ran.org/adopter-license
IEEE-1588-2008 IEEE Standard for a Precision Clock Synchronization Protocol for Networked Measurement and Control Systems	https://standards.ieee.org/standard/1588-2008.html
eCPRI Specification V2.0 Interface Specification	http://www.cpri.info/spec.html



2.0 Assumptions, Dependencies, and Constraints

This chapter contains limitations on the scope of the document.

2.1 Assumptions

Implementation and details of 5G NR gNodeB and LTE eNodeB software design are outside of the scope of this document.

It is expected that the user is familiar with the *O-RAN Fronthaul Working Group Control, User, and Synchronization Plane Specification* (refer to Table 2). Only implementation-specific details are provided in this document.

Unless otherwise specified, the information in this document is provided for the v21.03 version of the xRAN library.

2.2 Requirements

Usage of this library requires PTP for Linux* v2.0 (or later) to be installed to provide IEEE 1588 synchronization.

2.3 Dependencies

xRAN library implementation depends on the Data Plane Development Kit (DPDK v20.11).

DPDK v20.11 should be patched with corresponding DPDK patch provided with FlexRAN release (see <u>Table 1</u>, FlexRAN Reference Solution Software Release Notes)

Intel® C++ Compiler v19.0.3 is used.

NOTE: Optionally Octave v3.8.2 can be used to generate reference IQ samples (octave-3.8.2-20.e17.x86 64).

2.4 Constraints

This release has been designed and implemented to support the following numerologies defined in the 3GPP specifications for LTE and 5GNR (refer to <u>Table 2</u>):

5G NR

Category A support:

- Numerology 0 with bandwidth 5/10/20 MHz with up to 12 cells
- Numerology 1 with bandwidth 100 MHz with up to 1 cell
- Numerology 3 with bandwidth 100 MHz with up to 1 cell

Category B support:

Numerology 1 with bandwidth 100 MHz where the antenna panel is up to 64T64R with up to 3 cells.

LTE

Category A support:

Bandwidth 5/10/20 MHz with up to 12 cells

Assumptions, Dependencies, and Constraints



Category B support:

Bandwidth 5/10/20 MHz for 1 cell

The feature set of O-RAN protocol should be aligned with Radio Unit (O-RU) implementation. Inter-operability testing (IoT) is required to confirm the correctness of functionality on both sides. The exact feature set supported is described in Chapter 4.0 Transport Layer and O-RAN Fronthaul Protocol Implementation of this document.

§



Architecture Overview 3.0

This section provides an overview of the O-RAN architecture.

Introduction 3.1

The front haul interface, according to the O-RAN Fronthaul specification, is part of the 5G NR L1 reference implementation provided with the FlexRAN software package. It performs communication between O-RAN Distributed Unit (O-DU) and O-RAN Radio Unit (O-RU) and consists of multiple HW and SW components.

The logical representation of HW and SW components is shown in Figure 1.

The same architecture design is applicable for LTE; however, the FH library is not integrated with the PHY pipeline for FlexRAN LTE.

O-DU PHY WLS L2 5GNR Control TTI SYM IQs CU connection clock_gettime() **XRAN Lib** PTP4L **DPDK** PTP4L Fortville XL710 Fortville XL710 PHC2SYS **Back Haul** FH SYSTEM TIMER

Figure 1. **Architecture Block Diagram**

VF

From the hardware perspective, two networking ports are used to communicate to the Front Haul and Back (Mid) Haul network as well as to receive PTP synchronization. The system timer is used to provide a "sense" of time to the gNB application.

From the software perspective, the following components are used:

Linux* PTP provides synchronization of system timer to GPS time:

PF

- ptp41 is used to synchronize oscillator on Network Interface Controller (NIC) to PTP GM.
- phc2sys is used to synchronize system timer to oscillator on NIC.
- The DPDK to provide the interface to the Ethernet port.



- xRAN library is built on top of DPDK to perform U-plane and C-plane functionality according to the O-RAN Fronthaul specification.
- 5GNR reference PHY uses the xRAN library to access interface to O-RU. The interface between the library and PHY is defined to communicate TTI event, symbol time, C-plane information as well as IQ sample data.
- 5G NR PHY communicates with the L2 application using the set of MAC/PHY APIs and the shared memory interface defined as WLS.
- L2, in turn, can use Back (Mid) Haul networking port to connect to the CU unit in the context of 3GPP specification.

In this document, we focus on details of the design and implementation of the xRAN library for providing Front Haul functionality for both mmWave and Sub-6 scenarios as well as LTE.

The xRAN M-plane is not implemented and is outside of the scope of this description. Configuration files are used to specify selected M-plane level parameters.

3.2 5G NR L1 Application Threads

The specifics of the L1 application design and configuration for the given scenario can be found in document 603577, FlexRAN 5G NR Reference Solution RefPHY (Doxygen) (refer to Table 2) Only information relevant to front haul is presented in this section.

Configuration of l1app with xRAN interface for Front Haul is illustrated acting as an O-DU in Figure 2.

Figure 2. 5G NR L1app Threads

In this configuration of L1app, the base architecture of 5G NR L1 is not changed. The original Front Haul FPGA interface was updated with the O-RAN fronthaul interface abstracted via the xRAN library.

O-RAN FH Thread Performs:

- Symbol base "time event" to the rest of the system based on System Clock synchronized to GPS time via PTP
- Baseline polling mode driver performing TX and RX of Ethernet packets
- Most of the packet processing such as Transport header, Application header, Data section header, and interactions with the rest of the PHY processing pipeline.
- Polling of BBDev for FEC on PAC N3000 acceleration card

The other threads are standard for the L1app and created the independent usage of O-RAN as an interface to the Radio.




Communication between L1 and O-RAN layer is performed using a set of callback functions where L1 assigned callback and O-RAN layer executes those functions at a particular event or time moment. Detailed information on callback function options and setting, as well as design, can be found in the sections below.

Design and installation of the l1app do not depend on the Host, VM, or container environment and the same for all cases.

3.3 Sample Application Thread Model

Configuration of a sample application for both the O-DU and O-RU follows the model of 5G NR l1app application in Figure 2, but no BBU or FEC related threads are needed as minimal O-RAN FH functionality is used only.

Figure 3. Sample Application Threads




In this scenario, the main thread is used only for initializing and closing the application. No execution happens on core 0 during run time.

3.4 Functional Split

Figure 1 corresponds to the O-RU part of the O-RAN split. Implementation of the RU side of the O-RAN protocol is not covered in this document.




Figure 4. eNB/gNB Architecture with O-DU and RU



More than one RU can be supported with the same implementation of the xRAN library and depends on the configuration of gNB in general. In this document, we address details of implementation for a single O-DU – O-RU connection.

The O-RAN Fronthaul specification provides two categories of the split of Layer 1 functionality between O-DU and O-RU: Category A and Category B.

Figure 5. Functional Split






3.5 Data Flow

Table 3 lists the data flows supported for a single RU with a single Component Carrier.

Table 3. Supported Data Flow

Plane	ID	Name	Contents	Periodicity
U-Plane	1a	DL Frequency Domain IQ Data	DL user data (PDSCH), control channel data (PDCCH, etc.)	symbol
	1b	UL Frequency Domain IQ Data	UL user data (PUSCH), control channel data (PUCCH, etc.)	symbol
	1c	PRACH Frequency Domain IQ Data	UL PRACH data	slot or symbol
C-Plane	2a	Scheduling Commands (Beamforming is not supported)	Scheduling information, FFT size, CP length, Subcarrier spacing, UL PRACH scheduling	~ slot
S-Plane	S	Timing and Synchronization	IEEE 1588 PTP packets	-

Figure 6. Data Flows



Information on specific features of C-Plane and U-plane provided in Section <u>6.0.</u> Sample Application Configuration of S-plane used on test setup for simulation is provided in <u>Appendix B, PTP Configuration</u>.

Data flow separation is based on VLAN (applicable when layer 2 or layer 3 is used for the C/U-plane transport.)

- NOTE: The mechanism for assigning VLAN ID to U-Plane and C-Plane is assumed to be via the M-Plane.
- NOTE: VLAN Tag is configurable via the standard Linux IP tool, refer to Appendix A, Setup Configuration.
- NOTE: No Quality of Service (QoS) is implemented as part of xRAN library. Standard functionality of ETH port can be used to implement QoS.






Figure 7. C-plane and U-plane Packet Exchange

3.6 Timing, Latency, and Synchronization to GPS

The O-RAN Fronthaul specification defines the latency model of the front haul interface and interaction between O-DU and O-RU. This implementation of the xRAN library supports only the category with fixed timing advance and Defined Transport methods. It determines O-DU transmit and receive windows based on pre-defined transport network characteristics, and the delay characteristics of the RUs within the timing domain.

Table 4 below provides default values used for the implementation of O-DU – O-RU simulation with mmWave scenario. Table 5 and Table 6 below provide default values used for the implementation of O-DU – O-RU simulation with numerology 0 and numerology 1 for Sub6 scenarios. Configuration can be adjusted via configuration files for sample application and reference PHY.

NOTE: However, simulation of the different range of the settings was not performed, and additional implementation changes might be required as well as testing with actual O-RU. The parameters for the front haul network are out of scope as a direct connection between O-DU and O-RU is used for simulation.

Table 4. Front Haul Interface Latency (numerology 3 - mmWave)

	Model	C	-Plane	U-Plan	e
	Parameters	DL	UL	DL	UL
	T2amin	T2a_min_cp_dl=50	T2a_min_cp_ul=50	T2a_min_up=25	NA
O-RU	T2amax	T2a_max_cp_dl=140	T2a_max_cp_ul=140	T2a_max_up=140	NA
U-RU		Tadv_cp_dl	NA	NA	NA
	Ta3min	NA	NA	NA	Ta3_min=20



	Model Parameters	C-Plane		U-Plane		
		DL	UL	DL	UL	
	Ta3max	NA	NA	NA	Ta3_max=32	
	T1amin	T1a_min_cp_dl=70	T1a_min_cp_ul=60	T1a_min_up=35	NA	
O DII	T1amax	T1a_max_cp_dl=100	T1a_max_cp_ul=70	T1a_max_up=50	NA	
O-DU Ta4min		NA	NA	NA	Ta4_min=0	
	Ta4max	NA	NA	NA	Ta4_max=45	

Table 5. Front Haul Interface Latency (numerology 0 - Sub6)

	Model	C-I	Plane	U-Plane	
	Parameters	DL	UL	DL	UL
	T2amin	T2a_min_cp_dl=400	T2a_min_cp_ul=400	T2a_min_up=200	NA
T2amax O-RU	T2a_max_cp_dl=112 0	T2a_max_cp_ul=1120	T2a_max_up=1120	NA	
	Tadv_cp_dl	NA	NA	NA	
	Ta3min	NA	NA	NA	Ta3_min=160
	Ta3max	NA	NA	NA	Ta3_max=256
	T1amin	T1a_min_cp_dl=560	T1a_min_cp_ul=480	T1a_min_up=280	NA
O-DU	T1amax	T1a_max_cp_dl=800	T1a_max_cp_ul=560	T1a_max_up=400	NA
0-00	Ta4min	NA	NA	NA	Ta4_min=0
	Ta4max	NA	NA	NA	Ta4_max=360

Table 6. Front Haul Interface Latency (numerology 1 - Sub6)

	Model	C-Plane		U-Plane	
	Parameters	DL	UL	DL	UL
	T2amin	T2a_min_cp_dl=285	T2a_min_cp_ul=285	T2a_min_up=71	NA
	T2amax	T2a_max_cp_dl=429	T2a_max_cp_ul=429	T2a_max_up=428	NA
O-RU		Tadv_cp_dl	NA	NA	NA
	Ta3min	NA	NA	NA	Ta3_min=20
	Ta3max	NA	NA	NA	Ta3_max=32
	T1amin	T1a_min_cp_dl=285	T1a_min_cp_ul=285	T1a_min_up=96	NA
O-DU	T1amax	T1a_max_cp_dl=429	T1a_max_cp_ul=300	T1a_max_up=196	NA
0-00	Ta4min	NA	NA	NA	Ta4_min=0
	Ta4max	NA	NA	NA	Ta4_max=75

IEEE 1588 protocol and PTP for Linux* implementations are used to synchronize local time to GPS time. Details of the configuration used are provided in Appendix B, PTP Configuration. Local time is used to get Top of the Second



(ToS) as a 1 PPS event for SW implementation. Timing event is obtained by performing polling of local time using clock_gettime(CLOCK_REALTIME, ...)

All-time intervals are specified concerning the GPS time, which corresponds to OTA time.

3.7 Virtualization and Container-Based Usage

xRAN implementation is deployment agnostic and does not require special changes to be used in virtualized or container-based deployment options. The only requirement is to provide one SRIOV base virtual port for C-plane and one port for U-plane traffic per O-DU instance. This can be achieved with the default Virtual Infrastructure Manager (VIM) as well as using standard container networking.

To configure the networking ports, refer to the FlexRAN and Mobile Edge Compute (MEC) Platform Setup Guide (<u>Table 2</u>) and readme.md in xRAN library or Appendix A.

§



4.0 Transport Layer and O-RAN Fronthaul Protocol Implementation

This chapter describes how the transport layer and O-RAN Fronthaul protocol are implemented.

4.1 Introduction

Figure 8 presents an overview of the O-RAN Fronthaul process.

Figure 8. O-RAN Fronthaul Process



The xRAN library provides support for transporting In-band and Quadrature (IQ) samples between the O-DU and O-RU within the O-RAN architecture based on functional split 7.2x. The library defines the O-RAN packet formats to be used to transport radio samples within Front Haul according to the O-RAN Fronthaul specification, refer to Table 2. It provides functionality for generating O-RAN packets, appending IQ samples in the packet payload, and extracting IQ samples from O-RAN packets.

- **NOTE:** Version 21.03 of the library supports U-plane and C-plane only. M-plane is not supported. It is ready to be used in the PTP synchronized environment.
- NOTE: Regarding the clock model and synchronization topology, configurations C1 and C3 of the connection between O-DU and O-RU are the only configurations supported in this release of the xRAN implementation.
- NOTE: Quality of PTP synchronization for the S-plane of O-RAN Fronthaul requirements as defined for O-RU is out of the scope of this document. PTP master and PTP slave configuration are expected to satisfy only the O-DU side of requirements and provide the "best-effort" PTP master for O-RU. This may or may not be sufficient for achieving the end to end system requirements of S-plane. Specialized dedicated NIC card with additional HW functionality might be required to achieve PTP master functionality to satisfy O-RU precision requirements for RAN deployments scenarios.

Figure 9. Configuration C1







Figure 10. Configuration C3



4.2 Supported Feature Set

The O-RAN Fronthaul specification defines a list of mandatory functionalities.

NOTE: Not all features defined as Mandatory for O-DU are currently supported to full extended.

The following tables contain information on what is available, and the level of validation performed for this release.

NOTE: Cells with a red background are listed as mandatory in the specification but not supported in this implementation of xRAN.

Table 7. O-RAN Mandatory and Optional Feature Support

Category	Feature	O-DU Support	Support
	Support for CAT-A RU (up to 8 spatial streams)	Mandatory	Υ
RU Category	Support for CAT-A RU (> 8 spatial streams)		Υ
	Support for CAT-B RU (precoding in RU)	Mandatory	Υ
	Beam Index based	Mandatory	Υ
Decrete wein a	Real-time BF Weights	Mandatory	Υ
Beamforming	Real-Time Beamforming Attributes		N
	UE Channel Info		N
	Programmable static-bit-width Fixed Point IQ	Mandatory	Υ
	Real-time variable-bit-width		Υ
	Compressed IQ		Υ
	Block floating point compression		Υ
	Block scaling compression		N
Bandwidth Saving	u-law compression		N
	modulation compression		Υ
	beamspace compression		Υ
	Variable Bit Width per Channel (per data section)		Υ
	Static configuration of U-Plane IQ format and compression header		N

25



Category	Feature	O-DU Support	Support
	Use of "symInc" flag to allow multiple symbols in a C- Plane section		N
Energy Saving	Transmission blanking		N
O-DU - RU	Pre-configured Transport Delay Method	Mandatory	Υ
Timing	Measured Transport Method (eCPRI Msg 5)		N
Synchronization	G.8275.1	Mandatory	Y* (*C3 only)
	G.8275.2		N
	GNSS based sync		N
	SyncE		N
	L2: Ethernet	Mandatory	Υ
	L3: IPv4, IPv6 (CUS Plane)		N
	QoS over Fronthaul	Mandatory	Υ
	Prioritization of different U-plane traffic types		N
Transport	Support of Jumbo Ethernet frames		N
Features	eCPRI	Mandatory	Υ
	support of eCPRI concatenation		N
	IEEE 1914.3		N
	Application fragmentation	Mandatory	Υ
	Transport fragmentation		N
	LAA LBT O-DU Congestion Window mgmt		N
Other	LAA LBT RU Congestion Window mgmt		N

Details on the subset of O-RAN functionality implemented are shown in Table 8.

Level of Validation Specified as:

- **C**: Completed code implementation for xRAN Library
- I: Integrated into Reference PHY
- T: Tested end to end with O-RU

Table 8. Levels of Validation

Category	ltem	Status	С	1	Т
	Radio access technology (LTE/NR)	NR/LTE	N/A	N/A	N/A
Comoral	Nominal sub-carrier spacing	15/30/120KHz	Υ	Υ	N
General	FFT size	512/1024/2048/4096	Υ	Υ	N
	Channel bandwidth	5/10/20/100Mhz	Υ	Υ	N



Category	Item	Status	С	1	Т
	Number of the channel (Component Carrier)	12	Υ	Υ	N
	RU category	A, B	Υ	Υ	N
	TDD Config	Supported/Flexible	Υ	Υ	N
	FDD Support	Supported	Υ	Υ	N
	Tx/Rx switching based on 'dataDirection' field of C-plane message	Supported	Y	Υ	N
	IP version for Management traffic at fronthaul network	N/A	N/A	N/A	N/A
	One Type 3 message for all repeated PRACH preambles	Supported	Y	Υ	N
	Type 3 message per repeated PRACH preambles	1	Y	Υ	N
PRACH	timeOffset including cpLength	Supported	Υ	Υ	Ν
	Supported	Supported	Υ	Υ	N
	PRACH preamble format/index number (number of the occasion)	Supported	Υ	Υ	N
	Network delay determination	Supported	Υ	Υ	N
Delay management	lls-CU timing advance type	Supported	Υ	Υ	N
	Non-delay managed U-plane traffic	Not supported	N	N	N
	Transport encapsulation (Ethernet/IP)	Ethernet	Υ	Υ	N
	Jumbo frames	Supported	Υ	Υ	N
	Transport header (eCPRI/RoE)	eCPRI	Υ	Υ	N
	IP version when Transport header is IP/UDP	N/A	N/A	N/A	N/A
	eCPRI Concatenation when Transport header is eCPRI	Not supported	N	N	N
	eAxC ID CU_Port_ID bitwidth	4 *	Υ	Υ	N
C/U-plane Transport	eAxC ID BandSector_ID bitwidth	4 *	Υ	Υ	N
·	eAxC ID CC_ID bitwidth	4*	Υ	Υ	N
	eAxC ID RU_Port_ID bitwidth	4*	Υ	Υ	N
	Fragmentation	Supported	Υ	Υ	N
	Transport prioritization within U-plane	N/A	N	N	N
	Separation of C/U-plane and M-plane	Supported	Υ	Υ	N
	Separation of C-plane and U-plane	VLAN ID	Υ	Υ	N
	Max Number of VLAN per physical port	16	Υ	Υ	N
	Rx_on_time	Supported	Υ	Υ	N



Category	1	tem	Status	С	1	т
	Rx_early		Supported	N	N	N
Reception	Rx_late		Supported	N	N	N
Window Monitoring	Rx_corrupt		Supported	N	N	N
(Counters)	Rx_pkt_dupl		Supported	N	N	N
	Total_msgs_rcv	d	Supported	Υ	N	N
	RU beamforming ty	/pe	Index and weights	Υ	Υ	N
Beamforming	Beamforming conti	rol method	C-plane	Υ	N	N
	Number of beams		No-restrictions	Υ	Υ	N
	U-plane data comp	ression method	Supported	Υ	Υ	Υ
IQ compression	U-plane data IQ bit compression)	width (Before/After	BFP: 8,9,12,14 bits Modulation compression: 1,2,3,4 bits	Y	Y	Y
	Static configuration of U-plane IQ format and compression header		Supported	N	N	N
	ecpriVersion		001b	Υ	Υ	Υ
	ecpriReserved		Supported	Υ	Υ	Υ
	ecpriConcatenation		Not supported	N	N	N
		U-plane	Supported	Υ	Υ	Υ
eCPRI	ecpriMessage	C-plane	Supported	Υ	Υ	Υ
Header		Delay measurement	Supported	Υ	Υ	Υ
Format	ecpriPayload (pa	ayload size in bytes)	Supported	Υ	Υ	Υ
	ecpriRtcid/ecp	riPcid	Supported	Υ	Υ	Υ
	ecpriSeqid: Sequence ID		Supported	Υ	Υ	Υ
	ecpriSeqid: E bit		Supported	Υ	Υ	Υ
	ecpriSeqid: Subsequence ID		Not supported	N	N	N
	Section Type 0		Not supported	N	N	N
	Section Type 1		Supported	Υ	Υ	Υ
C-plane	Section Type 3		Supported	Υ	Υ	Υ
Туре	Section Type 5		Not supported	N	N	N
	Section Type 6		Not supported	N	N	N
	Section Type 7		Not supported	N	N	N
C-plane Packet	Coding of Information Elements –	dataDirection (data direction (gNB Tx/Rx))	Supported	Υ	Υ	N
Format	Application Layer, Common	payloadVersion (payload version)	001b	Υ	Υ	N



Category		Item	Status	С	1	Т
		filterIndex (filter index)	Supported	Y	Y	N
		frameId (frame identifier)	Supported	Υ	Y	N
		subframeId (subframe identifier)	Supported	Υ	Y	N
		slotId (slot identifier)	Supported	Υ	Y	N
		startSymbolid (start symbol identifier)	Supported	Y	Y	N
		numberOfsection s (number of sections)	up to the maximum number of PRBs	Y	Y	N
		sectionType (section type)	1 and 3	Υ	Y	N
		udCompHdr (user data compression header)	Supported	Y	Y	N
		numberOfUEs (number Of UEs)	Not supported	N	N	N
		timeOffset (time offset)	Supported	Y	Y	N
		frameStructure (frame structure)	mu=0,1,3	Υ	Y	N
		cpLength (cyclic prefix length)	Supported	Υ	Y	N
		sectionId (section identifier)	Supported	Υ	Y	N
		rb (resource block indicator)	0	Υ	Y	N
	Coding of	symInc (symbol number increment command)	0 or 1	Y	Y	N
	Information Elements – Application	startPrbc (starting PRB of control section)	Supported	Y	Y	N
	Layer, Sections	reMask (resource element mask)	Supported	Υ	Y	N
		numPrbc (number of contiguous PRBs per control section)	Supported	Y	Y	N
		numSymbol (number of symbols)	Supported	Υ	Y	N



Category	Item	Status	С	1	Т
	ef (extension flag)	Supported	Υ	Υ	N
	beamId (beam identifier)	Support	Υ	Υ	N
	ueId (UE identifier)	Not supported	N	N	N
	freqOffset (frequency offset)	Supported	Υ	Υ	N
	regularizationF actor (regularization Factor)	Not supported	N	N	N
	ciIsample, ciQsample (channel information I and Q values)	Not supported	N	N	N
	laaMsgType (LAA message type)	Not supported	N	N	N
	laaMsgLen (LAA message length)	Not supported	N	N	N
	lbtHandle	Not supported	N	N	N
	lbtDeferFactor (listen-before-talk defer factor)	Not supported	N	N	N
	lbtBackoffCount er (listen-before- talk backoff counter)	Not supported	N	N	N
	lbtOffset (listen- before-talk offset)	Not supported	N	N	N
	MCOT (maximum channel occupancy time)	Not supported	N	N	N
	lbtMode (LBT Mode)	Not supported	N	N	N
	lbtPdschRes (LBT PDSCH Result)	Not supported	N	N	N
	sfStatus (subframe status)	Not supported	N	N	N
	lbtDrsRes (LBT DRS Result)	Not supported	N	N	N
	initialPartialS F (Initial partial SF)	Not supported	N	N	N
	lbtBufErr (LBT Buffer Error)	Not supported	N	N	N
	sfnSf (SFN/SF End)	Not supported	N	N	N



Category	-	tem	Status	С	1	т
		lbtCWConfig_H (HARQ Parameters for Congestion Window management)	Not supported	N	N	N
		lbtCWConfig_T (TB Parameters for Congestion Window management)	Not supported	N	N	N
		lbtTrafficClass (Traffic class priority for Congestion Window management)	Not supported	N	N	N
		lbtCWR_Rst (Notification about packet reception successful or not)	Not supported	N	N	N
		reserved (reserved for future use)	0	N	N	N
		Section Extension Commands				
		<pre>extType (extension type)</pre>	Supported	Y	Υ	N
		ef (extension flag)	Supported	Υ	Υ	N
		extLen (extension length)	Supported	Υ	Υ	N
	Coding of Informati Application Layer, S					
		bfwCompHdr (beamforming weight compression header)	Supported	Y	Y	N
	ExtType=1: Beamforming Weights	bfwCompParam (beamforming weight compression parameter)	Supported	Y	Y	N
	Extension Type	bfwl (beamforming weight in-phase value)	Supported	Υ	Y	N
		bfwQ (beamforming weight quadrature value)	Supported	Y	Y	N
	ExtType=2: Beamforming Attributes Extension Type	bfaCompHdr (beamforming attributes compression header)	Supported	Y	N	N



Category		ltem	Status		1	Т
		bfAzPt (beamforming azimuth pointing parameter)	Supported	Y	N	N
		bfZePt (beamforming zenith pointing parameter)	Supported	Y	N	N
		bfAz3dd (beamforming azimuth beamwidth parameter)	Supported	Υ	N	N
		bfZe3dd (beamforming zenith beamwidth parameter)	Supported	Υ	N	N
		bfAzS1 (beamforming azimuth sidelobe parameter)	Supported	Y	N	N
		bfZeS1 (beamforming zenith sidelobe parameter)	Supported	Y	N	N
		zero-padding	Supported	Υ	N	N
		codebookIndex (precoder codebook used for transmission)	Supported	Υ	N	N
		layerID (Layer ID for DL transmission)	Supported	Υ	N	N
		txScheme (transmission scheme)	Supported	Y	N	N
	ExtType=3:	numLayers (number of layers used for DL transmission)	Supported	Y	N	N
	DL Precoding Extension Type	crsReMask (CRS resource element mask)	Supported	Y	N	N
		crsSyumINum (CRS symbol number indication)	Supported	Y	N	N
		crsShift (crsShift used for DL transmission)	Supported	Y	N	N
		beamIdAP1 (beam id to be used for antenna port 1)	Supported	Υ	N	N



Category	ı	tem	Status	С	1	т
		beamIdAP2 (beam id to be used for natenna port 2)	Supported	Y	N	N
		beamIdAP3 (beam id to be used for natenna port 3)	Supported	Y	N	N
	ExtType=4:	csf (constellation shift flag)	Supported	Y	Υ	N
	Modulation Compression Parameters Extension Type	modCompScaler (modulation compression scaler value)	Supported	Y	Y	N
	ExtType=5: Modulation	mcScaleReMask (modulation compression power scale RE mask)	Supported	Y	N	N
	Compression Additional Parameters Extension Type	csf (constellation shift flag)	Supported	Υ	N	N
		mcScaleOffset (scaling value for modulation compression)	Supported	Y	N	N
	ExtType=6: Non- contiguous PRB allocation in time	rbgSize (resource block group size)	Supported	Y	N N	N
	and frequency domain	rbgMask (resource block group bit mask)	Supported	Y	N	N
		symbolMask (symbol bit mask)	Supported	Y	N	N
	ExtType=10:	beamGroupType	Supported	Υ	N	N
	Section description for group configuration of multiple ports	numPortc	Supported	Y	N	N
	ExtType=11: Flexible Beamforming Weights	bfwCompHdr (beamforming weight compression header)	Supported	Y	Y	N
	Extension Type	bfwCompParam for PRB bundle x (beamforming weight compression parameter)	Supported	Y	Υ	N



Category	ı	tem	Status	С	1	т
		numBundPrb (Number of bundled PRBs per beamforming weights)	Supported	Y	Y	N
		bfwI (beamforming weight in-phase value)	Supported	Y	Y	Z
		bfwQ (beamforming weight quadrature value)	Supported	Y	Y	N
		disableBFWs (disable beamforming weights)	Supported	Y	Y	N
		RAD (Reset After PRB Discontinuity)	Supported	Y	Y	N
	dataDirection (gNB Tx/Rx)		Supported	Υ	Υ	Υ
	payloadVersion (payload version)		001b	Υ	Υ	Υ
	filterIndex (filter index)		Supported	Υ	Υ	Υ
	frameId (frame identifier)		Supported	Υ	Υ	Υ
	subframeId (subframe identifier)		Supported	Υ	Υ	Υ
	slotId (slot identifier)		Supported	Υ	Υ	Υ
	symbolid (symbolidentifier)		Supported	Υ	Υ	Υ
	sectionId (section identifier)		Supported	Υ	Υ	Υ
	rb (resource block indicator)		0	Υ	Υ	Υ
U-plane Packet Format	symInc (symbol number increment command)		0	Υ	Υ	Υ
Torritat	startPrbu (startingPRB of user plane section)		Supported	Υ	Υ	Υ
	numPrbu (number of PRBs per user plane section)		Supported	Υ	Y	Υ
	udCompHdr (user data compression header)		Supported	Y	Y	Υ
	reserved (reserved for future use)		0	Υ	Υ	Υ
	udCompParam (use parameter)	r data compression	Supported	Y	Y	Y
	iSample (in-phase	sample)	16	Υ	Υ	Υ
	qSample (quadratu	ire sample)	16	Υ	Υ	Υ




Category	Item		Status	С	1	т
	Topology configuration: C1		Supported	N	N	N
	Topology configuration: C2 Supported N N N Topology configuration: C3 Supported Y Y	N	N			
S-plane		Υ	Υ			
	Topology configura	ition: C4	Supported	N	N	N
	PTP	Full Timing Support (G.8275.1)	Supported	Υ	Υ	N
M-plane			Not supported	N	N	N

NOTE: The bit width of each component in eAxC ID can be configurable.

4.3 Transport Layer

O-RAN Fronthaul data can be transported over Ethernet or IPv4/IPv6. In the current implementation, the xRAN library supports only Ethernet with VLAN.

Figure 11. Native Ethernet Frame with VLAN



Standard DPDK routines are used to perform Transport Layer functionality.

VLAN tag functionality is offloaded to NIC as per the configuration of VF (refer to Appendix A, Setup Configuration).

The transport header is defined in the O-RAN Fronthaul specification based on the eCPRI specification, Refer to Table 2.




Figure 12. eCPRI Header Field Definitions

0 (msb)	1	2	3	4	5	6	7 (lsb)	# of bytes	
ecpriVersion ecpriReserved EcpriConcat enation							1	Octet 1	
	ecpriMessage							1	Octet 2
	ecpriPayload						2	Octet 3	
	ecpriRtcid / ecpriPad						2	Octet 5	
	ecpriSeqid						2	Octet 7	

Only ECPRI_IQ_DATA = 0×00 , ECPRI_RT_CONTROL_DATA= 0×02 and ECPRI_DELAY_MEASUREMENT message types are supported.

For one-way delay measurements the eCPRI Header Field Definitions are the same as above until the ecpriPayload. The one-delay measurement message format is shown in the next figure.

Figure 13. ecpri one-way delay measurement message





In addition, for the eCPRI one-delay measurement message there is a requirement of dummy bytes insertion so the overall ethernet frame has at least 64 bytes.

The measurement ID is a one-byte value used by the sender of the request to distinguish the response received between different measurements.

The action type is a one-byte value defined in Table 8 of the eCPRI Specification V2.0.

Action Type 0x00 corresponds to a Request

Action Type 0x01 corresponds to a Request with Follow Up

Both values are used by an eCPRI node to initiate a one-way delay measurement in the direction of its own node to another node.

Action Type 0x02 corresponds to a Response

Action Type 0x03 is a Remote Request

Action Type 0x04 is a Remote Request with Follow Up

Values 0x03 and 0x04 are used when an eCPRI node needs to know the one-way delay from another node to itself.


Action Type 0x05 is the Follow_Up message.

The timestamp uses the IEEE-1588 Timestamp format with 8 bytes for the seconds part and 4 bytes for the nanoseconds part. The timestamp is a positive time with respect to the epoch.

The compensation value is used with Action Types 0x00 (Request), 0x02 (Response) or 0x05 (Follow_up) for all others this field contains zeros. This value is the compensation time measured in nanoseconds and multiplied by 2^{16} and follows the format for the correction Field in the common message header specified by the IEE 1588-2008 clause 13.3.

Handling of ecpriRtcid/ecpriPcid Bit field size is configurable and can be defined on the initialization stage of the xRAN library.

Figure 14. Bit Allocations of ecpriRtcid/ecpriPcid



For ecpriSegid only, the support for a sequence number is implemented. The following number is not supported.

Comments in the source code can be used to see more information on the implementation specifics of handling this field.

4.4 U-plane

The following diagrams show O-RAN packet protocols' headers and data arrangement with and without compression support.

XRAN packet meant for traffic with compression enabled has the Compression Header added after each Application Header. According to *O-RAN Fronthaul's specification* (Refer to <u>Table 2</u>), the Compression Header is part of a repeated Section Application Header. In the xRAN library implementation, the header is implemented as a separate structure, following the Application Section Header. As a result, the Compression Header is not included in the O-RAN packet, if compression is not used.

Figure 15 shows the components of an O-RAN packet.

37



Figure 15. O-RAN Packet Components

r deket components		
Section Type 1,3 : DL/ UL I Q data msgs		
0 1 2 3 4 5 6 7	# of	
(msb) (lsb)	bytes	
transport header, see section 3.1.3	8	Octet 1
dataDirection payloadVersion filterIndex	1	Octet 9
frameId	1	Octet 10
subframe <u>I</u> d slot <u>I</u> d	1	Octet 11
slotId symbolid	1	Octet 12
sectionId .	1	Octet 13
sectionId rb symInc startPrbu	1	Octet 14
startPrbu startPrbu	1	Octet 15
numPrbu	1	Octet 16
udCompHdr (not always present)	1	Octet 17
reserved (not always present)	1	Octet 18
udCompParam (not always present)	1	Octet 17/19
iSample (14 RE in the PRB)	1*	Octet 18/20
qSample (1st RE in the PRB)	1*	Octet 19/21*
iSample (12th RE in the PRB)	1*	Octet 40/42*
qSample (124 RE in the PRB) + padding when needed	1*	Octet 41/43*
udCompParam (not always present)	1*	Octet 42/44*
iSample (1st RE in the PRB)	1*	Octet 43/45*
qSample (1st RE in the PRB)	1*	Octet 44/46*
iSample (12th RE in the PRB)	1*	Octet 65/67*
qSample (12 st RE in the PRB) + padding when needed	1*	Octet 66/68*


sectionId	1	Octet M
sectionId rb symInc startPrbu	1	M+1
startPrbu	1	M+2
numPrbu	1	M+3
udCompHdr (not always present)	1	M+4
reserved (not always present)	1	M+5
udCompParam (not always present)	1	M+4/6
iSample (1st RE in the PRB)	1*	M+5/7
qSample (1st RE in the PRB)	1*	M+6/8*
iSample (12th RE in the PRB)	1*	M+27/29*
acamala (439 p.c.; a sha ppp.) is an ddian indian an dad	1*	M+28/30*
qSample (12≤ RE in the PRB) + padding when needed	1*	M+29/31*
udCompParam (not always present)		M+30/32*
udCompParam (not always present) iSample (1 st RE in the PRB)	1*	
udCompParam (not always present)	1* 1*	M+31/33*
udCompParam (not always present) iSample (1st RE in the PRB) qSample (1st RE in the PRB) 	1*	M+31/33*
udCompParam (not always present) iSample (1 st RE in the PRB)		

4.4.1 Radio Application Header

The next header is a common header used for time reference.



Figure 16. Radio Application Header




The radio application header specific field values are implemented as follows:

- filterIndex = 0
- frameId = [0:99]
- subframeId = [0:9]
- slotId = [0:7]
- symbolId = [0:13]

4.4.2 Data Section Application Data Header

The Common Radio Application Header is followed by the Application Header that is repeated for each Data Section within the eCPRI message. The relevant section of the O-RAN packet is shown in color.

Figure 17. Data Section Application Data Header



A single section is used per one Ethernet packet with IQ samples startPrbu is equal to 0, and numPrbu is wqual to the number of RBs used:

- rb field is not used (value 0).
- symInc is not used (value 0)

39



4.4.3 Data Payload

An O-RAN packet data payload contains several PRBs. Each PRB is built of 12 IQ samples. Flexible IQ bit width is supported. If compression is enabled, udCompParam is included in the data payload. The data section is shown in color.

Figure 18. Data Payload

0	1	2	3	4	3 : DL/UL 1	_	6	7	# of		
(msb)		_			_		_	(Isb)	bytes		
	trar	sport head	er, see xR/	N specifica	ation section	3.1.3	3		8	Octet	
dataDire ction		payload	/ersion		1	ilterIn	ndex		1	Octet	
			fra	meId					1	Octet	
		ubframeId				slot	Id		1	Octet	
slotId	1				nbolid				1	Octet	
			sed	tionId		_			1	Octet	
	sectionId rb symInc startPrbu										
	star tPrbu										
				nPrbu					1	Octet	
			ompHdr (no						1	Octet	
			served (not						1	Octet	
			mpParam (i						1	Octet 1	
			Sample (1 ^e		_				1*	Octet 1	
		q:	Sample (1 ^{tt}	KE in the	PKB)				1*	Octet 19	
		100	ample (12 ⁶		DD D1				1*	Octet 40	
	aS:				ding when n	oodod	_		1*	Octet 4	
	qa					eeueu	_		1*	Octet 4	
	udCompParam (not always present) iSample (1 ^{et} RE in the PRB)									Octet 4	
	qSample (1st RE in the PRB)									Octet 4	
		- 4	Jan Jan		1112)				1*	- CLUL T	
		iS	ample (12 ⁸	RE in the	PRB)				1*	Octet 68	
	qSa	mple (12 st	RE in the P	RB) + pad	ding when n	eeded			1*	Octet 6	
			sed	tionI d					1	Octe	
		sectionId			b symInc		star	tPrbu	1	M+	
				rtPrbu					1	M+	
				nPrbu					1	M+	
			ompHdr (no						1	M+	
			served (not						1	M+	
			mpParam (r						1	M+4	
			Sample (1 st						1*	M+5	
		q	Sample (1 ^e	KE IN the	PKB)				1*	M+6/	
		is	ample (12 ⁶	RE in the	PRB)				1*	M+ 27/	
	aS:				ding when n	eeded			1*	M+ 28/	
	400		mpParam (r		_				1*	M+ 29/	
			Sample (1st						1*	M+30	
			Sample (1 st						1*	M+31,	
		iS	ample (12 ^e	RE in the	PRB)				1*	M+52/	
iSample (12th RE in the PRB) qSample (12th RE in the PRB) + padding when needed										M+53/	

4.5 C-plane

C-Plane messages are encapsulated using a two-layered header approach. The first layer consists of an eCPRI standard header, including corresponding fields used to indicate the message type, while the second layer is an application layer, including necessary fields for control and synchronization. Within the application layer, a



"section" defines the characteristics of U-plane data to be transferred or received from a beam with one pattern id. In general, the transport header, application header, and sections are all intended to be aligned on 4-byte boundaries and are transmitted in "network byte order" meaning the most significant byte of a multi-byte parameter is transmitted first.

Table 9 is a list of sections currently supported.

Table 9. Section Types

Section Type	Target Scenario	Remarks				
0	Unused Resource Blocks or symbols in Downlink or Uplink	Not supported				
1	Most DL/UL radio channels	Supported				
2	reserved for future use	N/A				
3	PRACH and mixed-numerology channels	Only PRACH is supported. Mixed numerology is not supported.				
4	Reserved for future use	Not supported				
5	UE scheduling information (UE-ID assignment to section)	Not supported				
6	Channel information	Not supported				
7	LAA	Not supported				
8-255	Reserved for future use	N/A				

Section extensions are not supported in this release.

The definition of the C-Plane packet can be found <code>lib/api/xran_pkt_cp.h</code>, and the fields are appropriately reordered to apply the conversion of network byte order after setting values.

The comments in the source code of xRAN lib can be used to see more information on implementation specifics of handling sections as well as particular fields. Additional changes may be needed on the C-plane to perform IOT with O-RU depending on the scenario

4.5.1 Ethernet Header

Refer to Figure 11.

4.5.2 eCPRI Header

Refer to Figure 12.

This header is defined as the structure of xran ecpri hdr in lib/api/xran pkt.h.

4.5.3 Radio Application Common Header

The Radio Application Common Header is used for time reference. Its structure is shown in Figure 19.



Figure 19. Radio Application Common Header

Section Type 1 : DL/UL control msgs												
	# of bytes	7 (Isb)	6	5	4	3	2	1	0 (msb)			
Octet 1	8		transport header, see section 3.1.3									
Octet 9	1		Index	filter		on	dataDirect ion					
Octet 10	1				meId	frar						
Octet 11	1		tId	slo			meId	subfra				
Octet 12	1			ymbolid	start			lotId	s			
Octet 13	1		numberOfsections									
Octet 14	1		sectionType = 1									

This header is defined as the structure of xran_cp_radioapp_common_header in lib/api/xran_pkt_cp.h.

NOTE: The payload version in this header is fixed to XRAN_PAYLOAD_VER (defined as 1) in this release.

4.5.4 Section Type 0 Structure

Figure 20 describes the structure of Section Type 0.

Figure 20. Section Type 0 Structure

			Continu T		lle / euse	d norted	-		
					lle / guar			,, c	
0 (msb)	1	2	3	4	5	6	7 (Isb)	# of bytes	
(IIIaD)		transnoi	rt header,	see sectio	n 3 1 3		(150)	8	Octet 1
dataDirec	ממ	vloadVers		see section		Index		1	Octet 9
tion	ра	yioauveis	ion		nicei.	IIIuex		1	Octet 9
	frameId								Octet 10
	subfrar	meId			slo	tId		1	Octet 1
slot	Id			startS	ymbolid			1	Octet 12
			numberOf	sections				1	Octet 1
			sectionTy	/pe = 0				1	Octet 1
			timeO					2	Octet 1
			frameSt	ructure				1	Octet 1
			cpLer	ngth				2	Octet 1
			Reser					1	Octet 2
	sectionId								Octet 2
	sectio	onId		rb	symInc	sta	rtPrbc	1	Octet 2
			start	rbc				1	Octet 2
			numF	rbc				1	Octet 2
			reMask	[11:4]				1	Octet 2
	reMask	[3:0]			numS	1	Octet 2		
			reserved ((16-bits)				2	Octet 2
			sectio	nId				1	Octet N
	sectio	onId		rb	symInc	sta	rtPrbc	1	N+1
			startí					1	N+2
			numF					1	N+3
			reMask	[11:4]				1	N+4
	reMask				numS	1	N+5		
	reserved (16-bits)							2	N+6
			<u> </u>		<u> </u>		<u> </u>		Octet M


NOTE: In Figure 19 through Figure 23, the color yellow means it is a transport header; the color pink is the radio application header; others are repeated sections.



4.5.5 Section Type 1 Structure

Figure 21 describes the structure of Section Type 1.

Figure 21. Section Type 1 Structure



Section Type 1 message has two additional parameters in addition to radio application common header:

- udCompHdr:defined as the structure of xran_radioapp_udComp_header
- · reserved : fixed by zero

Section type 1 is defined as the structure of $xran_cp_radioapp_section1$, and this part can be repeated to have multiple sections.

Whole section type 1 message can be described in this summary:

```
xran_cp_radioapp_common_header

xran_cp_radioapp_section1_header

xran_cp_radioapp_section1

......

xran_cp_radioapp_section1
```

NOTE: Even though API function can support to compose multiple sections in a C-Plane message, current implementation is to compose single section per a C-Plane message.



4.5.6 Section Type 3 Structure

Figure 22 describes the structure of Section Type 3.

Figure 22. Section Type 3 Structure

		Co.	etion Tu	n a 2 + DD	ACH & mix	ead nue	norology.		
0	1	2	3	ре 3 . РК. 4	5 5	6	nerology 7	# of	
(msb)	-			_		Ü	(lsb)	bytes	
()		transpo	ort heade	er, see sed	tion 3.1.3		(100)	8	
dataDirec tion	pay	/loadVe		,	filterIr	ndex		1	
			fr	am eId	1				
	subfrar	neId				1			
slotI	d			start9	Symbolid			1	
			numbe	rOfsection	S			1	
			sectio	nType = 3				1	
			tim	eOffset				2	
			frame	Structure				1	
			ср	Length				2	
			udC	ompHdr				1	
			se	ctionId				1	
	sectio	nId		rb	symInc	sta	rtPrbc	1	
			sta	artPrbc				1	
			nu	m Prbc				1	
reMask[11:4]									
	reMask	[3:0]			numSy	mbol		1	
ef				beam Id[1	l4:8]			1	
			bear	nId[7:0]				1	
				encyOffset				3	
				ed (8 bits)				1	
	S	ection e	extension	is as indica	ated by "ef"	,		var	
			se	ctionId	,			1	
	sectio	nId		rb	symInc	sta	rtPrbc	1	
				artPrbc				1	
				mPrbc				1	
			reMa	sk[11:4]				1	
	reMask	[3:0]			numSy	mbol		1	
ef beamId[14:8]								1	
	beamId[7:0]								
				encyOffset				3	
				ed (8 bits)				1	
	S	ection e	extension	ıs as indica	ated by "ef"	1		var	
	I	1	1	1	1	I	1	1	


Section Type 3 message has below four additional parameters in addition to radio application common header.

- timeOffset
- frameStrucutre: defined as the structure of xran_cp_radioapp_frameStructure
- cpLength
- udCompHdr: defined as the structure of xran_radioapp_udComp_header



Section Type 3 is defined as the structure of $xran_cp_radioapp_section3$ and this part can be repeated to have multiple sections.

Whole section type 3 message can be described in this summary:



4.5.7 Section Type 5 Structure

Figure 23 describes the structure of Section Type 5.

Figure 23. Section Type 5 Structure

0·· (msb)×	1¤	2¤	3¤	4я	5×	6¤	7⊷ (Isb)¤	#·of· bytes¤	и
		transpo	rt·heade	r,·see·se	ction·3.1.3×			8¤	Octet-1x
dataDirec tion×	pa	yloadVer	ion¤		filterI		1×	Octet-9×	
			fra	meId×				1¤	Octet-10
	subfrar	neId¤			slot		1×	Octet-11	
slotI	slotId×				tSymbolid×			1×	Octet-12:
			number	Ofsection	ns¤			1¤	Octet-13
	sectionType-=-5¤								Octet-14
	udCompHdr≖								Octet-15
				erved¤				1×	Octet-16
			sec	tionId¤			1×	Octet-17	
sectionId×				rb¤	symInc×	sta	rtPrbc×	1¤	Octet-18
startPrbc×							1×	Octet-19	
numPrbc×							1¤	Octet-20	
			reMa	sk[11:4]	ď			1×	Octet-21
	reMask	[3:0]×		1000	numSy	1¤	Octet-22		
ef×				ueId[1	4:8]¤	1¤	Octet-23		
	-		ueI	d[7:0]×	***************************************			1¤	Octet-24
		section-e	xtension	s-as-indic	ated·by·"ef">	t .		var¤	Octet-25
				¤				д	Ħ
			sec	tionId¤		1¤	Octet-N>		
	sectio	nId¤		rb×	symInc×	sta	artPrbc×	1¤	N+1¤
			sta	rtPrbc×	10-30-11-12			1×	N+2×
			nu	mPrbc≍				1¤	N+3¤
			reMa	sk[11:4]	4			1¤	N+4¤
	reMask	[3:0]¤			numSy	mbol¤		1¤	N+5¤
ef¤				ueId[1	4:8]¤		1¤	N+6×	
			ueI	d[7:0]¤				1×	N+7¤
		section-e	xtension	s-as-indic	ated·by·"ef"	c		var¤	N+8¤
Ħ	ж	×	д	H	×	и	×	×	Octet-Mx



4.5.8 Section Type 6 Structure

Figure 24 describes the structure of Section Type 6.

Figure 24. Section Type 6 Structure

0 (msb)	1	2	3	4	5	6	7 (Isb)	# of bytes		
(msb)		tra	nsport hea	ader, see	section 3.1.3		(ISD)	8		
dataDire	Р	ayloadVer				rIndex		1		
ction				frameId				1		
	subf	rameId		Hamera	sl	otId		1		
slot		T		st	artSymbolid	0110		1		
			1							
			1							
			1							
				reserved				1		
ef			1							
			1 2							
	regularizationFactor									
	reserved rb symInc startPrbc									
	startPrbc									
				numPrbc				1		
					irst antenna)			var		
					irst antenna)			var		
					cond antenna)			var var		
	ciQsample (first PRB, second antenna)									
ciIsample (first PRB, last antenna)								var		
	ciQsample (first PRB, last antenna)									
		- CIC	e-arripio (i		asc ancomia)			var		
		ci	Isample (la	ast PRB, la	ast antenna)			var		
					ast antenna)			var		
					dicated by "ef'	,		var		
ef					[14:8]			1		
				ueId[7:0]				1		
			regul	arizationF				2		
	Res	erved		rb	symInc	S	tartPrbc	1		
				startPrbc				1		
		_:1		numPrbc	irst antenna)			1 var		
					irst antenna) irst antenna)			var		
								var		
	ciIsample (first PRB, second antenna) ciQsample (first PRB, second antenna)									
		ciçs	ampie (iiis		conta antenna,			var		
	ciIsample (first PRB, last antenna)									
		ciC	Qsample (f	irst PRB, I	ast antenna)			var		
		ci	Isample (la	ast PRB, la	ast antenna)			var		
								var		
	ciQsample (last PRB, last antenna) section extensions as indicated by "ef"									



5.0 xRAN Library Design

The xRAN Library consists of multiple modules where different functionality is encapsulated. The complete list of all *. \circ and *. h files, as well as Makefile for xRAN v21.03 release, is:

```
dpdk.sh
     gen_test.m
    - ifft_in.txt

    Makefile

    - run_o_du.sh
    - run_o_ru.sh
    - src
       - app_io_fh_xran.c
      — app_io_fh_xran.h
       - common.c
       - common.h
       config.c
       - config.h
       - debug.h
        - sample-app.c
        - xran_mlog_task_id.h
     usecase
       - cat_a
       - cat b
       - Ite_a
       -Ite b
 - banner.txt
- build.sh
– lib
        - xran compression.h
       xran_compression.hpp
       - xran_cp_api.h
       - xran_fh_o_du.h
       - xran_mlog_lnx.h
       - xran_pkt_cp.h
        - xran_pkt.h
        - xran pkt up.h
        - xran sync api.h
        - xran timer.h
        - xran transport.h
        - xran_up_api.h
     ethernet
        - ethdi.c
        - ethdi.h
       - ethernet.c
        - ethernet.h
    - Makefile
      — xran_app_frag.c
      - xran_app_frag.h
      — xran_bfp_byte_packing_utils.hpp
      — xran_bfp_cplane16.cpp
      - xran bfp cplane16 snc.cpp
       - xran bfp cplane32.cpp
       - xran bfp cplane32 snc.cpp
```



```
xran bfp cplane64.cpp
      - xran bfp cplane64 snc.cpp
     - xran_bfp_cplane8.cpp
     - xran_bfp_cplane8_snc.cpp
     - xran_bfp_ref.cpp
     - xran_bfp_uplane_9b16rb.cpp
     - xran_bfp_uplane.cpp
     - xran_bfp_uplane_snc.cpp
     - xran bfp utils.hpp
     - xran cb_proc.c
     - xran cb proc.h
     - xran common.c
     - xran_common.h
     - xran_compression.cpp
     - xran_compression_snc.cpp
     - xran_cp_api.c
     - xran_cp_proc.c
     - xran_cp_proc.h
     - xran_delay_measurement.c
     - xran dev.c
      - xran dev.h
      - xran ecpri_owd_measurements.h
     - xran frame struct.c
     - xran frame struct.h
     - xran lib mlog tasks id.h
      - xran main.c
      - xran main.h
      - xran_mod_compression.cpp
     - xran_mod_compression.h
     - xran_prach_cfg.h
     - xran_printf.h
     - xran_rx_proc.c
     - xran_rx_proc.h
     - xran_sync_api.c
     - xran timer.c
     - xran_transport.c
     - xran tx_proc.c
     - xran_tx_proc.h
     - xran_ul_tables.c
     - xran_up_api.c
- Licenses.txt
- misc
icx-sp-cvl.sh
- readme.md
 test
   - common
     - common.cpp
     - common.hpp
     – common_typedef_xran.h
     - json.hpp
     - MIT License.txt
     - xranlib unit test main.cc
     - xran_lib_wrap.hpp
   - master.py
  - readme.txt
  - test xran
   - chain_tests.cc
    compander_functional.cc
  --- conf.json
```



```
c_plane_tests.cc
init_sys_functional.cc
Makefile
mod_compression_unit_test.cc
prach_functional.cc
prach_performance.cc
unittests.cc
u_plane_functional.cc
u plane performance.cc
```

5.1 General Introduction

The xRAN Library functionality is broken down into two main sections:

- O-RAN specific packet handling (src)
- Ethernet and supporting functionality (ethernet)

External functions and structures are available via a set of header files in the API folder.

This library depends on DPDK primitives to perform Ethernet networking in user space, including initialization and control of Ethernet ports. Ethernet ports are expected to be SRIOV virtual functions (VF) but also can be physical functions (PF) as well

This library is expected to be included in the project via xran_fh_o_du.h, statically compiled and linked with the L1 application as well as DPDK libraries. The O-RAN packet processing-specific functionality is encapsulated into this library and not exposed to the rest of the 5G NR pipeline.

This way, xRAN specific changes are decoupled from the L1 pipeline. As a result, the design and implementation of the 5G L1 pipeline code and xRAN library can be done in parallel, provided the defined interface is not modified.

Ethernet consists of two modules:


- Ethernet implements xRAN specific HW Ethernet initialization, close, send and receive
- ethdi provides Ethernet level software primitives to handle O-RAN packet exchange

The xRAN layer implements the next set of functionalities:

- Common code specific for both C-plane and U-plane as well as TX and RX
- Implementation of C-plane API available within the library and externally
- The primary function where general library initialization and configuration performed
- Module to provide the status of PTP synchronization
- Timing module where system time is polled
- eCPRI specific transport layer functions
- APIs to handle U-plane packets
- A set of utility modules for debugging (printf) and data tables are included as well.



Figure 25. Illustration of xRAN Sublayers



A detailed description of functions and input/output arguments, as well as key data structures, can be found in the Doxygen file for the FlexRAN 5G NR release, Refer to Table 2. In this document, supplemental information is provided for the overall design and implementation assumptions.

5.2 Initialization and Close

An example of the initialization sequence can be found in the sample application code. It consists of the following steps:

- 1. Setup structure struct xran fh init according to configuration.
- 2. Call xran_init () to instantiate the xRAN lib memory model and threads. The function returns a pointer to xRAN handle, which is used for consecutive configuration functions.
- 3. Initialize memory buffers used for L1 and xRAN exchange of information.
- 4. Assign callback functions for (one) TTI event and the reception of half of the slot of symbols (7 symbols) and Full slot of symbols (14 symbols).
- 5. Call xran open () to initialize PRACH configuration, initialize DPDK, and launch xRAN timing thread,
- 6. Call xran start() to start processing O-RAN packets for DL and UL

After this is complete 5G L1 runs with xRAN Front haul interface. During run time for every TTI event, the corresponding call back is called. For packet reception on UL direction, the corresponding call back is called. OTA time information such as frame id, subframe id, and slot id can be obtained as result synchronization of the L1 pipeline to GPS time is performed.

To stop and close the interface, perform this sequence of steps:

- 1. $Call xran_stop()$ to stop the processing of DL and UL
- 2. Call xran close () to remove usage of xRAN resources
- 3. Call xran mm destroy () to destroy memory management subsystem

After this session is complete, a restart of the full L1 application is required. The current version of the library does not support multiple sessions without a restart of the full L1 application.



5.2.1 Configuration

The xRAN library configuration is provided in the set of structures, such as struct xran_fh_init and struct xran_fh_config. The sample application gives an example of a test configuration used for LTE and 5GNR mmWave, and Sub 6. Sample application folder app/usecase/contains set of examples for different Radio Access technology (LTE|5G NR) deferent category (A|B) and list of numerologies (0,1,3) and list of bandwidth (5,10,20,100 MHz)

NOTE: Some configuration options are not used in v21.03 and are reserved for future use.

These options are available: (refer to FlexRAN 5G NR Reference Solution RefPHY (Doxygen); Table 2):

Structure struct xran_fh_init:

- Number of CC and corresponding settings for each
- Core allocation for xRAN
- Ethernet port allocation
- O-DU and RU Ethernet Mac address
- Timing constraints of O-DU and O-RU
- Debug features

Structure struct xran fh config:

- Number of eAxC
- TTI Callback function and parameters
- PRACH 5G NR specific settings
- TDD frame configuration
- · BBU specific configuration
- RU specific configuration

From an implementation perspective:

The xran_init() performs init of the xRAN library and interface according to struct xran_fh_init information as per the start of application configuration:

- Init DPDK with corresponding networking ports and core assignment
- Init mbuf pools
- Init DPDK timers and DPDK rings for internal packet processing
- · Instantiate ORAH FH thread doing
 - Timing processing (xran timing source thread())
 - ETH PMD (process_dpdk_io())
 - IO XRAN-PHY exchange (ring processing func())

The xran open () performs additional configuration as per run scenario:

- PRACH configuration
- C-plane initialization



The function $xran_close()$ performs free of resources and allows the potential restart of the front haul interface with a different scenario.

5.2.2 Start/Stop

Functions $xran_start()/xran_stop()$ enable/disable packet processing for both the DL and UL. This triggers the execution of callbacks into the L1 application.

5.2.3 Data Exchange

Exchange of IQ samples, as well as C-plane specific information, is performed using a set of buffers allocated by xRAN library from DPDK memory and shared with the l1 application. Buffers are allocated as a standard mbuf structure, and DPDK pools are used to manage the allocation and free resources. Shared buffers are allocated at the init stage and are expected to be reused within 80 TTIs (10 ms).

The xRAN protocol requires U-plane IQ data to be transferred in network byte order, and the L1 application handles IQ sample data in CPU byte order, requiring a swap. The PHY BBU pooling tasks perform copy and byte order swap during packet processing.

5.2.4 C-plane Information Settings

The interface between the xRAN library and PHY is defined via struct xran_prb_map and similar to the data plane. The same mbuf memory is used to allocate memory map of PRBs for each TTI.

```
/** Beamforming waights for single stream for each PRBs given number of Antenna
elements */
struct xran_cp_bf_weight{
                              /**< num TRX for this allocation */
   int16_t nAntElmTRx;
    /**< pointer to start of buffer for full C-plane packet
   int8 t* p_ext_section;
                               /**< pointer to form extType */</pre>
   /* For ext 11 */
   uint8_t bfwCompMeth; /* Compression Method for BFW */
uint8_t bfwIqWidth; /* Bitwidth of BFW */
uint8_t numSetBFWs; /* Total number of beam forming weights set (L) */
uint8_t numBundPrb; /* The number of bundled PRBs, 0 means to use ext1 */
   uint8 t RAD;
   uint8_t disableBFWs;
int16_t maxExtBufSize; /* Maximum space of external buffer */
   struct xran_ext11_bfw_info bfw[XRAN_MAX_SET_BFWS]
};
/** PRB element structure */
struct xran prb elm {
   int16_t nStartSymb; /**< start symbol ID */</pre>
   int16 t numSymb; /**< number of symbols */</pre>
   int16 t nBeamIndex; /**< beam index for given PRB */
   int16 t bf weight update; /** need to update beam weights or not */
   int16 t compMethod; /**< compression index for given PRB */
    int16 t iqWidth; /**< compression bit width for given PRB */
    uint16_t ScaleFactor; /**< scale factor for modulation compression */
    int16_t reMask; /**< 12-bit RE Mask for modulation compression */
```



```
int16 t BeamFormingType; /**< index based, weights based or attribute based beam
forming*/
   int16_t nSecDesc[XRAN_NUM_OF_SYMBOL_PER_SLOT]; /**< number of section descriptors</pre>
per symbol */
    struct xran section desc *
p sec desc[XRAN NUM OF SYMBOL PER SLOT][XRAN MAX FRAGMENT]; /**< section desctiptors
to U-plane data given RBs */
    struct xran cp bf weight bf weight; /**< beam forming information relevant for
given RBs */
        struct xran_cp_bf attribute bf attribute;
        struct xran cp bf precoding bf precoding;
/** PRB map structure */
struct xran_prb_map {
                             /**< DL or UL direction */
   uint8_t dir;
   uint8_t xran_port; /**< xran id of given RU [0-(XRAN_PORTS_NUM-1)] */
uint16_t band_id; /**< xran band id */
uint16_t cc_id; /**< component carrier id [0 - (XRAN_MAX_SECTOR_NR-1)] */</pre>
    uint16_t cc_id; /**< component carrier id [0 - (XRAN_MAX_SECTOR_NR-1)] */
uint16 t ru port id; /**< RU device antenna port id [0 - (XRAN_MAX_ANTENNA_NR-1)
    uint16 t tti id;
                             /**< xRAN slot id [0 - (max tti-1)] */
    uint8 t start sym id;
                                  /**< start symbol Id [0-13] */
    uint32 t nPrbElm; /**< total number of PRB elements for given map [0-
(XRAN MAX SECTIONS PER SLOT-1) | */
    struct xran prb elm prbMap[XRAN MAX SECTIONS PER SLOT];
```

C-plane sections are expected to be provided by L1 pipeline. If 100% of RBs always allocated single element of RB map is expected to be allocated across all symbols. Dynamic RB allocation is performed base on C-plane configuration.

The xRAN library will require that the content of the PRB map should be sorted in increasing order of PRB first and then symbols.

5.3 Memory Management

Memory used for the exchange of IQ data as well as control information, is controlled by the xRAN library. L1 application at the init stage performs:

- init memory management subsystem
- init buffer management subsystem (via DPDK pools)
- allocate buffers (mbuf) for each CC, antenna, symbol, and direction (DL, UL, PRACH) for XRAN_N_FE_BUF_LEN TTIs.
- buffers are reused for every XRAN N FE BUF LEN TTIs

After the session is completed, the application can free buffers and destroy the memory management subsystem.

From an implementation perspective, the xRAN library uses a standard mbuf primitive and allocates a pool of buffers for each sector. This function is performed using rte_pktmbuf_pool_create(), rte_pktmbuf_alloc(), and rte_pktmbuf_append() to allocate one buffer per symbol for the mmWave case. More information on mbuf and DPDK pools can be found in the DPDK documentation.

In the current implementation, mbuf, is the number of buffers shared with the L1 application is the same number of buffers used to send to and receive from the Ethernet port. Memory copy operations are not required if the packet



size is smaller than or equal to MTU. Future versions of the xRAN library are required to remove the memory copy requirement for packets where the size larger than MTU.

5.3.1 External Interface Memory

The xRAN library header file defines a set of structures to simplify access to memory buffers used for IQ data.

```
struct xran flat buffer {
   uint32 t nElementLenInBytes;
   uint32_t nNumberOfElements;
   uint32_t nOffsetInBytes;
   uint32_t nIsPhyAddr;
   uint8 t *pData;
   void *pCtrl;
};
struct xran buffer list {
   uint32 t nNumBuffers;
   struct xran flat buffer *pBuffers;
   void *pUserData;
   void *pPrivateMetaData;
struct xran io buf ctrl {
   /* -1-this subframe is not used in current frame format
         0-this subframe can be transmitted, i.e., data is ready
         1-this subframe is waiting transmission, i.e., data is not ready
         10 - DL transmission missing deadline. When FE needs this subframe data but
bValid is still 1,
       set bValid to 10.
    int32 t bValid; // when UL rx, it is subframe index.
         t nSegToBeGen;
   int32 t nSegGenerated; // how many date segment are generated by DL LTE processing
or received from FE
                       // -1 means that DL packet to be transmitted is not ready in BS
   int32 t nSeqTransferred; // number of data segments has been transmitted or
   struct rte mbuf *pData[N MAX BUFFER SEGMENT]; // point to DPDK allocated memory
   struct xran buffer list sBufferList;
```

There is no explicit requirement for user to organize a set of buffers in this particular way. From a compatibility perspective it is useful to follow the existing design of the 5G NR l1app used for Fronthaul FPGA and define structures shared between l1 and xRAN lib as shown:

```
struct bbu_xran_io_if {
    void*    nInstanceHandle[XRAN_PORTS_NUM][XRAN_MAX_SECTOR_NR]; /**< instance per O-
RAN port per CC */
    uint32_t

nBufPoolIndex[XRAN_PORTS_NUM][XRAN_MAX_SECTOR_NR][MAX_SW_XRAN_INTERFACE_NUM]; /**<
unique buffer pool */
    uint16_t nInstanceNum[XRAN_PORTS_NUM]; /**< instance is equivalent to CC */

    uint16_t DynamicSectionEna;
    uint32_t nPhaseCompFlag;

int32_t num_o_ru;
    int32_t num_o_ru;
    int32_t num_cc_per_port[XRAN_PORTS_NUM];
    int32_t map_cell id2port[XRAN_PORTS_NUM];</pre>
```



```
struct xran io shared ctrl ioCtrl[XRAN PORTS NUM]; /**< for each O-RU port */
    struct xran_cb_tag RxCbTag[XRAN_PORTS_NUM][XRAN_MAX_SECTOR_NR];
    struct xran_cb_tag PrachCbTag[XRAN_PORTS_NUM][XRAN_MAX_SECTOR_NR];
struct xran_cb_tag SrsCbTag[XRAN_PORTS_NUM][XRAN_MAX_SECTOR_NR];
struct xran io shared ctrl {
   /* io struct */
    struct xran io buf ctrl
sfrontHaulTxBbuloBufCtrl[XRAN N FE BUF LEN][XRAN MAX SECTOR NR][XRAN MAX ANTENNA NR];
   struct xran io buf ctrl
sFrontHaulTxPrbMapBbuIoBufCtrl[XRAN N FE BUF LEN][XRAN MAX SECTOR NR][XRAN MAX ANTENNA
    struct xran io buf ctrl
sfrontHaulRxBbuloBufCtrl[XRAN N FE BUF LEN][XRAN MAX SECTOR NR][XRAN MAX ANTENNA NR];
   struct xran io buf ctrl
sFrontHaulRxPrbMapBbuIoBufCtrl[XRAN N FE BUF LEN][XRAN MAX SECTOR NR][XRAN MAX ANTENNA
    struct xran io buf ctrl
sfhprachRxBbuIoBufCtrl[XRAN N FE BUF LEN][XRAN MAX SECTOR NR][XRAN MAX ANTENNA NR];
    /* Cat B */
    struct xran io buf ctrl
sfHsrsRxBbuIoBufCtrl[XRAN N FE BUF LEN][XRAN MAX SECTOR NR][XRAN MAX ANT ARRAY ELM NR]
    struct xran io buf ctrl
sfHSrsRxPrbMapBbuIoBufCtrl[XRAN N FE BUF LEN][XRAN MAX SECTOR NR][XRAN MAX ANT ARRAY E
LM NR];
    /* buffers lists */
    struct xran flat buffer
sfrontHaulTxBuffers[XRAN N FE BUF LEN][XRAN MAX SECTOR NR][XRAN MAX ANTENNA NR][XRAN N
UM OF SYMBOL PER SLOT];
    struct xran flat buffer
sFrontHaulTxPrbMapBuffers[XRAN_N_FE_BUF_LEN][XRAN_MAX_SECTOR_NR][XRAN_MAX_ANTENNA_NR];
    struct xran flat buffer
sFrontHaulRxBuffers[XRAN N FE BUF LEN][XRAN MAX SECTOR NR][XRAN MAX ANTENNA NR][XRAN N
UM OF SYMBOL PER SLOT];
    struct xran flat buffer
sFrontHaulRxPrbMapBuffers[XRAN N FE BUF LEN][XRAN MAX SECTOR NR][XRAN MAX ANTENNA NR];
    struct xran flat buffer
sfhprachRxBuffers[XRAN N FE BUF LEN][XRAN MAX SECTOR NR][XRAN MAX ANTENNA NR][XRAN NUM
OF SYMBOL PER SLOT];
    /* Cat B SRS buffers */
    struct xran flat buffer
sFHSrsRxBuffers[XRAN_N_FE_BUF_LEN][XRAN_MAX_SECTOR_NR][XRAN_MAX_ANT_ARRAY_ELM_NR][XRAN_
_MAX_NUM_OF_SRS_SYMBOL_PER_SLOT];
   struct xran flat buffer
sfHSrsRxPrbMapBuffers[XRAN_N_FE_BUF_LEN][XRAN_MAX_SECTOR_NR][XRAN_MAX_ANT_ARRAY_ELM_NR
```

The Doxygen file and xran_fh_o_du.h provides more details on the definition and usage of these structures. Refer to Table 2, for FlexRAN 5G NR Reference Solution RefPHY (Doxygen).



5.4 xRAN Specific Functionality

Front haul interface implementation in the general case is abstracted away using the interface defined in $xran\ fh\ o\ du.h$

The L1 application is not required to access O-RAN protocol primitives (eCPRI header, application header, and others) directly. It is recommended to use the interface to remove dependencies between different software modules such as the l1 pipeline and xRAN library.

5.4.1 External API

The U-plane and C-plane APIs can be used directly from the application if such an option is required. The set of header files can be exported and called directly.

```
xran_fh_o_du.h - xRAN main header file for O-DU scenario
xran_cp_api.h - Control plane functions
xran_pkt_cp.h - xRAN control plane packet definition
xran_pkt.h - xRAN packet definition
xran_pkt_up.h - xRAN User plane packet definition
xran_sync_api.h - api functions to check PTP status
xran_timer.h - API for timing
xran_transport.h - eCPRI transport layer definition and api
xran_up_api.h - user plane functions and definitions
xran_compression.h - interface to compression/decompression functions
```

Source code comments can provide more details on functions and structures available.

5.4.2 C-plane

Implementation of the C-plane set of functions is defined in xran_cp_api.c and is used to prepare the content of C-plane packets according to the given configuration. Users can enable/disable generation of C-plane messages using enableCP field in struct xran_fh_init structure during the initialization of O-RAN front haul. The time of generation of C-plane message for DL and UL is done "Slot-based," and timing can be controlled using O-DU settings according to Table 4.

The C-plane module contains:

- Initialization of C-plane database to keep track of allocation of resources
- Code to prepare C-plane packet for TX (O-DU)
 - eCPRI header
 - append radio application header
 - append control section header
 - append control section
- Parser of C-plane packet for RX (O-RU emulation)

parses and checks Section 1 and Section 3 packet content

Sending and receiving packets is performed using xRAN ethdi sublayer functions.

More information on function arguments and parameters can be found in Doxygen documents and corresponding source code. Refer to <u>Table 2</u>, for *FlexRAN 5G NR Reference Solution Ref PHY* (Doxygen).



5.4.2.1 Creating a C-Plane Packet

1. API and Data Structures

A C-Plane message can be composed using the following API:

```
int xran_prepare_ctrl_pkt(struct rte_mbuf *mbuf,
    struct xran_cp_gen_params *params,
    uint8_t CC_ID, uint8_t Ant_ID, uint8_t seq_id);
```

mbuf is the pointer of a DPDK packet buffer, which is allocated from the caller.

params are the pointer of the structure which has the parameters to create the message.

CC_ID is the parameter to specify component carrier index, Ant_ID is the parameters to specify the antenna port index (RU port index).

seq id is the sequence index for the message.

params, the parameters to create a C-Plane message are defined as the structure of $xran_cp_gen_params$ with an example given below:

```
struct xran_cp_gen_params {
    uint8_t    dir;
    uint8_t    sectionType;
    uint16_t    numSections;
    struct xran_cp_header_params hdr;
    struct xran_section_gen_info *sections;
};
```

 dir is the direction of the C-Plane message to be generated. Available parameters are defined as XRAN DIR UL and XRAN DIR DL.

sectionType is the section type for C-Plane message to generate, as O-RAN specification defines all sections in a C-Plane message shall have the same section type. If different section types are required, they shall be sent with separate C-Plane messages. Available types of sections are defined as XRAN_CP_SECTIONTYPE_x. Refer to Table 2, O-RAN Specification, Table 5-2 Section Types.

numSections is the total number of sections to generate, i.e., the number of the array in sections (struct xran section gen info).

hdr is the structure to hold the information to generate the radio application and section header in the C-Plane message. It is defined as the structure of xran_cp_header_params. Not all parameters in this structure are used for the generation, and the required parameters are slightly different by the type of section, as described in Table 10 and References in the remarks column are corresponding Chapter numbers in the O-RAN FrontHaul Working Group Control, User, and Synchronization Plane Specification in Table 2.

Table 10. struct xran_cp_header_params - Common Radio Application Header

	Description	Remarks
filterIdx	Filter Index. Available values are defined as XRAN_FILTERINDEX_XXXX.	5.4.4.3
frameId	Frame Index. It is modulo 256 of frame number.	5.4.4.4
subframeId	Sub-frame Index.	5.4.4.5
slotId	Slot Index. The maximum number is 15, as defined in the specification.	5.4.4.6



	Description	Remarks
startSymId	Start Symbol Index.	5.4.4.7

NOTE: References in the remarks column are corresponding Chapter numbers in the O-RAN FrontHaul Working Group Control, User, and Synchronization Plane Specification in Table 2.

Table 11. struct xran_cp_header_params - Section Specific Parameters

	Description		S	ection Ty	pe Applica	able		Remarks
		0	1	3	5	6	7	
fftSize	FFT size in frame structure. Available values are defined as XRAN_FFTSIZE_XXXX	х		х				5.4.4.13
Scs	Subcarrier Spacing in the frame structure. Available values are defined as XRAN_SCS_XXXX	x		x				5.4.4.13
iqWidth	I/Q bit width in user data compression header. Should be set by zero for 16bits		х	х	x			5.4.4.10 6.3.3.13
compMeth	Compression Method in user data compression header. Available values are defined as XRAN_COMPMETHOD_XXXX		х	x	x			5.4.4.10 6.3.3.13
numUEs	Number of UEs. Applies to section type 6 and not supported in this release.					Х		5.4.4.11
timeOffset	Time Offset. Time offset from the start of the slot to start of Cyclic Prefix.	Х		х				5.4.4.12
cpLength	Cyclic Prefix Length.	Х		Х				5.4.4.14

Note:

- 1. Only sections types 1 and 3 are supported in the current release.
- 2. References in the remarks column are corresponding Chapter numbers in the O-RAN Fronthaul Working Group Control, User, and Synchronization Plane Specification in Table 2.

Sections are the pointer to the array of structure which has the parameters for section(s) and it is defined as

```
struct xran_section_gen_info {
   struct xran section info info;
   uint16_t type;
uint16_t len;
void *data;
       } exData[XRAN MAX NUM EXTENSIONS];
```



info is the structure to hold the information to generate section and it is defined as the structure of xran section info. Like xran cp header params, all parameters are not required to generate section and Table 12 describes which parameters are required for each section.

Table 12. **Parameters for Sections**

	Description		Section ⁻	Туре арр	licable		Remarks
	Description	0	1	3	5	6	
Id	Section Identifier.	х	х	х	х	х	5.4.5.1
Rb	Resource Block Indicator. Available values are defined as XRAN_RBIND_xxxx.	x	x	х	х	x	5.4.5.2
symInc	Symbol number Increment command. Available values are defined as XRAN_SYMBOLNUMBER_XXXX.	x	x	x	x	x	5.4.5.3
startPrbc	Starting PRB of data section description.	х	х	х	х	х	5.4.5.4
numPrbc	The number of contiguous PRBs per data section description. When numPrbc is greater than 255, it will be converted to zero by the macro (XRAN_CONVERT_NUMPRBC).	x	x	x	x	x	5.4.5.6
reMask	Resource Element Mask.	х	х	х	Х		5.4.5.5
numSymbol	Number of Symbols.	x	х	х	Х		5.4.5.7
beamId	Beam Identifier.		x	Х			5.4.5.9
freqOffset	Frequency Offset.			х			5.4.5.11
ueId	UE identifier. They are not supported in this release.				х	х	5.4.5.10
regFactor	Regularization Factor. Not supported in this release					х	5.4.5.12
Ef	Extension Flag. They are not supported in this release.		х	х	х	х	5.4.5.8

Note:

- 1. Only sections types 1 and 3 are supported in the current release.
- 2. References in the remarks column are corresponding Chapter numbers in the O-RAN FrontHaul Working Group Control, User, and Synchronization Plane Specification in Table 2.

NOTE: xran section info has more parameters - type, startSymId, iqWidth, compMeth. These are the same parameters as those of radio application or section header but need to be copied into this structure again for the section data base.

exDataSize and exData are used to add section extensions for the section.

exDataSize is the number of elements in the exData array. The maximum number of elements is defined as XRAN MAX NUM EXTENSIONS and it is defined by four in this release with the assumption that four different types of section extensions can be added to a section (section extension type 3 is excluded since it is not supported). exData.type is the type of section extension and exData.len is the length of structure of



section extension parameter in exData.data.exData.data is the pointer to the structure of section extensions and different structures are used by the type of section extensions like below.

For section extension type 1, the structure of xran sectionext1 info is used.

NOTE: The xRAN library will use beamforming weight (bfwlQ) as-is, i.e., xRAN library will not perform the compression, so the user should provide proper data to bfwlQ.

For section extension type 2, the structure of $xran_sectionext2_info$ is used. Each parameter will be packed as specified bit width.

For section extension type 3, the structure of xran sectionext3 info is used.

```
struct xran_sectionext4_info {
    uint8_t    csf;
    uint8_t    pad0;
    uint16_t    modCompScaler;
```



};

For section extension type 4, the structure of xran sectionext4 info is used.

```
struct xran_sectionext5_info {
   uint8_t    num_sets;
   struct {
      uint16_t    csf;
      uint16_t    mcScaleReMask;
      uint16_t    mcScaleOffset;
      } mc[XRAN_MAX_MODCOMP_ADDPARMS];
   };
```

For section extension type 5, the structure of xran sectionext5 info is used.

NOTE: Current implementation supports maximum two sets of additional parameters.

```
struct xran_sectionext6_info {
    uint8_t     rbgSize;
    uint8_t     pad;
    uint16_t     symbolMask;
    uint32_t     rbgMask;
    };

For section extension type 6, the structure of xran_sectionext6_info is used.

struct xran_sectionext10_info {
    uint8_t     numPortc;
    uint8_t     beamGrpType;
    uint16_t     beamID[XRAN_MAX_NUMPORTC_EXT10];
    };
```

For section extension type 10, the structure of xran sectionext10 info is used.

```
struct xran_sectionext11_info {
    uint8_t      RAD;
    uint8_t      disableBFWs;
```

```
uint8_t    numBundPrb;
uint8_t    numSetBFWs;    /* Total number of beam forming weights set (L) */
```

For section extension type 11, the structure of xran sectionext11 info is used.

To minimize memory copy for beamforming weights, when section extension 11 is required to send beamforming weights(BFWs), external flat buffer is being used in current release. If extension 11 is used, it will be used instead of mbufs that pre-allocated external buffers which BFWs have been prepared already. BFW can be prepared by xran_cp_prepare_ext11_bfws() and the example usage can be found from app_init_xran_ig_content() from sample-app.c.



5.4.2.1.1 Detail Procedures in API

The xran prepare ctrl pkt() has several procedures to compose a C-Plane packet.

- 1. Append transport header:
 - Reserve eCPRI header space in the packet buffer
 - eCPRI version is fixed by XRAN ECPRI VER (0x0001)
 - Concatenation and transport layer fragmentation is not supported.

```
ecpri concat=0, ecpri seq id.sub seq id=0 and ecpri seq id.e bit=1
```

 The caller needs to provide a component carrier index, antenna index, and message identifier through function arguments.

```
CC ID, Ant ID and seq id
```

- ecpriRtcid (ecpri xtc id) is composed with CC ID and Ant ID by xran compose cid.
 - DU port ID and band sector ID are fixed by zero in this release.
 - The output of xran compose cid is stored in network byte order.
- The length of the payload is initialized by zero.
- 2. Append radio application header:
 - The xran_append_radioapp_header() checks the type of section through params->sectionType and determines proper function to append remaining header components.
 - Only section type 1 and 3 are supported, returns XRAN_STATUS_INVALID_PARAM for other types.
 - Each section uses a different function to compose the remaining header and size to calculate the total length in the transport header.
 - For section type 1, xran_prepare_section1_hdr() and sizeof(struct xran_cp_radioapp_section1_header)
 - For section type 3, xran_prepare_section3_hdr() and sizeof(struct xran_cp_radioapp_section3_header)
 - Reserves the space of common radio application header and composes header by xran prepare radioapp common header().

The header is stored in network byte order.

Appends remaining header components by the selected function above

The header is stored in network byte order

- 3. Append section header and section:
 - The xran_append_control_section() determines proper size and function to append section header and contents.
 - Appends section header and section(s) by selected function above.
 - If multiple sections are configured, then those will be added.
 - Since fragmentation is not considered in this implementation, the total length of a single C-Plane message shall not exceed MTU size.



- The header and section(s) are stored in network byte order.
 - Appends section extensions if it is set (ef=1)
 - The xran_append_section_extensions() adds all configured extensions by its type.
 - The $xran_prepare_sectionext_x()$ (x = 1, 2, 4, 5) will be called by the type from and these functions will create extension field.

5.4.2.1.2 Example Usage of API

There are two reference usages of API to generate C-Plane messages:

- xran_cp_create_and_send_section() in xran_main.c
- generate_cpmsg_prach() in xran_common.c

The $xran_cp_create_and_section()$ is to generate the C-Plane message with section type 1 for DL or UL symbol data scheduling.

This function has hardcoded values for some parameters such as:

- The filter index is fixed to XRAN FILTERINDEX STANDARD.
- RB indicator is fixed to XRAN RBIND EVERY.
- Symbol increment is not used (XRAN SYMBOLNUMBER NOTINC)
- Resource Element Mask is fixed to 0xfff

If section extensions include extension 1 or 11, direct mbuf will not be allocated/used and pre-allocated flat buffer will be attached to indirect mbuf. This external buffer will be used to compose C-Plane message and should have BFWs already by xran cp populate section ext 1() or xran cp prepare ext11 bfws().

Since current implementation uses single section single C-Plane message, if multi sections are present, this function will generate same amount of C-Plane messages with the number of sections.

After C-Plane message generation, it will send generated packet to TX ring after adding an Ethernet header and also will add section information of generated C-Plane packet to section database, to generate U-plane message by C-Plane configuration.

The generate cpmsg prach () is to generate the C-Plane message with section type 3 for PRACH scheduling.

This functions also has some hardcoded values for the following parameters:

- RB indicator is fixed to XRAN RBIND EVERY.
- Symbol increment is not used (XRAN SYMBOLNUMBER NOTINC).
- Resource Element Mask is fixed to 0xfff.

This function does not send generated packet, $send_cpmsg()$ should be called after this function call. The example can be found from $tx_cp_ul_cb()$ in $xran_main.c$. Checking and parsing received PRACH symbol data by section information from the C-Plane are not implemented in this release.

5.4.2.1.3 Example Configuration of C-Plane Messages

C-Plane messages can be composed through the API, and the sample application shows several reference usages of the configuration for different numerologies.

Below are the examples of the C-Plane message configuration with a sample application for mmWave - numerology 3, 100 MHz bandwidth, TDD (DDDS)



C-Plane Message – downlink symbol data for a downlink slot

- Single CP message with the single section of section type 1
- Configures single CP message for all consecutive downlink symbols
- Configures whole RBs (66) for a symbol
- Compression and beamforming are not used

```
Common Header Fields
       - dataDirection = XRAN DIR DL
       - payloadVersion = XRAN_PAYLOAD_VER
       - filterIndex = XRAN_FILTERINDEX_STANDARD
       frameId = [0..99]
       - subframeId = [0..9]
       slotID = [0..9]
       - startSymbolid = 0
       - numberOfsections = 1
       - sectionType = XRAN CP SECTIONTYPE 1
       - udCompHdr.idIgWidth = 0

    udCompHdr.udCompMeth = XRAN_COMPMETHOD_NONE

       reserved = 0
Section Fields
       sectionId = [0..4095]
       - rb = XRAN RBIND EVERY
       - syminc = XRAN_SYMBOLNUMBER_NOTINC
       - startPrbc = 0
       - numPrbc = 66
       - reMask = 0xfff
       - numSymbol = 14
        - ef = 0
       - beamId = 0
```

C-Plane Message – uplink symbol data for uplink slot

- Single CP message with the single section of section type 1
- Configures single CP message for all consecutive uplink symbols (UL symbol starts from 3)
- Configures whole RBs (66) for a symbol
- Compression and beamforming are not used



```
Common Header Fields
       - dataDirection = XRAN DIR UL

    payloadVersion = XRAN_PAYLOAD_VER

    filterIndex = XRAN_FILTERINDEX_STANDARD

        frameId = [0..99]
        - subframeId = [0..9]
        slotID = [0..9]
        - startSymbolid = 3
        - numberOfsections = 1
        sectionType = XRAN_CP_SECTIONTYPE_1
        udCompHdr.idIqWidth = 0
        udCompHdr.udCompMeth = XRAN_COMPMETHOD_NONE
        reserved = 0
Section Fields
       - sectionId = [0..4095]

    rb = XRAN RBIND EVERY

       - syminc = XRAN_SYMBOLNUMBER_NOTINC
        - startPrbc = 0

    numPrbc = 66

        reMask = 0xfff
        - numSymbol = 11
        - ef = 0
        - beamId = 0
```

C-Plane Message – PRACH

- Single CP message with the single section of section type 3 including repetition
- Configures PRACH format A3, config index 81, and detail parameters are:

```
- Filter Index: 3

- CP length: 0

- Time offset: 2026

- FFT size: 1024

- Subcarrier spacing: 120KHz

- Start symbol index: 7

- Number of symbols: 6

- Number of PRBCs: 12

- Frequency offset: -792
```

NOTE: Compression and beamforming are not used.



```
Common Header Fields
        - dataDirection = XRAN DIR UL
        - payloadVersion = XRAN_PAYLOAD_VER

    filterIndex = XRAN_FILTERINDEPRACH_ABC

        frameId = [0..99]

    subframeId = [0..3]

        - slotID = 3 or 7

    startSymbolid = 7

        - numberOfsections = 1
        sectionType = XRAN_CP_SECTIONTYPE 3
        timeOffset = 2026

    frameStructure.FFTSize = XRAN FFTSIZE 1024

        frameStructure.u = XRAN_SCS_120KHZ

    cpLength = 0

    udCompHdr.idIgWidth = 0

    udCompHdr.udCompMeth = XRAN_COMPMETHOD NONE

Section Fields
        - sectionId = [0..4095]
        rb = XRAN_RBIND_EVERY
        - syminc = XRAN SYMBOLNUMBER NOTINC
        startPrbc = 0

    numPrbc = 12

    reMask = 0xfff

        numSymbol = 6
        ef = 0
        - beamId = 0
        - frequencyOffset = -792

    reserved
```

5.4.2.2 Functions to Store/Retrieve Section Information

There are several functions to store/retrieve section information of C-Plane messages. Since U-plane messages must be generated by the information in the sections of a C-Plane message, it is required to store and retrieve section information.

5.4.2.2.1 APIs and Data Structure

APIs for initialization and release storage are:

```
• int xran_cp_init_sectiondb(void *pHandle);
```

```
    int xran cp free sectiondb(void *pHandle);
```

APIs to store and retrieve section information are:

```
    int xran_cp_add_section_info(void *pHandle, uint8_t dir, uint8_t cc_id, uint8_t ruport id, uint8 t ctx id, struct xran section info *info);
```

int xran_cp_add_multisection_info(void *pHandle, uint8_t cc_id, uint8_t ruport_id, uint8_t ctx_id, struct xran_cp_gen_params *gen_info);



- struct xran_section_info *xran_cp_find_section_info(void *pHandle, uint8_t dir, uint8 t cc id, uint8 t ruport id, uint8 t ctx id, uint16 t section id);
- struct xran_section_info *xran_cp_iterate_section_info(void *pHandle, uint8 t dir, uint8 t cc id, uint8 t ruport id, uint8 t ctx id, uint32 t *next);
- int xran_cp_getsize_section_info(void *pHandle, uint8_t dir, uint8_t cc_id, uint8_t ruport id, uint8 t ctx id);

APIs to reset the storage for a new slot are:

```
int xran_cp_reset_section_info(void *pHandle, uint8_t dir, uint8_t cc_id, uint8_t
ruport id, uint8 t ctx id);
```

The structure of xran_section_info is used to store/retrieve information. This is the same structure used to generate a C-Plane message. Refer to Section 1, API and Data Structures for more details.

The storage for section information is declared as a multi-dimensional array and declared as a local static variable to limit direct access. Each item is defined as the structure of xran_sectioninfo_db, and it has the number of stored section information items (cur index) and the array of the information (list), as shown below.

```
/**
  * This structure to store the section information of C-Plane
  * in order to generate and parse corresponding U-Plane */
struct xran_sectioninfo_db {
    uint32_t cur_index; /**< Current index to store for this eAXC */
    struct xran_section_info list[XRAN_MAX_NUM_SECTIONS]; /**< The array of section
information */
};
static struct xran_sectioninfo_db
sectiondb[XRAN_MAX_SECTIONDB_CTX][XRAN_DIR_MAX][XRAN_COMPONENT_CARRIERS_MAX][XRAN_MAX_ANTENNA_NR*2 + XRAN_MAX_ANT_ARRAY_ELM_NR];</pre>
```

The maximum size of the array can be adjusted if required by system configuration. Since transmission and reception window of U-Plane can be overlapped with the start of new C-Plane for next slot, functions have context index to identify and protect the information. Currently the maximum number of context is defined by two and it can be adjusted if needed.

NOTE:

Since the context index is not managed by the library and APIs are expecting it from the caller as a parameter, the caller shall consider a proper method to manage it to avoid corruption. The current reference implementation uses a slot and subframe index to calculate the context index.

5.4.2.2.2 Example Usage of APIs

There are references to show the usage of APIs as below.

• Initialization and release:

```
- xran_cp_init_sectiondb(): xran_open() in lib/src/xran_main.c
- xran_cp_free_sectiondb(): xran_close() in lib/src/xran_main.c
```

Store section information:

```
- xran_cp_add_section_info(): xran_cp_create_and_section() in xran_main.c
and send cpmsg ()in lib/src/xran common.c
```

Retrieve section information:

```
- xran_cp_iterate_section_info(): xran_process_tx_sym() in lib/src/xran_main.c
- xran_cp_getsize_section_info(): xran_process_tx_sym() in lib/src/xran_main.c
```



• Reset the storage for a new slot:

```
- xran_cp_reset_section_info(): tx_cp_dl_cb() and tx_cp_ul_cb() in
lib/src/xran_main.c
```

5.4.2.2.3 Function for RU emulation and Debug

xran parse cp pkt () is a function which can be utilized for RU emulation or debug. It is defined below:

```
int xran_parse_cp_pkt(struct rte_mbuf *mbuf,
    struct xran_cp_recv_params *result,
    struct xran_recv_packet_info *pkt_info);
```

It parses a received C-Plane packet and retrieves the information from its headers and sections.

The retrieved information is stored in the structures:

- struct xran cp recv params: section information from received C-Plane packet
- struct xran recv packet info: transport layer header information (eCPRI header)

These functions can be utilized to debug or RU emulation purposes.

5.4.3 U-plane

Single Section is the default mode of xRAN packet creation. It assumes that there is only one section per packet, and all IQ samples are attached to it. Compression is not supported.

A message is built in the mbuf space given as a parameter. The library builds eCPRI header filling structure fields by taking the IQ sample size and populating a particular packet length and sequence number.

With block floating point compression, supported IQ bit widths are 8,9,10,12,14. With modulation compression, supported IQ bit widths are defined according to modulation order as in section A.5 of O-RAN spec..

Implementation of a U-plane set of functions is defined in xran_up_api.c and is used to prepare U-plane packet content according to the given configuration.

The following list of functions is implemented for U-plane:

- Build eCPRI header
- Build application header
- Build section header
- Append IQ samples to packet
- Prepare full symbol of O-RAN data for single eAxC
- Process RX packet per symbol.

The time of generation of a U-plane message for DL and UL is "symbol-based" and can be controlled using O-DU settings (O-RU), according to <u>Table 4</u>.

For more information on function arguments and parameters refer to <u>Table 2</u>, *Doxygen and corresponding source code*.

5.5 Supporting Code

The xRAN library has a set of functions used to assist in packet processing and data exchange not directly used for O-RAN packet processing.



5.5.1 Timing

The sense of time for the O-RAN protocol is obtained from system time, where the system timer is synchronized to GPS time via PTP protocol using the Linux PHP package. On the software side, a simple polling loop is utilized to get time up to nanosecond precision and particular packet processing jobs are scheduled via the DPDK timer.

```
long poll next tick(int interval)
        struct timespec start time;
        struct timespec cur time;
        long target time;
       long delta;
       clock gettime(CLOCK REALTIME, &start time);
        target time = (start time.tv sec * NSEC PER SEC + start time.tv nsec +
interval * NSEC PER USEC) / (interval *
                                                      NSEC PER USEC) * interval;
       while(1)
                 clock gettime(CLOCK REALTIME, &cur time);
                 delta = (cur time.tv sec * NSEC PER SEC + cur time.tv nsec) -
target time * NSEC PER USEC;
                 if(delta > 0 || (delta < 0 && abs(delta) < THRESHOLD))</pre>
                     break;
        return delta;
```

Polling is used to achieve the required precision of symbol time. For example, in the mmWave scenario, the symbol time is 125 μ s/14=~8.9 μ s. Small deterministic tasks can be executed within the polling interval provided. It's smaller than the symbol interval time.

Current O-RAN library supports multiple O-RU of multiple numerologies, thus the sense of timing is based on the O-RU with highest numerology (smallest symbol time). It is required to configure the O-RU0 with highest numerology in the O-RAN configuration.

5.5.2 DPDK Timers

DPDK provides sets of primitives (struct rte_rimer) and functions (rte_timer_reset_sync() rte_timer_manage()) to schedule processing of function as timer. The timer is based on the TSC clock and is not synchronized to PTP time. As a result, this timer cannot be used as a periodic timer because the TSC clock can drift substantially relative to the system timer which in turn is synchronized to PTP (GPS)

Only single-shot timers are used to schedule processing based on events such as symbol time. The packet processing function calls rte_timer_manage () in the loop, and the resulting execution of timer function happens right after the timer was "armed".

5.5.3 xRAN Ethernet

The xran_init_port() function performs initialization of DPDK ETH port. Standard port configuration is used as per reference example from DPDK.

Jumbo Frames are used by default. mbufs size is extended to support 9600 bytes packets.

Configurable MTU size is supported starting from 20.11 release.

MAC address and VLAN tag are expected to be configured by Infrastructure software. Refer to <u>A.4, Install and Configure Sample Application</u>.



From an implementation perspective, modules provide functions to handle:

- Ethernet headers
- VLAN tag
- Send and Receive mbuf.

5.5.4 xRAN Ethdi

Ethdi provides functionality to work with the content of an Ethernet packet and dispatch processing to/from the xRAN layer. Ethdi instantiates a main PMD driver thread and dispatches packets between the ring and RX/TX using rte eth rx burst() and rte eth tx burst() DPDK functions.

For received packets, it maintains a set of handlers for ethertype handlers and xRAN layer register one O-RAN ethtype 0xAEFE, resulting in packets with this ethertype being routed to the xRAN processing function. This function checks the message type of the eCPRI header and dispatches packet to either C-plane processing or U-plane processing.

Initialization of memory pools, allocation, and freeing of the mbuf for Ethernet packets occur in this layer.

Refer to <u>Table 2</u> for detailed information on functions implemented for xRAN ethdi can be found in the Doxygen provided with the FlexRAN release.

5.5.5 O-RAN One Way Delay Measurements

The support for the eCPRI one- way delay measurements which are specified by the O-RAN to be used with the Measured Transport support per Section 2.3.3.3 of the O-RAN-WG4.CUS.0-v4.00 specification and section 3.2.4.6 of the eCPRI_v2.0 specification is implemented in the file xran_delay_measurement.c. Structure definitions used by the owd measurement functions are in the file xran_fh_o_du.h for common data and port specific variables and parameters.

The implementation of this feature has been done under the assumption that the requestor is the O-DU and the recipient is the O-RU. All of the action_types per the eCPRI 2.0 have been implemented. In the current version the timestamps are obtained using the linux function clock_gettime using CLOCK_REALTIME as the clock_id argument.

The implementation supports both the O-RU and the O-DU side in order to do the unit test in loopback mode.

The one-delay measurements are enabled at configuration time and run right after the xran_start() function is executed. The total number of consecutive measurements per port should be a power of 2 and in order to minimize the system startup it is advisable that the number is 16 or below.

The following functions can be found in the xran delay measurement.c:

xran_ecpri_one_way_delay_measurement_transmitter() which is invoked from the process_dpdk_io() function if the one-way delay measurements are enabled. This is the main function for the owd transmitter.

xran_generate_delay_meas() is a general function used by the transmitter to send the appropriate messages based on actionType and filling up all the details for the ethernet and ecpri layers.

Process_delay_meas() this function is invoked from the handle_ecpri_ethertype() function when the ecpri message type is ECPRI_DELAY_MEASUREMENT. This is the main owd receiver function.

From the Process_delay_meas() and depending on the message received we can execute one of the following functions

xran_process_delmeas_request() If we received a request message.

xran process delmeas request w fup() If we received a request with follow up message.



xran_process_delmeas_response() If we received a response message.

xran_process_delmeas_rem_request() If we received a remote request message

xran_delmeas_rem_request_w_fup() If we received a remote request with follow up message.

All of the receiver functions also can generate the appropriate send message by using the DPDK function rte_eth_tx_burst() to minimize the response delay.

Additional utility functions used by the owd implementation for managing of timestamps and time measurements are:

xran_ptp_ts_to_ns() that takes a TimeStamp argument from a received owd ecpri packet and places it in host order and returns the value in nanoseconds.

xran_timespec_to_ns() that takes an argument in timespec format like the return value from the linux function clock gettime() and returns a value in nanoseconds.

xran_ns_to_timespec() that takes an argument in nanoseconds and returns a value by reference in timespec format.

xran_compute_and_report_delay_estimate() This function takes an average of the computed one way delay measurements and prints out the average value to the console expressed in nanoseconds. Currently we exclude the first 2 measurements from the average.

Utility functions in support of the owd ecpri packet formulation are:

xran_build_owd_meas_ecpri_hdr() Builds the ecpri header with message type ECPRI_DELAY_MEASUREMENT and writes the payload size in network order.

xran_add_at_and_measId_to_header() This function is used to write the action Type and MeasurementID to the eCPRI owd header.

The current implementation of the one way delay measurements only supports a fixed message size. The message is defined in the xran_pkt.h in the structure xran_ecpri_delay_meas_pl.

The one-way delay measurements have been tested with the sample-app for the Front Haul Interface Library and have not yet been integrated with the L1 Layer functions.

5.5.6 Mlog Usage

t Mlog is a timing information log that contains information about task execution within the application. It is extensively used for the 5G NR L1 pipeline. By default, the xRAN library supports the gathering of t mlog data for critical functions in the code to be able to debug timing-related issues for latency between different events in the code. The file $t mlog_t t mlog_t t mlog_t t mlog_t to the library that the rest of the L1 application. The library expects that <math>t mlog_t t mlog_t mlog_t$

There are two compilation options:

- In xran/lib/Makefile: MLOG_ENABLED enables usage of MLOG (enabled by default)
- In libs/mlog/source/makecfg: MLOG_SYS_CLOCK_TICK enables usage of system clock for capturing of timing information instead of TSC (disabled by default as result TSC is used).


The benefit of the second option is the possibility to capture mlog file data from two different systems (O-DU server and simulation of RU on a different server) and analyze information together as baseline "sense of time" is the same and synchronized to GPS via PTP.



6.0 Sample Application

Figure 26 illustrates a sample xRAN application.

Figure 26. Sample Application



The sample application was created to execute test scenarios with features of the xRAN library and test external API as well as timing. The sample application is named sample-app, and depending on configuration file settings can act as O-DU or simplified simulation of O-RU. The first O-DU should be run on the machine that acts as O-DU and the second as O-RU. Both machines are connected via ETH. The sample application on both sides executes using a constant configuration according to settings in corresponding config files

(./app/usecase/mu0 10mhz/config file o du.dat and

./app/usecase/mu0_10mhz/config_file_o_ru.dat) and uses binary files (ant.bin) with IQ samples as input. Multiple-use cases for different numerologies and different BW are available as examples. Configuration files provide descriptions of each parameter, and in general, those are related to M-plane level settings as per the O-RAN Fronthaul specification, refer to Table 2.

From the start of the process, the application (O-DU) sends DL packets for the U-plane and C-plane and receives U-plane UL packets. Synchronization of O-DU and O-RU sides is achieved via IEEE 1588.

U-plane packets for UL and DL direction are constructed the same way except for the direction field.

Examples of default configurations used with the sample application for v20.04 release provided below:

1 Cell mmWave 100MHz TDD DDDS:

- Numerology 3 (mmWave)
- TTI period 125 μs
- 100 MHz Bandwidth: 792 subcarriers (all 66 RB utilized at all times)
- 4x4 MIMO
- No beamforming
- 1 Component carrier
- Jumbo Frame for Ethernet (up to 9728 bytes)
- Front haul throughput ~11.5 Gbps.



12 Cells Sub6 10MHz FDD:

- Numerology 0 (Sub-6)
- TTI period 1000 μs
- 10 MHz Bandwidth: 624 subcarriers (all 52 RB utilized at all times)
- 4x4 MIMO
- No beamforming
- 12 Component carrier
- Jumbo Frame for Ethernet (up to 9728 bytes)
- Front haul throughput ~13.7Gbps.

1 Cell Sub6 100 MHz TDD

- Numerology 1 (Sub-6)
- TTI period 500 μs
- 100 MHz Bandwidth: 3276 subcarriers (all 273 RB utilized at all times)
- 4x4 MIMO
- No beamforming
- 1 Component carrier
- Jumbo Frame for Ethernet (up to 9728 bytes)
- Front haul throughput ~11.7 Gbps.

1 Cell Sub6 100 MHz TDD (Category B):

- Numerology 1 (Sub-6)
- TTI period 500 μs
- 100 MHz Bandwidth: 3276 subcarriers (all 273 RB utilized at all times). 8 UEs per TTI per layer
- 8DL /4UL MIMO Layers
- Digital beamforming with 32T32R
- 1 Component carrier
- Jumbo Frame for Ethernet (up to 9728 bytes)
- Front haul throughput ~23.5 Gbps.

3 Cell Sub6 100MHz TDD Massive MIMO (Category B):

- Numerology 1 (Sub-6)
- TTI period 500 μs
- 100 Mhz Bandwidth: 3276 subcarriers (all 273 RB utilized at all times). 8 UEs per TTI per layer
- 16DL /8UL MIMO Layers
- Digital beamforming with 64T64R
- 1 Component carrier for each Cell
- Jumbo Frame for Ethernet (up to 9728 bytes)



Front haul throughput ~44 Gbps.

Other configurations can be constructed by modifying the config files (see app/usecase/)

One_way Delay Measurements:

There are 4 usecases defined that are based on cat a, numerology 0 and 20 MHz Bw:

Common to all cases the following parameters are needed in the usecase xu.cfg files where x=r for ORU and x=d for ODU.

```
oXuOwdmNumSamps=8  # Run 8 samples per port
oXuOwdmFltrType=0  # Simple average
oXuOwdmRespTimeOut=10000000 # 10 ms expressed in ns (Currently not enforced)
oXuOwdmMeasState=0  # Measurement state is INIT
oXuOwdmMeasId=0  # Measurement Id seed
oXuOwdmEnabled=1  # Measurements are enabled
oXuOwdmPlLength= n \# with 40 <= n <= 1400 bytes
```

For the ORU

oXuOwdmInitEn=0 #O-RU is always the recipient

For the ODU

oXuOwdmInitEn=1 #O-DU is always initiator

20 Corresponds to the Request/Response usecase with Payload Size 40 bytes

oXuOwdmMeasMeth=0 # Measurement Method REQUEST

21 Corresponds to the Remote Request usecase with Payload Size 512 bytes

oXuOwdmMeasMeth=1 # Measurement Method REM REQ

22 Corresponds to the Request with Follow Up usecase with Payload Size 1024 bytes

oXuOwdmMeasMeth=2 # Measurement Method REQUESTwFUP

23 Corresponds to the Remote Request with Follow Up usecase with default Payload Size

oXuOwdmMeasMeth=3 # Measurement Method REM_REQ_WFUP

§



Appendix A Setup Configuration


A.1 Setup Configuration

The configuration shown in Figure 26 shows how to set up a test environment to execute O-RAN scenarios where O-DU and 0-RU are simulated using the sample application provided with the FlexRAN release package. This setup allows development and prototyping as well as testing of O-RAN specific functionality. The O-DU side can be instantiated with a full 5G NR L1 reference as well. The configuration differences of the 5G NR l1app configuration are provided below. Steps for running the sample application on the O-DU side and O-RU side are the same, except configuration file options may be different.

Figure 27. Setup for O-RAN Testing



Figure 28. Setup for O-RAN Testing with PHY and Configuration C3








Figure 29. Setup for O-RAN Testing with PHY and Configuration C3 for Massive MIMO

A.2 Prerequisites

Each server in Figure 27 requires the following:

- Wolfpass server according to recommended BOM for FlexRAN such as Intel® Xeon® Skylake Gold 6148 FC-LGA3647 2.4 GHz 27.5 MB 150W 20 cores (two sockets) or higher
- Wilson City or Coyotee Pass server with Intel® Xeon® Icelake CPU for Massive-MIMO with L1 pipeline testing
- BIOS settings:
 - Intel® Virtualization Technology Enabled
 - Intel® VT for Directed I/O Enabled
 - ACS Control Enabled
 - Coherency Support Disabled
- Front Haul networking cards:
 - Intel® Ethernet Converged Network Adapter XL710-QDA2
 - Intel® Ethernet Converged Network Adapter XXV710-DA2
 - Intel® Ethernet Converged Network Adapter E810-CQDA2
 - Intel® FPGA Programmable Acceleration Card (Intel® FPGA PAC) N3000
- Back (Mid) Haul networking card can be either:
 - Intel® Ethernet Connection X722 for 10GBASE-T
 - Intel® 82599ES 10-Gigabit SFI/SFP+ Network Connection
 - Other networking cards capable of HW timestamping for PTP synchronization.

NOTE: Both Back (mid) Haul and Front Haul NIC require support for PTP HW timestamping.



The recommended configuration for NICs is:

```
ethtool -i enp33s0f0
driver: i40e
version: 2.14.13
firmware-version: 8.20 0x80009bd4 1.2879.0
expansion-rom-version:
bus-info: 0000:21:00.0
supports-statistics: yes
supports-test: yes
supports-eeprom-access: yes
supports-register-dump: yes
supports-priv-flags: yes
ethtool -T enp33s0f0
Time stamping parameters for enp33s0f0:
Capabilities:
             hardware-transmit (SOF_TIMESTAMPING_TX_HARDWARE)
software-transmit (SOF_TIMESTAMPING_TX_SOFTWARE)
hardware-receive (SOF_TIMESTAMPING_RX_HARDWARE)
software-receive (SOF_TIMESTAMPING_RX_SOFTWARE)
              software-system-clock (SOF TIMESTAMPING SOFTWARE)
             hardware-raw-clock (SOF_TIMESTAMPING_RAW_HARDWARE)
PTP Hardware Clock: 4
Hardware Transmit Timestamp Modes:
                                  (HWTSTAMP_TX_OFF)
                                                     (HWTSTAMP TX ON)
            none (HWTSTAMP_FILTER_NONE)
ptpv1-14-sync (HWTSTAMP_FILTER_PTP_V1_L4_SYNC)
ptpv1-14-delay-req (HWTSTAMP_FILTER_PTP_V1_L4_DELAY_REQ)
ptpv2-14-event (HWTSTAMP_FILTER_PTP_V2_L4_EVENT)
ptpv2-14-sync (HWTSTAMP_FILTER_PTP_V2_L4_SYNC)
ptpv2-14-delay-req (HWTSTAMP_FILTER_PTP_V2_L4_DELAY_REQ)
ptpv2-12-event (HWTSTAMP_FILTER_PTP_V2_L2_EVENT)
ptpv2-12-sync (HWTSTAMP_FILTER_PTP_V2_L2_SYNC)
ptpv2-12-delay-req (HWTSTAMP_FILTER_PTP_V2_L2_DELAY_REQ)
ptpv2-event (HWTSTAMP_FILTER_PTP_V2_EVENT)
ptpv2-sync (HWTSTAMP_FILTER_PTP_V2_SYNC)
Hardware Receive Filter Modes:
              ptpv2-delay-req (HWTSTAMP FILTER PTP V2 DELAY REQ)
```

The recommended configuration for Columbiaville NICs (base on Intel® Ethernet 800 Series (Columbiaville) CVL 2.3 release is:

```
ethtool -i enp81s0f0
driver: ice
version: 1.3.2
firmware-version: 2.3 0x80005D18
expansion-rom-version:
bus-info: 0000:51:00.0
supports-statistics: yes
supports-test: yes
supports-eeprom-access: yes
supports-register-dump: yes
supports-priv-flags: yes
ethtool -T enp81s0f0
Time stamping parameters for enp81s0f0:
Capabilities:
          hardware-transmit (SOF_TIMESTAMPING_TX_HARDWARE)
software-transmit (SOF_TIMESTAMPING_TX_SOFTWARE)
hardware-receive (SOF_TIMESTAMPING_RX_HARDWARE)
software-receive (SOF_TIMESTAMPING_RX_SOFTWARE)
          software-system-clock (SOF TIMESTAMPING SOFTWARE)
```



Note: If your firmware version does not match with the ones in the output images, you can download the correct version from the Intel Download Center. It is Intel's repository for the latest software and drivers for Intel products. The NVM Update Packages for Windows*, Linux*, ESX*, FreeBSD*, and EFI/EFI2 are located at:

https://downloadcenter.intel.com/download/24769 (700 series)

https://downloadcenter.intel.com/download/29736 (E810 series)

PTP Grand Master is required to be available in the network to provide synchronization of both O-DU and RU to GPS time.

The software package includes Linux* CentOS* operating system and RT patch according to FlexRAN Reference Solution Cloud-Native Setup document (refer to Table 2). Only real-time HOST is required.

- 1. Install Intel® C++ Compiler v19.0.3
- 2. Download DPDK v20.11
- 3. Patch DPDK with FlexRAN BBDev patch as per given release.
- 4. Double check that FlexRAN DPDK patch includes changes below relevant to O-RAN Front haul:

```
For Fortville:
diff --qit a/drivers/net/i40e/i40e ethdev.c b/drivers/net/i40e/i40e ethdev.c
index 85a6a86..236fbe0 100644
--- a/drivers/net/i40e/i40e ethdev.c
+++ b/drivers/net/i40e/i40e ethdev.c
00 - 2207,7 + 2207,7 = 00 void 140e flex payload reg set default(struct 140e hw *hw)
    /* Map queues with MSIX interrupt */
    main vsi->nb used qps = dev->data->nb rx queues -
             pf->nb cfg vmdq vsi * RTE LIBRTE I40E QUEUE NUM PER VM;
    i40e vsi queues bind intr(main vsi, I40E ITR INDEX DEFAULT);
    i40e vsi queues bind intr(main vsi, I40E ITR INDEX NONE);
    i40e vsi enable queues intr(main vsi);
    /* Map VMDQ VSI queues with MSIX interrupt */
@@ -2218,6 +2218,10 @@ void i40e_flex_payload_reg_set_default(struct i40e_hw *hw)
              i40e vsi enable queues intr(pf->vmdq[i].vsi);
    i40e aq debug write global register(hw,
                                                  0x0012A504,
                                                  0, NULL);
    /* enable FDIR MSIX interrupt */
    if (pf->fdir.fdir vsi) {
              i40e vsi queues bind intr(pf->fdir.fdir vsi,
diff --git a/drivers/net/i40e/i40e ethdev vf.c b/drivers/net/i40e/i40e ethdev vf.c
index 001c301..6f9ffdb 100644
```



```
--- a/drivers/net/i40e/i40e ethdev vf.c
+++ b/drivers/net/i40e/i40e ethdev vf.c
@@ -640,7 +640,7 @@ struct rte i40evf xstats name off {
    map info = (struct virtchnl irq map info *)cmd buffer;
    map_info->num_vectors = 1;
    map_info->vecmap[0].rxitr_idx = I40E_ITR_INDEX_DEFAULT;
   map_info->vecmap[0].rxitr_idx = I40E_ITR_INDEX_NONE;
    map_info->vecmap[0].vsi_id = vf->vsi_res->vsi_id;
    /* Alway use default dynamic MSIX interrupt */
    map_info->vecmap[0].vector id = vector id;
diff --git a/drivers/net/ixgbe/ixgbe ethdev.c b/drivers/net/ixgbe/ixgbe ethdev.c
index 26b1927..018eb8f 100644
--- a/drivers/net/ixgbe/ixgbe ethdev.c
+++ b/drivers/net/ixgbe/ixgbe ethdev.c
@@ -3705,7 +3705,7 @@ static int ixgbevf dev xstats get names( rte unused struct
rte eth dev *dev,
              * except for 82598EB, which remains constant.
              if (dev_conf->txmode.mq_mode == ETH_MQ_TX_NONE &&
                              hw->mac.type != ixgbe_mac_82598EB)
                              hw->mac.type != ixgbe mac 82598EB && hw->mac.type !=
ixqbe mac 82599EB)
                     dev info->max tx queues = IXGBE NONE MODE TX NB QUEUES;
    dev info->min rx bufsize = 1024; /* cf BSIZEPACKET in SRRCTL register */
diff --git a/lib/librte eal/common/include/rte dev.h
b/lib/librte eal/common/include/rte dev.h
old mode 100644
new mode 100755
for Columbiaville
diff --git a/drivers/net/ice/ice ethdev.c b/drivers/net/ice/ice ethdev.c
index de189daba..d9aff341c 100644
--- a/drivers/net/ice/ice ethdev.c
+++ b/drivers/net/ice/ice_ethdev.c
@@ -2604,8 +2604,13 @@ __vsi_queues_bind_intr(struct ice_vsi *vsi, uint16_t
msix vect,
                PMD DRV LOG(INFO, "queue %d is binding to vect %d",
                            base queue + i, msix vect);
                /* set ITRO value */
                ICE WRITE REG(hw, GLINT ITR(0, msix vect), 0x10);
                /* set ITRO value
                 * Empirical configuration for optimal real time latency
                 * reduced interrupt throttling to 2 ms
                * Columbiaville pre-PRQ : local patch subject to change
                ICE WRITE REG(hw, GLINT ITR(0, msix vect), 0x1);
                ICE_WRITE_REG(hw, QRX_ITR(base_queue + i), QRX_ITR_NO_EXPR_M);
                ICE_WRITE_REG(hw, QINT_RQCTL(base_queue + i), val);
                ICE_WRITE_REG(hw, QINT_TQCTL(base_queue + i), val_tx);
```

5. Build and install the DPDK.

```
See https://doc.dpdk.org/guides/prog_guide/build-sdk-meson.html
Insert VFIO module
```

Make sure that the i40e is patched with the code below to get the best latency of packet processing.

```
--- i40e.h 2018-11-30 11:27:00.000000000 +0000
+++ i40e patched.h 2019-03-06 15:49:06.877522427 +0000
```

Software Architecture Specification



```
@@ -451,7 +451,7 @@
 #define I40E QINT RQCTL VAL(qp, vector, nextq type) \
    (140E QINT RQCTL CAUSE ENA MASK | \
    (I40E RX ITR << I40E QINT RQCTL ITR INDX SHIFT) | \
    (I40E_ITR_NONE << I40E_QINT_RQCTL_ITR_INDX_SHIFT) | \
     ((vector) << I40E_QINT_RQCTL_MSIX_INDX_SHIFT) | \</pre>
     ((qp) << I40E QINT RQCTL NEXTQ_INDX_SHIFT) | \
     (I40E QUEUE TYPE ##nextq type << I40E QINT RQCTL NEXTQ TYPE SHIFT))
                     2018-11-30 11:27:00.000000000 +0000
--- i40e main.c
                              2019-03-06 15:46:13.521518062 +0000
+++ i40e main patched.c
@@ -15296,6 +15296,9 @@
             pf->hw features |= I40E HW HAVE CRT RETIMER;
    /* print a string summarizing features */
    i40e print features(pf);
    /* write to this register to clear rx descriptor */
    i40e aq debug write register(hw, 0x0012A504, 0, NULL);
    return 0;
```

A.3 Configuration of System

1. Boot Linux with the following arguments:

```
cat /proc/cmdline
BOOT_IMAGE=/vmlinuz-3.10.0-1062.12.1.rt56.1042.el7.x86_64 root=/dev/mapper/centos-
root ro crashkernel=auto rd.lvm.lv=centos/root rd.lvm.lv=centos/swap intel_iommu=on
iommu=pt usbcore.autosuspend=-1 selinux=0 enforcing=0 nmi_watchdog=0
softlockup_panic=0 audit=0 intel_pstate=disable cgroup_memory=1 cgroup_enable=memory
mce=off idle=poll hugepagesz=1G hugepages=16 hugepagesz=2M hugepages=0
default_hugepagesz=1G isolcpus=1-19,21-39 rcu_nocbs=1-19,21-39 kthread_cpus=0,20
irqaffinity=0,20 nohz full=1-19,21-39
```

2. Boot Linux with the following arguments for Icelake CPU:

```
cat /proc/cmdline
BOOT_IMAGE=/vmlinuz-3.10.0-957.10.1.rt56.921.el7.x86_64 root=/dev/mapper/centos-root
ro crashkernel=auto rd.lvm.lv=centos/root rd.lvm.lv=centos/swap rhgb quiet
intel_iommu=off usbcore.autosuspend=-1 selinux=0 enforcing=0 nmi_watchdog=0
softlockup_panic=0 audit=0 intel_pstate=disable cgroup_disable=memory mce=off
hugepagesz=1G hugepages=40 hugepagesz=2M hugepages=0 default_hugepagesz=1G
isolcpus=1-23,25-47 rcu_nocbs=1-23,25-47 kthread_cpus=0 irqaffinity=0 nohz_full=1-
23,25-47
```

- 3. Download from Intel Website and install updated version of i40e driver if needed. The current recommended version of i40e is 2.14.13. However, any latest version of i40e after 2.9.21 expected to be functional for O-RAN FH.
- 4. For Columbiaville download Intel® Ethernet 800 Series (Columbiaville) CVL2.3 B0/C0 Sampling Sample Validation Kit (SVK) from Intel Customer Content Library. The current recommended version of ICE driver is 1.3.2 with ICE COMMS Package version 1.3.24.0. IAVF recommended version 4.0.2
- 5. Identify PCIe Bus address of the Front Haul NIC (Fortville):

```
1spci|grep Eth
86:00.0 Ethernet controller: Intel Corporation Ethernet Controller XXV710 for 25GbE SFP28 (rev 02)
86:00.1 Ethernet controller: Intel Corporation Ethernet Controller XXV710 for 25GbE SFP28 (rev 02)
88:00.0 Ethernet controller: Intel Corporation Ethernet Controller XXV710 for 25GbE SFP28 (rev 02)
88:00.1 Ethernet controller: Intel Corporation Ethernet Controller XXV710 for 25GbE SFP28 (rev 02)
```

6. Identify PCIe Bus address of the Front Haul NIC (Columbiaville):

```
lspci |grep Eth
18:00.0 Ethernet controller: Intel Corporation Device 1593 (rev 02)
```



```
18:00.1 Ethernet controller: Intel Corporation Device 1593 (rev 02)
18:00.2 Ethernet controller: Intel Corporation Device 1593 (rev 02) 18:00.3 Ethernet controller: Intel Corporation Device 1593 (rev 02)
51:00.0 Ethernet controller: Intel Corporation Device 1593 (rev 02)
51:00.1 Ethernet controller: Intel Corporation Device 1593 (rev 02)
51:00.2 Ethernet controller: Intel Corporation Device 1593 (rev 02) 51:00.3 Ethernet controller: Intel Corporation Device 1593 (rev 02)
```

7. Identify the Ethernet device name:

```
ethtool -i enp33s0f0
driver: i40e
version: 2.14.13
firmware-version: 8.20 0x80009bd4 1.2879.0
expansion-rom-version:
bus-info: 0000:21:00.0
supports-statistics: yes
supports-test: yes
supports-eeprom-access: yes
supports-register-dump: yes
supports-priv-flags: yesEnable
```

```
ethtool -i enp81s0f0
driver: ice
version: 1.3.2
firmware-version: 2.3 0x80005D18
expansion-rom-version:
bus-info: 0000:51:00.0
supports-statistics: yes
supports-test: yes
supports-eeprom-access: yes
supports-register-dump: yes
supports-priv-flags: yes
```

8. Enable 3 virtual functions (VFs) on the each of two ports of each NIC:

```
#!/bin/bash
echo 0 > /sys/bus/pci/devices/0000\:88\:00.0/sriov numvfs
echo 0 > /sys/bus/pci/devices/0000\:88\:00.1/sriov_numvfs
echo 0 > /sys/bus/pci/devices/0000\:86\:00.0/sriov numvfs
echo 0 > /sys/bus/pci/devices/0000\:86\:00.1/sriov numvfs
modprobe -r iavf
modprobe iavf
echo 3 > /sys/bus/pci/devices/0000\:88\:00.0/sriov numvfs
echo 3 > /sys/bus/pci/devices/0000\:88\:00.1/sriov numvfs
echo 3 > /sys/bus/pci/devices/0000\:86\:00.0/sriov numvfs
echo 3 > /sys/bus/pci/devices/0000\:86\:00.1/sriov numvfs
a=8
if [ -z "$1" ]
then
elif [ $1 -lt $a ]
then
else
echo " Usage \$0 qos with 0 <= qos <= 7 with 0 as a default if no qos is provided"
```



```
exit 1
fi
#O-DU
ip link set enp136s0f0 vf 0 mac 00:11:22:33:00:00 vlan 1 qos $b
ip link set enp136s0f1 vf 0 mac 00:11:22:33:00:10 vlan 1 qos $b
ip link set enp136s0f0 vf 1 mac 00:11:22:33:01:00 vlan 2 qos $b
ip link set enp136s0f1 vf 1 mac 00:11:22:33:01:10 vlan 2 gos $b
ip link set enp136s0f0 vf 2 mac 00:11:22:33:02:00 vlan 3 gos $b
ip link set enp136s0f1 vf 2 mac 00:11:22:33:02:10 vlan 3 qos $b
#O-RU
ip link set enp134s0f0 vf 0 mac 00:11:22:33:00:01 vlan 1 gos $b
ip link set enp134s0f1 vf 0 mac 00:11:22:33:00:11 vlan 1 gos $b
ip link set enp134s0f0 vf 1 mac 00:11:22:33:01:01 vlan 2 gos $b
ip link set enp134s0f1 vf 1 mac 00:11:22:33:01:11 vlan 2 qos $b
ip link set enp134s0f0 vf 2 mac 00:11:22:33:02:01 vlan 3 qos $b
ip link set enp134s0f1 vf 2 mac 00:11:22:33:02:11 vlan 3 qos $b
```

where output is next:

```
ip link show
9: enp134s0f0: <BROADCAST,MULTICAST,UP,LOWER UP> mtu 1500 qdisc mq state UP mode DEFAULT group
default glen 1000
     link/ether 3c:fd:fe:b9:f9:60 brd ff:ff:ff:ff:ff
    vf 0 MAC 00:11:22:33:00:01, vlan 1, spoof checking on, link-state auto, trust off vf 1 MAC 00:11:22:33:01:01, vlan 2, spoof checking on, link-state auto, trust off
    vf 2 MAC 00:11:22:33:02:01, vlan 3, spoof checking on, link-state auto, trust off
11: enp134s0f1: <BROADCAST,MULTICAST,UP,LOWER UP> mtu 1500 qdisc mq state UP mode DEFAULT group
default glen 1000
     link/ether 3c:fd:fe:b9:f9:61 brd ff:ff:ff:ff:ff
    vf 0 MAC 00:11:22:33:00:11, vlan 1, spoof checking on, link-state auto, trust off vf 1 MAC 00:11:22:33:01:11, vlan 2, spoof checking on, link-state auto, trust off vf 2 MAC 00:11:22:33:02:11, vlan 3, spoof checking on, link-state auto, trust off
12: enp136s0f0: <BROADCAST,MULTICAST,UP,LOWER UP> mtu 1500 qdisc mq state UP mode DEFAULT group
default qlen 1000
     link/ether 3c:fd:fe:b9:f8:b4 brd ff:ff:ff:ff:ff
    vf 0 MAC 00:11:22:33:00:00, vlan 1, spoof checking on, link-state auto, trust off
    vf 1 MAC 00:11:22:33:01:00, vlan 2, spoof checking on, link-state auto, trust off vf 2 MAC 00:11:22:33:02:00, vlan 3, spoof checking on, link-state auto, trust off
14: enp136s0f1: <BROADCAST, MULTICAST, UP, LOWER UP> mtu 1500 qdisc mq state UP mode DEFAULT group
default glen 1000
    link/ether 3c:fd:fe:b9:f8:b5 brd ff:ff:ff:ff:ff
     vf 0 MAC 00:11:22:33:00:10, vlan 1, spoof checking on, link-state auto, trust off
    vf 1 MAC 00:11:22:33:01:10, vlan 2, spoof checking on, link-state auto, trust off
    vf 2 MAC 00:11:22:33:02:10, vlan 3, spoof checking on, link-state auto, trust off
```

More information about VFs supported by Intel NICs can be found at https://doc.dpdk.org/guides/nics/intel-vf.html.

The resulting configuration can look like the listing below, where six new VFs were added for each O-DU and O-RU port:

```
lspci|grep Eth
86:00.0 Ethernet controller: Intel Corporation Ethernet Controller XXV710 for 25GbE SFP28 (rev 02)
86:00.1 Ethernet controller: Intel Corporation Ethernet Controller XXV710 for 25GbE SFP28 (rev 02)
86:02.0 Ethernet controller: Intel Corporation Ethernet Virtual Function 700 Series (rev 02)
86:02.1 Ethernet controller: Intel Corporation Ethernet Virtual Function 700 Series (rev 02)
86:02.2 Ethernet controller: Intel Corporation Ethernet Virtual Function 700 Series (rev 02)
86:02.0 Ethernet controller: Intel Corporation Ethernet Virtual Function 700 Series (rev 02)
86:02.1 Ethernet controller: Intel Corporation Ethernet Virtual Function 700 Series (rev 02)
```



```
86:0a.2 Ethernet controller: Intel Corporation Ethernet Virtual Function 700 Series (rev 02)
88:00.0 Ethernet controller: Intel Corporation Ethernet Controller XXV710 for 25GbE SFF28 (rev 02)
88:00.1 Ethernet controller: Intel Corporation Ethernet Controller XXV710 for 25GbE SFF28 (rev 02)
88:02.0 Ethernet controller: Intel Corporation Ethernet Virtual Function 700 Series (rev 02)
88:02.1 Ethernet controller: Intel Corporation Ethernet Virtual Function 700 Series (rev 02)
88:02.2 Ethernet controller: Intel Corporation Ethernet Virtual Function 700 Series (rev 02)
88:0a.0 Ethernet controller: Intel Corporation Ethernet Virtual Function 700 Series (rev 02)
88:0a.1 Ethernet controller: Intel Corporation Ethernet Virtual Function 700 Series (rev 02)
88:0a.2 Ethernet controller: Intel Corporation Ethernet Virtual Function 700 Series (rev 02)
```

9. Example where O-DU and O-RU simulation run on the same system:

O-DU:

```
cat ./run_o_du.sh
#! /bin/bash

ulimit -c unlimited
echo 1 > /proc/sys/kernel/core_uses_pid

./build/sample-app --usecasefile ./usecase/cat_b/mul_100mhz/301/usecase_du.cfg --num_eth_vfs 6 \
    --vf_addr_o_xu_a "0000:88:02.0,0000:88:0a.0" \
    --vf_addr_o_xu_b "0000:88:02.1,0000:88:0a.1" \
    --vf_addr_o_xu_c "0000:88:02.2,0000:88:0a.2"
```

O-RU:

```
cat ./run_o_ru.sh
#! /bin/bash
ulimit -c unlimited
echo 1 > /proc/sys/kernel/core_uses_pid

./build/sample-app --usecasefile ./usecase/cat_b/mu1_100mhz/301/usecase_ru.cfg --num_eth_vfs 6 \
    --vf_addr_o_xu_a "0000:86:02.0,0000:86:0a.0" \
    --vf_addr_o_xu_b "0000:86:02.1,0000:86:0a.1" \
    --vf addr o xu c "0000:86:02.2,0000:86:0a.2"
```

A.4 Install and Configure Sample Application

To install and configure the sample application:

1. Set up the environment:

```
For Skylake and Cascadelake
export GTEST ROOT=`pwd`/gtest-1.7.0
export RTE SDK=`pwd`/dpdk-20.11
export RTE_TARGET=x86_64-native-linuxapp-icc
export DIR_WIRELESS_SDK_ROOT=`pwd`/wireless_sdk
export WIRELESS_SDK_TARGET_ISA=avx512
export SDK BUILD=build-${WIRELESS SDK TARGET ISA}-icc
export DIR WIRELESS SDK=${DIR WIRELESS SDK ROOT}/${SDK BUILD}
export MLOG DIR=`pwd`/flexran 11 sw/libs/mlog
export XRAN DIR=`pwd`/flexran xran
for Icelake
export GTEST ROOT=`pwd`/gtest-1.7.0
export RTE SDK=`pwd`/dpdk-20.11
export RTE TARGET=x86 64-native-linuxapp-icc
export DIR_WIRELESS_SDK_ROOT=`pwd`/wireless_sdk
export WIRELESS SDK TARGET ISA=snc
export SDK_BUILD=build-${WIRELESS_SDK_TARGET_ISA}-icc
export DIR WIRELESS SDK=${DIR WIRELESS SDK ROOT}/${SDK BUILD}
export MLOG_DIR=`pwd`/flexran_l1_sw/libs/mlog
export XRAN DIR=`pwd`/flexran xran
```

export FLEXRAN_SDK=\${DIR_WIRELESS_SDK}/install Compile mlog library:



```
[turner@xran home]$ cd $MLOG_DIR
[turner@xran xran]$ ./build.sh
```

3. Compile xRAN library and test the application:

```
[turner@xran home] cd $XRAN_DIR [turner@xran xran] choild.sh
```

4. Configure the sample app.

```
IQ samples can be generated using Octave* and script libs/xran/app/gen_test.m. (CentOS* has octave-3.8.2-20.e17.x86 64 compatible with get test.m)
```

Other IQ sample test vectors can be used as well. The format of IQ samples is binary int16_t I and Q for N slots of the OTA RF signal. For example, for mmWave, it corresponds to 792RE*2*14symbol*8slots*10~ms=3548160 bytes per antenna. Refer to comments in gen_test.m to correctly specify the configuration for IQ test vector generation.

Update usecase du.dat (or usecase ru.cfg) with a suitable configuration for your scenario.

Update config_file_o_du.dat (or config_file_o_ru.dat) with a suitable configuration for your scenario.

Update $run_o_du.sh$ ($run_o_ru.sh$) with PCIe bus address of VF0 and VF1 used for U-plane and C-plane correspondingly.

5. Run the application using run_o_du.sh (run_o_ru.sh).

A.4.1 Install and Configure FlexRAN 5G NR L1 Application

The 5G NR layer 1 application can be used for executing the scenario for mmWave with either the RU sample application or just the O-DU side. The current release supports the constant configuration of the slot pattern and RB allocation on the PHY side. The build process follows the same basic steps as for the sample application above and is similar to compiling 5G NR l1app for mmWave with Front Haul FPGA. Please follow the general build process in the FlexRAN 5G NR Reference Solution L1 User Guide (refer to Table 2.)

- 1. xRAN library is enabled by default l1 application:
- 2. Build the 5G NR L1 application using the command:

```
./flexran_build.sh -r 5gnr_mmw -i avx512 -m sdk -m fb -m mlog -m wls -m 5gnr llapp mmw -m xran -m 5gnr testmac
```

3. Configure the L1app using bin/nr5g/gnb/l1/phycfg_xran.xml and xrancfg_sub6.xml (or other xml if it is mmwaye or massive MIMO).



```
<PciBusAddoRu1Vf0>0000:51:01.4</PciBusAddoRu1Vf0>
   <PciBusAddoRu1Vf1>0000:51:01.5</PciBusAddoRu1Vf1>
   <PciBusAddoRu1Vf2>0000:51:01.6</PciBusAddoRu1Vf2>
   <!-- O-RU 2 -->
   <PciBusAddoRu2Vf0>0000:51:02.0</PciBusAddoRu2Vf0>
   <PciBusAddoRu2Vf1>0000:51:02.1</PciBusAddoRu2Vf1>
   <PciBusAddoRu2Vf2>0000:51:02.2</PciBusAddoRu2Vf2>
   <PciBusAddoRu2Vf3>0000:51:02.3</PciBusAddoRu2Vf3>
   <!-- O-RU 4 -->
   <PciBusAddoRu3Vf0>0000:00:00.0</PciBusAddoRu3Vf0>
   <PciBusAddoRu3Vf1>0000:00:00.0</PciBusAddoRu3Vf1>
   <PciBusAddoRu3Vf2>0000:00:00.0</PciBusAddoRu3Vf2>
   <PciBusAddoRu3Vf3>0000:00:00.0</PciBusAddoRu3Vf3>
   <!-- remote O-RU 0 Eth Link 0 VF0, VF1-->
   <oRuRem0Mac0>00:11:22:33:00:01<oRuRem0Mac0>
   <oRuRem0Mac1>00:11:22:33:00:11<oRuRem0Mac1>
   <!-- remote O-RU 0 Eth Link 1 VF2, VF3 -->
   <oRuRem0Mac2>00:11:22:33:00:21<oRuRem0Mac2>
   <oRuRem0Mac3>00:11:22:33:00:31<oRuRem0Mac3>
   <!-- remote O-RU 1 Eth Link 0 VF4, VF5-->
   <oRuRem1Mac0>00:11:22:33:01:01<oRuRem1Mac0>
   <oRuRem1Mac1>00:11:22:33:01:11<oRuRem1Mac1>
   <!-- remote O-RU 1 Eth Link 1 VF6, VF7 -->
   <oRuRem1Mac2>00:11:22:33:01:21<oRuRem1Mac2>
   <!-- remote O-RU 2 Eth Link 0 VF8, VF9 -->
   <oRuRem2Mac0>00:11:22:33:02:01<oRuRem2Mac0>
   <oRuRem2Mac1>00:11:22:33:02:11<oRuRem2Mac1>
   <!-- remote O-RU 2 Eth Link 1 VF10, VF11-->
   <oRuRem2Mac2>00:11:22:33:02:21<oRuRem2Mac2>
   <!-- remote O-RU 2 Eth Link 0 VF12, VF13 -->
   <oRuRem3Mac0>00:11:22:33:03:01<oRuRem3Mac0>
   <oRuRem3Mac1>00:11:22:33:03:11<oRuRem3Mac1>
   <!-- remote O-RU 2 Eth Link 1 VF14, VF15-->
   <oRuRem3Mac2>00:11:22:33:03:21<oRuRem3Mac2>
   <!-- Number of cells (CCs) running on this O-RU [1 - Cell , 2 - Cells, 3 -
Cells , 4 - Cells ] -->
   <oRu0NumCc>1</oRu0NumCc>
   <!-- First Phy instance ID mapped to this O-RU CCO -->
   <oRu0Cc0PhyId>0</oRu0Cc0PhyId>
   <!-- Second Phy instance ID mapped to this O-RU CC1 -->
   <oRu0Cc1PhyId>1</oRu0Cc1PhyId>
   <!-- Third Phy instance ID mapped to this O-RU CC2 -->
   <oRu0Cc2PhyId>2</oRu0Cc2PhyId>
   <!-- Forth Phy instance ID mapped to this O-RU CC3 -->
   <oRu0Cc3PhyId>3</oRu0Cc3PhyId>
        <!-- First Phy instance ID mapped to this O-RU CCO -->
   <oRu0Cc4PhyId>4</oRu0Cc4PhyId>
   <!-- Second Phy instance ID mapped to this O-RU CC1 -->
   <oRu0Cc5PhyId>5</oRu0Cc5PhyId>
   <!-- Third Phy instance ID mapped to this O-RU CC2 -->
   <oRu0Cc6PhyId>6</oRu0Cc6PhyId>
```



```
<!-- Forth Phy instance ID mapped to this O-RU CC3 -->
   <oRu0Cc7PhyId>7</oRu0Cc7PhyId>
   <!-- First Phy instance ID mapped to this O-RU CCO -->
   <oRu0Cc8PhyId>8</oRu0Cc8PhyId>
   <!-- Second Phy instance ID mapped to this O-RU CC1 -->
   <oRu0Cc9PhyId>9</oRu0Cc9PhyId>
   <!-- Third Phy instance ID mapped to this O-RU CC2 -->
   <oRu0Cc10PhyId>10</oRuCc10PhyId>
    <!-- Forth Phy instance ID mapped to this O-RU CC3 -->
    <oRu0Cc11PhyId>11</oRu0Cc11PhyId>
   <!-- Number of cells (CCs) running on this O-RU [1 - Cell , 2 - Cells, 3 -
Cells , 4 - Cells ] -->
   <oRu1NumCc>1</oRu1NumCc>
   <!-- First Phy instance ID mapped to this O-RU CCO -->
   <oRu1Cc0PhyId>1</oRu1Cc0PhyId>
   <!-- Second Phy instance ID mapped to this O-RU CC1 -->
   <oRu1Cc1PhyId>1</oRu1Cc1PhyId>
   <!-- Third Phy instance ID mapped to this O-RU CC2 -->
   <oRu1Cc2PhyId>2</oRu1Cc2PhyId>
   <!-- Forth Phy instance ID mapped to this O-RU CC3 -->
   <oRu1Cc3PhyId>3</oRu1Cc3PhyId>
   <!-- Number of cells (CCs) running on this O-RU [1 - Cell , 2 - Cells, 3 -
Cells , 4 - Cells ] -->
    <oRu2NumCc>1</oRu2NumCc>
   <!-- First Phy instance ID mapped to this O-RU CCO -->
   <oRu2Cc0PhyId>2</oRu2Cc0PhyId>
   <!-- Second Phy instance ID mapped to this O-RU CC1 -->
   <oRu2Cc1PhyId>1</oRu2Cc1PhyId>
   <!-- Third Phy instance ID mapped to this O-RU CC2 -->
   <oRu2Cc2PhyId>2</oRu2Cc2PhyId>
   <!-- Forth Phy instance ID mapped to this O-RU CC3 -->
   <oRu2Cc3PhyId>3</oRu2Cc3PhyId>
   <!-- XRAN Thread (core where the XRAN polling function is pinned: Core, priority,
<!-- core mask for XRAN Packets Worker (core where the XRAN packet processing is
pinned): Core, priority, Policy [0: SCHED FIFO 1: SCHED RR] -->
   <xRANWorker>0x0, 96, 0</xRANWorker>
   <!-- XRAN: Category of O-RU 0 - Category A, 1 - Category B -->
   <Category>0</Category>
   <!-- XRAN: enable sleep on PMD cores -->
   <xranPmdSleep>0</xranPmdSleep>
   <!-- RU Settings -->
   <Tadv_cp_dl>25</Tadv_cp_dl>
   <!-- Reception Window C-plane DL-->
   <T2a min cp dl>50</T2a min cp dl>
   <T2a max cp dl>140</T2a max cp dl>
   <!-- Reception Window C-plane UL-->
   <T2a min cp ul>50</T2a min cp ul>
   <T2a max cp ul>140</T2a max cp ul>
   <!-- Reception Window U-plane -->
   <T2a min up>25</T2a min up>
   <T2a max up>140</T2a max up>
    <!-- Transmission Window U-plane -->
    <Ta3 min>20</Ta3 min>
```



```
<Ta3 max>32</Ta3 max>
   <!-- O-DU Settings -->
   <!-- MTU size -->
   <MTU>9600</MTU>
   <!-- VLAN Tag used for C-Plane -->
   <c_plane_vlan_tag>1</c_plane_vlan_tag>
   <u plane vlan tag>2</u plane vlan tag>
   <!-- Transmission Window Fast C-plane DL -->
   <Tla min cp dl>70</Tla min cp dl>
   <Tla max cp dl>100</Tla max cp dl>
   <!-- Transmission Window Fast C-plane UL -->
   <Tla min cp ul>60</Tla min cp ul>
   <Tla max cp ul>70</Tla max cp ul>
   <!-- Transmission Window U-plane -->
   <Tla min up>35</Tla min up>
   <Tla max up>50</Tla max up>
   <!-- Reception Window U-Plane-->
   <Ta4 min>0</Ta4 min>
   <Ta4 max>45</Ta4 max>
   <!-- Enable Control Plane -->
   <EnableCp>1</EnableCp>
   <DynamicSectionEna>0</DynamicSectionEna>
   <!-- Enable Dynamic section allocation for UL -->
   <DynamicSectionEnaUL>0
    <xRANSFNWrap>0</xRANSFNWrap>
    <!-- Total Number of DL PRBs per symbol (starting from RB 0) that is transmitted
(used for testing. If 0, then value is used from PHY CONFIG API) -->
   <xRANNumDLPRBs>0</xRANNumDLPRBs>
   <!-- Total Number of UL PRBs per symbol (starting from RB 0) that is received
(used for testing. If 0, then value is used from PHY CONFIG API) -->
    <xRANNumULPRBs>0</xRANNumULPRBs>
   <!-- refer to alpha as defined in section 9.7.2 of O-RAN spec. this value should
be alpha*(1/1.2288ns), range 0 - 1e7 (ns) -->
   <Gps_Alpha>0</Gps_Alpha>
   <!-- beta value as defined in section 9.7.2 of ORAN spec. range -32767 \sim +32767 -
   <Gps Beta>0</Gps Beta>
   <!-- XRAN: Compression mode on O-DU <-> O-RU 0 - no comp 1 - BFP -->
   <xranCompMethod>0</xranCompMethod>
   <oRu0nPrbElemDl>1</oRu0nPrbElemDl>
   <!--nRBStart, nRBSize, nStartSymb, numSymb, nBeamIndex, bf weight update,
compMethod, iqWidth, BeamFormingType, Scalefactor, REMask -->
   <!-- weight base beams -->
   <oRu0PrbElemDl0>0,48,0,14,1,1,1,9,1,0,0</oRu0PrbElemDl0>
   <oRu0PrbElemDl1>48,48,0,14,2,1,1,9,1,0,0</oRu0PrbElemDl1>
   <oRu0PrbElemD12>96,48,0,14,3,1,1,9,1,0,0</oRu0PrbElemD12>
    <oRu0PrbElemDl3>144,48,0,14,4,1,1,9,1,0,0</oRu0PrbElemDl3>
    <oRu0PrbElemD14>144,36,0,14,5,1,1,9,1,0,0</oRu0PrbElemD14>
    <oRu0PrbElemDl5>180,36,0,14,6,1,1,9,1,0,0</oRu0PrbElemDl5>
    <oRu0PrbElemDl6>216,36,0,14,7,1,1,9,1,0,0</oRu0PrbElemDl6>
    <oRu0PrbElemD17>252,21,0,14,8,1,1,9,1,0,0</oRu0PrbElemD17>
    <oRu0nPrbElemUl>1</nPrbElemUl>
    <!--nRBStart, nRBSize, nStartSymb, numSymb, nBeamIndex, bf weight update,
compMethod, iqWidth, BeamFormingType, Scalefactor, REMask -->
    <!-- weight base beams -->
    <oRu0PrbElemUl0>0,48,0,14,1,1,1,9,1,0,0</oRu0PrbElemUl0>
```



4. Modify bin/nr5g/gnb/l1/dpdk.sh (change PCIe addresses from VFs).

```
$RTE_SDK/usertools/dpdk-devbind.py --bind=vfio-pci 0000:21:02.0
$RTE_SDK/usertools/dpdk-devbind.py --bind=vfio-pci 0000:21:02.1
```

5. Use configuration of test mac per:

```
/bin/nr5g/gnb.testmac/cascade_lake-sp/csxsp_mu1_100mhz_mmimo_hton_xran.cfg
phystart 4 0 40200
<!-- mmWave mu 3 100MHz -->
TEST FD, 1002, 1, fd/mu3 100mhz/2/fd testconfig tst2.cfg
```

6. To execute l1app with O-DU functionality according to O-RAN Fronthaul specification, enter:

```
[root@xran flexran] cd ./bin/nr5g/gnb/l1
[root@xran l1]#./l1.sh -xran
where output corresponding L1 is:
[root@sc12-xran-sub6 l1]# ./l1.sh -xranmmw
Radio mode with XRAN - mmWave 100Mhz
DPDK WLS MODE
kernel.sched_rt_runtime_us = -1
kernel.shmmax = 2147483648
kernel.shmall = 2147483648
Note: Forwarding request to 'systemctl disable irqbalance.service'.
using configuration file phycfg_xran_mmw.xml
>> Running... ./llapp table 0 1 --cfgfile=phycfg xran mmw.xml
FlexRAN SDK bblib_layerdemapping_5gnr version #DIRTY#
FlexRAN SDK bblib layermapping 5gnr version #DIRTY#
FlexRAN SDK bblib cestimate 5gnr version #DIRTY#
FlexRAN SDK bblib pucch cestimate 5qnr version #DIRTY#
FlexRAN SDK bblib llr demapping version #DIRTY#
FlexRAN SDK bblib pdcch remapping 5gnr version version #DIRTY#
FlexRAN SDK bblib reed muller version #DIRTY#
FlexRAN SDK bblib_lte modulation version #DIRTY#
FlexRAN SDK bblib_polar_decoder_5gnr version #DIRTY#
FlexRAN SDK bblib_polar_rate_dematching_5gnr version #DIRTY#
FlexRAN SDK bblib PhaseNoise 5G version #DIRTY#
FlexRAN SDK bblib mimo mmse detection 5gnr version #DIRTY#
FlexRAN SDK bblib_fd_correlation version #DIRTY# FlexRAN SDK bblib_scramble_5gnr version #DIRTY#
FlexRAN SDK bblib pucch equ 5gnr version #DIRTY#
FlexRAN SDK bblib ta compensation version 5gnr #DIRTY#
FlexRAN SDK bblib polar encoder 5gnr version #DIRTY#
FlexRAN SDK bblib prach 5gnr version #DIRTY#
FlexRAN SDK bblib fft ifft version #DIRTY#
FlexRAN SDK bblib pucch 5gnr version #DIRTY#
FlexRAN SDK bblib common version #DIRTY#
FlexRAN SDK bblib_lte_crc version #DIRTY#
FlexRAN SDK bblib lte dft idft version #DIRTY#
FlexRAN SDK bblib_irc_rnn_calculation_5gnr_version #DIRTY#
FlexRAN SDK bblib_mmse_irc_mimo_5gnr_version #DIRTY#
FlexRAN SDK bblib_srs_cestimate_5gnr version #DIRTY# FlexRAN SDK bblib_zf_matrix_gen version #DIRTY#
FlexRAN SDK bblib beamforming dl expand version #DIRTY#
_____
```



```
5GNR PHY Application
PhyCfg.xml Version: 20.04
--version=20.04
 --successiveNoApi=15
 --wls dev name=wls0
 --wlsMemorySize=0x3F600000
--dlIqLog=0
--ullqLoq=0
--iqLogDumpToFile=0x0
--phyMlog=1
--phyStats=1
--dpdkMemorySize=8192
--dpdkIovaMode=0
--dpdkBasebandFecMode=1
--dpdkBasebandDevice=0000:1f:00.1
 --radioEnable=4
 --ferryBridgeMode=1
 --ferryBridgeEthPort=1
 --ferryBridgeSyncPorts=0
 --ferryBridgeOptCableLoopback=0
 --radioCfg0PCIeEthDev=0000:19:00.0
 --radioCfg0DpdkRx=1
 --radioCfg0DpdkTx=2
 --radioCfg0TxAnt=2
 --radioCfg0RxAnt=2
 --radioCfg0RxAgc=0
 --radioCfg0NumCell=1
 --radioCfq0Cell0PhyId=0
 --radioCfg0Cell1PhyId=1
--radioCfg0Cell2PhyId=2
--radioCfg0Cell3PhyId=3
--radioCfg0Cell4PhyId=4
 --radioCfg0Cell5PhyId=5
 --radioCfg0riuMac=11:22:33:44:55:66
 --radioCfg1PCIeEthDev=0000:03:00.1
 --radioCfg1DpdkRx=1
--radioCfg1DpdkTx=1
--radioCfg1TxAnt=4
--radioCfg1RxAnt=4
 --radioCfg1RxAgc=0
--radioCfg1NumCell=1
--radioCfg1Cell0PhyId=2
--radioCfg1Cell1PhyId=3
--radioCfg1Cell2PhyId=2
 --radioCfg1Cell3PhyId=3
 --radioCfg1riuMac=ac:1f:6b:2c:9f:07
 --radioCfg2PCIeEthDev=0000:05:00.0
 --radioCfg2DpdkRx=10
 --radioCfg2DpdkTx=11
 --radioCfg2TxAnt=4
 --radioCfg2RxAnt=4
 --radioCfg2RxAgc=0
 --radioCfg2NumCell=2
 --radioCfg2Cell0PhyId=4
 --radioCfg2Cell1PhyId=5
 --radioCfg2Cell2PhyId=2
 --radioCfg2Cell3PhyId=3
 --radioCfg2riuMac=ac:1f:6b:2c:9f:07
 --radioCfg3PCIeEthDev=0000:05:00.1
```



```
--radioCfg3DpdkRx=12
--radioCfg3DpdkTx=13
--radioCfg3TxAnt=4
--radioCfg3RxAnt=4
--radioCfg3RxAgc=0
--radioCfg3NumCell=2
--radioCfg3Cell0PhyId=6
--radioCfg3Cell1PhyId=7
--radioCfg3Cell2PhyId=2
--radioCfg3Cell3PhyId=3
--radioCfg3riuMac=ac:1f:6b:2c:9f:07
--radioCfg4PCIeEthDev=0000:00:08.0
--radioCfg4DpdkRx=14
--radioCfg4DpdkTx=15
--radioCfg4TxAnt=4
--radioCfg4RxAnt=4
--radioCfg4RxAgc=0
--radioCfg4NumCell=2
--radioCfg4Cell0PhyId=8
--radioCfg4Cell1PhyId=9
--radioCfg4Cell2PhyId=2
--radioCfg4Cell3PhyId=3
--radioCfg4riuMac=ac:1f:6b:2c:9f:07
--radioCfg5PCIeEthDev=0000:08:00.0
--radioCfg5DpdkRx=16
--radioCfg5DpdkTx=16
--radioCfg5TxAnt=4
--radioCfg5RxAnt=4
--radioCfg5RxAgc=0
--radioCfg5NumCell=2
--radioCfq5Cell0PhyId=10
--radioCfg5Cell1PhyId=11
--radioCfg5Cell2PhyId=2
--radioCfg5Cell3PhyId=3
--radioCfg5riuMac=ac:1f:6b:2c:9f:07
--radioCfg6PCIeEthDev=0000:00:05.0
--radioCfg6DpdkRx=16
--radioCfq6DpdkTx=16
--radioCfg6TxAnt=4
--radioCfg6RxAnt=4
--radioCfg1RxAgc=0
--radioCfg6NumCell=2
--radioCfg6Cell0PhyId=12
--radioCfg6Cell1PhvId=13
--radioCfg6Cell2PhyId=2
--radioCfg6Cell3PhyId=3
--radioCfg6riuMac=ac:1f:6b:2c:9f:07
--radioCfg7PCIeEthDev=0000:00:06.0
--radioCfg7DpdkRx=16
--radioCfg7DpdkTx=16
--radioCfg7TxAnt=4
--radioCfg7RxAnt=4
--radioCfg7RxAgc=0
--radioCfg7NumCell=2
--radioCfg7Cell0PhyId=14
--radioCfg7Cell1PhyId=15
--radioCfg7Cell2PhyId=2
--radioCfq7Cell3PhyId=3
--radioCfg7riuMac=ac:1f:6b:2c:9f:07
--radioPort0=0
--radioPort1=1
--radioPort2=2
```



```
--radioPort3=3
--radioPort4=4
--radioPort5=5
--radioPort6=6
--radioPort7=7
--PdschSymbolSplit=0
--PdschDlWeightSplit=0
--FecEncSplit=4
--PuschChanEstSplit=0
--PuschMmseSplit=0
--PuschLlrRxSplit=0
--PuschUlWeightSplit=0
--FecDecEarlyTermDisable=0
--FecDecNumIter=0
--FecDecSplit=4
--llrOutDecimalDigit=2
--IrcEnableThreshold=-10
--CEInterpMethod=0
--PucchSplit=0
--SrsCeSplit=0
--prachDetectThreshold=10000
--MlogSubframes=128
--MlogCores=20
--MlogSize=3084
--systemThread=0, 0, 0
--timerThread=0, 96, 0
--xRANThread=4, 96, 0
--xRANWorker=0x0, 96, 0
--FpgaDriverCpuInfo=2, 96, 0
--FrontHaulCpuInfo=3, 96, 0
--radioDpdkMaster=2, 99, 0
--BbuPoolSleepEnable=1
--BbuPoolThreadCorePriority=94
--BbuPoolThreadCorePolicy=0
--BbuPoolThreadDefault_0_63=0x68
--BbuPoolThreadDefault_64_127=0x0
--BbuPoolThreadSrs_0_63=0x0
--BbuPoolThreadSrs_64_127=0x0
--BbuPoolThreadDlbeam 0 63=0x0
--BbuPoolThreadDlbeam 64 127=0x0
--BbuPoolThreadUrllc=8
--FrontHaulTimeAdvance=9450
--nEthPorts=459523
--nPhaseCompFlag=1
--nFecFpgaVersionMu3=0xFC101800
--nFecFpgaVersionMu0 1=0x0319d420
--nFhFpgaVersionMu3=0x8001000F
--nFhFpgaVersionMu0 1=0x90010008
--dpdkXranDeviceCP=0000:21:02.1
--dpdkXranDeviceUP=0000:21:02.0
--DuMac=00:11:22:33:44:66
--RuMac=00:11:22:33:44:55
--Category=0
--xranPmdSleep=0
-- Tadv cp d1=25
--T2a min cp dl=50
--T2a max cp dl=140
--T2a min cp ul=50
--T2a max cp ul=140
--T2a min up=25
--T2a max up=140
--Ta3 min=20
```



```
--Ta3 max=32
 --MTU=9600
 --c plane vlan tag=1
 --u plane vlan tag=2
 --T1a_min_cp_dl=70
 --T1a_max_cp_dl=100
 --Tla_min_cp_ul=60
 --T1a_max_cp_ul=70
--T1a_min_up=35
--T1a_max_up=50
--Ta4 min=0
--Ta4 max=45
--DynamicSectionEna=0
--xRANSFNWrap=0
--xRANNumDLPRBs=0
--xRANNumULPRBs=0
--Gps Alpha=0
--Gps Beta=0
 --xranCompMethod=0
 --nPrbElemDl=0
 --PrbElemDl0=0,48,0,14,1,1,1,9,1
 --PrbElemDl1=48,48,0,14,2,1,1,9,1
 --PrbElemDl2=96,48,0,14,3,1,1,9,1
 --PrbElemDl3=144,48,0,14,4,1,1,9,1
 --PrbElemD14=144,36,0,14,5,1,1,9,1
 --PrbElemDl5=180,36,0,14,6,1,1,9,1
--PrbElemD16=216,36,0,14,7,1,1,9,1
 --PrbElemD17=252,21,0,14,8,1,1,9,1
 --nPrbElemUl=0
 --PrbElemUl0=0,48,0,14,1,1,1,9,1
--PrbElemUl1=48,48,0,14,2,1,1,9,1
--PrbElemU12=72,36,0,14,3,1,1,9,1
--PrbElemUl3=108,36,0,14,4,1,1,9,1
--PrbElemUl4=144,36,0,14,5,1,1,9,1
--PrbElemUl5=180,36,0,14,6,1,1,9,1
 --PrbElemU16=216,36,0,14,7,1,1,9,1
 --PrbElemUl7=252,21,0,14,8,1,1,9,1
 --StreamStats=0
 --StreamIp=127.0.0.1
--StreamPort=2000
wls dev filename: wls0
phycfg apply: Initialize Radio Interface with XRAN library
Setting FecEncSplit to 1 to run on HW accelerator
Setting FecDecSplit to 1 to run on HW accelerator
timer set tsc freq from clock: System clock (rdtsc) resolution 1596249953 [Hz]
                               Ticks per usec 1596
MLogOpen: filename(l1mlog.bin) mlogSubframes (128), mlogCores(20), mlogSize(3084)
mlog mask (-1)
    mlogSubframes (128), mlogCores(20), mlogSize(3084)
    localMLogTimerInit
        System clock (rdtsc) resolution 1596250020 [Hz]
        Ticks per us 1596
    MLog Storage: 0x7f6e5b0e3100 -> 0x7f6e5b86b52c [ 7898156 bytes ]
    localMLogFreqReg: 1596. Storing: 1596
    Mlog Open successful
di xran init
di xran cfg setup successful
xran init: MTU 9600
BBDEV FEC ACCL NR5G
```



```
hw-accelerated bbdev 0000:1f:00.1
total cores 40 c mask 0x14 core 4 [id] system core 2 [id] pkt proc core 0x0 [mask]
pkt aux core 0 [id] timing core 4 [id]
xran_ethdi_init_dpdk_io: Calling rte_eal_init:wls0 -c 0x14 -n2 --iova-mode=pa --
socket-mem=8192 --socket-limit=8192 --proc-type=auto --file-prefix wls0 -w
0000:00:00.0 -w 0000:1f:00.1
EAL: Detected 40 lcore(s)
EAL: Detected 1 NUMA nodes
EAL: Auto-detected process type: PRIMARY
EAL: Multi-process socket /var/run/dpdk/wls0/mp socket
EAL: Selected IOVA mode 'PA'
EAL: No available hugepages reported in hugepages-2048kB
EAL: Probing VFIO support...
EAL: VFIO support initialized
EAL: PCI device 0000:1f:00.1 on NUMA socket 0
EAL: probe driver: 8086:d90 intel fpga 5gnr fec vf
EAL: using IOMMU type 1 (Type 1)
EAL: PCI device 0000:21:02.0 on NUMA socket 0
EAL: probe driver: 8086:154c net_i40e_vf
initializing port 0 for TX, drv=net_i40e_vf
Port 0 MAC: 00 11 22 33 44 66
Port 0: nb rxd 4096 nb txd 4096
Checking link status portid [0] EAL: PCI device 0000:21:02.1 on NUMA socket 0
EAL: probe driver: 8086:154c net i40e vf
initializing port 1 for TX, drv=net_i40e_vf
Port 1 MAC: 00 11 22 33 44 66
Port 1: nb rxd 4096 nb txd 4096
Checking link status portid [1] vf 0 local SRC MAC: 00 11 22 33 44 66
vf 0 remote DST MAC: 00 11 22 33 44 55
vf 1 local SRC MAC: 00 11 22 33 44 66
vf 1 remote DST MAC: 00 11 22 33 44 55
xran_init successful, pHandle = 0x5581f440
bbdev init:
Socket ID: 0
FEC is accelerated through BBDEV: 0000:1f:00.1
wls_layer_init[wls0] nWlsMemorySize[1063256064]
wls_lib: Open wls0 (DPDK memzone)
    lib: WLS Open 0x2bf600000
wls_lib: link: 0 <-> 1 wls_lib: Mode 0
wls lib: WLS shared management memzone: wls0
wls lib: hugePageSize on the system is 1073741824
wls lib: WLS Alloc [1063256064] bytes
PHY VERSION
Version: #DIRTY#
IMG-date: Apr 27 2020
IMG-time: 12:54:54
FlexRAN BBU pooling version #DIRTY#
FlexRAN SDK bblib layerdemapping 5gnr version #DIRTY#
FlexRAN SDK bblib layermapping 5gnr version #DIRTY#
```



```
FlexRAN SDK bblib cestimate 5qnr version #DIRTY#
FlexRAN SDK bblib pucch cestimate 5gnr version #DIRTY#
FlexRAN SDK bblib llr demapping version #DIRTY#
FlexRAN SDK bblib_pdcch_remapping_5gnr_version version #DIRTY#
FlexRAN SDK bblib_reed_muller version #DIRTY#
FlexRAN SDK bblib_lte_modulation version #DIRTY#
FlexRAN SDK bblib_polar_decoder_5gnr version #DIRTY#
FlexRAN SDK bblib_polar_rate_dematching_5gnr version #DIRTY#
FlexRAN SDK bblib PhaseNoise 5G version #DIRTY#
FlexRAN SDK bblib_mimo_mmse_detection_5gnr version #DIRTY# FlexRAN SDK bblib_fd_correlation version #DIRTY#
FlexRAN SDK bblib scramble 5gnr version #DIRTY#
FlexRAN SDK bblib pucch equ 5gnr version #DIRTY#
FlexRAN SDK bblib ta compensation version 5gnr #DIRTY#
FlexRAN SDK bblib polar encoder 5gnr version #DIRTY#
FlexRAN SDK bblib prach 5gnr version #DIRTY#
FlexRAN SDK bblib fft ifft version #DIRTY#
FlexRAN SDK bblib pucch 5gnr version #DIRTY#
FlexRAN SDK bblib lte crc version #DIRTY#
FlexRAN SDK bblib_common version #DIRTY#
Non BBU threads in application
nr5g gnb phy2mac api proc stats thread: [PID: 112583] binding on [CPU 0] [PRIO: 0]
[POLICY: 1]
                                            [PID: 112587] binding on [CPU 0]
wls rx handler (non-rt):
PHY>welcome to application console
PHY>Received MSG_TYPE_PHY_UL_IQ_SAMPLES
Processing MSG_TYPE_PHY_UL_IQ_SAMPLES: 0
phydi_read_write_iq_samples: direction[1] nNumerologyMult[8] fftSize[1024, 11088,
SRS: 792] numSubframe[80] numAntenna[2] numPorts[2] nIsRadioMode[1] carrNum[0]
TimerModeFreqDomain[1] PhaseCompensationEnable[0]
filename in ul iq[/home/turner/xran/master/npg wireless-
flexran 11 5g test/fd/mu3 100mhz/2/../../ul/mu3 100mhz/1/uliq00 tst1.bin]
filename in prach iq[]
Received MSG TYPE PHY CONFIG REQ: 0
Processing MSG TYPE PHY CONFIG REQ: 0
phy bbupool set config: Using cores: 0x00000000000008 for BBU Pool
nBbuPoolSleepEnable: 1
BBU Pooling: queueId = 0, the according nCoreNum = 3, the according cpuSetMask = 0x68
BBU Pooling: gCoreIdxMap[0] = 3 is available!
BBU Pooling: gCoreIdxMap[1] = 5 is available!
BBU Pooling: gCoreIdxMap[2] = 6 is available!
BBU Pooling: taskId = 0 taskName = DL_L1_CONFIG is registered
BBU Pooling: taskId = 1 taskName = DL_L1_PDSCH_TB is registered
BBU Pooling: taskId = 2 taskName = DL_L1_PDSCH_SCRAMBLER is registered
BBU Pooling: taskId = 3 taskName = DL_L1_PDSCH_SYMBOL_TX is registered
BBU Pooling: taskId = 4 taskName = DL_L1_PDSCH_RS_GEN is registered
BBU Pooling: taskId = 5 taskName = DL_L1_CONTROL_CHANNELS is registered
BBU Pooling: taskId = 6 taskName = UL L1 CONFIG is registered
BBU Pooling: taskId = 7 taskName = UL L1 PUSCH CE0 is registered
BBU Pooling: taskId = 8 taskName = UL L1 PUSCH CE7 is registered
BBU Pooling: taskId = 9 taskName = UL L1 PUSCH MMSE0 PRE is registered
BBU Pooling: taskId = 10 taskName = UL L1 PUSCH MMSE7 PRE is registered
BBU Pooling: taskId = 11 taskName = UL L1 PUSCH MMSEO is registered
```



```
BBU Pooling: taskId = 12 taskName = UL L1 PUSCH MMSE7 is registered
BBU Pooling: taskId = 13 taskName = UL L1 PUSCH LLR is registered
BBU Pooling: taskId = 14 taskName = UL L1 PUSCH DECODE is registered
BBU Pooling: taskId = 15 taskName = UL_L1_PUSCH_TB is registered
BBU Pooling: taskId = 16 taskName = UL_L1_PUCCH is registered BBU Pooling: taskId = 17 taskName = UL_L1_PRACH is registered BBU Pooling: taskId = 18 taskName = UL_L1_PRACH is registered BBU Pooling: taskId = 19 taskName = DL_L1_POST is registered BBU Pooling: taskId = 20 taskName = UL_L1_POST is registered
BBU Pooling: next taskList of DL_L1_CONFIG: DL_L1_PDSCH_TB
DL L1 PDSCH RS GEN DL L1 CONTROL CHANNELS
BBU Pooling: next taskList of DL L1 PDSCH TB:
                                                                           N/A
BBU Pooling: next taskList of DL L1 PDSCH SCRAMBLER: DL L1 PDSCH SYMBOL TX
BBU Pooling: next taskList of DL L1 PDSCH SYMBOL TX: DL L1 POST
BBU Pooling: next taskList of DL_L1_PDSCH_RS_GEN: DL_L1_PDSCH_SYMBOL_TX
BBU Pooling: next taskList of DL L1 CONTROL CHANNELS: DL L1 POST
BBU Pooling: next taskList of UL L1 CONFIG: UL L1 POST
BBU Pooling: next taskList of UL L1 PUSCH CEO: UL L1 PUSCH MMSEO
UL L1 PUSCH MMSE7
BBU Pooling: next taskList of UL_L1_PUSCH_CE7: UL_L1_PUSCH_MMSE7
BBU Pooling: next taskList of UL L1 PUSCH MMSEO PRE: UL L1 PUSCH MMSEO
UL L1 PUSCH MMSE7
BBU Pooling: next taskList of UL_L1_PUSCH_MMSE7_PRE: UL_L1_PUSCH_MMSE7
BBU Pooling: next taskList of UL_L1_PUSCH_MMSE0: UL_L1_PUSCH_LLR
BBU Pooling: next taskList of UL_L1_PUSCH_MMSE7: UL_L1_PUSCH_LLR
BBU Pooling: next taskList of UL LT PUSCH LLR: UL LT PUSCH DECODE
BBU Pooling: next taskList of UL L1 PUSCH DECODE:
BBU Pooling: next taskList of UL_L1_PUSCH_TB: UL_L1_POST
BBU Pooling: next taskList of UL_L1_PUCCH: UL_L1_POST
BBU Pooling: next taskList of UL_L1_PRACH: UL_L1_POST
BBU Pooling: next taskList of UL_L1_SRS: UL_L1_POST
BBU Pooling: next taskList of DL_L1_POST: N/A
BBU Pooling: next taskList of UL L1 POST:
                                                                           N/A
enter RtThread Launch
3 thread associated with queue 0:coreIdx 0 1 2
Leave RtThread Launch
launching Thread 0 Queue 0 uCoreIdx 0 CoreId 3 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
launching Thread 1 Queue 0 uCoreIdx 1 CoreId 5 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
launching Thread 2 Queue 0 uCoreIdx 2 CoreId 6 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
bbupool core main: the server's coreNum = 40, the nCore = 3,nRtCoreMask = 0x68, the
nFeIfCore = 0, nFeIfCoreMask = 0x0
bbupool core main pthread setaffinity np succeed: coreId = 0, result = 0
nr5g gnb mac2phy api proc print phy init [0]:
     nCarrierIdx:
     nDMRSTypeAPos: 2
     nPhyCellId: 100
     nDLAbsFrePointA: 27968160
     nULAbsFrePointA: 27968160
     nDLBandwidth: 100
     nULBandwidth: 100
     nDLFftSize: 1024
    nULFftSize: 1024
```



```
nSSBPwr: 0
    nSSBAbsFre: 0
    nSSBPeriod: 2
    nSSBSubcSpacing: 3
    nSSBSubcOffset: 0
    nSSBPrbOffset: 0
    nMIB[0]: 255
    nMIB[1]: 255
    nMIB[2]: 255
    nDLK0: 0
    nULK0: 0
    nSSBMask[0]: 63
    nSSBMask[1]: 0
    nNrOfTxAnt: 2
    nNrOfRxAnt: 2
    nNrOfDLPorts: 2
    nNrOfULPorts: 2
    nCarrierAggregationLevel: 0
    nFrameDuplexType: 1
    nSubcCommon: 3
    nTddPeriod: 5 (TDD)
    SlotConfig:
        Slot Sym 0 Sym 1 Sym 2 Sym 3 Sym 4 Sym 5 Sym 6 Sym 7 Sym 8 Sym 9 Sym10 Sym11
Sym12 Sym13
      DL
           1
                                   DL
                                                 DL
                                                       DL
                                                              DL
                                                                    DL
           4 UL UL
                            UL UL UL UL UL UL UL UL
                                                                                        UL
    nPrachConfIdx: 81
    nPrachSubcSpacing: 3
    nPrachZeroCorrConf: 2
    nPrachRestrictSet: 0
    nPrachRootSeqIdx: 0
    nPrachFreqStart: 0
    nPrachFdm: 1
   nPrachSsbRach: 0
   nPrachNrofRxRU: 2
   nCyclicPrefix: 0
    nGroupHopFlag: 0
    nSequenceHopFlag: 0
    nHoppingId: 0
read_table: File table/common/pss_table.bin of size 381 read_size: 381
read_table: File table/common/sss_table.bin of size 128016 read_size: 128016
read_table: File table/common/srs_zc_36_plus.bin of size 905916 read_size: 905916 read_table: File table/common/pucch_zc_36_plus.bin of size 383040 read_size: 383040 read_table: File table/common/srs_wiener_sinc_comb2.bin of size 81216 read_size:
81216
read table: File table/common/srs wiener sinc comb4.bin of size 81216 read size:
BBU Pooling Info: maximum period length was configured, preMaxSF = 8000, postMasSF =
set slot type SlotPattern:
               0 1 2
    Slot:
                DL DL DL SP UL
```



```
PHYDI-INIT[from 0] PhyInstance: 0
Global Variables:
                                    0
gCarrierAggLevel:
gCarrierAggLevelInit:
gSupportedAVX2
Received MSG TYPE PHY START REQ: 0
Processing MSG TYPE PHY START REQ: 0
xran max frame 99
XRAN UP VF: 0x0000
XRAN CP VF: 0x0001
xran timing source thread [CPU 4] [PID: 112582]
O-DU: thread run start time: 04/27/20 20:20:33.000000010 UTC [125]
Start C-plane DL 25 us after TTI [trigger on sym 3]
Start C-plane UL 55 us after TTI [trigger on sym 7]
Start U-plane DL 50 us before OTA [offset in sym -5]
Start U-plane UL 45 us OTA [offset in sym 6]
C-plane to U-plane delay 25 us after TTI
Start Sym timer 8928 ns
interval us 125
PHYDI-START[from 0] PhyInstance: 0, Mode: 4, Count: 100040207, Period: 0,
NumSlotPerSfn: 80
gnb start xran: gxRANStarted[0] CC 1 Ant 4 AntElm 0
XRAN front haul xran mm init
xran sector get instances [0]: CC 0 handle 0x7f6e397307c0
Handle: 0x1994ce00 Instance: 0x7f6e397307c0
gnb start xran [0]: CC 0 handle 0x7f6e397307c0
Sucess xran mm init Instance 0x7f6e397307c0
nSectorNum 1
ru 0 cc 0 idx 0: [ handle 0x7f6e397307c0 0 0 ] [nPoolIndex 0] nNumberOfBuffers 2240
nBufferSize 5856
CC:[ handle 0x7f6e397307c0 ru 0 cc_idx 0 ] [nPoolIndex 0] mb pool 0x2e817b900
ru 0 cc 0 idx 1: [ handle 0x7f6e397307c0 0 0 ] [nPoolIndex 1] nNumberOfBuffers 35840
nBufferSize 24
CC:[ handle 0x7f6e397307c0 ru 0 cc idx 0 ] [nPoolIndex 1] mb pool 0x2e7266c40
ru 0 cc 0 idx 2: [ handle 0x7f6e397307c0 0 0 ] [nPoolIndex 2] nNumberOfBuffers 2240
nBufferSize 48416
CC: [ handle 0x7f6e397307c0 ru 0 cc idx 0 ] [nPoolIndex 2] mb pool 0x2e5cb4600
ru 0 cc 0 idx 3: [ handle 0x7f6e397307c0 0 0 ] [nPoolIndex 3] nNumberOfBuffers 2240
nBufferSize 5856
CC:[ handle 0x7f6e397307c0 ru 0 cc idx 0 ] [nPoolIndex 3] mb pool 0x2df2872c0
ru 0 cc 0 idx 4: [ handle 0x7f6e397307c0 0 0 ] [nPoolIndex 4] nNumberOfBuffers 35840
nBufferSize 24
CC:[ handle 0x7f6e397307c0 ru 0 cc idx 0 ] [nPoolIndex 4] mb pool 0x2de372600
ru 0 cc 0 idx 5: [ handle 0x7f6e397307c0 0 0 ] [nPoolIndex 5] nNumberOfBuffers 2240
nBufferSize 48416
CC:[ handle 0x7f6e397307c0 ru 0 cc_idx 0 ] [nPoolIndex 5] mb pool 0x2dcdbffc0
ru 0 cc 0 idx 6: [ handle 0x7f6e397307c0 0 0 ] [nPoolIndex 6] nNumberOfBuffers 2240
nBufferSize 8192
CC:[ handle 0x7f6e397307c0 ru 0 cc idx 0 ] [nPoolIndex 6] mb pool 0x2d6392c80
gnb init xran cp
init xran successfully
mem mgr display size:
   Num Memory Alloc:
                                5,186
    Total Memory Size: 4,389,524,920
```



```
BBU Pooling: enter multicell Activate!

BBU Pooling Info: bbupool rt thread start on CoreIdx 2 coreId 6 at 547270377116554 at sf=0 with queue 0 successfully

BBU Pooling: active result: Q_id = 0, currenSf = 0, curCellNum = 0, activesfn = 4,

CellNumInActSfn = 1

BBU Pooling: multiCell Activate sucessfully!

BBU Pooling Info: bbupool rt thread start on CoreIdx 0 coreId 3 at 547270377104408 at sf=0 with queue 0 successfully

BBU Pooling Info: bbupool rt thread start on CoreIdx 1 coreId 5 at 547270377117634 at sf=0 with queue 0 successfully

phy_bbupool_rx_handler: PhyId[0] nSfIdx[4] frame,slot[0,5] gNumSlotPerSfn[80]

==== llapp Time: 5001 ms NumCarrier: 1 NumBbuCores: 3 rxPcktCnt: 93621 rachPcktCnt

46811 Total Proc Time: [ 62.00.. 98.39..209.00] usces====

==== [o-du][rx 619683 pps 123936 kbps 2621619][tx 1996407 pps 399281 kbps 9181862]

[on time 619683 early 0 late 0 corrupt 0 pkt dupl 16 Total 619683] IO Util: 79.61 %
```

7. To execute testmac with O-DU functionality according to O-RAN Fronthaul specification, enter:

[root@xran flexran] cd ./bin/nr5g/gnb/testmac

8. To execute test case type:

```
./12.sh --testfile=./cascade lake-sp/csxsp mul 100mhz mmimo hton xran.cfg
```

where output corresponding to Test MAC:

```
[root@sc12-xran-sub6 testmac]# ./12.sh --testfile=./cascade lake-
sp/csxsp_mu1_100mhz_mmimo_hton_xran.cfg
kernel.sched_rt_runtime_us = -1
kernel.shmmax = 2147483648
kernel.shmall = 2147483648
Note: Forwarding request to 'systemctl disable irgbalance.service'.
start 5GNR Test MAC
5GNR Testmac Application
testmac cfg set cfg filename: Coult not find string 'cfgfile' in command line. Using
default File: testmac cfg.xml
TestMacCfg.xml Version: 20.04
 --version=20.04
 --wls dev name=wls0
 --wlsMemorySize=0x3F600000
 --dpdkIovaMode=0
--PhyStartMode=1
--PhyStartPeriod=40
--PhyStartCount=0
--MlogSubframes=128
 --MlogCores=3
 --MlogSize=2048
 --wlsRxThread=1, 90, 0
--systemThread=0, 0, 0
 --runThread=0, 89, 0
 --urllcThread=19, 90, 0
wls dev filename: wls0
sys_reg_signal_handler:[err] signal handler in NULL
sys_reg_signal_handler:[err] signal handler in NULL
timer_set_tsc_freq_from_clock: System clock (rdtsc) resolution 1596245684 [Hz]
                                  Ticks per usec 1596
```



```
MLogOpen: filename(testmac-mlog.bin) mlogSubframes (128), mlogCores(3),
mlogSize(2048) mlog mask (-1)
    mlogSubframes (128), mlogCores(3), mlogSize(2048)
    localMLogTimerInit
        System clock (rdtsc) resolution 1596250375 [Hz]
        Ticks per us 1596
    MLog Storage: 0x7f84cae86100 -> 0x7f84caf46920 [ 788512 bytes ]
    localMLogFreqReq: 1596. Storing: 1596
    Mlog Open successful
Calling rte eal init: testmac -c1 --proc-type=auto --file-prefix wls0 --iova-mode=pa
EAL: Detected 40 lcore(s)
EAL: Detected 1 NUMA nodes
EAL: Auto-detected process type: SECONDARY
EAL: Multi-process socket /var/run/dpdk/wls0/mp socket 112640 1f1baf0a9b316
EAL: Selected IOVA mode 'PA'
EAL: Probing VFIO support...
EAL: VFIO support initialized
EAL: PCI device 0000:19:00.0 on NUMA socket 0
EAL: probe driver: 8086:d58 net i40e
EAL: PCI device 0000:19:00.1 on NUMA socket 0
EAL: probe driver: 8086:d58 net i40e
EAL: PCI device 0000:1d:00.0 on NUMA socket 0
EAL: probe driver: 8086:d58 net i40e
EAL: PCI device 0000:1d:00.1 on NUMA socket 0
      probe driver: 8086:d58 net i40e
EAL: PCI device 0000:21:00.0 on NUMA socket 0
EAL: probe driver: 8086:158b net i40e
EAL: PCI device 0000:21:00.1 on NUMA socket 0
EAL: probe driver: 8086:158b net i40e
EAL: PCI device 0000:21:02.0 on NUMA socket 0
EAL: probe driver: 8086:154c net i40e vf
EAL: using IOMMU type 1 (Type 1)
EAL: PCI device 0000:21:02.1 on NUMA socket 0
EAL: probe driver: 8086:154c net i40e vf
EAL: PCI device 0000:21:0a.0 on NUMA socket 0
EAL: probe driver: 8086:154c net_i40e_vf
      0000:21:0a.0 cannot find TAILQ entry for PCI device!
EAL: Requested device 0000:21:0a.0 cannot be used
EAL: PCI device 0000:21:0a.1 on NUMA socket 0
EAL: probe driver: 8086:154c net_i40e_vf
EAL: 0000:21:0a.1 cannot find TAILQ entry for PCI device!
EAL: Requested device 0000:21:0a.1 cannot be used
EAL: PCI device 0000:67:00.0 on NUMA socket 0
EAL: probe driver: 8086:37d2 net i40e
EAL: PCI device 0000:67:00.1 on NUMA socket 0
EAL: probe driver: 8086:37d2 net i40e
wls lib: Open wls0 (DPDK memzone)
wls_lib: WLS Open 0x2bf600000
wls_lib: link: 1 <-> 0
wls lib: Mode 1
wls_lib: WLS shared management memzone: wls0
wls_lib: hugePageSize on the system is 1073741824
    lib: WLS Alloc [1063256064] bytes
    lib: Connecting to remote peer ...
    lib: Connected to remote peer
wls mac create mem array: pMemArray[0xf3500f0] pMemArrayMemory[0x280000000]
totalSize[1063256064] nBlockSize[262144] numBlocks[4056]
WLS EnqueueBlock [1]
WLS inited ok [383]
TESTMAC VERSION
```



```
$Version: #DIRTY# $ (x86)
IMG-date: Apr 27 2020
IMG-time: 12:55:58
Testmac threads in application
testmac_run_thread: [PID: 112644] binding on [CPU 0] [PRIO: 89] [POLICY: 1] wls_mac_rx_task: [PID: 112643] binding on [CPU 1] [PRIO: 90] [POLICY: 1]
testmac set phy start: mode[1], period[40], count[0]
testmac_run_load_files:
Loading DL Config Files:
    testmac_run_parse_file Parsing config file:
/home/turner/xran/master/npg wireless-flexran 11 5g test/dl/testmac dl mu0 5mhz.cfg
    testmac run parse file Parsing config file:
/home/turner/xran/master/npg wireless-flexran 11 5g test/dl/testmac dl mu0 10mhz.cfg
    testmac_run_parse_file Parsing config file:
/home/turner/xran/master/npg_wireless-flexran_11_5g_test/dl/testmac_dl_mu0_20mhz.cfg
    testmac_run_parse_file Parsing config file:
/home/turner/xran/master/npg_wireless-flexran_11_5g_test/dl/testmac_dl_mu1_100mhz.cfg
    testmac run parse file Parsing config file:
/home/turner/xran/master/npg_wireless-flexran_11_5g_test/dl/testmac_dl_mu3_100mhz.cfg
Loading UL Config Files:
    testmac_run_parse_file Parsing config file:
/home/turner/xran/master/npg_wireless-flexran_11_5g_test/ul/testmac_ul_mu0_5mhz.cfg
    testmac run parse file Parsing config file:
/home/turner/xran/master/npg_wireless-flexran_11_5g_test/ul/testmac_ul_mu0_10mhz.cfg
    testmac_run_parse_file Parsing config file:
/home/turner/xran/master/npg_wireless-flexran_11_5g_test/ul/testmac_ul_mu0_20mhz.cfg
    testmac run parse file Parsing config file:
/home/turner/xran/master/npg wireless-flexran 11 5g test/ul/testmac ul mu1 100mhz.cfg
    testmac run parse file Parsing config file:
/home/turner/xran/master/npg wireless-flexran 11 5g test/ul/testmac ul mu3 100mhz.cfg
Loading FD Config Files:
    testmac_run_parse_file Parsing config file:
/home/turner/xran/master/npg wireless-flexran 11 5g test/fd/testmac fd mu0 5mhz.cfg
    testmac run parse file Parsing config file:
/home/turner/xran/master/npg wireless-flexran 11 5g test/fd/testmac fd mu0 10mhz.cfg
    testmac_run_parse_file Parsing config file:
/home/turner/xran/master/npg_wireless-flexran_11_5g_test/fd/testmac_fd_mu0_20mhz.cfg
    testmac run parse file Parsing config file:
/home/turner/xran/master/npg_wireless-flexran_l1_5g_test/fd/testmac_fd_mu1_40mhz.cfg
    testmac run parse file Parsing config file:
/home/turner/xran/master/npg wireless-flexran 11 5g test/fd/testmac fd mu1 100mhz.cfg
    testmac run parse file Parsing config file:
/home/turner/xran/master/npg wireless-flexran 11 5g test/fd/testmac fd mu3 100mhz.cfg
TESTMAC DL TESTS:
    Numerology[0] Bandwidth[5]
        1001 1002 1003 1004 1005 1006 1007 1008
    Numerology[0] Bandwidth[10]
        1001 1002 1003 1004 1005 1006 1007 1008
    Numerology[0] Bandwidth[20]
```



Numerology (1) Bandwidth (100)											
1200	1001	1002	1003	1004	1005	1006	1007	1008			
1200	Numerology										
1212 1213 1214 1215 1216 1217 1218 1219 1220 1221 1241 1242 1243 1244 1245 1250 1251 1252 1300 1301 1301 1305 1402 1404 1408 1416 1500 1501 1502 1503 1504 1505 1506 2215 2214 2215 2217 2218 2219 2223 2244 2225 2227 2226 2229 2209 22500 2501 2502 2503 2504 2313 2314 3215 3217 3218 3219 3223 3224 3225 3227 3228 3229 3223 3224 3225 3227 3228 3229 3223 3224 3225 3227 3228 3229 3223 3224 3225 3227 3228 3229 3223 3224 3225 3327 3228 3229 3233 3234 3225 3323 3234 3225 3323 3234 3225 3323 3234 3225 3323 3330 3030 3030 3030 3030 3030 2033 2001 2002 2003 2030 2033 3001 3002 3003 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030						1205	1206	1207	1210	1211	
1222 1223 1244 1245 1250 1251 1252 1205 1201 1502 1201 1301 1302 1303 1304 1305 1402 1404 1408 1416 1500 1501 1502 1503 1504 1505 1506 2213 2214 2215 2217 2218 2219 2223 2224 2225 2227 2226 2229 2500 2501 2502 2503 2504 3213 3214 3215 3217 3218 3219 3223 3224 3225 3227 3228 3229 3227 3228 3229 3220 3200 3003 3001 1001 1002 1003 1005 1006 1007 1008 1009 1010 1011 1012 1013 1014 1015 1016 1017 1018 1019 1030 1031 1032 1033 2001 2002 2003 2030 2033 3001 3002 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003 3003	1212	1213	1214				1218	1219	1220	1221	
1303 1304 1305 1402 1404 1408 1416 1500 1501 1502 1503 1504 1505 1506 2213 2214 2215 2217 2218 2219 2232 2224 2225 2227 2228 2229 2500 2501 2502 2503 3257 3228 3229 Numerology[31] Bandwidth[100] 1001 1002 1003 1005 1006 1007 1008 1009 1010 1011 1012 1013 1014 1015 1016 1017 1018 1019 1030 1031 1022 1033 2001 2002 2003 2030 2033 3001 3002 3003 3030 3030 3032 3030 3030 3002 3003 TESTMAC UL TESTS: Numerology[0] Bandwidth[5] 1001 1002 1003 1004 1005 1006 1007 1008 Numerology[0] Bandwidth[20] 1001 1002 1003 1004 1005 1006 1007 1008 Numerology[0] Bandwidth[20] 1001 1002 1003 1034 1035 1036 1037 1038 1039 1040 1041 1042 1043 1070 1071 1072 1073 1074 1080 1081 1082 1083 1084 1085 1086 1087 1091 1092 1093 1094 1095 1096 1100 1101 1102 1103 1104 1105 1106 1107 1108 1110 1111 1113 1114 1115 1116 1117 1118 1119 1120 1121 1122 1123 1124 1135 1136 1137 1138 1139 1140 1141 1142 1143 1150 1152 1153 1154 1155 1166 1167 1168 1169 1170 1107 1108 1209 1200 1211 1212 1213 1214 1215 1216 1207 1208 1209 1200 1211 1212 1213 1214 1215 1216 1207 1208 1209 1200 1211 1212 1213 1214 1215 1216 1207 1208 1209 1200 1211 1212 1213 1214 1215 1216 1540 1541 1542 1563 1564 1565 1566 1569 1504 1540 1541 1542 1563 1564 1565 1566 1569 1504 1540 1541 1542 1563 1564 1565 1566 1569 1504 1540 1541 1542 1639 1609 1610 1611 1612 1613 1614 1615 1616 1617 1618 1619 1620 1621 1622 1633 1634 1625 1626 1627 1628 1639 1600 1601 1602 1603 1604 1605 1606 1607 1608 1609	1222	1223		1225	1226	1227	1228	1229	1230	1241	
1503 1504 1505 1506 2213 2214 2215 2217 2218 2219 2223 2224 2225 2227 2228 2229 2500 2500 2502 2503 2504 3213 3214 3215 3217 3218 3219 3223 3224 3225 3227 3228 3229 Numerology[3] Bandwidth[100] 1001 1002 1003 1005 1006 1007 1008 1009 1010 1011 1012 1013 1014 1015 1016 1017 1018 1019 1030 1031 1032 1033 2001 2002 2003 2030 2033 3001 3002 3003 3030 TESTMAC UL TESTS: Numerology[0] Bandwidth[5] 1001 1002 1003 Numerology[0] Bandwidth[10] 10101 1002 Numerology[0] Bandwidth[10] 1001 1002 1003 1004 1005 1006 1007 1008 Numerology[1] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1007 1008 Numerology[1] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1007 1008 Numerology[1] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1007 1008 Numerology[1] Bandwidth[100] 1001 1003 1004 1004 1004 1005 1006 1007 1008 Numerology[1] Bandwidth[100] 1001 1001 1002 1003 1004 1005 1006 1007 1008 Numerology[1] Bandwidth[100] 1006 1001 1082 1003 1004 1005 1006 1007 1008 1009 1001 1002 1003 1004 1005 1006 1007 1008 1009 1001 1002 1003 1004 1005 1006 1007 1008 1009 1001 1002 1003 1004 1005 1006 1007 1008 1009 1001 1002 1003 1004 1005 1006 1007 1008 1009 1001 1002 1003 1004 1005 1006 1007 1008 1001 1001 1002 1003 1004 1005 1006 1007 1008 1001 1001 1002 1003 1004 1005 1006 1007 1008 1001 1002 1008 1004 1005 1006 1007 1008 1001 1002 1008 1004 1005 1006 1007 1008 1001 1002 1003 1004 1005 1006 1007 1008 1001 1002 1003 1004 1005 1006 1007 1008 1001 1002 1003 1004 1005 1006 1007 1008 1001 1002 1003 1004 1005 1006 1007 1000 1001 1001 1001 1002 1003 1004 1005 1006 1007 1000 1001 1001 1001 1002 1003 1004 1005 1006 1007 1002 1003 1004 1005 1006 1007 1008 1006 1007 1000 1001 1001 1001 1002 1003 1004 1005 1006 1007 1000 1001 1001 1001 1002 1003 1004 1005 1006 1007 1002 1003 1004 1005 1006 1007 1008 1000 1000 1000 1000 1000 1000	1242	1243	1244	1245	1250	1251	1252	1300	1301	1302	
2233 2224 2225 2227 2228 2229 2500 2501 2502 2503 2504 3213 3214 3215 3217 3228 3229 3224 3225 3227 3228 3229 3224 3225 3227 3228 3229 3224 3225 3227 3228 3229 3224 3225 3227 3228 3229 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3223 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225 3224 3225	1303	1304	1305	1402	1404	1408	1416	1500	1501	1502	
2504 3213 3214 3215 3217 3218 3219 3223 3224 3225 3227 3228 3229 Numerology[3] Bandwidth[100] 1011 1012 1013 1014 1015 1016 1017 1018 1019 1030 1031 1012 1013 1014 1015 1016 1017 1018 1019 1030 1031 1032 1033 2001 2002 2003 2030 2033 3001 3002 3003 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 30	1503	1504	1505	1506	2213	2214	2215	2217	2218	2219	
Numerology[3] Bandwidth[100] 1001 1002 1003 1005 1006 1007 1008 1009 1010 1011 1012 1013 1014 1015 1016 1017 1018 1019 1030 1031 1032 1033 2001 2002 2003 2030 2033 3001 3002 3003 3030 TESTMAC UL TESTS: Numerology[0] Bandwidth[5] 1001 1002 1003 Numerology[0] Bandwidth[100] 1001 1002 1003 Numerology[0] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1007 1008 Numerology[0] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1007 1008 Numerology[1] Bandwidth[100] 1001 1030 1031 1032 1033 1034 1035 1036 1037 1038 1039 1040 1041 1042 1043 1070 1071 1072 1073 1074 1080 1081 1082 1083 1084 1085 1036 1087 1091 1092 1093 1094 1095 1096 1100 1101 1102 103 1104 1105 1106 1107 1108 1110 1111 1113 1114 1115 1116 1117 1118 1119 1120 1121 1122 1123 1124 1130 1131 1132 1133 1134 1135 1136 1137 1138 1139 1140 1141 1142 1143 1150 1152 1153 1154 1155 1156 1157 1159 1160 1101 1101 117 1173 1200 1201 1202 1203 1204 1205 1206 1207 1208 1209 1210 1211 122 1213 1214 1215 1216 1217 1218 1219 1220 1221 1222 1230 1204 1205 1206 1207 1208 1209 1210 1211 122 1213 1134 1155 1516 1517 159 160 1505 1506 1507 1508 1511 1512 1513 1514 155 1516 157 159 150 1506 1507 1508 1507 1508 1511 1512 1513 1514 155 1516 157 159 160 1505 1506 1507 1508 1511 1512 1513 1514 155 1516 157 159 150 1506 1507 1508 1507 1508 1511 1512 1513 1514 155 1516 1506 1507 1508 1506 1507 1508 1510 1511 1512 1513 1514 155 1516 1516 1504 1404 1408 1406 1407 1408 1409 1409 1409 1409 1409 1409 1409 1409	2223	2224	2225	2227	2228	2229	2500	2501	2502	2503	
Numerology[3] Bandwidth[100] 1001 1002 1003 1005 1006 1007 1008 1009 1010 1011 1012 1013 1014 1015 1016 1017 1018 1019 1030 1031 1032 1033 2001 2002 2003 2030 2033 3001 3002 3003 3030 TESTMAC UL TESTS: Numerology[0] Bandwidth[5] 1001 1002 1003 Numerology[0] Bandwidth[100] 1001 1002 1003 1004 Numerology[0] Bandwidth[100] 10101 1002 1003 1004 Numerology[1] Bandwidth[100] 1010 1002 1003 1004 Numerology[1] Bandwidth[20] 1010 1010 102 1003 1004 Numerology[1] Bandwidth[20] 1010 103 1031 1032 1033 1034 1035 1036 1037 1038 1039 1040 1041 1042 1043 1070 1071 1072 1073 1074 1080 1081 1082 1083 1084 1085 1086 1087 1091 1092 1093 1094 1095 1096 1100 1101 1102 1103 1104 1105 1106 1107 1108 1110 1111 1113 1114 1115 1116 1117 1118 1119 1120 1121 1122 1123 1124 1130 1131 1132 1133 1134 1135 1136 1137 1138 1139 1140 1141 1142 1143 1150 1152 1153 1154 1155 1156 1157 1159 1160 1161 1162 1163 1164 1165 1166 1167 1168 1169 1170 1171 1172 1173 1200 1201 1202 1203 1204 1205 1206 1207 1208 1209 1210 1211 1212 1212 1213 1214 1215 1216 1217 1218 1219 1220 1221 1222 1230 1231 1232 1233 1234 1235 1236 1237 1402 1404 1408 1416 1420 1421 1422 1423 1424 1425 1426 1427 1428 1429 1430 1431 1432 1433 1434 1435 1436 1437 1438 1500 1503 1504 1505 1506 1507 1508 1511 1512 1513 1514 1515 1516 1540 1541 1542 1563 1564 1657 1568 1567 1568 1569 1570 1571 1572 1573 1574 1600 1601 1602 1603 1604 1615 1616 1617 1618 1619 1620 1621 1622 1623 1624 1625 1626 1627 1628 1629 1630 1631 1632 1633 1634 1635 1636 1637 1638 1639 1640 1641 1642 1700 1701 2236 2237 Numerology[3] Bandwidth[10] 1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1013 1014 1015 1020 1001 1001 1002 1003 3003 TESTMAC DE TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[1] Numerology[0] Bandwidth[1] Numerology[0] Bandwidth[1] Numerology[0] Bandwidth[1] Numerology[0] Bandwidth[1] Numerology[0] Bandwidth[1]				3215	3217	3218	3219	3223	3224	3225	
1001 1002 1003 1005 1006 1007 1008 1009 1010 1011 1012 1013 1014 1015 1016 1017 1018 1019 1020 1031 1032 1033 2001 2002 2003 2030 2033 3001 3002 3003 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030 3030											
1012 1013 1014 1015 1016 1017 1018 1019 1030 1031 1032 1033 2001 2002 2003 2030 2033 3001 3002 3003 3030 3030											
TESTMAC UL TESTS: Numerology[0] Bandwidth[5] 1001 1002 1003 Numerology[0] Bandwidth[101 1001 1002 1003 Numerology[0] Bandwidth[101 1001 1002 1003 1004 1005 1006 1007 1008 Numerology[1] Bandwidth[100] 1010 1002 1003 1004 1005 1006 1007 1008 Numerology[1] Bandwidth[100] 1010 1030 1031 1032 1033 1034 1035 1036 1037 1038 1039 1040 1041 1042 1043 1070 1071 1072 1073 1074 1080 1081 1082 1083 1084 1085 1086 1087 1091 1092 1093 1094 1095 1096 1100 1101 102 1103 1104 1105 1106 1107 1108 1110 1111 1113 1114 1115 1116 1117 1118 119 1120 1121 1122 1123 1124 1130 1131 1132 1133 1134 1135 1136 1137 1138 1139 1140 1141 1142 1143 1150 1152 1153 1154 1155 1156 1157 1159 1160 1161 1162 1163 1164 1165 1166 1167 1168 1169 1170 1171 1172 1173 1200 1211 1212 1212 1213 1214 1215 1216 1207 1208 1209 1210 1211 1212 1221 123 1214 1215 1216 1217 1218 1219 1220 1221 1221 1222 1230 1241 1255 1266 1207 1208 1209 1210 1211 1212 1221 1231 1241 125 1216 1214 1242 1423 1424 1425 1426 1427 1428 1429 1430 1431 1432 1433 1434 1435 1436 1437 1402 1404 1408 1416 1420 1421 1422 1423 1423 1424 1425 1426 1427 1428 1429 1430 1431 1432 1433 1434 1435 1436 1437 1400 1601 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1612 1613 1614 1615 1616 1617 1618 1619 1620 1621 1622 1623 1624 1625 1626 1627 1628 1629 1630 1631 1632 1633 1634 1635 1636 1637 1638 1639 1640 1641 1642 1700 1701 2036 2236 2237 3236 3237 Numerology[3] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1013 1014 1015 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1032 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1050 1051 1052 1056 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003											
TESTMAC UL TESTS: Numerology[0] Bandwidth[5] 1001 1002 1003 Numerology[0] Bandwidth[101] 1001 1002 1003 1004 1005 1006 1007 1008 Numerology[0] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1007 1008 Numerology[1] Bandwidth[100] 1010 1030 1031 1032 1033 1034 1035 1036 1037 1038 1039 1040 1041 1042 1043 1070 1071 1072 1073 1074 1080 1081 1082 1083 1084 1085 1086 1087 1091 1092 1093 1094 1095 1096 1100 1101 1102 1103 1104 1105 1106 1107 1108 1110 1111 1113 1114 1115 1116 1117 1118 1119 1120 1121 1122 1123 1124 1130 1131 1132 1133 1134 1135 1136 1137 1138 1139 1140 1141 1142 1143 1150 1152 1153 1154 1155 1156 1157 1159 1160 1161 1162 1163 1164 1165 1166 1167 1168 1169 1170 1171 1172 1173 1200 1201 1202 1203 1204 1205 1206 1207 1208 1209 1210 1211 1122 1213 1214 1215 1216 1217 1218 1219 1220 1221 1222 1230 1231 1232 1233 1234 1235 1236 1237 1402 1404 1408 1416 1420 1421 1422 1423 1424 1425 1426 1427 1428 1429 1430 1431 1432 1433 1434 1435 1436 1437 1438 1500 1503 1504 1506 1507 1508 1511 1512 1513 1514 1515 156 156 156 1567 1570 1571 1572 1573 1574 1600 1601 1602 1603 1604 1605 1606 1607 1608 1609 1610 1610 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1612 1613 1614 1615 1616 1617 1618 1619 1620 1621 1622 1623 1624 1625 1626 1627 1628 1629 1630 1631 1632 1633 1634 1635 1636 1637 1638 1639 1630 1631 1632 1633 1634 1635 1636 1637 1638 1639 1640 1601 1602 1603 1604 1605 1606 1607 1001 1004 1005 1006 1007 1010 1011 1012 1013 1014 1015 1020 1021 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1050 1051 1051 1060 1060 1071 1071 1073 1074 1081 1082 1083 1084 TESTMAC FD TESTS: Numerology(0] Bandwidth(10] 1001 2001 4001 6001 10001 12001 Numerology(0] Bandwidth(10] 1001 2001 4001 6001 10001 10001 10001 1000 1000											
TESTMAC UL TESTS: Numerology(0] Bandwidth(5) 1001 1002 1003 Numerology(0] Bandwidth(101) 1001 1002 1003 1004 1005 1006 1007 1008 Numerology(1] Bandwidth(1001) 1001 1002 1003 1004 1005 1006 1007 1008 Numerology(1] Bandwidth(1001) 1001 1030 1031 1032 1033 1034 1035 1036 1037 1038 1039 1040 1041 1042 1043 1070 1071 1072 1073 1074 1080 1081 1082 1083 1084 1085 1086 1087 1091 1092 1093 1094 1095 1096 1100 1101 1102 1103 1104 1105 1106 1107 1108 1110 1111 1113 1114 1115 1116 1117 1118 1119 1120 1121 1122 1123 1124 1130 1131 1132 1133 1134 1135 1136 1137 1138 1139 1140 1141 1142 11413 1150 1152 1153 1154 1155 1156 1157 1159 1160 1161 1162 1163 1164 1165 1166 1167 1168 1169 1170 1171 1172 1173 1200 1201 1202 1203 1204 1205 1206 1207 1208 1209 1210 1211 1212 1213 1214 1215 1216 1217 1218 1219 1220 1221 1222 1230 1241 1255 1216 1217 1218 1219 1220 1221 1222 1230 1241 1251 1216 1217 1218 1219 1220 1221 1222 1230 1241 1255 1216 1217 1218 1219 1220 1221 1222 1230 1241 1255 1266 1207 1208 1209 1303 1404 1408 1416 1420 1421 1422 1423 1424 1425 1426 1427 1428 1429 1430 1431 1432 1433 1434 1435 1436 1437 1438 1500 1503 1504 1505 1506 1507 1508 1511 1512 1513 1514 1515 1516 1516 1566 1607 1508 1511 1512 1513 1514 1515 1516 1516 1566 1607 1608 1609 1610 1611 1602 1603 1604 1605 1606 1607 1618 1619 1620 1621 1622 1623 1624 1625 1626 1627 1628 1629 1630 1631 1632 1633 1634 1635 1636 1637 1638 1639 1640 1641 1642 1700 1701 2236 2237 2236 3237 Numerology(3] Bandwidth(100) 1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1003 1014 1015 1020 1021 1023 1024 1025 1026 1027 1028 1029 1030 1031 1031 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1050 1051 1051 1060 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003		1033	2001	2002	2003	2030	2033	3001	3002	3003	
Numerology[0] Bandwidth[5]	3030										
Numerology[0] Bandwidth[5]											
Numerology[0] Bandwidth[10] 1001 1002 Numerology[0] Bandwidth[20] 1010 1002 1003 1004 1005 1006 1007 1008 Numerology[1] Bandwidth[100] 1010 1003 1031 1032 1033 1034 1035 1036 1037 1038 1039 1040 1041 1042 1043 1070 1071 1072 1073 1074 1080 1081 1082 1083 1084 1085 1086 1087 1091 1092 1093 1094 1095 1086 100 1101 1102 1103 1104 1105 1106 1107 1108 1110 1111 1113 1114 1115 1116 1117 1118 1119 1120 1121 1122 1123 1124 1130 1131 1132 1133 1134 1135 1136 1137 1138 1139 1140 1141 1142 1143 1150 1152 1153 1154 1155 1156 1157 1159 1160 1161 1162 1163 1164 1165 1166 1167 1168 1169 1170 1171 1172 1173 1200 1201 1202 1203 1204 1205 1206 1207 1208 1209 1210 1211 1212 1213 1214 1215 1216 1217 1218 1219 1220 1221 1222 1230 1231 1232 1233 1234 1235 1236 1237 1402 1404 1408 1416 1420 1421 1432 1433 1434 1435 1436 1437 1438 1500 1503 1504 1505 1506 1507 1508 1511 1512 153 1514 1515 1516 1540 1541 1542 1563 1564 1565 1566 1567 1568 1569 1570 1571 1572 1573 1574 1600 1601 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1602 1603 1604 1615 1616 1617 1618 1619 1620 1621 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1602 1603 1604 1605 1606 1607 1608 1609 1600 1611 1602 1603 1604 1605 1606 1607 1608 1609 1600 1611 1602 1603 1604 1605 1606 1607 1608 1609 1600 1611 1602 1603 1604 1605 1606 1607 1008 1009 1000 1001 1001 1001 1001 1002 1003 1004 1005 1006 1007 100 1011 1012 1013 1014 1015 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1050 1051 1052 1053 1054 1059 1060 1061 1061 1612 1633 1634 1635 1636 1637 1638 1639 1640 1641 1642 1700 1701 2036 2237 3236 3237 Numerology[0] Bandwidth[10] 1001 1002 1003 1004 1005 1006 1007 100 1011 1012 1013 1014 1015 1006 1007 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003			1 1 1	1.553							
Numerology[0] Bandwidth[10]				n[5]							
Numerology[0] Bandwidth[20] 1001 1002 1003 1004 1005 1006 1007 1008 Numerology[1] Bandwidth[100] 1010 1030 1031 1032 1033 1034 1035 1036 1037 1038 1039 1040 1041 1042 1043 1070 1071 1072 1073 1074 1080 1081 1082 1083 1084 1085 1086 1087 1091 1092 1093 1094 1095 1096 1100 1101 1102 1103 1104 1105 1106 1107 1108 1110 1111 1113 1114 1115 1116 1117 1118 1119 1120 1121 1122 1123 1124 1130 1131 1132 1133 1134 1135 1136 1137 1138 1139 1140 1141 1142 1143 1150 1152 1153 1154 1155 1156 1157 1159 1160 1161 1162 1163 1164 1165 1166 1167 1168 1169 1170 1171 1172 1173 1200 1201 1202 1203 1204 1205 1206 1207 1208 1209 1210 1211 1212 1213 1214 1215 1216 1217 1218 1219 1220 1221 1222 1230 1231 1232 1233 1234 1235 1236 1237 1402 1404 1408 1416 1420 1421 1422 1443 1434 1435 1436 1437 1438 1500 1503 1504 1505 1506 1507 1508 151 1515 1513 1514 1515 1516 1540 1541 1542 1563 1564 1565 1566 1567 1568 1569 1570 1571 1572 1573 1574 1600 1601 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1612 1613 1614 1615 1616 1617 1618 1619 1620 1621 1622 1623 1624 1625 1626 1627 1628 1629 1630 1631 1632 1633 1634 1635 1636 1637 1638 1639 1640 1641 1642 1700 1701 1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1037 1040 1041 1042 1043 1044 1045 1046 1055 1056 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 TESTMAC FD TEST: Numerology[0] Bandwidth[10] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[1] 1001 2001 4001 6001 8001 10001 12001 Numerology[0] Bandwidth[1]0 1001 2001 4001 6001 8001 10001 12001 Numerology[0] Bandwidth[1]0 1001 2001 4001 6001 8001 10001 12001 Numerology[0] Bandwidth[1]0				.b [10]							
Numerology[0] Bandwidth[20]			inawiat	n[10]							
Numerology[1] Bandwidth[100] 1010 1030 1031 1032 1033 1034 1035 1036 1037 1038 1039 1040 1041 1042 1043 1070 1071 1072 1073 1074 1080 1081 1082 1083 1084 1085 1086 1087 1091 1092 1093 1094 1095 1096 1100 1101 1102 1103 1104 1105 1106 1107 1108 1110 1111 1113 1114 1115 1116 1117 1118 1119 1120 1121 1122 1123 1124 1130 1131 1132 1133 1134 1135 1136 1137 1138 1139 1140 1141 1142 1143 1150 1152 1153 1154 1155 1156 1157 1159 1160 1161 1162 1163 1164 1165 1166 1167 1168 1169 1170 1171 1172 1173 1200 1201 1202 1203 1204 1205 1206 1207 1208 1209 1210 1211 1212 1223 1214 1215 1216 1217 1218 1219 1220 1221 1222 1230 1231 1232 1233 1234 1235 1236 1237 1402 1408 1416 1406 1406 1402 1421 1422 1423 1424 1425 1426 1427 1428 1429 1430 1431 1432 1433 1434 1435 1436 1437 1438 1500 1503 1504 1505 1506 1507 1508 1511 1512 1513 1514 1515 1516 1540 1541 1542 1563 1564 1565 1566 1567 1568 1569 1570 1571 1572 1573 1574 1600 1601 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1612 1613 1614 1615 1616 1617 1618 1619 1620 1621 1622 1623 1624 1625 1626 1627 1628 1629 1630 1631 1632 1633 1634 1635 1636 1637 1638 1639 1640 1641 1642 1700 1701 1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1005 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 TESTMAC FD TESTS: Numerology[0] Bandwidth[0] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[1] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[1] 1001 1001 2001 4001 6001 8001 10001 12001 Numerology[0] Bandwidth[1]				h [20]							
Numerology[1] Bandwidth[100] 1010 1030 1031 1032 1033 1034 1035 1036 1037 1038 1039 1040 1041 1042 1043 1070 1071 1072 1073 1074 1080 1081 1082 1083 1084 1085 1086 1087 1091 1092 1093 1094 1095 1096 1100 1101 1102 1103 1104 1105 1106 1107 1108 1110 1111 1113 1114 1115 1116 1117 1118 1119 1120 1121 1122 1123 1124 1130 1131 1132 1133 1134 1135 1136 1137 1138 1139 1140 1141 1142 1143 1150 1152 1153 1154 1155 1156 1157 1159 1160 1161 1162 1163 1164 1165 1166 1167 1168 1169 1170 1171 1172 1173 1200 1201 1202 1203 1204 1205 1206 1207 1208 1209 1210 1211 1212 1213 1214 1215 1216 1217 1218 1219 1220 1221 1222 1230 1231 1232 1233 1234 1235 1236 1237 1402 1404 1408 1416 1420 1421 1422 1423 1424 1425 1426 1427 1428 1429 1430 1431 1432 1433 1434 1435 1436 1437 1438 1500 1503 1504 1505 1506 1507 1508 1511 1512 1513 1514 1515 1516 1540 1541 1542 1563 1564 1565 1566 1567 1568 1569 1570 1571 1572 1573 1574 1600 1601 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1612 1613 1614 1615 1616 1617 1618 1619 1620 1621 1622 1623 1624 1625 1626 1627 1628 1629 1630 1631 1632 1633 1634 1635 1636 1637 1638 1639 1640 1641 1642 1700 1701 2236 2237 3236 3237 Numerology[3] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1013 1014 1015 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1050 1051 1052 1053 1054 1059 1060 1061 1062 1063 1064 1065 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003 TESTMAC FD TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 1001 2001 4001 6001 8001 10001 12001 Numerology[0] Bandwidth[10]					1005	1000	1007	1000			
1010						1006	1007	1008			
1039 1040 1041 1042 1043 1070 1071 1072 1073 1074 1080 1081 1082 1083 1084 1085 1086 1087 1091 1092 1093 1094 1095 1096 1100 1101 1102 1103 1104 1105 1106 1107 1108 1110 1111 1113 1114 1115 1116 1117 1118 1119 1120 1121 1122 1123 1124 1130 1131 1132 1133 1134 1135 1136 1137 1138 1139 1140 1141 1142 1143 1150 1152 1153 1154 1155 1156 1157 1159 1160 1161 1162 1163 1164 1165 1166 1167 1168 1169 1170 1171 1172 1173 1200 1201 1202 1203 1204 1205 1206 1207 1208 1209 1210 1211 1212 1213 1214 1215 1216 1217 1218 1219 1220 1221 1222 1230 1231 1232 1233 1234 1235 1236 1237 1402 1404 1408 1416 1420 1421 1422 1423 1424 1425 1426 1427 1428 1429 1430 1431 1432 1433 1434 1435 1436 1437 1438 1500 1503 1504 1505 1506 1507 1508 1511 1512 1513 1514 1515 1516 1540 1571 1572 1573 1574 1600 1601 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1612 1613 1614 1615 1616 1617 1618 1619 1620 1621 1622 1623 1624 1625 1626 1627 1628 1629 1630 1631 1632 1633 1634 1635 1636 1637 1638 1639 1640 1641 1642 1700 1701 1701 1013 1014 1015 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1065 1066 1607 1071 1071 1072 1073 1074 1075 1076 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077 1077						1024	1025	1026	1027	1020	
1080											
1093 1094 1095 1096 1100 1101 1102 1103 1104 1105 1106 1117 1108 1110 1111 1113 1114 1115 1116 1117 1118 1119 1120 1121 1122 1123 1124 1130 1131 1132 1133 1134 1135 1136 1137 1138 1139 1140 1141 1142 1143 1150 1152 1153 1154 1155 1156 1157 1159 1160 1161 1162 1163 1164 1165 1166 1167 1168 1169 1170 1171 1172 1173 1200 1201 1202 1203 1204 1205 1206 1207 1208 1209 1210 1211 1212 1213 1214 1215 1216 1217 1218 1219 1220 1221 1222 1230 1231 1232 1233 1234 1235 1236 1237 1402 1404 1408 1416 1420 1421 1422 1423 1424 1425 1426 1427 1428 1429 1430 1431 1432 1433 1434 1435 1436 1437 1438 1850 1503 1504 1505 1506 1507 1508 1511 1512 1513 1514 1515 1516 1540 1541 1542 1563 1564 1565 1566 1567 1568 1569 1570 1571 1572 1573 1574 1600 1601 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1612 1613 1614 1615 1616 1617 1618 1619 1620 1621 1622 1623 1624 1625 1626 1627 1628 1629 1630 1631 1632 1633 1634 1635 1636 1637 1638 1639 1640 1641 1642 1700 1701 2236 2237 3236 3237 Numerology[3] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1067 1010 1011 1012 1015 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1055 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003 3003 3003 3004 3005 3003 3004 3005 3003 3004 3005 3003 3004 3005 3003 3004 3005 3003 3004 3005 3003 3004 3005 3003 3004 3005 3005 3005 3005 3005 3005 3005 3005 3005 3005 3005 3005 3005 3005 3005 3005 3005 3005 3005 3005 3005											
1106											
1118 1119 1120 1121 1122 1123 1124 1130 1131 1132 1133 1134 1135 1136 1137 1138 1139 1140 1141 1142 1143 1150 1152 1153 1154 1155 1156 1157 1159 1160 1161 1162 1163 1164 1165 1166 1167 1168 1169 1170 1171 1172 1173 1200 1201 1202 1203 1204 1205 1206 1207 1208 1209 1210 1211 1212 1213 1214 1215 1216 1217 1218 1219 1220 1221 1222 1230 1231 1232 1233 1234 1235 1236 1237 1402 1404 1408 1416 1420 1421 1422 1423 1424 1425 1426 1427 1428 1429 1430 1431 1432 1433 1434 1435 1436 1437 1438 1500 1503 1504 1505 1506 1507 1508 1511 1512 1513 1514 1515 1516 1540 1541 1542 1563 1564 1565 1566 1567 1568 1569 1570 1571 1572 1573 1574 1600 1601 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1612 1613 1614 1615 1616 1617 1618 1619 1620 1621 1622 1623 1624 1625 1626 1627 1628 1629 1630 1631 1632 1633 1634 1635 1636 1637 1638 1639 1640 1641 1642 1700 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701 1701											
1133 1134 1135 1136 1137 1138 1139 1140 1141 1142 1143 1150 1152 1153 1154 1155 1156 1157 1159 1160 1161 1162 1163 1164 1165 1166 1167 1168 1169 1170 1171 1172 1173 1200 1201 1202 1203 1204 1205 1206 1207 1208 1209 1210 1211 1212 1213 1214 1215 1216 1217 1218 1219 1220 1221 1222 1230 1231 1232 1233 1234 1235 1236 1237 1402 1404 1408 1416 1420 1421 1422 1423 1424 1425 1426 1427 1428 1429 1430 1431 1432 1433 1434 1435 1436 1437 1438 1500 1503 1504 1505 1506 1507 1508 1511 1512 1513 1514 1515 1516 1540 1541 1542 1563 1564 1565 1566 1567 1568 1569 1570 1571 1572 1573 1574 1600 1601 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1612 1613 1614 1615 1616 1617 1618 1619 1620 1621 1622 1623 1624 1625 1626 1627 1628 1629 1630 1631 1632 1633 1634 1635 1636 1637 1638 1639 1640 1641 1642 1700 1701 2236 2237 3236 3237 Numerology[3] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1013 1014 1015 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1056 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003 TESTMAC FD TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002 TESTMAC FD TESTS:											
1143 1150 1152 1153 1154 1155 1156 1157 1159 1160											
1161											
1171											
1207											
1217											
1234											
1422											
1432 1433 1434 1435 1436 1437 1438 1500 1503 1504 1505 1506 1507 1508 1511 1512 1513 1514 1515 1516 1540 1541 1542 1563 1564 1565 1566 1567 1568 1569 1570 1571 1572 1573 1574 1600 1601 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1612 1613 1614 1615 1616 1617 1618 1619 1620 1621 1622 1623 1624 1625 1626 1627 1628 1629 1630 1631 1632 1633 1634 1635 1636 1637 1638 1639 1640 1641 1642 1700 1701 2236 2237 3236 3237 Numerology[3] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1013 1014 1015 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1050 1051 1052 1053 1054 1059 1060 1061 1062 1063 1064 1065 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003 TESTMAC FD TESTS: Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002								1429			
1505	1432	1433						1500	1503	1504	
1540 1541 1542 1563 1564 1565 1566 1567 1568 1569 1570 1571 1572 1573 1574 1600 1601 1602 1603 1604 1605 1606 1607 1608 1609 1610 1611 1612 1613 1614 1615 1616 1617 1618 1619 1620 1621 1622 1623 1624 1625 1626 1627 1628 1629 1630 1631 1632 1633 1634 1635 1636 1637 1638 1639 1640 1641 1642 1700 1701 2236 2237 3236 3237 Numerology[3] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1013 1014 1015 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1050 1051 1052 1053 1054 1059 1060 1061 1062 1063 1064 1065 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003 TESTMAC FD TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002	1505	1506	1507		1511	1512			1515	1516	
1570											
1605	1570	1571		1573				1602	1603	1604	
1625 1626 1627 1628 1629 1630 1631 1632 1633 1634 1635 1636 1637 1638 1639 1640 1641 1642 1700 1701 2236 2237 3236 3237 Numerology[3] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1013 1014 1015 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1050 1051 1052 1053 1054 1059 1060 1061 1062 1063 1064 1065 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003 TESTMAC FD TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002	1605	1606	1607	1608	1609	1610	1611	1612	1613	1614	
1635 1636 1637 1638 1639 1640 1641 1642 1700 1701 2236 2237 3236 3237 Numerology[3] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1013 1014 1015 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1050 1051 1052 1053 1054 1059 1060 1061 1062 1063 1064 1065 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003 TESTMAC FD TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002	1615										
2236 2237 3236 3237 Numerology[3] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1013 1014 1015 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1050 1051 1052 1053 1054 1059 1060 1061 1062 1063 1064 1065 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003 TESTMAC FD TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002											
Numerology[3] Bandwidth[100] 1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1013 1014 1015 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1050 1051 1052 1053 1054 1059 1060 1061 1062 1063 1064 1065 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003 TESTMAC FD TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002					1639	1640	1641	1642	1700	1701	
1001 1002 1003 1004 1005 1006 1007 1010 1011 1012 1013 1014 1015 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1050 1051 1052 1053 1054 1059 1060 1061 1062 1063 1064 1065 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003 TESTMAC FD TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002											
1013 1014 1015 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1050 1051 1052 1053 1054 1059 1060 1061 1062 1063 1064 1065 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003 TESTMAC FD TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002				h[100]							
1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1040 1041 1042 1043 1044 1045 1046 1050 1051 1052 1053 1054 1059 1060 1061 1062 1063 1064 1065 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003 TESTMAC FD TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002											
1037 1040 1041 1042 1043 1044 1045 1046 1050 1051 1052 1053 1054 1059 1060 1061 1062 1063 1064 1065 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003 TESTMAC FD TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002											
1052 1053 1054 1059 1060 1061 1062 1063 1064 1065 1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003 TESTMAC FD TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002											
1066 1067 1070 1071 1073 1074 1081 1082 1083 1084 1085 1086 2001 2002 2003 3001 3002 3003 TESTMAC FD TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002											
1085 1086 2001 2002 2003 3001 3002 3003 TESTMAC FD TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002											
TESTMAC FD TESTS: Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002									1083	1084	
Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002	1085	1086	2001	2002	2003	3001	3002	3003			
Numerology[0] Bandwidth[5] 1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002	MECHANIC DD 550	m.c.									
1001 6001 8001 10001 12001 Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002			n de el el el	h [E]							
Numerology[0] Bandwidth[10] 1001 2001 4001 6001 8001 10001 12001 1002 2002 4002					12001						
1001 2001 4001 6001 8001 10001 12001 1002 2002 4002					12001						
					8001	10001	12001	1002	2002	4002	
	1001	2001	4001	0001	0001	10001	12001	1002	2002	4002	



```
6002 8002 10002 12002
                                   1003
    Numerology[0] Bandwidth[20]
         1002 1004 1012 1014 1015 1016 1017 1018 1020 1021
         1022 1023 1024 1025 1030 1031 1032 1033 1200 1201

    1202
    1206
    1207
    1208
    1209
    1210
    1211
    1212
    1220
    1221

    1222
    1223
    1224
    1225
    1226
    1227
    1228

    Numerology[1] Bandwidth[40]
         1001 1002 1003
    Numerology[1] Bandwidth[100]
         1001 1200 1201 1202
1209 1210 1300 1301
                                   1203 1204 1205 1206 1207 1208
                                   1302 1303 1304
                                                       1305 1306 1307
         1308 1350 1351 1352 1353 1354 1355 1356 1357 1358
         1370 1371 1372 1373 1401 1402 1403 1404 1405 1406
         1411 1412 1490 1494 1500 1501 1502 1503 1504 1510
         1511 1512 1513 1514 1515 1520 1521 1522 1523 1524
         1525 1526 1527 1528 1529 1530 1531 1532 1540 1541
         1700 1701 1702 2520 2521 2522 2523 2524 2525 2526
         2527 2528 2529 2530 2531 2532 3524 3525 3526 3527
         3528 3529 3530 3531 3532 4524 4525 4526 4527 4528
         4529 4530 4531 4532
    Numerology[3] Bandwidth[100]

    1001
    1002
    1004
    1005
    1006
    1007
    1008
    1009
    1010
    1011

    1012
    1013
    1014
    1015
    1061
    1062
    1063
    1064
    1065
    1080

    1081
    1082
    2001
    3001

    testmac run parse file Parsing config file: ./cascade lake-
sp/csxsp mul 100mhz mmimo hton_xran.cfg
testmac set phy start: mode[4], period[0], count[100040200]
    Adding Test[1002]. NumCarr[1], Current Directory:
/home/turner/xran/master/npg wireless-flexran 11 5g test/
       Carrier[0]: ConfigFile: fd/mu3 100mhz/2/fd testconfig tst2.cfg
Running Test[1002]. NumCarr[1], Current Directory:
/home/turner/xran/master/npg_wireless-flexran_l1_5g_test/
Carrier[0]: ConfigFile: fd/mu3_100mhz/2/fd_testconfig_tst2.cfg
TESTMAC>welcome to application console
MLogRestart
MLogOpen: filename(testmac-mlog.bin) mlogSubframes (128), mlogCores(3),
mlogSize(2048) mlog mask (-1)
    mlogSubframes (128), mlogCores(3), mlogSize(2048)
    localMLogTimerInit
        System clock (rdtsc) resolution 1596249901 [Hz]
        Ticks per us 1596
    MLog Storage: 0x7f84bc000900 -> 0x7f84bc0c1120 [ 788512 bytes ]
    localMLogFreqReg: 1596. Storing: 1596
    Mlog Open successful
testmac mac2phy set num cells: Setting Max Cells: 1
testmac_config_parse: test_num[1002] test_type[2] numcarrier[1]
host_config_set_int Error(nPrachSsbRach, 3): Out of range: [min(0), max(1)]
Queueing MSG_TYPE_PHY_UL_IQ_SAMPLES(0)
Received MSG_TYPE_PHY_UL_IQ_SAMPLES(0)
Queueing MSG_TYPE_PHY_CONFIG_REQ(0) and sending list
Received MSG TYPE PHY CONFIG RESP(0)
Queueing MSG TYPE PHY START REQ(0) and sending list
Received MSG TYPE PHY START RESP(0)
==== testmac Time: 5000 ms NumCarrier: 1 Total Proc Time: [ 0.00.. 4.11.. 14.00]
Core Utilization [Core: 1] [Util %: 2.97%]
==== testmac Time: 10000 ms NumCarrier: 1 Total Proc Time: [ 2.00.. 4.10.. 13.00]
```



```
Core Utilization [Core: 1] [Util %: 4.81%]
==== testmac Time: 15000 ms NumCarrier: 1 Total Proc Time: [ 2.00.. 4.10.. 6.00]
usces====
```

A.4.2 Configure FlexRAN 5G NR L1 Application for multiple O-RUs with multiple numerologies

The 5G NR layer 1 application can be used for executing the scenario for multiple cells with multiple numerologies. The current release supports the constant configuration of different numerologies on different O-RU ports. It is required that the first O-RU (O-RU0) to be configured with highest numerology. The configuration procedure is similar as described in above section. Please refer to the configuration file located in

 $bin\nr5g\gnb\l1\complex. and 20mhz_sub6_mu1_100mhz_4x4\gnb\xrancfg_sub6_oru.xml$

A.4.3 Install and Configure FlexRAN 5G NR L1 Application for Massive - MIMO

The 5G NR layer 1 application can be used for executing the scenario for Massive-MIMO with either the RU sample application or just the O-DU side. 3 cells scenario with 64T64R Massive MIMO is targeted for Icelake system with Columbiavile NIC. The current release supports the constant configuration of the slot pattern and RB allocation on the PHY side. Please follow the general build process in the FlexRAN 5G NR Reference Solution L1 User Guide (refer to Table 2.)

- 1. xRAN library is enabled by default l1 application
- 2. Build the 5G NR L1 application using the command:

```
./flexran_build.sh -r 5gnr_llapp_sub6 -i snc -m sdk -m fb -m mlog -m wls -m 5gnr_llapp_mmw -m xran -m 5gnr_testmac
```

3. Configure the L1app using bin/nr5q/qnb/l1/xrancfg sub6 mmimo.xml.

```
<version>20.08</version>
   <!-- numbers of O-RU connected to O-DU. All O-RUs are the same capabilities. Max
O-RUs is per XRAN PORTS NUM i.e. 4 -->
   <oRuNum>3</oRuNum>
    <!-- # 10G,25G,40G,100G speed of Physical connection on O-RU -->
    <oRuEthLinkSpeed>25</oRuEthLinkSpeed>
   <!-- # 1, 2, 3 total number of links per O-RU (Fronthaul Ethernet link in IOT
   <oRuLinesNumber>2</oRuLinesNumber>
   <!-- (1) - C- plane and U-plane on the same set of VFs. (0) - C-plane and U-
Plane use dedicated VFs -->
   <oRuCUon1Vf>1</oRuCUon1Vf>
   <!-- O-RU 0 -->
   <PciBusAddoRu0Vf0>0000:51:01.0</PciBusAddoRu0Vf0>
   <PciBusAddoRu0Vf1>0000:51:01.1</PciBusAddoRu0Vf1>
   <PciBusAddoRu0Vf2>0000:51:01.2</PciBusAddoRu0Vf2>
   <PciBusAddoRu0Vf3>0000:51:01.3</PciBusAddoRu0Vf3>
   <!-- O-RU 1 -->
   <PciBusAddoRu1Vf0>0000:51:01.2</PciBusAddoRu1Vf0>
   <PciBusAddoRu1Vf1>0000:51:01.3</PciBusAddoRu1Vf1>
   <PciBusAddoRu1Vf2>0000:51:01.6</PciBusAddoRu1Vf2>
   <PciBusAddoRulVf3>0000:51:01.7</PciBusAddoRulVf3>
```



```
<!-- O-RU 2 -->
    <PciBusAddoRu2Vf0>0000:51:01.4</PciBusAddoRu2Vf0>
    <PciBusAddoRu2Vf1>0000:51:01.5</PciBusAddoRu2Vf1>
    <PciBusAddoRu2Vf2>0000:51:02.2</PciBusAddoRu2Vf2>
   <PciBusAddoRu2Vf3>0000:51:02.3</PciBusAddoRu2Vf3>
   <!-- O-RU 4 -->
    <PciBusAddoRu3Vf0>0000:00:00.0</PciBusAddoRu3Vf0>
    <PciBusAddoRu3Vf1>0000:00:00.0</PciBusAddoRu3Vf1>
    <PciBusAddoRu3Vf2>0000:00:00.0</PciBusAddoRu3Vf2>
   <PciBusAddoRu3Vf3>0000:00:00.0</PciBusAddoRu3Vf3>
   <!-- remote O-RU 0 Eth Link 0 VF0, VF1-->
   <oRuRem0Mac0>00:11:22:33:00:01<oRuRem0Mac0>
   <!-- remote O-RU 0 Eth Link 1 VF2, VF3 -->
   <oRuRem0Mac2>00:11:22:33:00:21<oRuRem0Mac2>
   <oRuRem0Mac3>00:11:22:33:00:31<oRuRem0Mac3>
   <!-- remote O-RU 1 Eth Link 0 VF4, VF5-->
   <oRuRem1Mac0>00:11:22:33:01:01<oRuRem1Mac0>
    <oRuRem1Mac1>00:11:22:33:01:11<oRuRem1Mac1>
    <!-- remote O-RU 1 Eth Link 1 VF6, VF7 -->
    <oRuRem1Mac2>00:11:22:33:01:21<oRuRem1Mac2>
    <oRuRem1Mac3>00:11:22:33:01:31<oRuRem1Mac3>
   <!-- remote O-RU 2 Eth Link 0 VF8, VF9 -->
   <oRuRem2Mac0>00:11:22:33:02:01<oRuRem2Mac0>
   <oRuRem2Mac1>00:11:22:33:02:11<oRuRem2Mac1>
   <!-- remote O-RU 2 Eth Link 1 VF10, VF11-->
   <oRuRem2Mac2>00:11:22:33:02:21<oRuRem2Mac2>
   <oRuRem2Mac3>00:11:22:33:02:31<oRuRem2Mac3>
   <!-- remote O-RU 2 Eth Link 0 VF12, VF13 -->
   <oRuRem3Mac0>00:11:22:33:03:01<oRuRem3Mac0>
    <oRuRem3Mac1>00:11:22:33:03:11<oRuRem3Mac1>
    <!-- remote O-RU 2 Eth Link 1 VF14, VF15-->
    <oRuRem3Mac2>00:11:22:33:03:21<oRuRem3Mac2>
    <oRuRem3Mac3>00:11:22:33:03:31<oRuRem3Mac3>
   <!-- Number of cells (CCs) running on this O-RU [1 - Cell , 2 - Cells, 3 -
Cells , 4 - Cells | -->
   <oRu0NumCc>1</oRu0NumCc>
   <!-- First Phy instance ID mapped to this O-RU CCO -->
   <!-- Second Phy instance ID mapped to this O-RU CC1 -->
   <oRu0Cc1PhyId>1</oRu0Cc1PhyId>
   <!-- Third Phy instance ID mapped to this O-RU CC2 -->
   <oRu0Cc2PhyId>2</oRu0Cc2PhyId>
   <!-- Forth Phy instance ID mapped to this O-RU CC3 -->
    <oRu0Cc3PhyId>3</oRu0Cc3PhyId>
   <!-- Number of cells (CCs) running on this O-RU [1 - Cell , 2 - Cells, 3 -
Cells , 4 - Cells ] -->
    <oRu1NumCc>1</oRu1NumCc>
    <!-- First Phy instance ID mapped to this O-RU CCO -->
   <oRu1Cc0PhyId>1</oRu1Cc0PhyId>
   <!-- Second Phy instance ID mapped to this O-RU CC1 -->
    <oRu1Cc1PhyId>1</oRu1Cc1PhyId>
    <!-- Third Phy instance ID mapped to this O-RU CC2 -->
    <oRu1Cc2PhyId>2</oRu1Cc2PhyId>
    <!-- Forth Phy instance ID mapped to this O-RU CC3 -->
```



```
<oRu1Cc3PhyId>3</oRu1Cc3PhyId>
    <!-- Number of cells (CCs) running on this O-RU [1 - Cell , 2 - Cells, 3 -
Cells , 4 - Cells ] -->
   <oRu2NumCc>1</oRu2NumCc>
   <!-- First Phy instance ID mapped to this O-RU CCO -->
   <oRu2Cc0PhyId>2</oRu2Cc0PhyId>
   <!-- Second Phy instance ID mapped to this O-RU CC1 -->
    <oRu2Cc1PhyId>1</oRu2Cc1PhyId>
    <!-- Third Phy instance ID mapped to this O-RU CC2 -->
   <oRu2Cc2PhyId>2</oRu2Cc2PhyId>
   <!-- Forth Phy instance ID mapped to this O-RU CC3 -->
   <oRu2Cc3PhyId>3</oRu2Cc3PhyId>
   <!-- XRAN Thread (core where the XRAN polling function is pinned: Core, priority,
Policy [0: SCHED FIFO 1: SCHED RR] -->
   <xRANThread>22, 96, 0</xRANThread>
   <!-- core mask for XRAN Packets Worker (core where the XRAN packet processing is
pinned): Core, priority, Policy [0: SCHED_FIFO 1: SCHED_RR] -->
   <xRANWorker>0x3800000, 96, 0</xRANWorker>
   <!-- XRAN: Category of O-RU 0 - Category A, 1 - Category B -->
   <Category>1</Category>
   <!-- XRAN: enable sleep on PMD cores -->
   <xranPmdSleep>0</xranPmdSleep>
   <!-- RU Settings -->
   <Tadv cp dl>25</Tadv cp dl>
   <!-- Reception Window C-plane DL-->
   <T2a min cp d1>285</T2a min cp d1>
   <T2a max cp d1>429</T2a max cp d1>
   <!-- Reception Window C-plane UL-->
   <T2a_min_cp_ul>285</T2a_min_cp_ul>
   <T2a_max_cp_ul>429</T2a_max_cp_ul>
    <!-- Reception Window U-plane -->
    <T2a_min_up>71</T2a_min_up>
    <T2a max up>428</T2a max up>
    <!-- Transmission Window U-plane -->
    <Ta3 min>20</Ta3 min>
   <Ta3 max>32</Ta3 max>
   <!-- O-DU Settings -->
   <!-- MTU size -->
   <MTU>9600</MTU>
   <!-- VLAN Tag used for C-Plane -->
   <c plane vlan tag>1</c plane vlan tag>
   <u_plane_vlan_tag>2</u_plane_vlan_tag>
   <!-- Transmission Window Fast C-plane DL -->
    <Tla_min_cp_dl>258</Tla_min_cp_dl>
    <Tla_max_cp_dl>429</Tla_max_cp_dl>
        Transmission Window Fast C-plane UL -->
    <Tla min cp ul>285</Tla min cp ul>
    <Tla max cp ul>300</Tla max cp ul>
    <!-- Transmission Window U-plane -->
   <Tla min up>96</Tla min up>
   <Tla max up>196</Tla max up>
    <!-- Reception Window U-Plane-->
   <Ta4 min>0</Ta4 min>
    <Ta4 max>75</Ta4 max>
```



```
<!-- Enable Control Plane -->
   <EnableCp>1</EnableCp>
   <DynamicSectionEna>0
   <!-- Enable Dynamic section allocation for UL -->
    <DynamicSectionEnaUL>0</DynamicSectionEnaUL>
    <xRANSFNWrap>1</xRANSFNWrap>
    <!-- Total Number of DL PRBs per symbol (starting from RB 0) that is transmitted
(used for testing. If 0, then value is used from PHY CONFIG API) -->
    <xRANNumDLPRBs>0</xRANNumDLPRBs>
    <!-- Total Number of UL PRBs per symbol (starting from RB 0) that is received
(used for testing. If 0, then value is used from PHY CONFIG API)
    <xRANNumULPRBs>0</xRANNumULPRBs>
   <!-- refer to alpha as defined in section 9.7.2 of O-RAN spec. this value should
be alpha*(1/1.2288ns), range 0 - 1e7 (ns) -->
   <Gps Alpha>0</Gps Alpha>
   <!-- beta value as defined in section 9.7.2 of O-RAN spec. range -32767 ~ +32767
   <Gps Beta>0</Gps Beta>
   <!-- XRAN: Compression mode on O-DU <-> O-RU 0 - no comp 1 - BFP -->
   <xranCompMethod>1</xranCompMethod>
   <oRu0nPrbElemDl>6</oRu0nPrbElemDl>
    <!--nRBStart, nRBSize, nStartSymb, numSymb, nBeamIndex, bf weight update,
compMethod, iqWidth, BeamFormingType, Scalefactor, REMask -->
   <!-- weight base beams -->
   <oRu0PrbElemD10>0,48,0,14,1,1,1,9,1,0,0</oRu0PrbElemD10>
   <oRu0PrbElemDl1>48,48,0,14,2,1,1,9,1,0,0</oRu0PrbElemDl1>
   <oRu0PrbElemD12>96,48,0,14,2,1,1,9,1,0,0</oRu0PrbElemD12>
   <oRu0PrbElemDl3>144,48,0,14,4,1,1,9,1,0,0</oRu0PrbElemDl3>
   <oRu0PrbElemD14>192,48,0,14,5,1,1,9,1,0,0</oRu0PrbElemD14>
   <oRu0PrbElemDl5>240,33,0,14,6,1,1,9,1,0,0</oRu0PrbElemDl5>
   <oRu0PrbElemDl6>240,33,0,14,7,1,1,9,1,0,0</oRu0PrbElemDl6>
   <oRu0PrbElemD17>252,21,0,14,8,1,1,9,1,0,0</oRu0PrbElemD17>
   <!-- extType = 11 -->
    <oRu0ExtBfwDl0>2,24,0,0,9,1</oRu0ExtBfwDl0>
    <oRu0ExtBfwDl1>2,24,0,0,9,1</oRu0ExtBfwDl1>
    <oRu0ExtBfwD12>2,24,0,0,9,1</oRu0ExtBfwD12>
   <oRu0ExtBfwDl3>2,24,0,0,9,1</oRu0ExtBfwDl3>
   <oRu0ExtBfwD14>2,24,0,0,9,1</oRu0ExtBfwD14>
   <oRu0ExtBfwDl5>2,17,0,0,9,1</oRu0ExtBfwDl5>
   <oRu0nPrbElemUl>6</oRu0nPrbElemUl>
   <!--nRBStart, nRBSize, nStartSymb, numSymb, nBeamIndex, bf weight update,
compMethod, iqWidth, BeamFormingType, Scalefactor, REMask -->
   <!-- weight base beams -->
   <oRu0PrbElemUl0>0,48,0,14,1,1,1,9,1,0,0</oRu0PrbElemUl0>
   <oRu0PrbElemUl1>48,48,0,14,2,1,1,9,1,0,0</oRu0PrbElemUl1>
   <oRu0PrbElemUl2>96,48,0,14,2,1,1,9,1,0,0</oRu0PrbElemUl2>
    <oRu0PrbElemUl3>144,48,0,14,4,1,1,9,1,0,0</oRu0PrbElemUl3>
    <oRu0PrbElemU14>192,48,0,14,5,1,1,9,1,0,0</oRu0PrbElemU14>
    <oRu0PrbElemU15>240,33,0,14,6,1,1,9,1,0,0</oRu0PrbElemU15>
    <oRu0PrbElemUl6>240,33,0,14,7,1,1,9,1,0,0</oRu0PrbElemUl6>
    <oRu0PrbElemUl7>252,21,0,14,8,1,1,9,1,0,0</oRu0PrbElemUl7>
   <!-- extType = 11 -->
    <oRu0ExtBfwUl0>2,24,0,0,9,1</oRu0ExtBfwUl0>
    <oRu0ExtBfwUl1>2,24,0,0,9,1</oRu0ExtBfwUl1>
    <oRu0ExtBfwU12>2,24,0,0,9,1</oRu0ExtBfwU12>
    <oRu0ExtBfwUl3>2,24,0,0,9,1</oRu0ExtBfwUl3>
```



```
<oRu0ExtBfwUl4>2,24,0,0,9,1</oRu0ExtBfwUl4>
    <oRu0ExtBfwUl5>2,17,0,0,9,1</oRu0ExtBfwUl5>
    <oRu0nPrbElemSrs>1</oRu0nPrbElemSrs>
    <!--nRBStart, nRBSize, nStartSymb, numSymb, nBeamIndex, bf weight update,
compMethod, iqWidth, BeamFormingType, Scalefactor, REMask -->
   <!-- weight base beams -->
   <oRu0PrbElemSrs0>0,273,0,14,1,1,1,9,1,0,0</oRu0PrbElemSrs0>
    <!--nRBStart, nRBSize, nStartSymb, numSymb, nBeamIndex, bf weight update,
compMethod, iqWidth, BeamFormingType, Scalefactor, REMask -->
   <!-- weight base beams -->
   <oRu1PrbElemDl0>0,48,0,14,0,1,1,9,1,0,0</oRu1PrbElemDl0>
   <oRu1PrbElemDl1>48,48,0,14,2,1,1,9,1,0,0</oRu1PrbElemDl1>
   <oRu1PrbElemD12>96,48,0,14,3,1,1,9,1,0,0</oRu1PrbElemD12>
   <oRu1PrbElemDl3>144,48,0,14,4,1,1,9,1,0,0</oRu1PrbElemDl3>
   <oRu1PrbElemD14>144,36,0,14,5,1,1,9,1,0,0</oRu1PrbElemD14>
   <oRu1PrbElemDl5>180,36,0,14,6,1,1,9,1,0,0</oRu1PrbElemDl5>
   <oRu1PrbElemD16>216,36,0,14,7,1,1,9,1,0,0</oRu1PrbElemD16>
   <oRu1PrbElemDl7>252,21,0,14,8,1,1,9,1,0,0</oRu1PrbElemDl7>
   <!-- extType = 11 -->
    <oRu1ExtBfwDl0>2,24,0,0,9,1</oRu1ExtBfwDl0>
    <oRu1ExtBfwDl1>2,24,0,0,9,1</oRu1ExtBfwDl1>
    <!--nRBStart, nRBSize, nStartSymb, numSymb, nBeamIndex, bf weight update,
compMethod, iqWidth, BeamFormingType, Scalefactor, REMask -->
   <!-- weight base beams -->
   <oRu1PrbElemUl0>0,48,0,14,1,1,1,9,1,0,0</oRu1PrbElemUl0>
   <oRu1PrbElemUl1>48,48,0,14,2,1,1,9,1,0,0</oRu1PrbElemUl1>
   <oRu1PrbElemUl2>72,36,0,14,3,1,1,9,1,0,0</oRu1PrbElemUl2>
   <oRu1PrbElemUl3>108,36,0,14,4,1,1,9,1,0,0</oRu1PrbElemUl3>
   <oRu1PrbElemUl4>144,36,0,14,5,1,1,9,1,0,0</oRu1PrbElemUl4>
   <oRu1PrbElemUl5>180,36,0,14,6,1,1,9,1,0,0</oRu1PrbElemUl5>
    <oRu1PrbElemU16>216,36,0,14,7,1,1,9,1,0,0</oRu1PrbElemU16>
    <oRu1PrbElemUl7>252,21,0,14,8,1,1,9,1,0,0</oRu1PrbElemUl7>
   <!-- extType = 11 -->
   <oRu1ExtBfwUl0>2,24,0,0,9,1</oRu1ExtBfwUl0>
   <oRu1ExtBfwUl1>2,24,0,0,9,1</oRu1ExtBfwUl1>
   <oRu1nPrbElemSrs>1</oRu1nPrbElemSrs>
   <!--nRBStart, nRBSize, nStartSymb, numSymb, nBeamIndex, bf weight update,
compMethod, iqWidth, BeamFormingType, Scalefactor, REMask -->
   <!-- weight base beams -->
   <oRu1PrbElemSrs0>0,273,0,14,1,1,1,9,1,0,0</oRu1PrbElemSrs0>
   <!--nRBStart, nRBSize, nStartSymb, numSymb, nBeamIndex, bf_weight_update,
compMethod, iqWidth, BeamFormingType, Scalefactor, REMask -->
    <!-- weight base beams -->
    <oRu2PrbElemDl0>0,48,0,14,1,1,1,9,1,0,0</oRu2PrbElemDl0>
    <oRu2PrbElemDl1>48,48,0,14,2,1,1,9,1,0,0</oRu2PrbElemDl1>
    <oRu2PrbElemDl2>96,48,0,14,3,1,1,9,1,0,0</oRu2PrbElemDl2>
    <oRu2PrbElemDl3>144,48,0,14,4,1,1,9,1,0,0</oRu2PrbElemDl3>
    <oRu2PrbElemD14>144,36,0,14,5,1,1,9,1,0,0</oRu2PrbElemD14>
    <oRu2PrbElemDl5>180,36,0,14,6,1,1,9,1,0,0</oRu2PrbElemDl5>
   <oRu2PrbElemDl6>216,36,0,14,7,1,1,9,1,0,0</oRu2PrbElemDl6>
   <oRu2PrbElemD17>252,21,0,14,8,1,1,9,1,0,0</oRu2PrbElemD17>
```



```
<!-- extType = 11 -->
    <oRu2ExtBfwDl0>2,24,0,0,9,1</oRu2ExtBfwDl0>
    <oRu2ExtBfwDl1>2,24,0,0,9,1</oRu2ExtBfwDl1>
    <oRu2nPrbElemUl>2</oRu2nPrbElemUl>
    <!--nRBStart, nRBSize, nStartSymb, numSymb, nBeamIndex, bf_weight_update,
compMethod, iqWidth, BeamFormingType, Scalefactor, REMask
    <!-- weight base beams -->
    <oRu2PrbElemUl0>0,48,0,14,1,1,1,9,1,0,0</oRu2PrbElemUl0>
    <oRu2PrbElemUl1>48,48,0,14,2,1,1,9,1,0,0</oRu2PrbElemUl1>
    <oRu2PrbElemUl2>72,36,0,14,3,1,1,9,1,0,0</oRu2PrbElemUl2>
    <oRu2PrbElemUl3>108,36,0,14,4,1,1,9,1,0,0</oRu2PrbElemUl3>
    <oRu2PrbElemUl4>144,36,0,14,5,1,1,9,1,0,0</oRu2PrbElemUl4>
    <oRu2PrbElemUl5>180,36,0,14,6,1,1,9,1,0,0</oRu2PrbElemUl5>
    <oRu2PrbElemUl6>216,36,0,14,7,1,1,9,1,0,0</oRu2PrbElemUl6>
    <oRu2PrbElemU17>252,21,0,14,8,1,1,9,1,0,0</oRu2PrbElemU17>
    <!-- extType = 11 -->
    <oRu2ExtBfwUl0>2,24,0,0,9,1</oRu2ExtBfwUl0>
    <oRu2ExtBfwUl1>2,24,0,0,9,1</oRu2ExtBfwUl1>
    <oRu2nPrbElemSrs>1</oRu2nPrbElemSrs>
    <!--nRBStart, nRBSize, nStartSymb, numSymb, nBeamIndex, bf weight update,
compMethod, iqWidth, BeamFormingType, Scalefactor, REMask -->
    <!-- weight base beams -->
    <oRu2PrbElemSrs0>0,273,0,14,1,1,1,9,1,0,0</oRu2PrbElemSrs0>
</XranConfig>
```

4. Modify ./bin/nr5g/gnb/l1/dpdk.sh (change PCIe addresses from VFs).

```
ethDevice0=0000:51:01.0
ethDevice1=0000:51:01.1
ethDevice2=0000:51:01.2
ethDevice3=0000:51:01.3
ethDevice4=0000:51:01.4
ethDevice5=0000:51:01.5
ethDevice6=
ethDevice7=
ethDevice8=
ethDevice9=
ethDevice10=
ethDevice10=
ethDevice11=
fecDevice0=0000:92:00.0
```

5. Use configuration of test mac per:

```
/bin/nr5g/gnb/testmac/icelake-sp/icxsp_mu1_100mhz_mmimo_64x64_hton_xran.cfg
phystart 4 0 100200
TEST_FD, 3370, 3, fd/mu1_100mhz/376/fd_testconfig_tst376.cfg,
fd/mu1_100mhz/377/fd_testconfig_tst377.cfg,
fd/mu1_100mhz/377/fd_testconfig_tst377.cfg
```

6. To execute l1app with O-DU functionality according to O-RAN Fronthaul specification, enter:

```
[root@xran flexran] cd ./bin/nr5g/gnb/l1
    ./l1.sh -xranmmimo
Radio mode with XRAN - Sub6 100Mhz Massive-MIMO (CatB)
DPDK WLS MODE
kernel.sched_rt_runtime_us = -1
kernel.shmmax = 2147483648
kernel.shmall = 2147483648
Note: Forwarding request to 'systemctl disable irqbalance.service'.
using configuration file phycfg_xran.xml
using configuration file xrancfg_sub6_mmimo.xml
```



```
>> Running... ./llapp table 0 1 --cfgfile=phycfg xran.xml --
xranfile=xrancfg sub6 mmimo.xml
FlexRAN SDK bblib layerdemapping 5gnr version #DIRTY#
FlexRAN SDK bblib_layermapping_5gnr version #DIRTY#
FlexRAN SDK bblib_cestimate_5gnr_version #DIRTY#
FlexRAN SDK bblib_pucch_cestimate_5gnr version #DIRTY#
FlexRAN SDK bblib_llr_demapping version #DIRTY#
FlexRAN SDK bblib_pdcch_remapping_5gnr_version version #DIRTY#
FlexRAN SDK bblib_reed_muller version #DIRTY#
FlexRAN SDK bblib_lte_modulation version #DIRTY#
FlexRAN SDK bblib_polar_decoder_5gnr version #DIRTY#
FlexRAN SDK bblib polar rate dematching 5gnr version #DIRTY#
FlexRAN SDK bblib PhaseNoise 5G version #DIRTY#
FlexRAN SDK bblib mimo mmse detection 5gnr version #DIRTY#
FlexRAN SDK bblib fd correlation version #DIRTY#
FlexRAN SDK bblib scramble 5gnr version #DIRTY#
FlexRAN SDK bblib pucch equ 5qnr version #DIRTY#
FlexRAN SDK bblib ta compensation version 5qnr #DIRTY#
FlexRAN SDK bblib_polar_encoder_5gnr version #DIRTY#
FlexRAN SDK bblib_prach_5gnr version #DIRTY#
FlexRAN SDK bblib_fft_ifft version #DIRTY#
FlexRAN SDK bblib_pucch_5gnr version #DIRTY#
FlexRAN SDK bblib_lte_ldpc_decoder version #DIRTY#
FlexRAN SDK bblib_lte_ldpc_encoder version #DIRTY#
FlexRAN SDK bblib_lte_LDPC_ratematch version #DIRTY#
FlexRAN SDK bblib_lte_rate_dematching_5gnr version #DIRTY#
FlexRAN SDK bblib_common version #DIRTY#
FlexRAN SDK bblib lte crc version #DIRTY#
FlexRAN SDK bblib lte dft idft version #DIRTY#
FlexRAN SDK bblib irc rnn calculation 5gnr version #DIRTY#
FlexRAN SDK bblib mmse irc mimo 5gnr version #DIRTY#
FlexRAN SDK bblib srs cestimate 5gnr version #DIRTY#
FlexRAN SDK bblib_zf_matrix_gen version #DIRTY#
FlexRAN SDK bblib_beamforming_dl_expand version #DIRTY#
5GNR PHY Application
File[phycfg xran.xml] Version: 20.08
 --version=20.08
 --successiveNoApi=15
 --wls dev name=wls0
 --wlsMemorySize=0x3F600000
 --dlIqLog=0
 --ullqLog=0
 --iqLogDumpToFile=0
 --phyMlog=1
 --phyStats=1
 --dpdkMemorySize=18432
 --dpdkIovaMode=0
 --dpdkBasebandFecMode=1
 --dpdkBasebandDevice=0000:92:00.0
 --radioEnable=4
 --ferryBridgeMode=1
 --ferryBridgeEthPort=1
 --ferryBridgeSyncPorts=0
 --ferryBridgeOptCableLoopback=0
 --radioCfg0PCIeEthDev=0000:19:00.0
 --radioCfg0DpdkRx=1
```



```
--radioCfg0DpdkTx=2
--radioCfg0TxAnt=2
--radioCfg0RxAnt=2
--radioCfg0RxAgc=0
--radioCfg0NumCell=1
--radioCfg0Cell0PhyId=0
--radioCfg0Cell1PhyId=1
--radioCfg0Cell2PhyId=2
--radioCfq0Cell3PhyId=3
--radioCfg0Cell4PhyId=4
--radioCfg0Cell5PhyId=5
--radioCfg0riuMac=11:22:33:44:55:66
--radioCfg1PCIeEthDev=0000:03:00.1
--radioCfg1DpdkRx=1
--radioCfg1DpdkTx=1
--radioCfg1TxAnt=4
--radioCfg1RxAnt=4
--radioCfg1RxAgc=0
--radioCfg1NumCell=1
--radioCfg1Cell0PhyId=2
--radioCfg1Cell1PhyId=3
--radioCfg1Cell2PhyId=2
--radioCfg1Cell3PhyId=3
--radioCfg1riuMac=ac:1f:6b:2c:9f:07
--radioCfg2PCIeEthDev=0000:05:00.0
--radioCfg2DpdkRx=10
--radioCfg2DpdkTx=11
--radioCfg2TxAnt=4
--radioCfg2RxAnt=4
--radioCfg2RxAgc=0
--radioCfg2NumCell=2
--radioCfg2Cell0PhyId=4
--radioCfg2Cell1PhyId=5
--radioCfg2Cell2PhyId=2
--radioCfg2Cell3PhyId=3
--radioCfg2riuMac=ac:1f:6b:2c:9f:07
--radioCfg3PCIeEthDev=0000:05:00.1
--radioCfq3DpdkRx=12
--radioCfg3DpdkTx=13
--radioCfg3TxAnt=4
--radioCfg3RxAnt=4
--radioCfg3RxAgc=0
--radioCfg3NumCell=2
--radioCfg3Cell0PhyId=6
--radioCfg3Cell1PhyId=7
--radioCfg3Cell2PhyId=2
--radioCfg3Cell3PhyId=3
--radioCfg3riuMac=ac:1f:6b:2c:9f:07
--radioCfg4PCIeEthDev=0000:00:08.0
--radioCfg4DpdkRx=14
--radioCfq4DpdkTx=15
--radioCfg4TxAnt=4
--radioCfg4RxAnt=4
--radioCfg4RxAgc=0
--radioCfg4NumCell=2
--radioCfg4Cell0PhyId=8
--radioCfg4Cell1PhyId=9
--radioCfq4Cell2PhyId=2
--radioCfg4Cell3PhyId=3
--radioCfg4riuMac=ac:1f:6b:2c:9f:07
--radioCfg5PCIeEthDev=0000:08:00.0
--radioCfg5DpdkRx=16
```



```
--radioCfg5DpdkTx=16
--radioCfg5TxAnt=4
--radioCfg5RxAnt=4
--radioCfg5RxAgc=0
--radioCfg5NumCell=2
--radioCfg5Cell0PhyId=10
--radioCfg5Cell1PhyId=11
--radioCfg5Cell2PhyId=2
--radioCfq5Cell3PhyId=3
--radioCfg5riuMac=ac:1f:6b:2c:9f:07
--radioCfg6PCIeEthDev=0000:00:05.0
--radioCfg6DpdkRx=16
--radioCfg6DpdkTx=16
--radioCfq6TxAnt=4
--radioCfg6RxAnt=4
--radioCfg1RxAgc=0
--radioCfg6NumCell=2
--radioCfg6Cell0PhyId=12
--radioCfg6Cell1PhyId=13
--radioCfg6Cell2PhyId=2
--radioCfg6Cell3PhyId=3
--radioCfg6riuMac=ac:1f:6b:2c:9f:07
--radioCfg7PCIeEthDev=0000:00:06.0
--radioCfq7DpdkRx=16
--radioCfg7DpdkTx=16
--radioCfg7TxAnt=4
--radioCfg7RxAnt=4
--radioCfg7RxAgc=0
--radioCfg7NumCell=2
--radioCfg7Cell0PhvId=14
--radioCfg7Cell1PhyId=15
--radioCfg7Cell2PhyId=2
--radioCfg7Cell3PhyId=3
--radioCfg7riuMac=ac:1f:6b:2c:9f:07
--radioPort0=0
--radioPort1=1
--radioPort2=2
--radioPort3=3
--radioPort4=4
--radioPort5=5
--radioPort6=6
--radioPort7=7
--PdschSymbolSplit=0
--PdschDlWeightSplit=0
--FecEncSplit=4
--PuschChanEstSplit=0
--PuschMmseSplit=0
--PuschLlrRxSplit=0
--PuschUlWeightSplit=0
--FecDecEarlyTermDisable=0
--FecDecNumIter=12
--FecDecSplit=4
--llrOutDecimalDigit=2
--IrcEnableThreshold=-10
--PuschNoiseScale=2
--CEInterpMethod=0
--PucchSplit=0
--SrsCeSplit=0
--prachDetectThreshold=0
--MlogSubframes=128
--MlogCores=40
--MlogSize=10000
```

March 2021



```
--systemThread=2, 0, 0
 --timerThread=0, 96, 0
 -- FpgaDriverCpuInfo=3, 96, 0
 --FrontHaulCpuInfo=3, 96, 0
 --radioDpdkMaster=2, 99, 0
 --BbuPoolSleepEnable=1
 --BbuPoolThreadCorePriority=94
 --BbuPoolThreadCorePolicy=0
--BbuPoolThreadDefault_0_63=0xF0
--BbuPoolThreadDefault_64_127=0x0
 --BbuPoolThreadSrs_0_63=0x0
 --BbuPoolThreadSrs 64 127=0x0
 --BbuPoolThreadDlbeam 0 63=0x0
 --BbuPoolThreadDlbeam 64 127=0x0
 --BbuPoolThreadUrllc=0x100
 --FrontHaulTimeAdvance=7450
 --nEthPorts=462607
 --nPhaseCompFlag=0
 --nFecFpgaVersionMu3=0x20010900
 --nFecFpgaVersionMu0_1=0x0423D420
 --nFhFpgaVersionMu3=\overline{0}x8001000F
 --nFhFpgaVersionMu0 1=0x90010008
 --StreamStats=0
 --StreamIp=10.255.83.5
 --StreamPort=4010
wls dev filename: wls0
phycfg apply: Initialize Radio Interface with XRAN library
Setting FecEncSplit to 1 to run on HW accelerator
Setting FecDecSplit to 1 to run on HW accelerator
File[xrancfg sub6 mmimo.xml] Version: 20.08
 --version=20.08
 --oRuNum=3
 --oRuEthLinkSpeed=25
 --oRuLinesNumber=2
 --oRuCUon1Vf=1
 --PciBusAddoRu0Vf0=0000:51:01.0
 --PciBusAddoRu0Vf1=0000:51:01.1
 --PciBusAddoRu0Vf2=0000:51:01.2
 --PciBusAddoRu0Vf3=0000:51:01.3
 --PciBusAddoRu1Vf0=0000:51:01.2
 --PciBusAddoRu1Vf1=0000:51:01.3
 --PciBusAddoRu1Vf2=0000:51:01.6
 --PciBusAddoRu1Vf3=0000:51:01.7
 --PciBusAddoRu2Vf0=0000:51:01.4
 --PciBusAddoRu2Vf1=0000:51:01.5
 --PciBusAddoRu2Vf2=0000:51:02.2
 --PciBusAddoRu2Vf3=0000:51:02.
 --PciBusAddoRu3Vf0=0000:00:00.0
 --PciBusAddoRu3Vf1=0000:00:00.0
 --PciBusAddoRu3Vf2=0000:00:00.0
 --PciBusAddoRu3Vf3=0000:00:00.0
 --oRuRem0Mac0=00:11:22:33:00:01
 --oRuRem0Mac1=00:11:22:33:00:11
 --oRuRem0Mac2=00:11:22:33:00:21
 --oRuRem0Mac3=00:11:22:33:00:31
 --oRuRem1Mac0=00:11:22:33:01:01
```



```
--oRuRem1Mac1=00:11:22:33:01:11
--oRuRem1Mac2=00:11:22:33:01:21
--oRuRem1Mac3=00:11:22:33:01:31
--oRuRem2Mac0=00:11:22:33:02:01
--oRuRem2Mac1=00:11:22:33:02:11
--oRuRem2Mac2=00:11:22:33:02:21
--oRuRem2Mac3=00:11:22:33:02:31
--oRuRem3Mac0=00:11:22:33:03:01
--oRuRem3Mac1=00:11:22:33:03:11
--oRuRem3Mac2=00:11:22:33:03:21
--oRuRem3Mac3=00:11:22:33:03:31
--oRu0NumCc=1
--oRu0Cc0PhyId=0
--oRu0Cc1PhyId=1
--oRu0Cc2PhyId=2
--oRu0Cc3PhyId=3
--oRu1NumCc=1
--oRu1Cc0PhyId=1
--oRu1Cc1PhyId=1
--oRu1Cc2PhyId=2
--oRu1Cc3PhyId=3
--oRu2NumCc=1
--oRu2Cc0PhyId=2
--oRu2Cc1PhyId=1
--oRu2Cc2PhyId=2
--oRu2Cc3PhyId=3
--xRANThread=22, 96, 0
--xRANWorker=0x3800000, 96, 0
--Category=1
--xranPmdSleep=0
-- Tadv cp d1=25
--T2a min cp dl=285
--T2a_max_cp_d1=429
--T2a_min_cp_u1=285
--T2a_max_cp_u1=429
--T2a_min_up=71
--T2a_max_up=428
--Ta3_min=20
--Ta3 max=32
--MTU=9600
--c_plane_vlan_tag=1
--u plane vlan tag=2
--Tla min cp dl=258
--T1a max cp d1=429
--T1a min cp ul=285
--T1a max cp ul=300
--T1a min up=96
--T1a_max_up=196
--Ta4_min=0
--Ta4 max=75
--EnableCp=1
--DynamicSectionEna=0
--DynamicSectionEnaUL=0
--xRANSFNWrap=1
--xRANNumDLPRBs=0
--xRANNumULPRBs=0
--Gps Alpha=0
--Gps Beta=0
--xranCompMethod=1
--oRu0nPrbElemDl=6
--oRu0PrbElemDl0=0,48,0,14,1,1,1,9,1,0,0
--oRu0PrbElemDl1=48,48,0,14,2,1,1,9,1,0,0
```



```
--oRu0PrbElemD12=96,48,0,14,2,1,1,9,1,0,0
--oRu0PrbElemDl3=144,48,0,14,4,1,1,9,1,0,0
--oRu0PrbElemD14=192,48,0,14,5,1,1,9,1,0,0
--oRuOPrbElemDl5=240,33,0,14,6,1,1,9,1,0,0
--oRu0PrbElemD16=240,33,0,14,7,1,1,9,1,0,0
--oRu0PrbElemDl7=252,21,0,14,8,1,1,9,1,0,0
--oRu0ExtBfwDl0=2,24,0,0,9,1
--oRu0ExtBfwDl1=2,24,0,0,9,1
--oRu0ExtBfwDl2=2,24,0,0,9,1
--oRu0ExtBfwDl3=2,24,0,0,9,1
--oRu0ExtBfwDl4=2,24,0,0,9,1
--oRu0ExtBfwDl5=2,17,0,0,9,1
--oRu0nPrbElemUl=6
--oRu0PrbElemUl0=0,48,0,14,1,1,1,9,1,0,0
--oRuOPrbElemUl1=48,48,0,14,2,1,1,9,1,0,0
--oRu0PrbElemUl2=96,48,0,14,2,1,1,9,1,0,0
--oRu0PrbElemUl3=144,48,0,14,4,1,1,9,1,0,0
--oRu0PrbElemUl4=192,48,0,14,5,1,1,9,1,0,0
--oRu0PrbElemUl5=240,33,0,14,6,1,1,9,1,0,0
--oRu0PrbElemUl6=240,33,0,14,7,1,1,9,1,0,0
--oRu0PrbElemU17=252,21,0,14,8,1,1,9,1,0,0
--oRu0ExtBfwUl0=2,24,0,0,9,1
--oRu0ExtBfwUl1=2,24,0,0,9,1
--oRu0ExtBfwUl2=2,24,0,0,9,1
--oRu0ExtBfwUl3=2,24,0,0,9,1
--oRu0ExtBfwUl4=2,24,0,0,9,1
--oRu0ExtBfwU15=2,17,0,0,9,1
--oRu0nPrbElemSrs=1
--oRuOPrbElemSrs0=0,273,0,14,1,1,1,9,1,0,0
--oRu1nPrbElemDl=2
--oRu1PrbElemDl0=0,48,0,14,0,1,1,9,1,0,0
--oRu1PrbElemDl1=48,48,0,14,2,1,1,9,1,0,0
--oRu1PrbElemD12=96,48,0,14,3,1,1,9,1,0,0
--oRu1PrbElemDl3=144,48,0,14,4,1,1,9,1,0,0
--oRu1PrbElemD14=144,36,0,14,5,1,1,9,1,0,0
--oRu1PrbElemD15=180,36,0,14,6,1,1,9,1,0,0
--oRu1PrbElemD16=216,36,0,14,7,1,1,9,1,0,0
--oRu1PrbElemD17=252,21,0,14,8,1,1,9,1,0,0
--oRu1ExtBfwDl0=2,24,0,0,9,1
--oRu1ExtBfwDl1=2,24,0,0,9,1
--oRulnPrbElemUl=2
--oRu1PrbElemUl0=0,48,0,14,1,1,1,9,1,0,0
--oRu1PrbElemUl1=48,48,0,14,2,1,1,9,1,0,0
--oRu1PrbElemUl2=72,36,0,14,3,1,1,9,1,0,0
--oRulPrbElemUl3=108,36,0,14,4,1,1,9,1,0,0
--oRulPrbElemUl4=144,36,0,14,5,1,1,9,1,0,0
--oRu1PrbElemUl5=180,36,0,14,6,1,1,9,1,0,0
--oRulPrbElemUl6=216,36,0,14,7,1,1,9,1,0,0
--oRu1PrbElemUl7=252,21,0,14,8,1,1,9,1,0,0
--oRu1ExtBfwUl0=2,24,0,0,9,1
--oRu1ExtBfwUl1=2,24,0,0,9,1
--oRu1nPrbElemSrs=1
--oRu1PrbElemSrs0=0,273,0,14,1,1,1,9,1,0,0
--oRu2nPrbElemDl=2
--oRu2PrbElemDl0=0,48,0,14,1,1,1,9,1,0,0
--oRu2PrbElemDl1=48,48,0,14,2,1,1,9,1,0,0
--oRu2PrbElemDl2=96,48,0,14,3,1,1,9,1,0,0
--oRu2PrbElemDl3=144,48,0,14,4,1,1,9,1,0,0
--oRu2PrbElemDl4=144,36,0,14,5,1,1,9,1,0,0
--oRu2PrbElemDl5=180,36,0,14,6,1,1,9,1,0,0
--oRu2PrbElemD16=216,36,0,14,7,1,1,9,1,0,0
--oRu2PrbElemD17=252,21,0,14,8,1,1,9,1,0,0
```



```
--oRu2ExtBfwDl0=2,24,0,0,9,1
--oRu2ExtBfwDl1=2,24,0,0,9,1
--oRu2nPrbElemUl=2
--oRu2PrbElemUl0=0,48,0,14,1,1,1,9,1,0,0
--oRu2PrbElemUl1=48,48,0,14,2,1,1,9,1,0,0
--oRu2PrbElemUl2=72,36,0,14,3,1,1,9,1,0,0
--oRu2PrbElemUl3=108,36,0,14,4,1,1,9,1,0,0
--oRu2PrbElemUl4=144,36,0,14,5,1,1,9,1,0,0
--oRu2PrbElemUl5=180,36,0,14,6,1,1,9,1,0,0
--oRu2PrbElemUl6=216,36,0,14,7,1,1,9,1,0,0
--oRu2PrbElemU17=252,21,0,14,8,1,1,9,1,0,0
--oRu2ExtBfwUl0=2,24,0,0,9,1
--oRu2ExtBfwUl1=2,24,0,0,9,1
--oRu2nPrbElemSrs=1
--oRu2PrbElemSrs0=0,273,0,14,1,1,1,9,1,0,0
timer set tsc freq from clock: System clock (rdtsc) resolution 1496526035 [Hz]
                               Ticks per usec 1496
MLogOpen: filename(11mlog.bin) mlogSubframes (128), mlogCores(40), mlogSize(10000)
mlog_mask (-1)
   mlogSubframes (128), mlogCores(40), mlogSize(10000)
    localMLogTimerInit
       System clock (rdtsc) resolution 1496525824 [Hz] Ticks per us 1496
   MLog Storage: 0x7f7403835100 \rightarrow 0x7f740690b830 [ 51210032 bytes ]
    localMLogFreqReg: 1496. Storing: 1496
   Mlog Open successful
gnb io xran init
num o ru 3 EthLinesNumber 2 where VFs 1 per EthLine
VF[0] 0000:51:01.0 [C+U Plane]
VF[1] 0000:51:01.1 [C+U Plane]
VF[2] 0000:51:01.2 [C+U Plane]
VF[3] 0000:51:01.3 [C+U Plane]
VF[4] 0000:51:01.4 [C+U Plane]
VF[5] 0000:51:01.5 [C+U Plane]
oRu0nPrbElemDl0: oRu0: nRBStart 0,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 1,
bf weight update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):0 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRu0nPrbElemD11: oRu0: nRBStart 48,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 2,
bf weight update 1 compMethod 1, igWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):1 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRu0nPrbElemD12: oRu0: nRBStart 96,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 2,
bf weight update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):2 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRu0nPrbElemDl3: oRu0: nRBStart 144,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 4,
bf_weight_update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):3 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRu0nPrbElemD14: oRu0: nRBStart 192,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 5,
bf weight update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):4 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRu0nPrbElemD15: oRu0: nRBStart 240,nRBSize 33,nStartSymb 0,numSymb 14,nBeamIndex 6,
bf weight update 1 compMethod 1, igWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,17,0,0,9,1):5 numBundPrb 2, numSetBFW 17, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
```

115



```
oRu0nPrbElemUl0: oRu0: nRBStart 0,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 1,
bf weight update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):0 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRu0nPrbElemUl1: oRu0: nRBStart 48,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 2,
bf_weight_update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):1 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRu0nPrbElemUl2: oRu0: nRBStart 96,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 2,
bf weight update 1 compMethod 1, igWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):2 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRu0nPrbElemUl3: oRu0: nRBStart 144,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 4,
bf weight update 1 compMethod 1, igWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):3 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRu0nPrbElemUl4: oRu0: nRBStart 192,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 5,
bf weight update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):4 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRu0nPrbElemUl5: oRu0: nRBStart 240,nRBSize 33,nStartSymb 0,numSymb 14,nBeamIndex 6,
bf_weight_update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,17,0,0,9,1):5 numBundPrb 2, numSetBFW 17, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRu0nPrbElemSrs0: oRu0: nRBStart 0,nRBSize 273,nStartSymb 0,numSymb 14,nBeamIndex 1,
bf_weight_update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
oRulnPrbElemDl0: oRul: nRBStart 0,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 0,
bf weight update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):0 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRulnPrbElemDl1: oRul: nRBStart 48,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 2,
bf weight update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):1 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRulnPrbElemUlO: oRul: nRBStart 0,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 1,
bf_weight_update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):0 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
oRulnPrbElemUll: oRul: nRBStart 48,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 2,
bf weight update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):1 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRulnPrbElemSrs0: oRul: nRBStart 0,nRBSize 273,nStartSymb 0,numSymb 14,nBeamIndex 1,
bf weight update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
oRu2nPrbElemDl0: oRu2: nRBStart 0,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 1,
bf weight update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):0 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRu2nPrbElemD11: oRu2: nRBStart 48,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 2,
bf_weight_update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):1 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRu2nPrbElemUl0: oRu2: nRBStart 0,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 1,
bf weight update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):0 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRu2nPrbElemUl1: oRu2: nRBStart 48,nRBSize 48,nStartSymb 0,numSymb 14,nBeamIndex 2,
bf weight update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
(2,24,0,0,9,1):1 numBundPrb 2, numSetBFW 24, RAD 0, disableBFW 0, bfwIqWidth 9,
bfwCompMeth 1
oRu2nPrbElemSrs0: oRu2: nRBStart 0,nRBSize 273,nStartSymb 0,numSymb 14,nBeamIndex 1,
bf weight update 1 compMethod 1, iqWidth 9 BeamFormingType 1 scaler 0 remask 0x0
```



```
gnb io xran cfg setup successful
xran init: MTU 9600
xran init: MTU 9600
xran init: MTU 9600
PF Eth line speed 25G
PF Eth lines per O-xU port 2
BBDEV_FEC_ACCL_NR5G
hw-accelerated bbdev 0000:92:00.0
total cores 48 c_mask 0x3c00004 core 22 [id] system_core 2 [id] pkt_proc_core 0x3800000 [mask] pkt_aux_core 0 [id] timing_core 22 [id] xran_ethdi_init_dpdk_io: Calling rte_eal_init:wls0 -c 0x3c00004 -n2 --iova-mode=pa --
socket-mem=18432 --socket-limit=18432 --proc-type=auto --file-prefix wls0 -w
0000:00:00.0 -w 0000:92:00.0
EAL: Detected 48 lcore(s)
EAL: Detected 1 NUMA nodes
EAL: Auto-detected process type: PRIMARY
EAL: Multi-process socket /var/run/dpdk/wls0/mp socket
EAL: Selected IOVA mode 'PA'
EAL: No available hugepages reported in hugepages-2048kB
EAL: Probing VFIO support...
EAL: PCI device 0000:92:00.0 on NUMA socket 0
EAL: probe driver: 8086:d8f intel_fpga_5gnr_fec_pf
xran init mbuf pool: socket 0
EAL: PCI device 0000:51:01.0 on NUMA socket 0
      probe driver: 8086:1889 net iavf
initializing port 0 for TX, drv=net_iavf
Port 0 MAC: 00 11 22 33 00 00
Port 0: nb rxd 4096 nb txd 4096
[0] mempool rx 0
[0] mempool small 0
iavf init rss(): RSS is enabled by PF by default
Checking link status portid [0] ... done
Port 0 Link Up - speed 100000 Mbps - full-duplex
EAL: PCI device 0000:51:01.1 on NUMA socket 0
EAL: probe driver: 8086:1889 net_iavf
initializing port 1 for TX, drv=net_iavf
Port 1 MAC: 00 11 22 33 00 10
Port 1: nb_rxd 4096 nb_txd 4096 [1] mempool rx 1
[1] mempool small
iavf init rss(): RSS is enabled by PF by default
Checking link status portid [1] ... done
Port 1 Link Up - speed 100000 Mbps - full-duplex
EAL: PCI device 0000:51:01.2 on NUMA socket 0
EAL: probe driver: 8086:1889 net iavf
initializing port 2 for TX, drv=net_iavf
Port 2 MAC: 00 11 22 33 01 00
Port 2: nb rxd 4096 nb txd 4096
[2] mempool_rx__2
[2] mempool small
iavf init rss(): RSS is enabled by PF by default
Checking link status portid [2] ... done
Port 2 Link Up - speed 100000 Mbps - full-duplex
EAL: PCI device 0000:51:01.3 on NUMA socket 0
EAL: probe driver: 8086:1889 net iavf
initializing port 3 for TX, drv=net iavf
Port 3 MAC: 00 11 22 33 01 10
Port 3: nb rxd 4096 nb txd 4096
[3] mempool rx 3
```

117



```
[3] mempool small 3
iavf init rss(): RSS is enabled by PF by default
Checking link status portid [3]
                                    ... done
Port 3 Link Up - speed 100000 Mbps - full-duplex
EAL: PCI device 0000:51:01.4 on NUMA socket 0
EAL: probe driver: 8086:1889 net_iavf
initializing port 4 for TX, drv=net_iavf
Port 4 MAC: 00 11 22 33 02 00
Port 4: nb_rxd 4096 nb_txd 4096 [4] mempool_rx__4
[4] mempool_small
iavf init rss(): RSS is enabled by PF by default
Checking link status portid [4] ... done
Port 4 Link Up - speed 100000 Mbps - full-duplex
EAL: PCI device 0000:51:01.5 on NUMA socket 0
EAL: probe driver: 8086:1889 net iavf
initializing port 5 for TX, drv=net iavf
Port 5 MAC: 00 11 22 33 02 10
Port 5: nb_rxd 4096 nb_txd 4096
[5] mempool_rx__5
[5] mempool small
iavf init rss(): RSS is enabled by PF by default
Checking link status portid [5]
Port 5 Link Up - speed 100000 Mbps - full-duplex
[ 0] vf 0 local SRC MAC: 00 11 22 33 00 00
[ 0] vf 0 remote DST MAC: 00 11 22 33 00 01
[ 0] vf 1 local SRC MAC: 00 11 22 33 00 10
[ 0] vf 1 remote DST MAC: 00 11 22 33 00 11
[ 1] vf 2 local SRC MAC: 00 11 22 33 01 00
[ 1] vf 2 remote DST MAC: 00 11 22 33 01 01
[ 1] vf 3 local SRC MAC: 00 11 22 33 01 10
[ 1] vf 3 remote DST MAC: 00 11 22 33 01 11
[ 2] vf 4 local SRC MAC: 00 11 22 33 02 00
[ 2] vf 4 remote DST MAC: 00 11 22 33 02 01 [ 2] vf 5 local SRC MAC: 00 11 22 33 02 10 [ 2] vf 5 remote DST MAC: 00 11 22 33 02 11
created dl gen ring up 0
created dl gen ring up
created dl gen ring up
xran init successful, pHandle = 0x7f7393b23040
bbdev init:
Socket ID: 0
FEC is accelerated through BBDEV: 0000:92:00.0
wls_layer_init[wls0] nWlsMemorySize[1063256064]
wls_lib: Open wls0 (DPDK memzone)
wls_lib: WLS_Open 0x43f600000
wls_lib: link: 0 <-> 1 wls_lib: Mode 0
    lib: WLS shared management memzone: wls0
    lib: hugePageSize on the system is 1073741824
wls lib: WLS Alloc [1063256064] bytes
PHY VERSION
```



```
______
Version: #DIRTY#
IMG-date: Aug 5 2020
IMG-time: 18:31:18
FlexRAN BBU pooling version #DIRTY#
FlexRAN SDK bblib layerdemapping 5gnr version #DIRTY#
FlexRAN SDK bblib layermapping 5gnr version #DIRTY#
FlexRAN SDK bblib cestimate 5gnr version #DIRTY#
FlexRAN SDK bblib pucch cestimate 5gnr version #DIRTY#
FlexRAN SDK bblib llr demapping version #DIRTY#
FlexRAN SDK bblib pdcch remapping 5gnr version version #DIRTY#
FlexRAN SDK bblib reed muller version #DIRTY#
FlexRAN SDK bblib lte modulation version #DIRTY#
FlexRAN SDK bblib_polar_decoder_5gnr version #DIRTY#
FlexRAN SDK bblib_polar_rate_dematching_5gnr version #DIRTY#
FlexRAN SDK bblib_PhaseNoise_5G version #DIRTY#
FlexRAN SDK bblib_mimo_mmse_detection_5gnr version #DIRTY#
FlexRAN SDK bblib fd correlation version #DIRTY#
FlexRAN SDK bblib scramble 5qnr version #DIRTY#
FlexRAN SDK bblib pucch equ 5gnr version #DIRTY#
FlexRAN SDK bblib_ta_compensation_version_5gnr #DIRTY#
FlexRAN SDK bblib_polar_encoder_5gnr version #DIRTY#
FlexRAN SDK bblib prach 5gnr version #DIRTY#
FlexRAN SDK bblib fft ifft version #DIRTY#
FlexRAN SDK bblib pucch 5gnr version #DIRTY#
FlexRAN SDK bblib lte crc version #DIRTY#
FlexRAN SDK bblib common version #DIRTY#
Non BBU threads in application
nr5g gnb phy2mac api proc stats thread: [PID: 29438] binding on [CPU 2] [PRIO: 0]
[POLICY: 1]
wls rx handler (non-rt):
                                     [PID: 29445] binding on [CPU 2]
______
PHY>welcome to application console
PHY>
PHY>Received MSG TYPE PHY ADD REMOVE CORE
Processing MSG_TYPE_PHY_ADD_REMOVE_CORE
phy bbupool set core[0] (add): 137170526192 [0x0000001ff0001ff0] Current: 0
[0x00000000000000000]
nr5g_gnb_mac2phy_api_set_options: PDSCH SPLIT[4] nCellMask[0x00000001]
nr5g gnb mac2phy api set options: PDSCH DL WEIGHT SPLIT[4] nCellMask[0x00000001]
nr5g_gnb_mac2phy_api_set_options: PUSCH_CHANEST_SPLIT[2] nCellMask[0x00000001]
nr5g gnb mac2phy api set options: PUSCH MMSE SPLIT[4] nCellMask[0x00000001]
nr5g gnb mac2phy api set options: PUSCH LLR RX SPLIT[2] nCellMask[0x00000001]
nr5g gnb mac2phy api set options: PUSCH UL WEIGHT SPLIT[2] nCellMask[0x00000001]
```



```
nr5g gnb mac2phy api set options: FEC DEC NUM ITER[3] nCellMask[0x00fffffff]
Received MSG TYPE PHY UL IQ SAMPLES
Received MSG TYPE PHY UL IQ SAMPLES
Received MSG TYPE PHY UL IQ SAMPLES
Processing MSG TYPE PHY UL IQ SAMPLES: 0
phydi_read_write_iq_samples: direction[1] nNumerologyMult[2] fftSize[4096, 45864,
SRS: 3276] numSubframe[20] numAntenna[64] numPorts[8] nIsRadioMode[1] carrNum[0]
TimerModeFreqDomain[1] PhaseCompensationEnable[0]
filename in ul iq[/home/vzakharc/master/../master aux/flexran 11 5q test/fd/mul 100mh
z/376/uliq00 tst376.bin] filename in prach iq[]
Processing MSG TYPE PHY UL IQ SAMPLES: 1
phydi read write iq samples: direction[1] nNumerologyMult[2] fftSize[4096, 45864,
SRS: 3276] numSubframe[20] numAntenna[64] numPorts[8] nIsRadioMode[1] carrNum[1]
TimerModeFreqDomain[1] PhaseCompensationEnable[0]
filename in ul iq[/home/vzakharc/master/../master aux/flexran 11 5g test/fd/mul 100mh
z/377/uliq00 tst377.bin] filename in prach iq[]
Processing MSG TYPE PHY UL IQ SAMPLES: 2
phydi read write ig samples: direction[1] nNumerologyMult[2] fftSize[4096, 45864,
SRS: 3276] numSubframe[20] numAntenna[64] numPorts[8] nIsRadioMode[1] carrNum[2]
TimerModeFreqDomain[1] PhaseCompensationEnable[0]
filename_in_ul_iq[/home/vzakharc/master/../master_aux/flexran_l1_5g_test/fd/mu1_100mh
z/377/uliq00_tst377.bin] filename_in_prach_iq[]
Received MSG_TYPE_PHY_CONFIG_REQ: 0
Received MSG TYPE PHY CONFIG REQ: 1
Received MSG TYPE PHY CONFIG REQ:
Processing MSG TYPE PHY CONFIG REQ: 0
phy bbupool init: Changing Core Mask0 [0xf0] to [0x1ff0001ff0]
phy_bbupool_set_config: Using cores: 0x0000001ff0001ff0 for BBU Pool
nBbuPoolSleepEnable: 1
BBU Pooling: queueId = 0, the according nCoreNum = 18, the according cpuSetMask =
0x1ff0001ff0
BBU Pooling: gCoreIdxMap[0] = 4 is available!
BBU Pooling: gCoreIdxMap[1] = 5 is available!
BBU Pooling: gCoreIdxMap[2] = 6 is available!
BBU Pooling: gCoreIdxMap[3] = 7 is available!
BBU Pooling: gCoreIdxMap[4] = 8 is available!
BBU Pooling: gCoreIdxMap[5] = 9 is available!
BBU Pooling: gCoreIdxMap[6] = 10 is available!
BBU Pooling: gCoreIdxMap[7] = 11 is available!
BBU Pooling: gCoreIdxMap[8] = 12 is available!
BBU Pooling: gCoreIdxMap[9] = 28 is available!
BBU Pooling: gCoreIdxMap[10] = 29 is available!
BBU Pooling: gCoreIdxMap[11] = 30 is available!
BBU Pooling: gCoreIdxMap[12] = 31 is available!
BBU Pooling: gCoreIdxMap[13] = 32 is available!
BBU Pooling: gCoreIdxMap[14] = 33 is available!
BBU Pooling: gCoreIdxMap[15] = 34 is available!
BBU Pooling: gCoreIdxMap[16] = 35 is available!
BBU Pooling: gCoreIdxMap[17] = 36 is available!
phy_bbupool_init: Changing SrsCore Mask0 [(nil)] to [0x10000010]
phy_bbupool_init: Changing DlbeamCore Mask0 [(nil)] to [0x7e0]
Massive Mimo Config: nCarrierAggregationLevel[3],
nMassiveMimoSrsCoresMask[0x10000010] nTotalSrsCores[2]
   Setting aside core[4] for SRS
   Setting aside core[28] for SRS
Massive Mimo Config: nCarrierAggregationLevel[3], nMassiveMimoDlbeamCoresMask[0x7e0]
nTotalDlbeamCores[6]
   Setting aside core[5] for DL beam
   Setting aside core[6] for DL beam
   Setting aside core[7] for DL beam
   Setting aside core[8] for DL beam
   Setting aside core[9] for DL beam
```



```
Setting aside core[10] for DL beam
BBU Pooling: taskId = 0 taskName = DL_L1_CONFIG is registered
BBU Pooling: taskId = 1 taskName = DL_L1_PDSCH_TB is registered
BBU Pooling: taskId = 2 taskName = DL_L1_PDSCH_SCRAMBLER is registered
BBU Pooling: taskId = 2 taskName = DL_LI_PDSCH_SCRAMBLER is registered
BBU Pooling: taskId = 3 taskName = DL_LI_PDSCH_SYMBOL_TX is registered
BBU Pooling: taskId = 4 taskName = DL_LI_PDSCH_RS_GEN is registered
BBU Pooling: taskId = 5 taskName = DL_LI_CONTROL_CHANNELS is registered
BBU Pooling: taskId = 6 taskName = UL_LI_CONFIG is registered
BBU Pooling: taskId = 7 taskName = UL_LI_PUSCH_CEO is registered
BBU Pooling: taskId = 8 taskName = UL_LI_PUSCH_CE7 is registered
BBU Pooling: taskId = 9 taskName = UL_LI_PUSCH_MMSEO_PRE is registered
BBU Pooling: taskId = 10 taskName = UL L1 PUSCH MMSE7 PRE is registered
BBU Pooling: taskId = 11 taskName = UL L1 PUSCH MMSEO is registered
BBU Pooling: taskId = 12 taskName = UL L1 PUSCH MMSE7 is registered
BBU Pooling: taskId = 13 taskName = \overline{\text{UL}} LI PUSCH LLR is registered
BBU Pooling: taskId = 14 taskName = UL L1 PUSCH DECODE is registered
BBU Pooling: taskId = 15 taskName = UL_L1_PUSCH_TB is registered
BBU Pooling: taskId = 16 taskName = UL_L1_PUCCH is registered
BBU Pooling: taskId = 17 taskName = UL_L1_PRACH is registered
BBU Pooling: taskId = 18 taskName = UL_L1_SRS is registered
BBU Pooling: taskId = 19 taskName = DL_L1_POST is registered
BBU Pooling: taskId = 20 taskName = UL_L1_POST is registered
BBU Pooling: taskId = 21 taskName = DL_L1_BEAM_WEIGHT_GEN is registered BBU Pooling: taskId = 22 taskName = DL_L1_BEAM_WEIGHT_TX is registered BBU Pooling: taskId = 23 taskName = UL_L1_BEAM_WEIGHT_GEN is registered BBU Pooling: taskId = 24 taskName = UL_L1_BEAM_WEIGHT_TX is registered
BBU Pooling: taskId = 25 taskName = UL L1 SRS CE is registered
BBU Pooling: taskId = 26 taskName = UL L1 SRS REPORT is registered
BBU Pooling: taskId = 27 taskName = UL L1 PUSCH CEO PRE is registered
BBU Pooling: taskId = 28 taskName = UL L1 PUSCH CE7 PRE is registered
BBU Pooling: next taskList of DL_L1_CONFIG: DL_L1_PDSCH_TB
DL L1 PDSCH RS GEN DL L1 CONTROL CHANNELS
BBU Pooling: next taskList of DL L1 PDSCH TB:
                                                                                               N/A
BBU Pooling: next taskList of DL_L1_PDSCH_SCRAMBLER: DL_L1_PDSCH_SYMBOL_TX
BBU Pooling: next taskList of DL_L1_PDSCH_SYMBOL_TX: DL_L1_POST
BBU Pooling: next taskList of DL_L1_PDSCH_RS_GEN: DL_L1_PDSCH_SYMBOL_TX
BBU Pooling: next taskList of DL_L1_CONTROL_CHANNELS: DL_L1_POST
BBU Pooling: next taskList of UL_L1_CONFIG: UL_L1_POST
UL L1 BEAM WEIGHT GEN
BBU Pooling: next taskList of UL L1 PUSCH CEO: UL L1 PUSCH MMSEO
UL L1 PUSCH MMSE7
BBU Pooling: next taskList of UL L1 PUSCH CE7: UL L1 PUSCH MMSE7
BBU Pooling: next taskList of UL 11 PUSCH MMSE0 PRE: UL 11 PUSCH MMSE0
UL L1 PUSCH MMSE7
BBU Pooling: next taskList of UL L1 PUSCH MMSE7 PRE: UL L1 PUSCH MMSE7
BBU Pooling: next taskList of UL_L1_PUSCH_MMSE0: UL_L1_PUSCH_LLR
BBU Pooling: next taskList of UL_L1_PUSCH_MMSE7: UL_L1_PUSCH_LLR
BBU Pooling: next taskList of UL_L1_PUSCH_LLR: UL_L1_PUSCH_DECODE
BBU Pooling: next taskList of UL L1 PUSCH DECODE:
BBU Pooling: next taskList of UL_L1_PUSCH_TB: UL_L1_POST
BBU Pooling: next taskList of UL_L1_PUCCH: UL_L1_POST
BBU Pooling: next taskList of UL_L1_PRACH: UL_L1_POST
BBU Pooling: next taskList of UL_L1_SRS: UL_L1_SRS_CE
BBU Pooling: next taskList of DL_L1_POST: N/A
BBU Pooling: next taskList of
                                                     UL L1 POST:
                                                                                                N/A
BBU Pooling: next taskList of DL L1 BEAM WEIGHT GEN: DL L1 BEAM WEIGHT TX
BBU Pooling: next taskList of DL L1 BEAM WEIGHT TX:
BBU Pooling: next taskList of UL L1 BEAM WEIGHT GEN: UL L1 BEAM WEIGHT TX
```

Software Architecture Specification



```
BBU Pooling: next taskList of UL L1 BEAM WEIGHT TX:
                                                              UL L1 POST
BBU Pooling: next taskList of
                                  UL L1 SRS CE: UL L1 SRS REPORT
BBU Pooling: next taskList of UL L1 SRS REPORT:
BBU Pooling: next taskList of UL L1 PUSCH CE0 PRE: UL L1 PUSCH CE0
UL_L1 PUSCH CE7
BBU Pooling: next taskList of UL L1 PUSCH CE7 PRE: UL L1 PUSCH CE7
enter RtThread Launch
Allocated gpThreadWorker[coreIdx: 0][CoreNum: 4]: [0x7f738c000b70]
Allocated gpThreadWorker[coreIdx: 1][CoreNum: 5]: [0x7f738c000e20] Allocated gpThreadWorker[coreIdx: 2][CoreNum: 6]: [0x7f738c0010d0]
Allocated gpThreadWorker[coreIdx: 3][CoreNum: 7]: [0x7f738c001380]
Allocated gpThreadWorker[coreIdx: 4][CoreNum: 8]: [0x7f738c001630]
Allocated gpThreadWorker[coreIdx: 5][CoreNum: 9]: [0x7f738c0018e0]
launching Thread 1 Queue 0 uCoreIdx 1 CoreId 5 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
launching Thread 0 Queue 0 uCoreIdx 0 CoreId 4 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
launching Thread 2 Queue 0 uCoreIdx 2 CoreId 6 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
launching Thread 3 Queue 0 uCoreIdx 3 CoreId 7 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
Allocated gpThreadWorker[coreIdx: 6][CoreNum: 10]: [0x7f738c001b90]
launching Thread 4 Queue 0 uCoreIdx 4 CoreId 8 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
launching Thread 5 Queue 0 uCoreIdx 5 CoreId 9 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
Allocated gpThreadWorker[coreIdx: 7][CoreNum: 11]: [0x7f738c001e40]
Allocated gpThreadWorker[coreIdx: 8][CoreNum: 12]: [0x7f738c0020f0]
bbupool_core_main: the server's coreNum = 48, the nCore = 18,nRtCoreMask =
0x1ff0001ff0, the nFeIfCore = 0,nFeIfCoreMask = 0x0
bbupool_core_main pthread_setaffinity_np succeed: coreId = 2, result = 0
Allocated gpThreadWorker[coreIdx: 9][CoreNum: 28]: [0x7f738c0023a0]
launching Thread 6 Queue 0 uCoreIdx 6 CoreId 10 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
Allocated gpThreadWorker[coreIdx: 10][CoreNum: 29]: [0x7f738c002650]
launching Thread 7 Queue 0 uCoreIdx 7 CoreId 11 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
Allocated gpThreadWorker[coreIdx: 11][CoreNum: 30]: [0x7f738c002900]
launching Thread 8 Queue 0 uCoreIdx 8 CoreId 12 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
launching Thread 9 Queue 0 uCoreIdx 9 CoreId 28 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
Allocated gpThreadWorker[coreIdx: 12][CoreNum: 31]: [0x7f738c002bb0]
Allocated gpThreadWorker[coreIdx: 13][CoreNum: 32]: [0x7f738c002e60]
launching Thread 10 Queue 0 uCoreIdx 10 CoreId 29 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
launching Thread 11 Queue 0 uCoreIdx 11 CoreId 30 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
Allocated gpThreadWorker[coreIdx: 14][CoreNum: 33]: [0x7f738c003110]
```



```
Allocated qpThreadWorker[coreIdx: 15][CoreNum: 34]: [0x7f738c0033c0]
launching Thread 12 Queue 0 uCoreIdx 12 CoreId 31 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
Allocated gpThreadWorker[coreIdx: 16][CoreNum: 35]: [0x7f738c003670]
launching Thread 13 Queue 0 uCoreIdx 13 CoreId 32 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
Allocated gpThreadWorker[coreIdx: 17][CoreNum: 36]: [0x7f738c003920]
18 thread associated with queue 0:coreIdx 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17
Leave RtThread Launch
launching Thread 14 Queue 0 uCoreIdx 14 CoreId 33 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
launching Thread 15 Queue 0 uCoreIdx 15 CoreId 34 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
launching Thread 16 Queue 0 uCoreIdx 16 CoreId 35 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
launching Thread 17 Queue 0 uCoreIdx 17 CoreId 36 Priority 94 Policy 1 nRtCoreSleep 1
nFriendCnt 0 nCurrentSfIdx -1
nr5g gnb mac2phy api proc print phy init [0]:
    nCarrierIdx: 0
    nDMRSTypeAPos: 2
    nPhyCellId: 50
   nDLAbsFrePointA: 3500000
   nULAbsFrePointA: 3500000
    nDLBandwidth: 100
    nULBandwidth: 100
   nDLFftSize: 4096
   nULFftSize: 4096
   nSSBPwr: 0
   nSSBAbsFre: 0
   nSSBPeriod: 4
    nSSBSubcOffset: 0
    nSSBPrbOffset: 0
    nMIB[0]: 255
   nMIB[1]: 255
    nMIB[2]: 255
    nDLK0: 0
   nSSBMask[0]: 0
   nSSBMask[1]: 0
   nNrOfTxAnt: 64
   nNrOfRxAnt: 64
    nNrOfDLPorts: 16
   nNrOfULPorts: 8
    nCarrierAggregationLevel: 2
    nFrameDuplexType: 1
    nSubcCommon:
    nTddPeriod: 10 (TDD)
    SlotConfig:
        Slot Sym 0 Sym 1 Sym 2 Sym 3 Sym 4 Sym 5 Sym 6 Sym 7 Sym 8 Sym 9 Sym10 Sym11
Sym12 Sym13
      DL
```



```
2
              DL
   nPrachConfIdx: 100
   nPrachSubcSpacing: 1
   nPrachZeroCorrConf: 1
   nPrachRestrictSet: 0
   nPrachRootSeqIdx: 0
   nPrachFregStart: 100
   nPrachFdm: 1
   nPrachSsbRach: 0
   nPrachNrofRxRU: 4
   nCyclicPrefix: 0
   nGroupHopFlag: 0
   nSequenceHopFlag: 0
   nHoppingId: 0
   nUrllcCapable: 0
   nUrllcMiniSlotMask: 1 (0x00000001)
read_table: File table/common/pss_table.bin of size 381 read_size: 381
read_table: File table/common/sss_table.bin of size 128016 read_size: 128016
read_table: File table/common/srs_zc_36_plus.bin of size 905916 read_size: 905916
read_table: File table/common/pucch_zc_36_plus.bin of size 383040 read_size: 383040
read table: File table/common/srs wiener sinc comb2.bin of size 81216 read size:
read table: File table/common/srs wiener sinc comb4.bin of size 81216 read size:
BBU Pooling Info: maximum period length was configured, preMaxSF = 20480, postMasSF =
20480
set slot type SlotPattern:
                             3
                                  4
                                       5
                                                 7
    Slot:
              0 1 2
                                            6
              DL DL DL SP UL DL DL DL
PHYDI-INIT[from 2] PhyInstance: 0
Processing MSG TYPE PHY CONFIG REQ: 1
nr5g_gnb_mac2phy_api_proc_print_phy_init [1]:
   nCarrierIdx: 1
   nDMRSTypeAPos: 2
   nPhyCellId: 50
   nDLAbsFrePointA: 3500000
    nULAbsFrePointA: 3500000
   nDLBandwidth: 100
   nULBandwidth: 100
   nDLFftSize: 4096
   nULFftSize: 4096
   nSSBPwr: 0
   nSSBAbsFre: 0
    nSSBPeriod: 4
    nSSBSubcSpacing: 1
```



```
nSSBSubcOffset: 0
   nSSBPrbOffset: 0
   nMIB[0]: 255
   nMIB[1]: 255
   nMIB[2]: 255
   nDLK0: 0
   nULK0: 0
   nSSBMask[0]: 0
   nSSBMask[1]: 0
   nNrOfTxAnt: 64
   nNrOfRxAnt: 64
   nNrOfDLPorts: 16
   nNrOfULPorts: 8
   nCarrierAggregationLevel: 2
   nFrameDuplexType: 1
   nTddPeriod: 10 (TDD)
    SlotConfig:
       Slot Sym 0 Sym 1 Sym 2 Sym 3 Sym 4 Sym 5 Sym 6 Sym 7 Sym 8 Sym 9 Sym10 Sym11
Sym12 Sym13
           1
      DL
           3
           4
               DL
                     DL
                           DL
                                 DL
                                       DL
                                             DL
                                                   DL
                                                         DL
                                                                DL
                                                                      DL
                                                                            DL
                                                                                  DL
   nPrachConfIdx: 100
   nPrachSubcSpacing: 1
   nPrachZeroCorrConf: 1
   nPrachRestrictSet: 0
   nPrachRootSeqIdx: 0
   nPrachFreqStart: 100
   nPrachFdm: 1
   nPrachSsbRach: 0
   nPrachNrofRxRU: 4
   nCyclicPrefix: 0
   nGroupHopFlag: 0
   nSequenceHopFlag: 0
   nHoppingId: 0
    nUrllcCapable: 0
    nUrllcMiniSlotMask: 1 (0x0000001)
BBU Pooling Info: maximum period length was configured, preMaxSF = 20480, postMasSF =
set slot type SlotPattern:
    Slot:
                              3
                                    4
                                              6
                                                   7
                                                        8
                                                             9
       0
                              SP
                                        DL
                                             DL
                                                  DL
                                                       SP
```



```
PHYDI-INIT[from 2] PhyInstance: 1
Processing MSG TYPE PHY CONFIG REQ: 2
nr5g gnb mac2phy api proc print phy init [2]:
    nCarrierIdx: 2
    nDMRSTypeAPos: 2
    nPhyCellId: 50
    nDLAbsFrePointA: 3500000
    nULAbsFrePointA: 3500000
    nDLBandwidth: 100
    nULBandwidth: 100
    nDLFftSize: 4096
    nULFftSize: 4096
    nSSBPwr: 0
    nSSBAbsFre: 0
    nSSBPeriod: 4
    nSSBSubcSpacing: 1
    nSSBSubcOffset: 0
    nSSBPrbOffset: 0
   nMIB[0]: 255
   nMIB[1]: 255
   nMIB[2]: 255
   nDLK0: 0
    nSSBMask[0]: 0
    nSSBMask[1]: 0
    nNrOfTxAnt: 64
    nNrOfRxAnt: 64
    nNrOfDLPorts: 16
    nNrOfULPorts: 8
    nCarrierAggregationLevel: 2
    nFrameDuplexType: 1
    nTddPeriod: 10 (TDD)
    SlotConfig:
        Slot Sym 0 Sym 1 Sym 2 Sym 3 Sym 4 Sym 5 Sym 6 Sym 7 Sym 8 Sym 9 Sym10 Sym11
Sym12 Sym13
               DL
                     DL
                           DL
UL
      UL
           5
           6
               DL
                     DL
                           DL
                                 DL
                                        DL
                                              DL
                                                    DL
                                                          DL
                                                                DL
                                                                      DL
           9
UL
     UL
    nPrachConfIdx: 100
    nPrachSubcSpacing: 1
    nPrachZeroCorrConf: 1
    nPrachRestrictSet: 0
    nPrachRootSeqIdx: 0
```



```
nPrachFreqStart: 100
    nPrachFdm: 1
    nPrachSsbRach: 0
    nPrachNrofRxRU: 4
    nCyclicPrefix: 0
    nGroupHopFlag: 0
    nSequenceHopFlag: 0
    nUrllcCapable: 0
    nUrllcMiniSlotMask: 1 (0x00000001)
BBU Pooling Info: maximum period length was configured, preMaxSF = 20480, postMasSF =
20480
set_slot_type SlotPattern:
    Slot: 0 1 2 3 4 5 6 7 8 0 DL DL DL SP UL DL DL SP
               DL DL DL SP UL DL DL DL SP UL
PHYDI-INIT[from 2] PhyInstance: 2
Global Variables:
gCarrierAggLevel:
gCarrierAggLevelInit:
gSupportedAVX2
Received MSG TYPE PHY START REQ: 0
Received MSG TYPE PHY START REQ: 1
Received MSG TYPE PHY START REQ: 2
Processing MSG TYPE PHY_START_REQ: 0
di open port 0
xran_init_vfs_mapping: p 0 vf 0
xran_init_vfs_mapping: p 0 vf 1
XRAN_UP_VF: 0x0000
xran_timing_source_thread [CPU 22] [PID: 29437]
xran_open [CPU 2] [PID: 29437]
Waithing on Timing thread...
TTI interval 500 [us]
Start C-plane DL 71 us after TTI [trigger on sym 2]
Start C-plane UL 200 us after TTI [trigger on sym 6]
Start U-plane DL 196 us before OTA [offset in sym -5]
Start U-plane UL 75 us OTA [offset in sym 3]
C-plane to U-plane delay 125 us after TTI
Start Sym timer 35714 ns
di open port 1
xran_init_vfs_mapping: p 1 vf 2
xran_init_vfs_mapping: p 1 vf 3
Start C-plane DL 71 us after TTI [trigger on sym 2]
Start C-plane UL 200 us after TTI [trigger on sym 6]
Start U-plane DL 196 us before OTA [offset in sym -5]
Start U-plane UL 75 us OTA [offset in sym 3]
C-plane to U-plane delay 125 us after TTI
Start Sym timer 35714 ns xran_open [CPU 2] [PID: 29437]
Waithing on Timing thread...
di open port 2
xran init vfs mapping: p 2 vf 4
xran init vfs mapping: p 2 vf 5
Start C-plane DL 71 us after TTI [trigger on sym 2]
```



```
Start C-plane UL 200 us after TTI [trigger on sym 6]
Start U-plane DL 196 us before OTA [offset in sym -5]
Start U-plane UL 75 us OTA
                             [offset in sym 3]
C-plane to U-plane delay 125 us after TTI
Start Sym timer 35714 ns
O-XU 0
HW
Num cores 4
Num ports 3
O-RU Cat
O-RU CC
O-RU eAxC 16
p:0 XRAN JOB TYPE CP DL worker id 1
p:0 XRAN JOB TYPE CP UL worker id 1
p:1 XRAN JOB TYPE CP DL worker id 1
p:1 XRAN JOB TYPE CP UL worker id 1
p:2 XRAN JOB TYPE CP DL worker id 1
p:2 XRAN JOB TYPE CP UL worker id 1
p:1 XRAN JOB TYPE CP DL worker id 2
p:1 XRAN_JOB_TYPE_CP_UL worker id 2
p:2 XRAN_JOB_TYPE_CP_DL worker id 2
p:2 XRAN_JOB_TYPE_CP_UL worker id 2
xran_generic_worker_thread [CPU 23] [PID: 29437]
spawn worker 0 core 23
xran generic worker thread [CPU 24] [PID: 29437]
spawn worker 1 core 24
xran generic worker thread [CPU 25] [PID: 29437]
spawn worker 2 core 25
xran_open [CPU 2] [PID: 29437]
Waithing on Timing thread...
mem mgr display size:
    Num Memory Alloc: 38,294
    Total Memory Size: 20,049,968,118
PHYDI-START[from 2] PhyInstance: 0, Mode: 4, Count: 100207, Period: 0, NumSlotPerSfn:
PHYDI-START[from 2] PhyInstance: 1, Mode: 4, Count: 100207, Period: 0, NumSlotPerSfn:
20
PHYDI-START[from 2] PhyInstance: 2, Mode: 4, Count: 100207, Period: 0, NumSlotPerSfn:
20
Setting nMultiCellModeDelay: 40000
nr5g anb urllc register call backs: nTimerMode[0] nUrllcMiniSlotMask[0]
port [0] gnb io xran start: gGnbIoXranStarted[0] CC 3 Ant 16 AntElm 64 [Cell:
nNrOfDLPorts 16 nNrOfULPorts 8]
port 0 has 1 CCs
port 0 cc id 0 is phy id 0
XRAN front haul xran mm init
xran_sector_get_instances [0]: CC 0 handle 0x7f6fe7383280
Handle: 0xee1c8e0 Instance: 0x7f6fe7383280
gnb io xran start [0]: CC 0 handle 0x7f6fe7383280
Sucess xran mm init Instance 0x7f6fe7383280
nSectorNum 1
ru 0 cc 0 idx 0: [ handle 0x7f6fe7383280 0 0 ] [nPoolIndex 0] nNumberOfBuffers 8960
nBufferSize 14432
CC: [ handle 0x7f6fe7383280 ru 0 cc idx 0 ] [nPoolIndex 0] mb pool 0x44c493480
ru_0_cc_0_idx_1: [ handle 0x7f6fe7383280 0 0 ] [nPoolIndex 1] nNumberOfBuffers_286720
nBufferSize 32
CC:[ handle 0x7f6fe7383280 ru 0 cc idx 0 ] [nPoolIndex 1] mb pool 0x444381640
```



```
ru 0 cc 0 idx 2: [ handle 0x7f6fe7383280 0 0 ] [nPoolIndex 2] nNumberOfBuffers 8960
nBufferSize 12560
CC:[ handle 0x7f6fe7383280 ru 0 cc idx 0 ] [nPoolIndex 2] mb pool 0x443dff2c0
ru_0_cc_0_idx_3: [ handle 0x7f6fe7383280 0 0 ] [nPoolIndex 3] nNumberOfBuffers 8960
nBufferSize 14432
CC:[ handle 0x7f6fe7383280 ru 0 cc_idx 0 ] [nPoolIndex 3] mb pool 0x443c5cf40
 \texttt{ru\_0\_cc\_0\_idx\_4:} \ [ \ \texttt{handle} \ \ \texttt{0x7f6fe7\overline{3}83280} \ \ \texttt{0} \ \ \texttt{0} \ \ ] \ \ [\texttt{nPoolIndex} \ \ \texttt{4}] \ \ \texttt{nNumberOfBuffers} \ \ 286720 
nBufferSize 32
CC:[ handle 0x7f6fe7383280 ru 0 cc idx 0 ] [nPoolIndex 4] mb pool 0x443ababc0
ru 0 cc 0 idx 5: [ handle 0x7f6fe7383280 0 0 ] [nPoolIndex 5] nNumberOfBuffers 8960
nBufferSize 12560
CC:[ handle 0x7f6fe7383280 ru 0 cc idx 0 ] [nPoolIndex 5] mb pool 0x443538840
ru 0 cc 0 idx 6: [ handle 0x7f6fe7383280 0 0 ] [nPoolIndex 6] nNumberOfBuffers 8960
nBufferSize 8192
CC:[ handle 0x7f6fe7383280 ru 0 cc idx 0 ] [nPoolIndex 6] mb pool 0x4433964c0
ru 0 cc 0 idx 7: [ handle 0x7f6fe7383280 0 0 ] [nPoolIndex 7] nNumberOfBuffers 35840
nBufferSize 14432
CC: [ handle 0x7f6fe7383280 ru 0 cc idx 0 ] [nPoolIndex 7] mb pool 0x4431f4140
ru 0 cc 0 idx 8: [ handle 0x7f6fe7383280 0 0 ] [nPoolIndex 8] nNumberOfBuffers
1146880 nBufferSize 32
CC:[ handle 0x7f6fe7383280 ru 0 cc_idx 0 ] [nPoolIndex 8] mb pool 0x442ff1dc0
ru_0_cc_0_idx_9: [ handle 0x7f6fe7383280 0 0 ] [nPoolIndex 9] nNumberOfBuffers 35840
nBufferSize 12560
CC:[ handle 0x7f6fe7383280 ru 0 cc idx 0 ] [nPoolIndex 9] mb pool 0x441e6fa40
port [0] gnb io xran init cp
port [0] init xran successfully
port [1] gnb io xran start: gGnbIoXranStarted[0] CC 3 Ant 16 AntElm 64 [Cell:
nNrOfDLPorts 16 nNrOfULPorts 81
port 1 has 1 CCs
port 1 cc id 0 is phy id 1
XRAN front haul xran mm init
xran sector get instances [1]: CC 0 handle 0x7f6fe7383380
Handle: 0xee1c940 Instance: 0x7f6fe7383380
gnb_io_xran_start [1]: CC 0 handle 0x7f6fe7383380
Sucess xran mm init Instance 0x7f6fe7383280
nSectorNum 1
ru_1_cc_0_idx_0: [ handle 0x7f6fe7383380 1 0 ] [nPoolIndex 0] nNumberOfBuffers 8960
nBufferSize 14432
CC:[ handle 0x7f6fe7383380 ru 1 cc idx 0 ] [nPoolIndex 0] mb pool 0x2a1525740
ru 1 cc 0 idx 1: [ handle 0x7f6fe7383380 1 0 ] [nPoolIndex 1] nNumberOfBuffers 286720
nBufferSize 32
CC:[ handle 0x7f6fe7383380 ru 1 cc idx 0 ] [nPoolIndex 1] mb pool 0x299413900
ru 1 cc 0 idx 2: [ handle 0x7f6fe7383380 1 0 ] [nPoolIndex 2] nNumberOfBuffers 8960
nBufferSize 12560
CC: [ handle 0x7f6fe7383380 ru 1 cc idx 0 ] [nPoolIndex 2] mb pool 0x28f1112c0
ru 1 cc 0 idx 3: [ handle 0x7f6fe7383380 1 0 ] [nPoolIndex 3] nNumberOfBuffers 8960
nBufferSize 14432
CC:[ handle 0x7f6fe7383380 ru 1 cc idx 0 ] [nPoolIndex 3] mb pool 0x287f4fb80
ru 1 cc 0 idx 4: [ handle 0x7f6fe7\overline{3}83380 1 0 ] [nPoolIndex 4] nNumberOfBuffers 286720
nBufferSize 32
CC:[ handle 0x7f6fe7383380 ru 1 cc_idx 0 ] [nPoolIndex 4] mb pool 0x27fe3dd40
ru_1_cc_0_idx_5: [ handle 0x7f6fe7383380 1 0 ] [nPoolIndex 5] nNumberOfBuffers 8960
nBufferSize 12560
CC:[ handle 0x7f6fe7383380 ru 1 cc idx 0 ] [nPoolIndex 5] mb pool 0x275b3b700
ru 1 cc 0 idx 6: [ handle 0x7f6fe7383380 1 0 ] [nPoolIndex 6] nNumberOfBuffers 8960
nBufferSize 8192
CC:[ handle 0x7f6fe7383380 ru 1 cc_idx 0 ] [nPoolIndex 6] mb pool 0x26e979fc0
ru 1 cc 0 idx 7: [handle 0x7f6fe7383380 1 0 ] [nPoolIndex 7] nNumberOfBuffers 35840
nBufferSize 14432
CC:[ handle 0x7f6fe7383380 ru 1 cc idx 0 ] [nPoolIndex 7] mb pool 0x269ce9980
ru 1 cc 0 idx 8: [ handle 0x7f6fe7383380 1 0 ] [nPoolIndex 8] nNumberOfBuffers
1146880 nBufferSize 32
```



```
O-DU: thread run start time: 08/11/20 23:05:24.000000001 UTC [500]
CC: [ handle 0x7f6fe7383380 ru 1 cc idx 0 ] [nPoolIndex 8] mb pool 0x249d33b40
ru 1 cc 0 idx 9: [ handle 0x7f6fe7383380 1 0 ] [nPoolIndex 9] nNumberOfBuffers 35840
nBufferSize 12560
CC:[ handle 0x7f6fe7383380 ru 1 cc idx 0 ] [nPoolIndex 9] mb pool 0x2215b1500
port [1] gnb_io_xran_init_cp
port [1] init xran successfully
port [2] gnb_io_xran_start: gGnbIoXranStarted[0] CC 3 Ant 16 AntElm 64 [Cell:
nNrOfDLPorts 16 nNrOfULPorts 8]
port 2 has 1 CCs
port 2 cc id 0 is phy id 2
XRAN front haul xran mm init
xran sector get instances [2]: CC 0 handle 0x7f6fe7383440
Handle: 0xee1c9a0 Instance: 0x7f6fe7383440
gnb io xran start [2]: CC 0 handle 0x7f6fe7383440
Sucess xran mm init Instance 0x7f6fe7383280
nSectorNum 1
ru 2 cc 0 idx 0: [ handle 0x7f6fe7383440 2 0 ] [nPoolIndex 0] nNumberOfBuffers 8960
nBufferSize 14432
CC:[ handle 0x7f6fe7383440 ru 2 cc_idx 0 ] [nPoolIndex 0] mb pool 0x203b7bdc0
ru_2_cc_0_idx_1: [ handle 0x7f6fe7383440 2 0 ] [nPoolIndex 1] nNumberOfBuffers 286720
nBufferSize 32
CC:[ handle 0x7f6fe7383440 ru 2 cc idx 0 ] [nPoolIndex 1] mb pool 0x1fba69f80
ru 2 cc 0 idx 2: [ handle 0x7f6fe7383440 2 0 ] [nPoolIndex 2] nNumberOfBuffers 8960
CC:[ handle 0x7f6fe7383440 ru 2 cc idx 0 ] [nPoolIndex 2] mb pool 0x1f1767940
ru 2 cc 0 idx 3: [ handle 0x7f6fe7383440 2 0 ] [nPoolIndex 3] nNumberOfBuffers 8960
nBufferSize 14432
CC:[ handle 0x7f6fe7383440 ru 2 cc idx 0 ] [nPoolIndex 3] mb pool 0x1ea5a6200
ru 2 cc 0 idx 4: [ handle 0x7f6fe7383440 2 0 ] [nPoolIndex 4] nNumberOfBuffers 286720
nBufferSize 32
CC:[ handle 0x7f6fe7383440 ru 2 cc idx 0 ] [nPoolIndex 4] mb pool 0x1e24943c0
ru 2 cc 0 idx 5: [ handle 0x7f6fe7383440 2 0 ] [nPoolIndex 5] nNumberOfBuffers 8960
nBufferSize 12560
CC:[ handle 0x7f6fe7383440 ru 2 cc idx 0 ] [nPoolIndex 5] mb pool 0x1d8191d80
ru_2_cc_0_idx_6: [ handle 0x7f6fe7383440 2 0 ] [nPoolIndex 6] nNumberOfBuffers 8960
nBufferSize 8192
CC: [ handle 0x7f6fe7383440 ru 2 cc idx 0 ] [nPoolIndex 6] mb pool 0x1d0fd0640
    cc 0 idx 7: [ handle 0x7f6fe7383440 2 0 ] [nPoolIndex 7] nNumberOfBuffers 35840
nBufferSize 14432
CC:[ handle 0x7f6fe7383440 ru 2 cc idx 0 ] [nPoolIndex 7] mb pool 0x1cc340000
ru 2 cc 0 idx 8: [ handle 0x7f6fe7383440 2 0 ] [nPoolIndex 8] nNumberOfBuffers
1146880 nBufferSize 32
CC:[ handle 0x7f6fe7383440 ru 2 cc idx 0 ] [nPoolIndex 8] mb pool 0x1ac38a1c0
ru 2 cc 0 idx 9: [ handle 0x7f6fe7383440 2 0 ] [nPoolIndex 9] nNumberOfBuffers 35840
nBufferSize 12560
CC:[ handle 0x7f6fe7383440 ru 2 cc idx 0 ] [nPoolIndex 9] mb pool 0x183c07b80
port [2] gnb_io_xran_init_cp
port [2] init xran successfully
O-DU: XRAN start time: 08/11/20 23:05:24.384220762 UTC [500]
BBU Pooling: enter multicell Activate!
BBU Pooling Info: bbupool rt thread start on CoreIdx 14 coreId 33 at 118352443946329
at sf=0 with queue 0 successfully
BBU Pooling Info: bbupool rt thread start on CoreIdx 1 coreId 5 at 118352443939667 at
sf=0 with queue 0 successfully
BBU Pooling Info: bbupool rt thread start on CoreIdx 11 coreId 30 at 118352443942535
at sf=0 with queue 0 successfully
BBU Pooling Info: bbupool rt thread start on CoreIdx 8 coreId 12 at 118352443944575
at sf=0 with queue 0 successfully
BBU Pooling: active result: Q id = 0, currenSf = 0, curCellNum = 0, activesfn = 4,
CellNumInActSfn = 3
```



```
BBU Pooling Info: bbupool rt thread start on CoreIdx 2 coreId 6 at 118352443929961 at
sf=0 with queue 0 successfully
BBU Pooling Info: bbupool rt thread start on CoreIdx 15 coreId 34 at 118352443933301
at sf=0 with queue 0 successfully
BBU Pooling: multiCell Activate sucessfully!
BBU Pooling Info: bbupool rt thread start on CoreIdx 13 coreId 32 at 118352443935245
at sf=0 with queue 0 successfully
BBU Pooling Info: bbupool rt thread start on CoreIdx 4 coreId 8 at 118352443936745 at
sf=0 with queue 0 successfully
BBU Pooling Info: bbupool rt thread start on CoreIdx 6 coreId 10 at 118352443936883
at sf=0 with queue 0 successfully
BBU Pooling Info: bbupool rt thread start on CoreIdx 3 coreId 7 at 118352443936747 at
sf=0 with queue 0 successfully
BBU Pooling Info: bbupool rt thread start on CoreIdx 12 coreId 31 at 118352443938019
at sf=0 with queue 0 successfully
BBU Pooling Info: bbupool rt thread start on CoreIdx 5 coreId 9 at 118352443939937 at
sf=0 with queue 0 successfully
BBU Pooling Info: bbupool rt thread start on CoreIdx 9 coreId 28 at 118352443941217
at sf=0 with queue 0 successfully
BBU Pooling Info: bbupool rt thread start on CoreIdx 16 coreId 35 at 118352443944465
at sf=0 with queue 0 successfully
BBU Pooling Info: bbupool rt thread start on CoreIdx 17 coreId 36 at 118352443937701
at sf=0 with queue 0 successfully
BBU Pooling Info: bbupool rt thread start on CoreIdx 0 coreId 4 at 118352443926969 at
sf=0 with queue 0 successfully
BBU Pooling Info: bbupool rt thread start on CoreIdx 10 coreId 29 at 118352443928691
at sf=0 with queue 0 successfully
BBU Pooling Info: bbupool rt thread start on CoreIdx 7 coreId 11 at 118352443931713
at sf=0 with queue 0 successfully
phy bbupool rx handler: PhyId[0] nSfIdx[4] frame,slot[0,5] qNumSlotPerSfn[20]
==== 11app Time: 5002 ms NumCarrier: 3 NumBbuCores: 18. Tti2Tti Time: [ 0.00...
0.00.. 0.00] usces
==== [o-du0][rx 3807776 pps 761555 kbps 4744396][tx 10937607 pps 2187521 kbps
26031486] [on_time 3807776 early 0 late 0 corrupt 0 pkt_dupl 144 Total 3807776]
    Pusch[ 439372 439372 439372 439372 439372 439372 439372]
SRS[ 292800]
==== [o-du1][rx 1469469 pps 293893 kbps 2684928][tx 3649817 pps 729963 kbps 9156812]
[on time 1469469 early 0 late 0 corrupt 0 pkt dupl 144 Total 1469469]
    Pusch[ 146964 146956 146964 146956 146964 146956]
==== [o-du2][rx 1469463 pps 293892 kbps 2684960][tx 3648883 pps 729776 kbps 9152795]
[on time 1469463 early 0 late 0 corrupt 0 pkt dupl 144 Total 1469463]

        Cell
        DL Tput
        UL Tput
        UL BLER

        0 (Kbps)
        0
        0 / 0
        0.00%

        1 (Kbps)
        0
        0 / 0
        0.00%

        2 (Kbps)
        0
        0 / 0
        0.00%

Core Utilization [18 BBU core(s)]:
     Core Id: 4 5 6 7 8 9 10 11 12 28 29 30 31 32 33 34 35 36
Avg
              0 4 2 4 4 2 3 13 17 0 13 15 14 16 14 17 15 14
     Util %:
     Xran Id: 22 23 24 25
                                Master Core Util: 85 %
==== 11app Time: 10002 ms NumCarrier: 3 NumBbuCores: 18. Tti2Tti Time: [ 0.00...
0.00.. 0.00] usces
```



```
==== [o-du0][rx 5472406 pps 332926 kbps 4744396][tx 21871698 pps 2186818 kbps
26038405] [on time 5472406 early 0 late 0 corrupt 0 pkt dupl 144 Total 5472406]
    Pusch[ 192084 192078 192078 192078 192078 192078 192078]
SRS[ 128000]
==== [o-du1][rx 2109680 pps 128042 kbps 2684917][tx 7297930 pps 729622 kbps 9156922]
[on_time 2109680 early 0 late 0 corrupt 0 pkt_dupl 144 Total 2109680]
    Pusch[ 64026 64026 64026 64026 64026 64026 64026]
SRS[ 128004]
==== [o-du2][rx 2109682 pps 128043 kbps 2684993][tx 7296833 pps 729590 kbps 9156258]
[on time 2109682 early 0 late 0 corrupt 0 pkt dupl 144 Total 2109682]
     Pusch[ 64026 64026 64026 64026 64026 64026 64026 64026]
SRS[ 128011]

        Cell
        DL Tput
        UL Tput
        UL BLER

        0 (Kbps)
        6,894,368
        576,420 / 576,492
        0.00%

        1 (Kbps)
        0
        0 / 0
        0.00%

        2 (Kbps)
        0
        0 / 0
        0.00%

Core Utilization [18 BBU core(s)]:
     Core Id: 4 5 6 7 8 9 10 11 12 28 29 30 31 32 33 34 35 36
               15 30 34 29 26 28 26 46 50 0 40 40 43 42 44 42 48 50
     ==== 11app Time: 15003 ms NumCarrier: 3 NumBbuCores: 18. Tti2Tti Time: [ 0.00..
0.00.. 0.001 usces
==== [o-du0][rx 7136544 pps 332827 kbps 4744396][tx 32806663 pps 2186993 kbps
26042173] [on time 7136544 early 0 late 0 corrupt 0 pkt dupl 144 Total 7136544]
    Pusch[ 192012 192018 192018 192018 192018 192018 192018 192018]
SRS[ 128000]
==== [o-du1][rx 2749728 pps 128009 kbps 2684895][tx 10945622 pps 729538 kbps 9155645]
[on_time 2749728 early 0 late 0 corrupt 0 pkt_dupl 144 Total 2749728]
    Pusch[ 64006 64006 64006 64006 64006 64006 64006]
==== [o-du2][rx 2749730 pps 128009 kbps 2684840][tx 10944272 pps 729487 kbps 9154660]
[on time 2749730 early 0 late 0 corrupt 0 pkt dupl 144 Total 2749730]
     Pusch[ 64006 64006 64006 64006 64006 64006 64006]
SRS[ 128000]

        Cell
        DL Tput
        UL Tput
        UL BLER

        0 (Kbps)
        6,896,256
        576,780 / 576,780
        0.00%

        1 (Kbps)
        539,740
        65,260 / 65,260
        0.00%

        2 (Kbps)
        0 / 0
        0.00%

Core Utilization [18 BBU core(s)]:
     Core Id: 4 5 6 7 8 9 10 11 12 28 29 30 31 32 33 34 35 36
Avg
     Util %: 27 33 40 38 38 35 34 56 56 26 50 47 48 47 51 48 57 57
     Xran Id: 22 23 24 25 Master Core Util: 95 %
Setting MLogMask because nMLogDelay == 0
==== 11app Time: 20002 ms NumCarrier: 3 NumBbuCores: 18. Tti2Tti Time:
[480.00..500.23..516.00] usces
```



```
==== [o-du0][rx 8799776 pps 332646 kbps 4744396][tx 43740623 pps 2186792 kbps
26042944] [on time 8799776 early 0 late 0 corrupt 0 pkt dupl 144 Total 8799776]
        Pusch[ 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 191904 19
SRS[ 128000]
==== [o-du1][rx 3389472 pps 127948 kbps 2684982][tx 14591619 pps 729199 kbps 9154093]
[on_time 3389472 early 0 late 0 corrupt 0 pkt_dupl 144 Total 3389472]
        Pusch[ 63968 63968 63968 63968 63968 63968 63968]
SRS[ 128000]
==== [o-du2][rx 3389474 pps 127948 kbps 2684873][tx 14589997 pps 729145 kbps 9152608]
[on time 3389474 early 0 late 0 corrupt 0 pkt dupl 144 Total 3389474]
         Pusch[ 63968 63968 63968 63968 63968 63968 63968]
SRS[ 128000]

        Cell
        DL Tput
        UL Tput
        UL BLER

        0 (Kbps)
        6,896,256
        576,780 / 576,780
        0.00%

        1 (Kbps)
        539,814
        65,260 / 65,260
        0.00%

        2 (Kbps)
        539,814
        65,260 / 65,260
        0.00%

Core Utilization [18 BBU core(s)]:
        Core Id: 4 5 6 7 8 9 10 11 12 28 29 30 31 32 33 34 35 36
         Util %: 43 47 46 43 42 43 41 61 60 27 57 56 58 57 55 56 64 62
        ==== llapp Time: 25002 ms NumCarrier: 3 NumBbuCores: 18. Tti2Tti Time:
[442.00..500.12..562.00] usces
==== [o-du0][rx 10463824 pps 332809 kbps 4744396][tx 54675513 pps 2186978 kbps
26044150] [on time 10463824 early 0 late 0 corrupt 0 pkt dupl 144 Total 10463824]
        Pusch[ 192006 192006 192006 192006 192006 192006 192006 192006]
SRS[ 128000]
==== [o-du1][rx 4029487 pps 128003 kbps 2684928][tx 18237287 pps 729133 kbps 9150163]
[on_time 4029487 early 0 late 0 corrupt 0 pkt_dupl 144 Total 4029487]
       Pusch[ 64002 64002 64002 64002 64002 64002 64001]
 ==== [o-du2][rx 4029474 pps 128000 kbps 2684873][tx 18235338 pps 729068 kbps 9148513]
[on_time 4029474 early 0 late 0 corrupt 0 pkt dupl 144 Total 4029474]
         Pusch[ 64000 64000 64000 64000 64000 64000 64000]
SRS[ 128000]

        Cell
        DL Tput
        UL Tput
        UL BLER

        0 (Kbps)
        6,896,256
        576,492 / 576,492
        0.00%

        1 (Kbps)
        539,814
        65,260 / 65,260
        0.00%

        2 (Kbps)
        539,814
        65,260 / 65,260
        0.00%

Core Utilization [18 BBU core(s)]:
         Core Id: 4 5 6 7 8 9 10 11 12 28 29 30 31 32 33 34 35 36
         Util %: 44 48 46 46 44 41 43 62 61 27 58 59 55 56 56 58 61 62
         ==== 11app Time: 30002 ms NumCarrier: 3 NumBbuCores: 18. Tti2Tti Time:
[435.00..500.12..562.00] usces
==== [o-du0][rx 12127888 pps 332812 kbps 4744396][tx 65610457 pps 2186988 kbps
26044065] [on time 12127888 early 0 late 0 corrupt 0 pkt dupl 144 Total 12127888]
```



```
Pusch[ 192012 192006 192012 192006 192010 192006 192006]
==== [o-du1][rx 4669504 pps 128003 kbps 2685058][tx 21883550 pps 729252 kbps 9152750]
[on time 4669504 early 0 late 0 corrupt 0 pkt dupl 144 Total 4669504]
    Pusch[ 64002 64002 64002 64002 64002 64002 64002
SRS[ 128000]
==== [o-du2][rx 4669498 pps 128004 kbps 2684993][tx 21881293 pps 729191 kbps 9151846]
[on time 4669498 early 0 late 0 corrupt 0 pkt dupl 144 Total 4669498]
     Pusch[ 64004 64004 64004 64000 64002 64002

        Cell
        DL Tput
        UL Tput
        UL BLER

        0 (Kbps)
        6,896,256
        577,069 / 577,069
        0.00%

        1 (Kbps)
        539,814
        65,260 / 65,260
        0.00%

        2 (Kbps)
        539,814
        65,260 / 65,260
        0.00%

Core Utilization [18 BBU core(s)]:
    Core Id: 4 5 6 7 8 9 10 11 12 28 29 30 31 32 33 34 35 36
     Util %: 44 47 45 47 43 43 42 63 63 27 56 56 56 55 58 55 65 62
    ==== 11app Time: 35002 ms NumCarrier: 3 NumBbuCores: 18. Tti2Tti Time:
[434.00..500.12..554.00] usces
==== [o-du0][rx 13792256 pps 332873 kbps 4744892][tx 76545521 pps 2187012 kbps
26042901] [on time 13792256 early 0 late 0 corrupt 0 pkt_dupl 144 Total 13792256]
    Pusch[ 192042 192048 192042 192048 192044 192048 192048 192048]
==== [o-du1][rx 5309632 pps 128025 kbps 2685102][tx 25528867 pps 729063 kbps 9151639]
[on_time 5309632 early 0 late 0 corrupt 0 pkt_dupl 144 Total 5309632]
    Pusch[ 64016 64016 64016 64016 64016 64016 64016]
SRS[ 128000]
==== [o-du2][rx 5309632 pps 128026 kbps 2685102][tx 25526238 pps 728989 kbps 9150147]
[on time 5309632 early 0 late 0 corrupt 0 pkt_dupl 144 Total 5309632]
    Pusch[ 64016 64016 64016 64016 64018 64018 64017 64017]
SRS[ 128000]

        Cell
        DL Tput
        UL Tput
        UL BLER

        0 (Kbps)
        6,896,256
        576,780 / 576,780
        0.00%

        1 (Kbps)
        539,814
        65,260 / 65,260
        0.00%

        2 (Kbps)
        539,814
        65,260 / 65,260
        0.00%

Core Utilization [18 BBU core(s)]:
    Core Id: 4 5 6 7 8 9 10 11 12 28 29 30 31 32 33 34 35 36
     Util %: 43 48 45 47 43 41 42 66 61 27 57 57 55 56 57 56 64 62
     Xran Id: 22 23 24 25 Master Core Util: 95 %
==== 11app Time: 40002 ms NumCarrier: 3 NumBbuCores: 18. Tti2Tti Time:
[440.00..500.12..553.00] usces
==== [o-du0][rx 15455740 pps 332696 kbps 4744396][tx 87479892 pps 2186874 kbps
26042995] [on time 15455740 early 0 late 0 corrupt 0 pkt dupl 144 Total 15455740]
    Pusch[ 191940 191940 191940 191940 191940 191940 191940 191940]
SRS[ 127964]
```



```
==== [o-du1][rx 5949408 pps 127955 kbps 2684764][tx 29174424 pps 729111 kbps 9150009]
[on time 5949408 early 0 late 0 corrupt 0 pkt dupl 144 Total 5949408]
    Pusch[ 63980 63980 63980 63980 63980 63980 63980 63980]
SRS[ 127936]
==== [o-du2][rx 5949410 pps 127955 kbps 2684840][tx 29171380 pps 729028 kbps 9148386]
[on_time 5949410 early 0 late 0 corrupt 0 pkt_dupl 144 Total 5949410]
     Pusch[ 63980 63980 63980 63980 63980 63981 63981]
SRS[ 127936]

        Cell
        DL Tput
        UL Tput
        UL BLER

        0 (Kbps)
        6,896,256
        576,780 / 576,780
        0.00%

        1 (Kbps)
        539,814
        65,260 / 65,260
        0.00%

        2 (Kbps)
        539,814
        65,260 / 65,260
        0.00%

Core Utilization [18 BBU core(s)]:
    Core Id: 4 5 6 7 8 9 10 11 12 28 29 30 31 32 33 34 35 36
     Util %: 44 48 44 45 42 42 43 63 63 27 57 56 55 58 56 56 64 62
                                   Master Core Util: 95 %
     Xran Id: 22 23 24 25
==== 11app Time: 45002 ms NumCarrier: 3 NumBbuCores: 18. Tti2Tti Time:
[436.00..500.12..556.00] usces
  == [o-du0][rx 17119776 pps 332807 kbps 4743900][tx 98415119 pps 2187045 kbps
26043843] [on time 17119776 early 0 late 0 corrupt 0 pkt dupl 144 Total 17119776]
    Pusch[ 192000 192000 192000 192000 192000 192000 192000 192000]
SRS[ 128036]
==== [o-du1][rx 6589472 pps 128012 kbps 2684753][tx 32820214 pps 729158 kbps 9154170]
[on time 6589472 early 0 late 0 corrupt 0 pkt dupl 144 Total 6589472]
    Pusch[ 64000 64000 64000 64000 64000 64000 64000 64000]
==== [o-du2][rx 6589474 pps 128012 kbps 2684753][tx 32816780 pps 729080 kbps 9152613]
[on_time 6589474 early 0 late 0 corrupt 0 pkt_dupl 144 Total 6589474]
    Pusch[ 64000 64000 64000 6400\overline{0} 64000 64000 64000 64000]
SRS[ 128064]

        Cell
        DL Tput
        UL Tput
        UL BLER

        0 (Kbps)
        6,896,256
        576,780 / 576,780
        0.00%

        1 (Kbps)
        539,814
        65,260 / 65,260
        0.00%

        2 (Kbps)
        539,814
        65,260 / 65,260
        0.00%

Core Utilization [18 BBU core(s)]:
     Core Id: 4 5 6 7 8 9 10 11 12 28 29 30 31 32 33 34 35 36
     Util %: 44 47 46 47 43 42 42 61 63 27 56 58 56 56 58 57 63 65
     Xran Id: 22 23 24 25 Master Core Util: 95 %
==== 11app Time: 50002 ms NumCarrier: 3 NumBbuCores: 18. Tti2Tti Time:
[436.00..500.12..551.00] usces
==== [o-du0][rx 18783776 pps 332800 kbps 4744396][tx 109350065 pps 2186989 kbps
26043142] [on time 18783776 early 0 late 0 corrupt 0 pkt_dupl 144 Total 18783776]
    Pusch[ 192000 192000 192000 192000 192000 192000 192000 192000]
SRS[ 128000]
==== [o-du1][rx 7229472 pps 128000 kbps 2684928][tx 36466505 pps 729258 kbps
18302595] [on time 7229472 early 0 late 0 corrupt 0 pkt dupl 144 Total 7229472]
```



7. To execute testmac with O-DU functionality according to O-RAN Fronthaul specification, enter:

[root@xran flexran] cd ./bin/nr5g/gnb/testmac

8. To execute test case type:

```
./12.sh --testfile=./cascade lake-sp/csxsp mul 100mhz mmimo hton xran.cfg
```

where output corresponding to Test MAC:

```
[root@icelake-scs1-1 testmac]# ./12.sh --testfile=./icelake-
sp/icxsp mul 100mhz mmimo 64x64 hton xran.cfg
kernel.sched rt runtime us = -1
kernel.shmmax = 2147483648
kernel.shmall = 2147483648
Note: Forwarding request to 'systemctl disable irqbalance.service'.
start 5GNR Test MAC
5GNR Testmac Application
testmac cfg set cfg filename: Coult not find string 'cfgfile' in command line. Using
default File: testmac cfg.xml
TestMacCfg.xml Version: 20.08
--version=20.08
--wls dev name=wls0
--wlsMemorySize=0x3F600000
--dpdkIovaMode=0
--PhyStartMode=1
 --PhyStartPeriod=40
 --PhyStartCount=0
 --MlogSubframes=128
 --MlogCores=3
 --MlogSize=2048
 --latencyTest=0
 --wlsRxThread=1, 90, 0
--systemThread=0, 0, 0
```



```
--runThread=0, 89, 0
 --urllcThread=16, 90, 0
wls dev filename: wls0
sys reg signal handler: [err] signal handler in NULL
sys_reg_signal_handler:[err] signal handler in NULL
timer_set_tsc_freq_from_clock: System clock (rdtsc) resolution 1496523032 [Hz]
                               Ticks per usec 1496
MLogOpen: filename(testmac-mlog.bin) mlogSubframes (128), mlogCores(3),
mlogSize(2048) mlog mask (-1)
    mlogSubframes (128), mlogCores(3), mlogSize(2048)
    localMLogTimerInit
        System clock (rdtsc) resolution 1496526140 [Hz]
        Ticks per us 1496
    MLog Storage: 0x7f821905d100 -> 0x7f821911d920 [ 788512 bytes ]
    localMLogFregReg: 1496. Storing: 1496
    Mlog Open successful
Calling rte eal init: testmac -c1 --proc-type=auto --file-prefix wls0 --iova-mode=pa
EAL: Detected 48 lcore(s)
EAL: Detected 1 NUMA nodes
EAL: Auto-detected process type: SECONDARY
EAL: Multi-process socket /var/run/dpdk/wls0/mp socket 29473 6b9e031eaf8b
EAL: Selected IOVA mode 'PA'
EAL: Probing VFIO support...
EAL: PCI device 0000:01:00.0 on NUMA socket 0
     probe driver: 8086:1533 net e1000 igb
EAL: PCI device 0000:18:00.0 on NUMA socket 0
EAL: probe driver: 8086:1563 net ixqbe
EAL: PCI device 0000:18:00.1 on NUMA socket 0
EAL: probe driver: 8086:1563 net ixqbe
EAL: PCI device 0000:8c:00.0 on NUMA socket 0
EAL: probe driver: 8086:d58 net i40e
EAL: PCI device 0000:8c:00.1 on NUMA socket 0
EAL: probe driver: 8086:d58 net i40e
EAL: PCI device 0000:90:00.0 on NUMA socket 0
EAL: probe driver: 8086:d58 net_i40e
EAL: PCI device 0000:90:00.1 on NUMA socket 0
EAL: probe driver: 8086:d58 net i40e
wls lib: Open wls0 (DPDK memzone)
wls lib: WLS Open 0x43f600000
wls lib: link: 1 <-> 0
wls lib: Mode 1
wls lib: WLS shared management memzone: wls0
wls lib: hugePageSize on the system is 1073741824
wls lib: WLS Alloc [1063256064] bytes
wls lib: Connecting to remote peer ...
wls lib: Connected to remote peer
wls mac create mem array: pMemArray[0xf354350] pMemArrayMemory[0x400000000]
totalSize[1063256064] nBlockSize[262144] numBlocks[4056]
WLS EnqueueBlock [1]
WLS inited ok [383]
TESTMAC VERSION
$Version: #DIRTY# $ (x86)
IMG-date: Aug 5 2020
```



```
IMG-time: 18:32:53
Testmac threads in application
testmac_run_thread: [PID: 29477] binding on [CPU 0] [PRIO: 89] [POLICY: 1] wls_mac_rx_task: [PID: 29476] binding on [CPU 1] [PRIO: 90] [POLICY: 1]
testmac set phy start: mode[1], period[40], count[0]
testmac run load files:
Loading DL Config Files:
    testmac_run_parse_file Parsing config file:
/home/vzakharc/master/../master_aux/flexran_11_5g_test/dl/testmac_dl_mu0_5mhz.cfg
    testmac_run_parse_file Parsing config file:
/home/vzakharc/master/../master_aux/flexran_11_5g_test/dl/testmac_dl_mu0_10mhz.cfg
    testmac_run_parse_file Parsing config file:
/home/vzakharc/master/../master aux/flexran 11 5g test/dl/testmac dl mu0 20mhz.cfg
    testmac_run_parse_file Parsing config file:
/home/vzakharc/master/../master_aux/flexran_11_5g_test/dl/testmac_dl_mu1_100mhz.cfg
    testmac run parse file Parsing config file:
/home/vzakharc/master/../master aux/flexran 11 5g test/dl/testmac dl mu3 100mhz.cfg
Loading UL Config Files:
    testmac run parse file Parsing config file:
/home/vzakharc/master/../master aux/flexran 11 5g test/ul/testmac ul mu0 5mhz.cfg
    testmac_run_parse_file Parsing config file:
/home/vzakharc/master/../master_aux/flexran_11_5g_test/ul/testmac_ul_mu0_10mhz.cfg
    testmac_run_parse_file Parsing config file:
/home/vzakharc/master/../master_aux/flexran_l1_5g_test/ul/testmac_ul_mu0_20mhz.cfg
    testmac_run_parse_file Parsing config file:
/home/vzakharc/master/../master_aux/flexran_11_5g_test/ul/testmac_ul_mu1_10mhz.cfg
    testmac_run_parse_file Parsing config file:
/home/vzakharc/master/../master aux/flexran 11 5g test/ul/testmac ul mu1 20mhz.cfg
    testmac_run_parse_file Parsing config file:
/home/vzakharc/master/../master aux/flexran 11 5g test/ul/testmac ul mu1 40mhz.cfg
    testmac run parse file Parsing config file:
/home/vzakharc/master/../master_aux/flexran_11_5g_test/ul/testmac_ul_mu1_100mhz.cfg
    testmac run parse file Parsing config file:
/home/vzakharc/master/../master aux/flexran 11 5g test/ul/testmac ul mu3 100mhz.cfg
Loading FD Config Files:
    testmac_run_parse_file Parsing config file:
/home/vzakharc/master/../master aux/flexran 11 5g test/fd/testmac fd mu0 5mhz.cfg
    testmac run parse file Parsing config file:
/home/vzakharc/master/../master_aux/flexran_l1_5g_test/fd/testmac_fd_mu0_10mhz.cfg
    testmac_run_parse_file Parsing config file:
/home/vzakharc/master/../master_aux/flexran_l1_5g_test/fd/testmac_fd_mu0_20mhz.cfg
    testmac run parse file Parsing config file:
/home/vzakharc/master/../master aux/flexran 11 5g test/fd/testmac fd mu1 40mhz.cfg
    testmac run parse file Parsing config file:
/home/vzakharc/master/../master aux/flexran 11 5g test/fd/testmac fd mul 100mhz.cfg
    testmac run parse file Parsing config file:
/home/vzakharc/master/../master aux/flexran 11 5g test/fd/testmac fd mu3 100mhz.cfg
TESTMAC DL TESTS:
   Numerology[0] Bandwidth[5]
```



1001 1002 1003 1004	1005	1006	1007	1008			
Numerology[0] Bandwidth[10]							
1001 1002 1003 1004	1005	1006	1007	1008			
Numerology[0] Bandwidth[20]							
1001 1002 1003 1004		1006	1007	1008			
Numerology[1] Bandwidth[100]		1005	1206	1007	1010	1011	
	1204 1216	1205 1217		1207			
		1217					
1242 1243 1244 1245		1251		1260			
		1268		1270			
1300 1301 1302 1303		1305		1404			
		1505	1506	2213	2214	2215	
	2224	2225		2228			
		3214	3215	3217	3218	3219	
	3228	3229					
Numerology[3] Bandwidth[100] 1001 1002 1003 1005		1007	1000	1000	1010	1011	
		1017					
		2030					
3030	2000	2000	2000	0001	0002		
TESTMAC UL TESTS:							
Numerology[0] Bandwidth[5]							
1001 1002 1003 1069	1070	1071	1072	1073	1074	1075	
1076 1077							
Numerology[0] Bandwidth[10] 1001 1002 1069 1070	1071	1072	1072	1074	1075	1076	
1001 1002 1089 1070	10/1	1072	1073	10/4	1073	1076	
Numerology[0] Bandwidth[20]							
1001 1002 1003 1004	1005	1006	1007	1008	1069	1070	
		1076					
Numerology[1] Bandwidth[10]							
	1073	1074	1075	1076	1077		
Numerology[1] Bandwidth[20]							
1069 1070 1071 1072	1073	1074	1075	1076	1077		
Numerology[1] Bandwidth[40]	1070	1074	1075	1076	1077		
1069 1070 1071 1072		1074	1075	1076	1077		
Numerology[1] Bandwidth[100] 1010 1030 1031 1032		1034	1035	1036	1037	1038	
	1033	1034					
	1084	1085					
1093 1094 1095 1096		1101		1103		1105	
1106 1107 1108 1110	1111	1113	1114	1115	1116	1117	
1118 1119 1120 1121	1122	1123	1124	1130	1131	1132	
1133 1134 1135 1136	1137	1138	1139	1140	1141	1142	
1143 1150 1152 1153	1154	1155	1156	1157	1159	1160	
1161 1162 1163 1164	1165	1166	1167	1168	1169	1170	
1171 1172 1173 1200 1207 1208 1209 1210	1201	1202 1212	1203 1213	1204	1205 1215	1206	
1207 1208 1209 1210 1217 1218 1219 1220	1211 1221	1212	1213	1214 1231	1215	1216 1233	
1234 1235 1236 1237	1402	1404	1408	1416	1420	1421	
1422 1423 1424 1425	1426	1427	1428	1429	1430	1431	
1432 1433 1434 1435	1436	1437	1438	1500	1503	1504	
1505 1506 1507 1508	1512	1513	1514	1515	1516	1540	
1541 1542 1563 1564	1565	1566	1567	1568	1569	1570	
1571 1572 1573 1574	1575	1576	1577	1600	1601	1602	
1603 1604 1605 1606	1607	1608	1609	1610	1611	1612	
1613 1614 1615 1616	1617	1618	1619	1620	1621	1622	
1623 1624 1625 1626 1633 1634 1635 1636	1627 1637	1628 1638	1629 1639	1630 1640	1631 1641	1632 1642	
1700 1701 1702 1969	1970	1971	1972	1973	1974	1975	
1700 1701 1702 1909	1710	エフノエ	1712	1913	エフィュ	1973	



```
1976 1977 2236 2237
                                3236
   Numerology[3] Bandwidth[100]
        1001 1002 1003 1004 1005
                                      1006
                                           1007 1010 1011 1012
        1013 1014
                   1015
                         1020
                               1021
                                      1022
                                            1023
                                                 1024 1025
        1027 1028 1029 1030
                                           1033
                                                 1034 1035
                                                             1036
                   1041
        1037 1040
                          1042
                                1043
                                      1044
                                           1045
                                                  1046
                                                       1050
             1053
                   1054
                         1059
                                      1061
                                            1062
                                                  1063
                                                       1064
             1067
                         1071
         1066
                                1073
                                      1074
                                            1081
                                                  1082
                                                        1083
         1085
             1086
                    2001
                          2002
                                2003
                                            3002
TESTMAC FD TESTS:
   Numerology[0] Bandwidth[5]
        1001 6001 8001 10001 12001
   Numerology[0] Bandwidth[10]
        1001 2001 4001 6001
                                8001 10001 12001 1002
                                                       2002
        6002 8002 10002 12002
   Numerology[0] Bandwidth[20]
        1002 1004 1012 1014
                                1015
                                      1016 1017
                                                  1018
        1022 1023 1024 1025
                                                        1200
                                1209
        1202 1206 1207
                         1208
        1222 1223 1224 1225
                                1226
                                      1227
   Numerology[1] Bandwidth[40]
   Numerology[1] Bandwidth[100]
                                            1204
                                                        1206
         1208 1209
                    1210
                          1300
                                                        1305
                                            1303
                                                  1304
        1307 1308 1350
                                      1353
                                            1354
                                                  1355
                                                        1356
        1358 1359 1370
                         1371
                                1372
                                      1373
                                            1374
                                                  1375
                                                        1376
        1378 1401 1402 1403
                               1404
                                      1405
                                            1406
                                                  1411
                                                        1412
        1494 1500 1501 1502
                                      1504
                                            1510
                                                  1511
                                                        1512
        1514 1515 1520 1521
                               1522
                                      1523
                                           1524
                                                  1525
                                                        1526
        1528 1529 1530 1531 1532
                                     1540 1541
                                                 1700
                                                       1701
        2520 2521 2522 2523 2524
                                      2525
                                            2526
                                                 2527
                                                        2528
        2530 2531 2532 3524 3525
                                            3527
                                                  3528
                                                        3529
                                      3526
        3531 3532 4524 4525
                                4526
                                      4527
                                            4528
                                                  4529
                                                        4530
        4532
   Numerology[3] Bandwidth[100]
         1001 1002 1004 1005
1012 1013 1014 1015
                                1006
                                      1007
                                            1008
                                                  1009
                                                       1010
                   1014
                         1015
                                           1063
                                                 1064
         1081 1082 2001
                         3001
    testmac run parse file Parsing config file: ./icelake-
sp/icxsp mul 100mhz mmimo 64x64 hton xran.cfg
testmac_set_phy_start: mode[4], period[0], count[100200]
    Adding setoption pdsch split [numTests: 0] [nCellMask: 0x00000001] [nOption: 4]
[pMacOptions: 260 / 0x00000104]
   Adding setoption pdsch dl weight split [numTests: 0] [nCellMask: 0x00000001]
[nOption: 4] [pMacOptions: 260 / 0x00000104]
   Adding setoption pusch_chan_est_split [numTests: 0] [nCellMask: 0x00000001]
[nOption: 2] [pMacOptions: 258 / 0x00000102]
   Adding setoption pusch_mmse_split [numTests: 0] [nCellMask: 0x00000001] [nOption:
  [pMacOptions: 260 / 0x00000104]
    Adding setoption pusch_llr_rx_split [numTests: 0] [nCellMask: 0x00000001]
[nOption: 2] [pMacOptions: 258 / 0x00000102]
    Adding setoption pusch_ul_weight_split [numTests: 0] [nCellMask: 0x00000001]
[nOption: 2] [pMacOptions: 258 / 0x00000102]
    Adding setoption timer multi cell [numTests: 0] [nCellMask: 0xffffffff] [nOption:
10000] [pMacOptions: 10000 / 0x00002710]
   Adding setoption fec dec num iter [numTests: 0] [nCellMask: 0xffffffff] [nOption:
  [pMacOptions: -253 / 0xffffff03]
   Adding SetCoreMask[numTests: 0][setCoreCnt: 0]. CoreMask[137170526192 /
0x000001ff0001ff0]
```



```
Adding SetDlbeamCoreMask[numTests: 0][setCoreCnt: 0]. CoreMask[2016 /
0x00000000000007e01
    Adding SetSrsCoreMask[numTests: 0][setCoreCnt: 0]. CoreMask[268435472 /
0x000000010000010]
Setting Testmac System Core: 2
Setting Testmac Run Core: 2
Setting Testmac Wls Core: 3
    Adding Test[3370]. NumCarr[3], Current Directory:
/home/vzakharc/master/../master_aux/flexran_l1_5g_test/
Carrier[0]: ConfigFile: fd/mu1_100mhz/376/fd_testconfig_tst376.cfg
Carrier[1]: ConfigFile: fd/mu1_100mhz/377/fd_testconfig_tst377.cfg
         Carrier[2]: ConfigFile: fd/mul 100mhz/377/fd testconfig tst377.cfg
testmac set multi cell timer: 10000
Running Test[3370]. NumCarr[3], Current Directory:
/home/vzakharc/master/../master_aux/flexran_l1_5g_test/
Carrier[0]: ConfigFile: fd/mul_100mhz/376/fd_testconfig_tst376.cfg
Carrier[1]: ConfigFile: fd/mul_100mhz/377/fd_testconfig_tst377.cfg
Carrier[2]: ConfigFile: fd/mul
                                    100mhz/377/fd testconfig tst377.cfg
TESTMAC>welcome to application console
MLogRestart
MLogOpen: filename(testmac-mlog.bin) mlogSubframes (128), mlogCores(3),
mlogSize(2048) mlog mask (-1)
    mlogSubframes (128), mlogCores(3), mlogSize(2048)
    localMLogTimerInit
         System clock (rdtsc) resolution 1496525908 [Hz]
         Ticks per us 1496
    MLog Storage: 0x7f8208000900 -> 0x7f82080c1120 [ 788512 bytes ]
    localMLogFreqReg: 1496. Storing: 1496
    Mlog Open successful
testmac mac2phy set num cells: Setting Max Cells: 3
testmac config parse: test num[3370] test type[2] numcarrier[3]
Queueing MSG_TYPE_PHY_UL_IQ_SAMPLES(0)
Queueing MSG_TYPE_PHY_UL_IQ_SAMPLES(1)
Queueing MSG TYPE PHY UL IQ SAMPLES (2)
Received MSG TYPE PHY UL IQ SAMPLES (0)
Oueueing MSG TYPE PHY CONFIG REO(0)
Received MSG TYPE PHY UL IQ SAMPLES(1)
Queueing MSG TYPE PHY CONFIG REQ(1)
Received MSG_TYPE_PHY_UL_IQ_SAMPLES(2)
Queueing MSG_TYPE_PHY_CONFIG_REQ(2) and sending list
Received MSG_TYPE_PHY_CONFIG_RESP(0)
Queueing MSG_TYPE_PHY_START_REQ(0)
Received MSG_TYPE_PHY_CONFIG_RESP(1)
Queueing MSG_TYPE_PHY_START_REQ(1)
Received MSG_TYPE_PHY_CONFIG_RESP(2)
Queueing MSG_TYPE_PHY_START_REQ(2) and sending list
Received MSG TYPE PHY START RESP(0)
Received MSG TYPE PHY START RESP(1)
Received MSG TYPE PHY START RESP(2)
==== testmac Time: 5000 ms NumCarrier: 3 Total Proc Time: [ 0.00.. 6.30.. 19.00]
usces====
    Core Utilization [Core: 3] [Util %: 0.42%]
```



```
==== testmac Time: 10000 ms NumCarrier: 3 Total Proc Time: [ 6.00..116.80..206.00]
usces====
   Core Utilization [Core: 3] [Util %: 27.86%]
==== testmac Time: 20000 ms NumCarrier: 3 Total Proc Time: [ 10.00..156.33..260.00]
   Core Utilization [Core: 3] [Util %: 32.31%]
==== testmac Time: 25000 ms NumCarrier: 3 Total Proc Time: [ 11.00..156.33..260.00]
usces====
   Core Utilization [Core: 3] [Util %: 32.30%]
==== testmac Time: 30000 ms NumCarrier: 3 Total Proc Time: [ 11.00..156.44..256.00]
   Core Utilization [Core: 3] [Util %: 32.32%]
==== testmac Time: 35000 ms NumCarrier: 3 Total Proc Time: [ 11.00..156.42..258.00]
   Core Utilization [Core: 3] [Util %: 32.32%]
==== testmac Time: 40000 ms NumCarrier: 3 Total Proc Time: [ 11.00..156.45..258.00]
  Core Utilization [Core: 3] [Util %: 32.33%]
==== testmac Time: 45000 ms NumCarrier: 3 Total Proc Time: [ 11.00..156.40..282.00]
usces====
   Core Utilization [Core: 3] [Util %: 32.32%]
TESTMAC>=== testmac Time: 50000 ms NumCarrier: 3 Total Proc Time: [
11.00..156.39..260.00] usces====
   Core Utilization [Core: 3] [Util %: 32.31%]
Received MSG TYPE PHY STOP RESP(0)
Queueing MSG TYPE PHY SHUTDOWN REQ(0)
Received MSG TYPE PHY STOP RESP(1)
Queueing MSG TYPE PHY SHUTDOWN REQ(1)
Received MSG TYPE PHY STOP RESP(2)
Queueing MSG TYPE PHY SHUTDOWN REQ(2) and sending list
Received MSG TYPE PHY SHUTDOWN RESP(2)
Received MSG_TYPE_PHY_SHUTDOWN_RESP(0)
Received MSG TYPE PHY SHUTDOWN RESP(1)
MLogPrint: ext_filename((null).bin)
    Opening MLog File: testmac-mlog-c0.bin
   MLog file testmac-mlog-c0.bin closed
   Mlog Print successful
Test[FD mul 100mhz 3370] Completed
wls mac free list all:
        nTotalBlocks[4056] nAllocBlocks[1010] nFreeBlocks[3046]
        nTotalAllocCnt[4538427] nTotalFreeCnt[4537417] Diff[1010]
        nDlBufAllocCnt[3609068] nDlBufFreeCnt[3609068] Diff[0]
        nUlBufAllocCnt[929359] nUlBufFreeCnt[928349] Diff[1010]
All Tests Completed, Total run 1 Tests, PASS 1 Tests, and FAIL 0 Tests
```

§



Appendix B PTP Configuration

B.1 PTP Synchronization

Precision Time Protocol (PTP) provides an efficient way to synchronize time on the network nodes. This protocol uses Master-Slave architecture. Grandmaster Clock (Master) is a reference clock for the other nodes, which adapt their clocks to the master.

Using Physical Hardware Clock (PHC) from the Grandmaster Clock, NIC port precision timestamp packets can be served for other network nodes. Slave nodes adjust their PHC to the master following the IEEE 1588 specification.

There are existing implementations of PTP protocol that are widely used in the industry. One of them is PTP for Linux, which is a set of tools providing necessary PTP functionality. There is no need to re-implement the 1588 protocol because PTP for Linux is precise and efficient enough to be used out of the box.

To meet O-RAN requirements, two tools from PTP for Linux package are required: ptp41 and phc2sys.

B.1.1 PTP for Linux* Requirements

PTP for Linux* introduces some software and hardware requirements. The machine on which the tools will be run needs to use at least a 3.10 Kernel version (built-in PTP support). Several Kernel options need to be enabled in Kernel configuration:

- CONFIG PPS
- CONFIG_NETWORK_PHY_TIMESTAMPING
- PTP 1588 CLOCK

Be sure that the Kernel is compiled with these options.

For the best precision, PTP uses hardware timestamping. NIC has its own clock, called Physical Hardware Clock (PHC), to read current time just a moment before the packet is sent to minimalize the delays added by the Kernel processing the packet. Not every NIC supports that feature. To confirm that currently attached NIC support Hardware Timestamps, use ethtool with the command:

```
ethtool -T eth0
```

Where the eth0 is the potential PHC port. The output from the command should say that there is Hardware Timestamps support.

To set up PTP for Linux*:

1. Download source code:

```
git clone http://git.code.sf.net/p/linuxptp/code linuxptp
git checkout v2.0
```

NOTE: Apply patch (this is required to work around an issue with some of the GM PTP packet sizes.)



```
timestamp_post_recv(m, &m->follow_up.preciseOriginTimestamp);
break;
case DELAY_RESP:
+ cnt -= 4;
timestamp_post_recv(m, &m->delay_resp.receiveTimestamp);
port_id_post_recv(&m->delay_resp.requestingPortIdentity);
break;
```

2. Build and install ptp41.

```
# make && make install
```

3. Modify configs/default.cfg to control frequency of Sync interval to 0.0625 s.

```
logSyncInterval -4
```

B.1.2 ptp4l

This tool handles all PTP traffic on the provided NIC port and updated PHC. It also determines the Grandmaster Clock and tracks synchronization status. This tool can be run as a daemon or as a regular Linux* application. When the synchronization is reached, it gives output on the screen for precision tracking. The configuration file of ptp4l contains many options that can be set to get the best synchronization precision. Although, even with default.cfg the synchronization quality is excellent.

To start the synchronization process run:

```
cd linuxptp
./ptp41 -f ./configs/default.cfg -2 -i <if_name> -m
```

The output below shows what the output on non-master node should look like when synchronization is started. This means that PHC on this machine is synchronized to the master PHC.

```
ptp41[1434165.358]: port 1: INITIALIZING to LISTENING on INIT COMPLETE
ptp41[1434165.358]: port 0: INITIALIZING to LISTENING on INIT COMPLETE
ptp41[1434166.384]: port 1: new foreign master fcaf6a.fffe.029708-1
ptp41[1434170.352]: selected best master clock fcaf6a.fffe.029708
ptp41[1434170.352]: updating UTC offset to 37
ptp41[1434170.352]: port 1: LISTENING to UNCALIBRATED on RS SLAVE
ptp41[1434171.763]: master offset -5873 s0 freq -18397 path delay ptp41[1434172.763]: master offset -6088 s2 freq -18612 path delay
                                                                           2778
                                                                           2778
ptp41[1434172.763]: port 1: UNCALIBRATED to SLAVE on MASTER CLOCK SELECTED
2732
                                                                           2728
                                                                          2728
                                                                          2755
                                                                          2792
                                                                          2792
                                                                          2813
                                       9 s2 freq -18521 path delay
                                                                          2813
ptp41[1434183.763]: master offset
                                    11 s2 freq -18517 path delay
                                                                          2813
```

B.1.3 phc2sys

The PHC clock is independent from the system clock. Synchronizing only PHC does not make the system clock exactly the same as the master. The xRAN library requires use of the system clock to determine a common point in time on two machines (O-DU and RU) to start transmission at the same moment and keep time frames defined by O-RAN Fronthaul specification.

This application keeps the system clock updated to PHC. It makes it possible to use POSIX timers as a time reference in xRAN application.



Run phc2sys with the command:

```
cd linuxptp
./phc2sys -s enp25s0f0 -w -m -R 8
```

Command output will look like:

```
### ALTIME phc offset  
### 450 s2 freq -39119 delay  
### 450 s2 freq -38620 delay  
### 450 s2 freq -38484 delay  
### 450 s2 freq -38484 delay  
### 450 s2 freq -38484 delay  
### 450 s2 freq -38620 delay  
### 450
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    1354
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  1344
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    1347
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  1346
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             1340
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           1340
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           1349
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           1343
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             1342
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             1344
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             1341
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             1340
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                1340
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  1343
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    1342
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    1348
```

Configuration C3 27 can be simulated for O-DU using a separate server acting as Fronthaul Network and O-RU at the same time. O-RU server can be configured to relay PTP and act as PTP master for O-DU. Settings below can be used to instantiate this scenario. The difference is that on the O-DU side, the Fronthaul port can be used as the source of PTP as well as for U-plane and C-plane traffic.

- Follow the steps in Appendix B.1.1, PTP for Linux* Requirements to install PTP on the O-RU server.
- 2. Copy configs/default.cfg to configs/default slave.cfg and modify the copied file as below:

```
diff --git a/configs/default.cfg b/configs/default.cfg
old mode 100644
new mode 100755
index e23dfd7..f1ecaf1
--- a/configs/default.cfg
+++ b/configs/default.cfg
@@ -3,26 +3,26 @@
# Default Data Set
twoStepFlag
-slaveOnly
+slaveOnly
priority1
-priority2
                      128
+priority2
                      255
domainNumber
#utc offset
                      37
-clockClass
                      248
+clockClass
                      255
clockAccuracy 0xFE
offsetScaledLogVariance
                             TTTTXO
 free_running 0
 freq_est_interval
dscp event
 dscp general
-dataset_comparison
                      ieee1588
```



```
+dataset comparison
G.8275.defaultDS.localPriority 128
maxStepsRemoved
# Port Data Set
logAnnounceInterval
-logSyncInterval
+logSyncInterval
operLogSyncInterval 0
logMinDelayRegInterval 0
logMinPdelayReqInterval
@@ -37,7 +37,7 @@ G.8275.portDS.localPriority 128
asCapable
                       auto
BMCA
                      ptp
inhibit announce
-inhibit pdelay req
                      0
+#inhibit pdelay req
ignore source id
# Run time options
```

3. Start slave port toward PTP GM:

```
./ptp41 -f ./configs/default slave.cfg -2 -i enp25s0f0 -m
```

Example of output:

```
./ptp41 -f ./configs/default_slave.cfg -2 -i enp25s0f0 -m
ptp41[3904470.256]: selected /dev/ptp6 as PTP clock
ptp41[3904470.274]: port 1: INITIALIZING to LISTENING on INIT_COMPLETE
ptp41[3904470.275]: port 0: INITIALIZING to LISTENING on INIT_COMPLETE
ptp41[3904471.085]: port 1: new foreign master fcaf6a.fffe.029708-1
ptp41[3904475.053]: selected best master clock fcaf6a.fffe.029708
ptp41[3904475.053]: updating UTC offset to 37
ptp41[3904475.053]: port 1: LISTENING to UNCALIBRATED on RS SLAVE
1109
                                                                                                  1109
ptp41[3904478.029]: port 1: UNCALIBRATED to SLAVE on MASTER CLOCK SELECTED

      ptp41[3904479.029]: master offset
      86 s2 freq -18468 path delay

      ptp41[3904480.029]: master offset
      23 s2 freq -18505 path delay

      ptp41[3904481.029]: master offset
      3 s2 freq -18518 path delay

      ptp41[3904482.029]: master offset
      -169 s2 freq -18689 path delay

                                                                                                  1109
                                                                                                  1124
                                                                                                   1141
```

4. Synchronize local timer clock on O-RU for sample application

```
./phc2sys -s enp25s0f0 -w -m -R 8
```

Example of output:

```
./phc2sys -s enp25s0f0 -w -m -R 8
phc2sys[3904510.892]: CLOCK_REALTIME phc offset 343 s0 freq -38967 delay 1530
phc2sys[3904511.017]: CLOCK_REALTIME phc offset 368 s2 freq -38767 delay 1537
phc2sys[3904511.142]: CLOCK_REALTIME phc offset 339 s2 freq -38428 delay 1534
phc2sys[3904511.267]: CLOCK_REALTIME phc offset 298 s2 freq -38368 delay 1532
phc2sys[3904511.392]: CLOCK_REALTIME phc offset 239 s2 freq -38337 delay 1534
phc2sys[3904511.518]: CLOCK_REALTIME phc offset 145 s2 freq -38360 delay 1530
phc2sys[3904511.643]: CLOCK_REALTIME phc offset 106 s2 freq -38355 delay 1527
phc2sys[3904511.768]: CLOCK_REALTIME phc offset -30 s2 freq -38459 delay 1534
phc2sys[3904511.893]: CLOCK_REALTIME phc offset -92 s2 freq -38530 delay 1530
phc2sys[3904512.018]: CLOCK_REALTIME phc offset -173 s2 freq -38639 delay 1528
phc2sys[3904512.143]: CLOCK_REALTIME phc offset -246 s2 freq -38764 delay 1530
phc2sys[3904512.268]: CLOCK_REALTIME phc offset -300 s2 freq -38892 delay 1530
```

5. Modify configs/default.cfg as shown below to run PTP master on Fronthaul of O-RU.



```
diff --git a/configs/default.cfg b/configs/default.cfg
old mode 100644
new mode 100755
index e23dfd7..c9e9d4c
--- a/configs/default.cfg
+++ b/configs/default.cfg
@@ -15,14 +15,14 @@ free_running
freq est interval 1
dscp_event
dscp general
                      ieee1588
-dataset comparison
+dataset_comparison G.8275.x
G.8275.defaultDS.localPriority 128
maxStepsRemoved
# Port Data Set
logAnnounceInterval 1
-logSyncInterval
                               -4
+logSyncInterval
operLogSyncInterval
 logMinDelayReqInterval 0
 logMinPdelayReqInterval
@@ -37,7 +37,7 @@ G.8275.portDS.localPriority 128
asCapable
                       auto
                        ptp
inhibit_announce
-inhibit_pdelay_req
+#inhibit pdelay req
ignore source id
# Run time options
```

6. Start PTP master toward O-DU:

```
./ptp4l -f ./configs/default.cfg -2 -i enp175s0f1 -m
```

Example of output:

```
./ptp41 -f ./configs/default.cfg -2 -i enp175s0f1 -m
ptp41[3903857.249]: selected /dev/ptp3 as PTP clock
ptp41[3903857.266]: port 1: INITIALIZING to LISTENING on INIT_COMPLETE
ptp41[3903857.267]: port 0: INITIALIZING to LISTENING on INIT_COMPLETE
ptp41[3903863.734]: port 1: LISTENING to MASTER on ANNOUNCE_RECEIPT_TIMEOUT_EXPIRES
ptp41[3903863.734]: selected local clock 3cfdfe.fffe.bd005d as best master
ptp41[3903863.734]: assuming the grand master role
```

7. Synchronize local NIC PTP master clock to local NIC PTP slave clock.

```
./phc2sys -c enp175s0f1 -s enp25s0f0 -w -m -R 8
```

Example of output:

```
./phc2sys -c enp175s0f1 -s enp25s0f0 -w -m -R 8
 phc2sys[3904600.332]: enp175s0f1 phc offset
                                                                                   2042 s0 freq -2445 delay
                                                                                                                                    4525
pnczsys[3904600.710]: enp175s0f1 phc offset 2125 s2 freq phc2sys[3904600.836]: enp175s0f1 phc offset 1847 s2 freq phc2sys[3904600.961]: enp175s0f1 phc offset 1500 s2 freq phc2sys[3904601.086]: enp175s0f1 phc offset 1146 s2 freq phc2sys[3904601.086]: enp175s0f1 phc offset 877 s2 free phc2sys[3904601.212]: enp175s0f1 phc offset phc2sys[3904601.3371:
                                                                                                         -2223 delay
-98 delay
+262 delay
                                                                                                                                    4505
                                                                                                                                    4518
                                                                                                          +469 delay
                                                                                                                                    4515
                                                                                                           +565 delay
                                                                                                                                    4547
                                                                                                            +640 delay
                                                                                                                                    4542
                                                                                                          +543 delay
                                                                                                                                    4517
                                                                               189 s2 freq +370 delay
-125 s2 freq +113 delay
                                                                                                                                    4510
 phc2sys[3904601.462]: enp175s0f1 phc offset
                                                                                                                                    4554
 phc2sys[3904601.587]: enp175s0f1 phc offset
                                                                                -412 s2 freq
                                                                                                          -212 delay
                                                                                                                                    4513
```



- 8. On O-DU Install PTP for Linux tools from source code the same way as on O-RU above but no need to apply the patch for msg.c
- 9. Start slave port toward PTP master from O-RU using the same default_slave.cfg as on O-RU (see above) ./ptp41 -f ./configs/default slave.cfg -2 -i enp181s0f0 -m

Example of output:

```
./ptp41 -f ./configs/default_slave.cfg -2 -i enp181s0f0 -m
ptp41[809092.918]: selected /dev/ptp6 as PTP clock
ptp41[809092.934]: port 1: INITIALIZING to LISTENING on INIT_COMPLETE
ptp41[809092.934]: port 0: INITIALIZING to LISTENING on INIT_COMPLETE
ptp41[809092.949]: port 1: new foreign master 3cfdfe.fffe.bd005d-1
ptp41[809096.949]: selected best master clock 3cfdfe.fffe.bd005d
ptp41[809096.950]: port 1: LISTENING to UNCALIBRATED on RS_SLAVE
ptp41[809098.363]: port 1: UNCALIBRATED to SLAVE on MASTER_CLOCK_SELECTED
ptp41[809099.051]: rms 38643 max 77557 freq +719 +/- 1326 delay 1905 +/- 0
ptp41[809100.051]: rms 1134 max 1935 freq -103 +/- 680 delay 1891 +/- 4
ptp41[809101.051]: rms 453 max 855 freq +341 +/- 642 delay 1888 +/- 0
ptp41[809102.052]: rms 491 max 772 freq +1120 +/- 752 delay 1702 +/- 0
ptp41[809103.052]: rms 423 max 654 freq +1352 +/- 653 delay 1888 +/- 0
ptp41[809105.053]: rms 441 max 672 freq +1001 +/- 672 delay 1702 +/- 0
ptp41[809105.053]: rms 441 max 672 freq +807 +/- 709 delay 1826 +/- 88
ptp41[809107.054]: rms 401 max 466 freq +946 +/- 646 delay 1702 +/- 0
ptp41[809107.054]: rms 401 max 466 freq +946 +/- 646 delay 1702 +/- 0
ptp41[809108.055]: rms 401 max 502 freq +912 +/- 659
```

10. Synchronize local clock on O-DU for sample application or l1 application.

```
./phc2sys -s enp181s0f0 -w -m -R 8
```

Example of output:

```
./phc2sys -s enp181s0f0 -w -m -R 8
phc2sys[809127.123]: CLOCK_REALTIME phc offset
phc2sys[809127.249]: CLOCK_REALTIME phc offset
phc2sys[809127.374]: CLOCK_REALTIME phc offset
phc2sys[809127.500]: CLOCK_REALTIME phc offset
phc2sys[809127.500]: CLOCK_REALTIME phc offset
phc2sys[809127.625]: CLOCK_REALTIME phc offset
phc2sys[809127.625]: CLOCK_REALTIME phc offset
374 s2 freq -36561 delay
                                                                                                1646
                                                                                                1654
                                                                                                1648
                                                                                                1642
                                                                                                1643
1649
                                                                                                1650
                                                                                                1645
                                                                                                1643
                                                                                                1644
phc2sys[809128.503]: CLOCK REALTIME phc offset -349 s2 freq -37322 delay
                                                                                                1644
phc2sys[809128.629]: CLOCK REALTIME phc offset -402 s2 freq -37480 delay
                                                                                                1641
phc2sys[809128.754]: CLOCK REALTIME phc offset -377 s2 freq -37576 delay
                                                                                                1648
phc2sys[809128.879]: CLOCK REALTIME phc offset -467 s2 freq -37779 delay
phc2sys[809129.005]: CLOCK REALTIME phc offset -408 s2 freq -37860 delay
phc2sys[809129.130]: CLOCK REALTIME phc offset -480 s2 freq -38054 delay
phc2sys[809129.256]: CLOCK REALTIME phc offset -350 s2 freq -38068 delay
                                                                                                1650
```



B.1.5 Support in xRAN Library

The xRAN library provides an API to check whether PTP for Linux is running correctly. There is a function called $xran_is_synchronized()$. It checks if ptp41 and phc2sys are running in the system by making PMC tool requests for the current port state and comparing it with the expected value. This verification should be done before initialization.

NOTE: "SLAVE" is the only expected value in this release; only a non-master scenario is supported currently.



Appendix C eCPRI DDP Profile for Columbiaville (Experimental Feature)

C.1 Introduction

The Intel® Ethernet 800 Series is the next generation of Intel® Ethernet Controllers and Network Adapters. The Intel® Ethernet 800 Series is designed with an enhanced programmable pipeline, allowing deeper and more diverse protocol header processing. This on-chip capability is called Dynamic Device Personalization (DDP). In the Intel® Ethernet 800 Series, a DDP profile is loaded dynamically on driver load per device.

A general-purpose DDP package is automatically installed with all supported Intel® Ethernet 800 Series drivers on Windows*, ESX*, FreeBSD*, and Linux* operating systems, including those provided by the Data Plane Development Kit (DPDK). This general-purpose DDP package is known as the OS-default package.

For more information on DDP technology in the Intel® Ethernet 800 Series products and the OS-default package, refer to the Intel® Ethernet Controller E810 Dynamic Device Personalization (DDP) Technology Guide, published here: https://cdrdv2.intel.com/v1/dl/getContent/617015.

This document describes an optional DDP package targeted towards the needs of Wireless and Edge (Wireless Edge) customers. This Wireless Edge DDP package (v1.3.22.101) adds support for eCPRI protocols in addition to the protocols in the OS-default package. The Wireless Edge DDP package is supported by DPDK.

Starting from DPDK 21.02 drivers and in the future will also be supported by the Intel® Ethernet 800 Series ice driver. on Linux operating systems. The Wireless DDP Package can be loaded on all Intel® Ethernet 800 Series devices, or different packages can be selected via serial number per device.

C.2 Software/Firmware Requirements

The specific DDP package requires certain firmware and DPDK versions and Intel® Ethernet 800 Series firmware/NVM versions. Support for eCPRI DDP profile included starting from Columbiaville (CVL)release 2.4 or later. The required DPDK version contains the support of loading the specific Wireless Edge DDP package.

- Intel Ethernet 800 Series Linux Driver (ice) 1.4.0 (or later)
- Wireless Edge DDP Package version (ice wireless edge) 1.3.22.101
- Intel[®] Ethernet 800 Series firmware version 1.5.4.2 (or later)
- Intel Ethernet 800 Series NVM version 2.4 (or later)
- DPDK version—21.02 (or later)

TE: For FlexRAN release 21.03, corresponding support of CVL 2.4 driver pack and DPDK 21.02 is "experimental" and subject to additional testing and potential changes.

C.3 DDP Package Setup

The Intel® Ethernet 800 Series Comms DDP package supports only Linux-based operating systems currently.

Currently, the eCPRI is fully supported only by DPDK 21.02. It can be loaded either by DPDK or the Intel® Ethernet 800 Series Linux base driver.



C.3.1 Wireless Edge DDP Package

For details on how to set up DPDK, refer to Intel® Ethernet Controller E810 Data Plane Development Kit (DPDK) Configuration Guide (Doc ID: 633514).

There are two methods where DDP package can be loaded and used under DPDK (see <u>Section C.3.2</u> and <u>Section C.3.2</u>). For both methods, the user must obtain the ice_wireless_edge-1.3.22.101.pkg or later from Intel (please contact your Intel representative for more information)

C.3.2 Option 1: ice Linux Base Driver

The first option is to have the ice Linux base driver load the package.

The *ice* Linux base driver looks for the symbolic link *intel/ice/ddp/ice.pkg* under the default firmware search path, checking the following folders in order:

- /lib/firmware/updates/
- /lib/firmware/

To install the Comms package, copy the extracted .pkg file and its symbolic link to /lib/firmware/updates/intel/ice/ddp as follows, and reload the ice driver:

```
# cp /usr/tmp/ice_wireless_edge-1.3.22.101.pkg /lib/firmware/updates/intel/ice/ddp/
# ln -sf /lib/firmware/updates/intel/ice/ddp/ice_wireless_edge-1.3.22.101.pkg
/lib/firmware/updates/intel/ice/ddp/ice.pkg
# modprobe -r irdma
# modprobe -r ice
# modprobe ice
```



The kernel message log (dmesg) indicates status of package loading in the system. If the driver successfully finds and loads the DDP package, dmesg indicates that the DDP package successfully loaded. If not, the driver transitions to safe mode.

Once the driver loads the package, the user can unbind the *ice* driver from a desired port on the device so that DPDK can utilize the port.

The following example unbinds Port 0 and Port 1 of device on Bus 6, Device 0. Then, the port is bound to either igb uio or vfio-pci.

```
# ifdown <interface>
# dpdk-devbind -u 06:00.0
# dpdk-devbind -u 06:00.1
# dpdk-devbind -b igb_uio 06:00.0 06:00.1
```

C.3.3 Option 2: DPDK Driver Only

The second method is if the system does not have the *ice* driver installed. In this case, the user can download the DDP package from the Intel download center and extract the zip file to obtain the package (*.pkg*) file. Similar to the Linux base driver, the DPDK driver looks for the *intel/ddp/ice.pkg* symbolic link in the kernel default firmware search path /lib/firmware/updates and /lib/firmware/.

Copy the extracted DDP .pkg file and its symbolic link to /lib/firmware/intel/ice/ddp, as follows.

```
# cp /usr/tmp/ice_wireless_edge-1.3.22.101 /lib/firmware/intel/ice/ddp/
# cp /usr/tmp/ice.pkg /lib/firmware/intel/ice/ddp/
```

When DPDK driver loads, it looks for *ice.pkg* to load. If the file exists, the driver downloads it into the device. If not, the driver transitions into safe mode.

C.3.4 Loading DDP Package to a Specific Intel® Ethernet 800 Series Device

On a host system running with multiple Intel® Ethernet 800 Series devices, there is sometimes a need to load a specific DDP package on a selected device while loading a different package on the remaining devices.

The Intel[®] Ethernet 800 Series Linux base driver and DPDK driver can both load a specific DDP package to a selected adapter based on the device's serial number. The driver does this by looking for a specific symbolic link package filename containing the selected device's serial number.

The following example illustrates how a user can load a specific package (e.g., *ice_wireless_edge-1.3.22.101*) on the device of Bus 6.

1. Find device serial number.

To view bus, device, and function of all Intel Ethernet 800 Series Network Adapters in the system:

```
# lspci | grep -i Ethernet | grep -i Intel
06:00.0 Ethernet controller: Intel Corporation Ethernet Controller E810-C for QSFP (rev
01)
06:00.1 Ethernet controller: Intel Corporation Ethernet Controller E810-C for QSFP (rev
01)
82:00.0 Ethernet controller: Intel Corporation Ethernet Controller E810-C for SFP (rev
01)
82:00.1 Ethernet controller: Intel Corporation Ethernet Controller E810-C for SFP (rev
01)
```



```
82:00.2 Ethernet controller: Intel Corporation Ethernet Controller E810-C for SFP (rev 01) 82:00.3 Ethernet controller: Intel Corporation Ethernet Controller E810-C for SFP (rev 01)
```

Use the **Ispci** command to obtain the selected device serial number:

```
# lspci -vv -s 06:00.0 | grep -i Serial
Capabilities: [150 v1] Device Serial Number 35-11-a0-ff-ff-ca-05-68
```

Or, fully parsed without punctuation:

```
# lspci -vv -s 06:00.0 | grep Serial | awk '{print $7}' | sed s/-//g 3511a0ffffca0568
```

2. Rename the package file with the device serial number in the name.

Copy the specific package over to /lib/firmware/updates/intel/ice/ddp (or /lib/firmware/intel/ice/ddp) and create a symbolic link with the serial number linking to the package, as shown. The specific symbolic link filename starts with "ice-" followed by the device serial in lower case without dash ('-').

```
# ln -s /lib/firmware/updates/intel/ice/ddp/ice_wireless_edge-1.3.22.101.pkg
/lib/firmware/updates/intel/ice/ddp/ice-3511a0ffffca0568.pkg
```

3. If using Linux kernel driver (ice), reload the base driver (not required if using only DPDK driver).

```
# rmmod ice
# modprobe ice
```

The driver loads the specific package to the selected device and the OS-default package to the remaining Intel® Ethernet 800 Series devices in the system.

4. Verify.

C.3.5 For kernel driver:

Example of output of successful load of Wireless Edge Package to all devices:

```
# dmesg | grep -i "ddp \| safe"
[606960.921404] ice 0000:18:00.0: The DDP package was successfully loaded: ICE
Wireless Edge Package version 1.3.22.101
[606961.672999] ice 0000:18:00.1: DDP package already present on device: ICE Wireless
Edge Package version 1.3.22.101
[606962.439067] ice 0000:18:00.2: DDP package already present on device: ICE Wireless
Edge Package version 1.3.22.101
[606963.198305] ice 0000:18:00.3: DDP package already present on device: ICE Wireless
Edge Package version 1.3.22.101
[606964.252076] ice 0000:51:00.0: The DDP package was successfully loaded: ICE
Wireless Edge Package version 1.3.22.101
[606965.017082] ice 0000:51:00.1: DDP package already present on device: ICE Wireless
Edge Package version 1.3.22.101
[606965.802115] ice 0000:51:00.2: DDP package already present on device: ICE Wireless
Edge Package version 1.3.22.101
[606966.576517] ice 0000:51:00.3: DDP package already present on device: ICE Wireless
Edge Package version 1.3.22.101
```

C.3.6 If using only DPDK driver:

Verify using DPDK's testpmd application to indicate the status and version of the loaded DDP package.



Example of eCPRI config with dpdk-testpmd

16 O-RAN eCPRI IQ streams mapped to 16 independent HW queues each.

```
#./dpdk-testpmd -1 22-25 -n 4 -a 0000:af:01.0 -- -i --rxq=16 --txq=16 --cmdline-
file=/home/flexran xran/ddp.txt
cat /home/flexran xran/ddp.txt
port stop 0
port config mtu 0 9600
port config 0 rx offload vlan strip on
port start 0
flow create 0 ingress pattern eth / ecpri common type iq data pc id is 0x0000 / end
actions queue index 0 / mark / end
flow create 0 ingress pattern eth / ecpri common type iq_data pc_id is 0x0001 / end
actions queue index 1 / mark / end
flow create 0 ingress pattern eth / ecpri common type iq data pc id is 0x0002 / end
actions queue index 2 / mark / end
flow create 0 ingress pattern eth / ecpri common type iq data pc id is 0x0003 / end
actions queue index 3 / mark / end
flow create 0 ingress pattern eth / ecpri common type iq data pc id is 0x0004 / end
actions queue index 4 / mark / end
flow create 0 ingress pattern eth / ecpri common type iq_data pc_id is 0 \times 0005 / end
actions queue index 5 / mark / end
flow create 0 ingress pattern eth / ecpri common type iq data pc id is 0x0006 / end
actions queue index 6 / mark / end
flow create 0 ingress pattern eth / ecpri common type iq data pc id is 0 \times 0007 / end
actions queue index 7 / mark / end
flow create 0 ingress pattern eth / ecpri common type iq data pc id is 0x0008 / end
actions queue index 8 / mark / end
flow create 0 ingress pattern eth / ecpri common type iq data pc id is 0x0009 / end
actions queue index 9 / mark / end
flow create 0 ingress pattern eth / ecpri common type iq data pc id is 0x000a / end
actions queue index 10 / mark / end
flow create 0 ingress pattern eth / ecpri common type iq data pc id is 0x000b / end
actions queue index 11 / mark / end
flow create 0 ingress pattern eth / ecpri common type iq_data pc_id is 0x000c / end
actions queue index 12 / mark / end
flow create 0 ingress pattern eth / ecpri common type iq_data pc_id is 0x000d / end
actions queue index 13 / mark / end
flow create 0 ingress pattern eth / ecpri common type iq data pc id is 0x000e / end
actions queue index 14 / mark / end
flow create 0 ingress pattern eth / ecpri common type iq data pc id is 0x000f / end
actions queue index 15 / mark / end
set fwd rxonly
start
show fwd stats all
```

C.4 O-RAN Front haul eCPRI

Intel® Ethernet 800 Series DDP capabilities support several functionalities important for the O-RAN FH.

- RSS for packet steering based on ecpriMessage
- RSS for packet steering based on ecpriRtcid/ecpriPcid
- Queue mapping based on ecpriRtcid/ecpriPcid



Queue mapping based on ecpriMessage




Figure 30. O-RAN FH VNF

Table 13. Patterns & Input Sets for Flow Director and RSS (DPDK 21.02)

Pattern	Input Set	
ETH / VLAN / eCPRI	ecpriMessage ecpriRtcid/ecpriPcid	
ETH / VLAN /IPv4(6)/UDP/eCPRI	ecpriMessage ecpriRtcid/ecpriPcid (*)	

Note: * IP/UDP is not used with FlexRAN

C.4.1 Limitations

DPDK 21.02 allows up to 1024 queues per VF and RSS across up to 64 receive queues.

C.5 RTE Flow API

The DPDK Generic flow API (rte_flow) will be used to the configure the Intel® Ethernet 800 Series to match specific ingress traffic and forward it to specified queues.

For further information, please refer to section 11 of the <u>DPDK Programmers guide</u>.

The specific ingress traffic is identified by a matching pattern which is composed of one or more Pattern items (represented by struct rte_flow_item). Once a match has been determined one or more associated Actions (represented by struct rte_flow_action) will be performed.



A number of flow rules can be combined such that one rule directs traffic to a queue group based on *ecpriMessage/ecpriRtcid/ecpriPcid* etc. and a second rule distributes matching packets within that queue group using RSS.

The following subset of the RTE Flow API functions can be used to validate, create and destroy RTE Flow rules.

C.5.1 RTE Flow Rule Validation

A RTE Flow rule is created via a call to the function $rte_flow_validate$. This can be used to check the rule for correctness and whether it would be accepted by the device given sufficient resources.

port_id : port identifier of Ethernet device attr : flow rule attributes(ingress/egress)

pattern: pattern specification (list terminated by the END pattern item).

action : associated actions (list terminated by the END action).

error : perform verbose error reporting if not NULL.

0 is returned upon success, negative errno otherwise.

C.5.2 RTE Flow Rule Creation

A RTE Flow rule is created via a call to the function rte_flow_create.

port_id : port identifier of Ethernet device attr : flow rule attributes(ingress/egress)

pattern: pattern specification (list terminated by the END pattern item).

action : associated actions (list terminated by the END action).

error : perform verbose error reporting if not NULL.

A valid handle is returned upon success, NULL otherwise.

C.5.3 RTE Flow Rule Destruction



A RTE Flow rule is destroyed via a call to the function rte flow destroy.

```
int
        rte flow destroy(uint16 t port id,
                 struct rte_flow *flow,
                 struct rte_flow_error *error);
```

port identifier of Ethernet device port_id: flow flow rule handle to destroy.

perform verbose error reporting if not NULL.

0 is returned upon success, negative errno otherwise.

C.5.4 RTE Flow Flush

All flow rule handles associated with a port can be released using rte_flow_flush. They are released as with successive calls to function rte flow destroy.

```
rte flow flush(uint16_t port_id,
                struct rte flow error *error);
```

port identifier of Ethernet device port_id:

error : perform verbose error reporting if not NULL.

0 is returned upon success, negative errno otherwise.

RTE Flow Query C.5.5

A RTE Flow rule is queried via a call to the function rte_flow_query .

```
int rte flow query (uint16 t port id,
                 struct rte flow *flow,
                 const struct rte_flow_action *action,
                 void *data,
                 struct rte flow error *error);
```

port id: port identifier of Ethernet device

flow flow rule handle to query

action to query, this must match prototype from flow rule. action : pointer to storage for the associated query data type data

perform verbose error reporting if not NULL. error

0 is returned upon success, negative errno otherwise.



C.6 RTE Flow Rules

A flow rule is the combination of attributes with a matching pattern and a list of actions. Each flow rules consists of:

- Attributes (represented by struct rte_flow_attr): properties of a flow rule such as its direction (ingress or egress) and priority.
- Pattern Items (represented by struct rte_flow_item): is part of a matching pattern that either matches specific packet data or traffic properties.
- Matching pattern: traffic properties to look for, a combination of any number of items.
- Actions (represented by struct rte_flow_action): operations to perform whenever a packet is matched by a pattern.

C.6.1 Attributes

Flow rule patterns apply to inbound and/or outbound traffic. For the purposes described in later sections the rules apply to ingress only. For further information, please refer to section 11 of the DPDK Programmers guide.

```
struct rte_flow_attr {
     uint32_t group;
     uint32_t priority;
     uint32_t ingress:1;
     uint32_t egress:1;
     uint32_t transfer:1;
     uint32_t reserved:29;
};
```

C.6.2 Pattern items

For the purposes described in later sections Pattern items are primarily for matching protocol headers and packet data, usually associated with a specification structure. These must be stacked in the same order as the protocol layers to match inside packets, starting from the lowest.

Item specification structures are used to match specific values among protocol fields (or item properties).

Up to three structures of the same type can be set for a given item:

- spec: values to match (e.g. a given IPv4 address).
- last: upper bound for an inclusive range with corresponding fields in spec.
- mask: bit-mask applied to both spec and last whose purpose is to distinguish the values to take into account and/or partially mask them out (e.g. in order to match an IPv4 address prefix).

Table 14. Example RTE FLOW Item Types

Item Type*	Description	Specification Structure
END	End marker for item lists	None
VOID	Used as a placeholder for convenience	None
ETH	Matches an Ethernet header	rte_flow_item_eth
VLAN	Matches an 802.1Q/ad VLAN tag.	rte_flow_item_vlan
IPV4	Matches an IPv4 header	rte_flow_item_ipv4



IPV6	Matches an IPv6 header	rte_flow_item_ipv6
ICMP	Matches an ICMP header.	rte_flow_item_icmp
UDP	Matches an UDP header.	rte_flow_item_udp
TCP	Matches a TCP header.	rte_flow_item_tcp
SCTP	Matches a SCTP header.	rte_flow_item_sctp
VXLAN	Matches a VXLAN header.	rte_flow_item_vxlan
NVGRE	Matches a NVGRE header.	rte_flow_item_nvgre
ECPRI	Matches ECPRI Header	rte_flow_item_ecpri

```
RTE_FLOW_ITEM_TYPE_ETH

struct rte_flow_item_eth {
         struct rte_ether_addr dst; /**< Destination MAC. */
         struct rte_ether_addr src; /**< Source MAC. > */
         rte_be16_t type; /**< EtherType or TPID.> */
};

struct rte_ether_addr {
        uint8_t addr_bytes[RTE_ETHER_ADDR_LEN]; /**< Addr bytes in tx order */
}</pre>
```

```
struct rte_flow_item_ipv4 {
    struct rte_ipv4_hdr hdr; /**< IPv4 header definition. */
};

struct rte_ipv4_hdr {
    uint8_t version_ihl; /**< version and header length */
    uint8_t type_of_service; /**< type of service */
    rte_bel6_t total_length; /**< length of packet */
    rte bel6_t packet_id; /**< packet ID */
    rte bel6_t fragment_offset; /**< fragmentation offset */
    uint8_t time_to_live; /**< time to live */
    uint8_t next_proto_id; /**< protocol ID */
    rte_bel6_t hdr_checksum; /**< header checksum */
    rte_be32_t src_addr; /**< source address */
    rte_be32_t dst_addr; /**< destination address */
}

RTE_FLOW_ITEM_TYPE_UDP

struct rte_flow_item_udp {
    struct rte_udp_hdr hdr; /**< UDP header definition. */
};

struct rte_udp_hdr {
    rte_bel6_t dst_port; /**< UDP source_port. */
    rte_bel6_t dst_port; /**< UDP destination port. */
    rte_bel6_t dgram_len; /**< UDP datagram_length */
    rte_bel6_t dgram_cksum; /**< UDP datagram_checksum */
}</pre>
```



```
RTE FLOW ITEM TYPE ECPRI
struct rte flow item ecpri {
       struct rte ecpri combined msg hdr hdr;
struct rte ecpri combined msg hdr {
        struct rte_ecpri_common_hdr common;
                 struct rte ecpri msg iq data type0;
                  struct rte ecpri msg bit seq type1;
                  struct rte ecpri msg rtc ctrl type2;
                 struct rte_ecpri_msg_bit_seq type3;
                 struct rte_ecpri_msg_rm_access type4;
                 struct rte ecpri msg delay measure type5;
                 struct rte ecpri msg remote reset type6;
                 struct rte ecpri msg event ind type7;
                 rte be32 t dummy[3];
        };
struct rte_ecpri_common_hdr {
                 rte be32 t u32; /**< 4B common header in BE */
                  struct {
#if RTE BYTE ORDER == RTE LITTLE ENDIAN
                         uint32 t size:16; /**< Payload Size */
                         uint32 t type:8; /**< Message Type */</pre>
                         uint32 t c:1; /**< Concatenation Indicator */</pre>
                         uint32 t res:3; /**< Reserved */</pre>
                         uint32 t revision:4; /**< Protocol Revision */</pre>
#elif RTE BYTE ORDER == RTE BIG ENDIAN
                         uint32 t revision:4; /**< Protocol Revision */</pre>
                         uint32_t res:3; /**< Reserved */</pre>
                         uint32_t c:1; /**< Concatenation Indicator */</pre>
                         uint32_t type:8; /**< Message Type */
                         uint32 t size:16; /**< Payload Size */
#endif
                 1;
        };
* eCPRI Message Header of Type #0: IQ Data
struct rte_ecpri_msg_iq_data {
       rte be16 t pc id;
                                                      /**< Physical channel ID */
       rte be16 t seq id;
                                                      /**< Sequence ID */
};
 * eCPRI Message Header of Type #1: Bit Sequence
struct rte_ecpri_msg_bit_seq {
       rte_be16_t pc_id;
                                                      /**< Physical channel ID */
                                                       /**< Sequence ID */
        rte be16 t seq id;
* eCPRI Message Header of Type #2: Real-Time Control Data
struct rte ecpri msg rtc ctrl {
```



```
rte be16 t rtc_id;
                                                         /**< Real-Time Control Data ID */
        rte be16 t seq id;
                                                         /**< Sequence ID */
 * eCPRI Message Header of Type #3: Generic Data Transfer
struct rte ecpri msg gen data {
        rte be32 t pc id;
                                                         /**< Physical channel ID */
        rte be32 t seq id;
                                                         /**< Sequence ID */
};
* eCPRI Message Header of Type #4: Remote Memory Access
RTE STD C11
struct rte_ecpri_msg_rm_access {
#if RTE_BYTE_ORDER == RTE_LITTLE_ENDIAN
uint32_t ele_id:16;
uint32_t rr:4;
uint32_t rw:4;
uint32_t rma_id:8;
#elif RTE_BYTE_ORDER == RTE_BIG_ENDIAN
                                                         /**< Element ID */
                                                         /**< Req/Resp */
                                                         /**< Read/Write */
                                                         /**< Remote Memory Access ID */
        uint32 t rma id:8;
                                                         /**< Remote Memory Access ID */
        uint32 t rw:4;
                                                         /**< Read/Write */
        uint32 t rr:4;
                                                         /**< Reg/Resp */
        uint32 t ele id:16;
                                                         /**< Element ID */
#endif
                                  /**< 48-bits address */
        uint8 t addr[6];
                                                         /**< number of bytes */
        rte be16 t length;
 * eCPRI Message Header of Type #5: One-Way Delay Measurement
struct rte ecpri msg delay measure {
        uint8 t msr id;
                                                         /**< Measurement ID */
                                                         /**< Action Type */
        uint8 t act type;
/**
* eCPRI Message Header of Type #6: Remote Reset
struct rte ecpri msg remote reset {
                                                        /**< Reset ID */
       rte_be16_t rst_id;
                                                         /**< Reset Code Op */
        uint8_t rst_op;
};
/**
 * eCPRI Message Header of Type #7: Event Indication
struct rte ecpri msg event ind {
        uint8 t evt id;
                                                         /**< Event ID */
        uint8 t evt_type;
                                                         /**< Event Type */
        uint8 t seq;
                                                         /**< Sequence Number */
        uint8 t number;
                                                         /**< Number of Faults/Notif */</pre>
```

161



C.6.3 Matching Patterns

A matching pattern is formed by stacking items starting from the lowest protocol layer to match. Patterns are terminated by END pattern item.

Actions

Each possible action is represented by a type. An action can have an associated configuration object. Actions are terminated by the END action.

Table 15. RTE FLOW Actions

Action*	Description	Configuration Structure
END	End marker for action lists	none
VOID	Used as a placeholder for convenience	none
PASSTHRU	Leaves traffic up for additional processing by subsequent flow rules; makes a flow rule non-terminating.	none
MARK	Attaches an integer value to packets and sets PKT_RX_FDIR and PKT_RX_FDIR_ID mbuf flags	rte_flow_action_mark
QUEUE	Assigns packets to a given queue index	rte_flow_action_queue
DROP	Drops packets	none
COUNT	Enables Counters for this flow rule	rte_flow_action_count
RSS	Similar to QUEUE, except RSS is additionally performed on packets to spread them among several queues according to the provided parameters.	rte_flow_action_rss
VF	Directs matching traffic to a given virtual function of the current device	rte_flow_action_vf

C.6.4 Route to specific Queue id based on ecpriRtcid/ecpriPcid

An RTE Flow Rule will be created to match an eCPRI packet with a specific pc_id value and route it to specified queues.

Pattern Items

Table 16. Pattern Items to match eCPRI packet with a Specific Physical Channel ID (pc_id)

Index	Item	Spec	Mask
0	Ethernet	0	0
1	eCPRI	hdr.common.type = RTE_ECPRI_MSG_TYPE_IQ_DATA; hdr.type0.pc_id = pc_id;	hdr.common.type = 0xff; hdr.type0.pc_id = 0xffff;
2	END	0	0

The following code sets up the RTE_FLOW_ITEM_TYPE_ETH and RTE_FLOW_ITEM_TYPE_ECPRI Pattern Items.



The RTE_FLOW_ITEM_TYPE_ECPRI Pattern is configured to match on the pc_id value (in this case 8 converted to Big Endian byte order).

```
uint8 t pc id be = 0x0800;
#define MAX PATTERN NUM
                                    3
struct rte_flow_item pattern[MAX_PATTERN_NUM];
struct rte_flow_action action[MAX_ACTION_NUM];
struct rte flow item ecpri ecpri spec;
struct rte_flow_item_ecpri ecpri_mask;
/* Ethernet */
patterns[0].type = RTE_FLOW_ITEM_TYPE_ETH;
patterns[0].spec = 0;
patterns[0].mask = 0;
/* ECPRI */
ecpri_spec.hdr.common.type = RTE_ECPRI_MSG_TYPE_IQ_DATA;
ecpri_spec.hdr.type0.pc_id = pc_id_be;
ecpri_mask.hdr.common.type = 0xff;
ecpri_mask.hdr.type0.pc_id = 0xffff;
ecpri_spec.hdr.common.u32 = rte_cpu_to_be_32(ecpri_spec.hdr.common.u32);
pattern[1].type = RTE_FLOW_ITEM_TYPE_ECPRI;
pattern[1].spec = &ecpri_spec;
pattern[1].mask = &ecpri_mask;
/* END the pattern array */
patterns[2].type = RTE_FLOW_ITEM_TYPE_END
```

Action

Table 17. QUEUE action for given queue id

Index	Action	Fields	Description	Value
0	QUEUE	index	queue indices to use	Must be 0,1,2,3, etc
1	END			

The following code sets up the action RTE_FLOW_ACTION_TYPE_QUEUE and calls the rte_flow_create function to create the RTE Flow rule.



```
#define MAX_ACTION_NUM 2
uint16_t rx_q = 4;
struct rte_flow_action_queue queue = { .index = rx_q };

struct rte_flow *handle;
struct rte_flow_error err;
struct rte_flow_action actions[MAX_ACTION_NUM];
struct rte_flow_attr attributes = { .ingress = 1 };

action[0].type = RTE_FLOW_ACTION_TYPE_QUEUE;
action[0].conf = &queue;
action[1].type = RTE_FLOW_ACTION_TYPE_END;

handle = rte_flow_create (port_id, &attributes, patterns, actions, &err);
```