




GTC4Lusso USA - Identification plates and labels - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

04.02 Identification plates and labels



- A** - VIN plate (Vehicle Identification Number)
- B** - Stop&Start system warning
- C** - Brake fluid tank
- D** - Tyre type and pressure label
- E** - Checking the engine oil level
- F** - High voltage warning
- G** - Engine and gearbox oil identification
- H** - Driver and passenger side airbag hazard warning
- I** - Radiator with antifreeze label
- M** - Fuel specifications

- N** - Tyre pressure monitoring system identifier label
- O** - Original paintwork label
- P** - Max. speed with winter tyres label
- Q** - Vehicle emissions control information label (VECI)
- R** - Vehicle identification label
- T** - Safety standard compliance label

VIN label (Vehicle Identification Number)



Located on rear driver side door jamb.

Stop&Start system warning



Located on right hand engine compartment cosmetic shield.

Brake fluid tank



Located on left hand engine compartment cosmetic shield.

Tyre type and pressure



Located on driver side door.

Checking the engine oil level




Located on right hand engine compartment cosmetic shield.

High voltage warning



Located on right hand engine compartment cosmetic shield.

Engine and gearbox oil identification



Located on right hand engine compartment cosmetic shield.

Driver and passenger side airbag hazard warning



Located above passenger side sun visor.



Located above driver side sun visor.

Radiator containing antifreeze



Located on right hand engine compartment cosmetic shield.

Fuel specifications



Located on inner side of fuel filler flap.

TPMS system installed warning



Located on driver side door.

Original paint



Located on inner side of engine compartment lid.

Maximum speed with winter tyres



Located on rear driver side door jamb.

Vehicle emissions control information label (VECI)




Located on inner side of engine compartment lid.

Vehicle identification



Located on rear driver side door jamb.

'Do not install child seat on passenger seat' label



Located above glove compartment.

Safety standard compliance label



Located on rear driver side door jamb.