



GTC4Lusso USA - Checking the Blow-by system pipes and connections - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

A3.16 Checking the Blow-by system pipes and connections


Checking Blow-by system pipes and connections

➤ Remove the engine compartment cosmetic shields ( E3.14).


 Remove the right hand lateral cosmetic shield.

➤ Remove the front wheelhouses ( E3.05).

 Remove the rear element of the front right hand wheelhouse.



- Check the condition of the unions of the respective pipes.
- If any leakage is noted, replace the pipe and/or the respective clamp.



- Check the condition of the unions of the respective pipes.
- If any leakage is noted, replace the pipe and/or the respective clamp.



- Check the condition of the unions of the respective pipes.
- If any leakage is noted, replace the pipe and/or the respective clamp.

- Refit the front wheelhouses (🔧 E3.05).
 - ❗ Refit the rear element of the front right hand wheelhouse.
- Refit the engine compartment cosmetic shields (🔧 E3.14).
 - ❗ Remove the right hand lateral cosmetic shield.