



GTC4Lusso USA - Checking proper installation and function of seats and seat belts - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.
Copyright by Ferrari S.p.A. - P.IVA 00159560366

A3.25 Checking proper installation and function of seats and seat belts

Checking proper installation and function of seats and seat belts

- With the seat adjustment controls, check that the electrical seats move through their entire adjustment travel without impediment.
- Check that the seat guides are securely fastened to the floor mounts.
- Lubricate the guide connections and sliding surfaces with waterproof lithium grease.
- Check that the seat belt anchor screws are properly tightened.