



GTC4Lusso USA - Tightening torques - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

B1.03 Tightening torques



Tightening torque		Nm	Class
Fastening engine earth braid	Screw	18 Nm	B
Fastening engine oil pipes leading from tank	Screw	10 Nm	B
Fastening clamp on water pipe leading from radiator to hose union	Screw collar	5 Nm	B
Fastening engine oil delivery pipe for thermostat to section	Screw	9 Nm	B
Fastening spark plugs	Spark plug	11 Nm	A
Fastening the active carbon filter	Screw	9 Nm	B
Fastening the active carbon filter cover	Screw	9 Nm	B
Fastening the fuel vapour separator mounting bracket	Screw	9 Nm	B
Fastening fuel pipes to chassis	Screw / Nut	9 Nm	B
Fastening fuel pipe retainer brackets	Screw / Nut	5 Nm	B
Fastening fuel pump filter ground cable	Screw	4 Nm	B
Fastening fuel tank	Screw (pretightening)	12 Nm	A
	Screw	24 Nm	A
Fastening fuel tank heat shield	Screw	9 Nm	A
Fastening fuel tank inspection cover	Nut	5 Nm	B
Fastening the fuel pump filters	Screw	5 Nm	B
Fastening the fuel level sensor	Screw	5 Nm	B
Fastening fuel filler neck	Screw	5 Nm	B
Fastening engine oil filter	Filter	30 Nm	B
Fastening engine oil tank	Screw	24 Nm	B
	Screw	9 Nm	B
	Nut	9 Nm	B



Tightening torque		Nm	Class
Fastening engine oil return pipe leading from thermostat valve to tank Products to use: ZEPLON Spray	Union	70 Nm	B
Fastening engine oil delivery pipe leading from tank to section Products to use: ZEPLON Spray	Nut	10 Nm	B
Fastening engine oil delivery pipe leading from tank to section Products to use: ZEPLON Spray Products to use: ZEPLON Spray	Nut Nut	10 Nm 10 Nm	B B
Fastening the magnetic engine oil drain plug	Magnetic plug	60 Nm	B
Fastening engine oil pipes leading from thermostat valve to radiator	Ring nut	70 Nm	B
Fastening the expansion tank	Screw	9 Nm	B
Fastening water/oil pump to crankcase	Screw (pretightening)	5 Nm	0
	Screw	25 Nm	B
Fastening hose connector to water/oil pump	Screw	10 Nm	B
Fastening engine mounting strut to crankcase	Screw	45 Nm	A
Fastening oil pipe leading from engine to disconnecter	Nut	20 Nm	B
Fastening engine oil pipe to water/oil pump	Screw	10 Nm	B
Fastening the radiator assemblies	Nut	24 Nm	C
Fastening engine coolant filler pipe	Screw	9 Nm	B
Fastening engine coolant pipes	Screw collar	5 Nm	B
	Screw collar	4 Nm	B
Fastening engine coolant pressure switch/thermostat	Screw	9 Nm	B
Fastening the radiator air duct	Screw	5 Nm	B
Fastening the resonator pipes	Screw collar	4 Nm	B
Fastening the electric radiator fan cowl	Screw	5 Nm	B
Fastening radiators	Nut	20 Nm	B
Fastening engine air filter covers	Screw	5 Nm	B
Fastening intake manifold	Nut	15 Nm	B
Fastening intake plenum	Screw	10 Nm	B
	Screw	12 Nm	B
	Screw	12 Nm	B
Fastening exhaust silencers	Spherical clamp (pretightening)	25 Nm	B
	Spherical clamp	35 Nm	B
	Nut	10 Nm	B
Fastening exhaust silencer crosspiece	Screw	25 Nm	B
Fastening rear bushing mounting brackets	Nut	10 Nm	B
Fastening oxygen sensors	Oxygen sensor	50 Nm	B



Tightening torque		Nm	Class
Fastening the catalytic converters	Nut (pretightening)	15 Nm	B
	Nut	25 Nm	B
	Screw	25 Nm	B
	Nut	25 Nm	B
Fastening central exhaust pipe extensions	Clamp	43.4 Nm	B
	Clamp (pretightening)	25 Nm	B
Fastening rear exhaust pipe extensions	Nut	25 Nm	B
Fastening the exhaust manifolds	Nut	30 Nm	B
Fastening heat shields of rear extensions	Screw	9 Nm	B