



GTC4Lusso USA - Location of controls in vehicle - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

E5.01 Location of controls in vehicle

Instruments and controls on roof panel



- A - Door lock/unlock
- B - Anti-lift system on/off
- C - Driver side light on/off
- D - Stop&Start system on/off (for vehicles with HELE)
- E - Passenger side light on/off
- F - Cabin light
- G - Rear view mirror
- H - Activating / deactivating electrochromic mirror
- I - Passenger side and driver side light on/off

Instruments and controls on the dashboard



- A - Left hand TFT display control panel
- B - EPB electric parking brake control panel
- C - External lights control
- D - Instrument panel
- E - NIT
- F - A.C. control panel

Instruments and controls on steering wheel



- A - Horn button
- B - Turn indicator on/off buttons
- C - High beam light switch
- D - Windscreen washer control
- E - Suspension damping system on/off button
- F - Manettino
- G - Engine start button
- H - Gearshift paddles

Instruments and controls on centre console



- A** - DCT gearbox control panel
- B** - Hazard warning light button
- C** - Door window controls