



GTC4Lusso USA - Internal lights - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366


E5.12 Internal lights

Removing the cabin light

➤ Disconnect the battery (🔑 F2.01).




- Using a suitable tool, prise off and remove the cabin light unit (A).



- Disconnect the connectors (1).
- Remove the cabin light (A) from the vehicle.

Refitting the cabin light



- Place the cabin light **(A)** in the vehicle.
- Connect the connectors **(1)**.



- Fit the cabin light unit **(A)** in the relative seat, pressing until it snaps audibly into place.

➤ Connect the battery (🔌 F2.01).