



GTC4Lusso USA - Sanding and cleaning - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

E6.01 Sanding and cleaning

	Pre-Cleaning Steel. Remove rust by sandblasting, wire brush or coarse sanding paper (P16 to P80) to achieve a bare substrate. For rust through areas tinning is recommended. In case of larger damaged areas it might be necessary to weld in a new sheet or to replace the whole part. Remove any remains like scale from welding, tinning or any parting compounds and fluxing agents thoroughly.																				
	Cleaning Clean any old paint (OE finish) thoroughly with water first to remove any water soluble dirt. Clean with a suitable pre-cleaner, e.g. D837 DX330 Spirit Wipe o D845 DX310 High Strength Degreaser . If there is any VOC legislation in force, use D842 DX380 low VOC Cleaner or D8401 Waterborne low VOC Cleaner . If using D842 , rinse the surface with T494 Envirobaser thinner immediately after degreasing, then dry the panel surface.																				
	Dry Sanding (rotary-orbital machine) Use the following paper grades depending on the substrate. Start with the coarsest grade and carry on down to the finest grade. Fleeces and pads are especially recommended for edges and borders. Use a guide coat for best results: <table> <tr> <td>TM</td><td>™ red pad, 3M Soft Pad ultrafine</td></tr> <tr> <td>TM</td><td>™ grey pad, 3M Soft Pad ultrafine</td></tr> <tr> <td>Tinned Steel</td><td>P80-P220</td></tr> <tr> <td>TM</td><td>™ red pad, 3M Soft Pad ultrafine</td></tr> <tr> <td>E-Coat (spare parts)</td><td>P280 - P400, 3M Scotch-Brite™ grey pad, 3M Soft Pad ultrafine (faultless E-Coat requires only cleaning)</td></tr> <tr> <td>OE Finish / Repair Coatings</td><td>P240 - P400, 3M Scotch-Brite™ red pad, 3M Soft Pad superfine</td></tr> <tr> <td>Putty / Filler</td><td>Coarse sanding: P80 - P150, fine sanding: P240 - P320</td></tr> <tr> <td>Spray Polyester</td><td>Coarse sanding: P150, fine sanding: P240 - P320</td></tr> <tr> <td>Primer</td><td>P320 - P400, 3M Soft Pad ultrafine</td></tr> <tr> <td>Surfacer</td><td>P320 - P400, 3M Soft Pad ultrafine</td></tr> </table>	TM	™ red pad, 3M Soft Pad ultrafine	TM	™ grey pad, 3M Soft Pad ultrafine	Tinned Steel	P80-P220	TM	™ red pad, 3M Soft Pad ultrafine	E-Coat (spare parts)	P280 - P400, 3M Scotch-Brite™ grey pad, 3M Soft Pad ultrafine (faultless E-Coat requires only cleaning)	OE Finish / Repair Coatings	P240 - P400, 3M Scotch-Brite™ red pad, 3M Soft Pad superfine	Putty / Filler	Coarse sanding: P80 - P150, fine sanding: P240 - P320	Spray Polyester	Coarse sanding: P150, fine sanding: P240 - P320	Primer	P320 - P400, 3M Soft Pad ultrafine	Surfacer	P320 - P400, 3M Soft Pad ultrafine
TM	™ red pad, 3M Soft Pad ultrafine																				
TM	™ grey pad, 3M Soft Pad ultrafine																				
Tinned Steel	P80-P220																				
TM	™ red pad, 3M Soft Pad ultrafine																				
E-Coat (spare parts)	P280 - P400, 3M Scotch-Brite™ grey pad, 3M Soft Pad ultrafine (faultless E-Coat requires only cleaning)																				
OE Finish / Repair Coatings	P240 - P400, 3M Scotch-Brite™ red pad, 3M Soft Pad superfine																				
Putty / Filler	Coarse sanding: P80 - P150, fine sanding: P240 - P320																				
Spray Polyester	Coarse sanding: P150, fine sanding: P240 - P320																				
Primer	P320 - P400, 3M Soft Pad ultrafine																				
Surfacer	P320 - P400, 3M Soft Pad ultrafine																				

Topcoat (blending areas)	P800 - P1500, 3M Soft Pad ultrafine, 3M Scotch-Brite™ pad superfine
Clearcoat (blending areas)	P800 - P1500, 3M Soft Pad ultrafine, 3M Scotch-Brite™ pad superfine



Dry Sanding (rotary-orbital machine)

Use the following paper grades depending on the substrate. Start with the coarsest grade and carry on down to the finest grade. Fleeces and pads are especially recommended for edges and borders:

E-Coat (spare parts)	P600 - P800, 3M Soft Pad ultrafine (faultless E-Coat requires only cleaning)
OE Finish / Repair Coatings	P320 - P400, 3M Soft Pad ultrafine
Putty / Filler	NEVER USE wet sanding for putties!
Spray Polyester	NEVER USE wet sanding for putties!
Primer	P320 - P400, 3M Soft Pad ultrafine
Surfacer	P320 - P400, 3M Soft Pad ultrafine
Topcoat (blending areas)	P320 - P400, 3M Soft Pad ultrafine
Clearcoat (blending areas)	P1000 - P1200, 3M Soft Pad ultrafine



Cleaning

Clean any old paint (OE finish) thoroughly with water first to remove any water soluble dirt. Clean with a suitable pre-cleaner, e.g. **D837 DX330 Spirit Wipe** or **D845 DX310 High Strength Degreaser**. If there is any VOC legislation in force, use **D842 DX380 low VOC Cleaner** or **D8401 Waterborne low VOC Cleaner**. If using **D842**, rinse the surface with **T494 Envirobase thinner** immediately after degreasing, then dry the panel surface.