



GTC4Lusso USA - Lamps - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

F2.05 Lamps

Replacing Xenon high/low beam lamps

- Disconnect the battery ( F2.01).
- Remove the front wheelhouses ( E3.05).
-  Remove the front elements of the front wheelhouses.



- Detach and remove cover (1).



- Turn the retainer ring **(2)** fastening the lamp **(A)** counterclockwise.
- Remove the light bulb **(A)** from the headlight.
- Disconnect the connector **(3)**.
- Replace the lamp **(A)**.
- Connect the connector **(3)** to the new lamp.
- Fit the new lamp **(A)** in its respective seat inside the headlamp unit.
- Turn the retainer ring **(2)** fastening the lamp clockwise **(A)** and check that the lamp is securely fastened.



- Refit the cover **(1)**.

- Refit the front wheelhouses (🔧 E3.05).
- Refit the front elements of the front wheelhouses.
- Connect the battery (🔧 F2.01).