




GTC4Lusso USA - Accelerator control - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.
Copyright by Ferrari S.p.A. - P.IVA 00159560366

F3.10 Accelerator control

Removing the accelerator pedal


➤ Disconnect the battery (🔌 F2.01).



- Remove the indicated plugs.
- Undo the three nuts located beneath the indicated plugs.
- Disconnect the connector (1).
- Remove the accelerator pedal (A).

Refitting the accelerator pedal

			
Tightening torque		Nm	Class
Fastening accelerator pedal	Nut	9 Nm	B



- Fit the accelerator pedal **(A)**.
- Tighten the nuts located beneath the indicated plugs.



Tightening torque	Nm	Class
Nut	9 Nm	B

- Fit the indicated plugs.
- Connect the connector **(1)**.

➤ Connect the battery (🔌 F2.01).