
PWM ZSTOP GND VCC
GND YSTOP
GND XSTOP
VCC R G B
VCC GND
-BED OUT+
-BED IN+
-POWER IN+
FAN1
FAN0
T0
T1
T2
+HE-
BIGTREETECH®
BTT002 V1.0
WWW.BIGTREE-TECH.COM
RST SWCLK GND SWDIO 3.3V
RST RX TX GND VCC
EN M0 M1 M2 RST SLP STP DIR
VM GND B1 B2 A2 A1 VDD GND
GND VM
EM
ZBM
ZAM
YM
XM