

CAN_H CAN_L





CM4		
+5V		
+5V		
GND		
GPI014 UART_TX		
GPI015 UART_RX		
GPI018 PCM_CLK		
GND		
GPI023		
GPI024		
GND		
GPI025		
GPI08 SPI0_CE0		
GPI07 SPI0_CE1		
GPI01 EEPROM_SCL ID_SC		
GND		
GPI012 PWM0		
GND		
GPI016		
GPI020 PCM_DIN		
GPI021 PCM_DOUT		

CB1		
+5V		
+5V		
GND		
UART_TX		
UART_RX		
PC13		
GND		
PC11		
PC9		
GND		
NC		
NC		
PG8		
PG7		
GND		
PG9		
GND		
NC		
PH10		
PC8		

TFT SPI Interface		
Function	CM4	CB1
+5V	+5V	+5V
GND	GND	GND
MIS0	GPI09	PH8
MOSI	GPI010	PH7
CLK	GPI011	PH6
NSS	GPI07	PC7
TFT_RS	GPI017	PC14
SDA	GPI027	PC12
SCL	GPI022	PC0