


= GND



48 E1-DIR

45 PWRDE

43 SD-DET

39 SD-CS

97 SD_DET

96 Status

85 X_DIR

82 Y NSS

81 Y-STP

80 Y-DIR

76 Z NSS

93 X_STOP

38

95

94

8

92

55

90

89

88

72

63

14

41 LCD-ENCB

40 LCD-ENCA

62 4P FANO DET

61 4P_FAN1_DET

LCD-BEEP

li GND

PE10

PE8

PE7

PF7

PF6

PE3

PE2

PE1

PE0

PD11

PD10

PD7

PD4

PD3

PD2

PC13 77

PC9

PC8

PB5

PB4

PA8

PF13

PF12

PF11

PF8

VSS

VSS/VSSA

