

Foamtec International
Wilshire Contamination Control Division
*cleaning critical surfaces*



LAM KIYO POLY E-CHUCK

LAM KIYO POLY E-CHUCK

# APPLICATION NOTE
# LAM 2300 KIYO
# POLY ETCH Chamber PM

OBJECTIVE:

TO EFFECTIVELY PM THE LAM 2300 KIYO POLY ETCH CHAMBER IN A TIMELY MANNER, WHILE IMPROVING TOOL RECOVERY AND PARTICLE PERFORMANCE

| | |
|---|---|
| **Surface Build-up:** | PROCESS INDUCED RESIDUE |
| **Tool:** | LAM 2300 KIYO POLY ETCH |
| **Tool Parts:** | CHAMBER, E-CHUCK AND ASSOCIATED PARTS |
| **Old Method:** | 1 HOUR USING POLYESTER WIPES AND ALCOHOL (100+ WIPES). Does not remove most residue. |
| **Tool Recovery:** | ?? **Hours** Conditioning Wafers |
| **New Method:** | 1 HOUR USING 800D ScrubPAD, DI WATER & IPA |
| **Tool Recovery:** | ?? **Hours** Conditioning Wafers |

**Products**:



- (1) HT4580D-10-1 Diamond ScrubPAD, 800 Grit
- (1) HT4754 UltraSOLV® Sponge
- (1) FTPEN-1 ScrubWRIGHT™ Pen
- (1) HT4580DW-5 ScrubBelt™ (1 scrubBELT)
- (2) HT5790S-5 MiraWIPES® (10 total wipes)

## LAM 2300 KIYO POLY ETCH PM PROCEDURE:

**Step 1:** Using proper procedures and safety guidelines, shutdown and prepare LAM 2300 Kiyo chamber for wet clean

**Step 2:** Stage a container of DI water next to the chamber and place a HT4580D 800 grit Diamond ScrubPAD and HT4754 UltraSOLV® Sponge into the container (See Fig 1)

**Fig 1:** ScrubPAD and UltraSOLV® Sponge in container of DI



**NOTE:** MAY SUBSTITUE A SMALL AMOUNT OF DI WATER or 90/10 TO MOISTEN UltraSOLV® SPONGE AND ScrubPAD AS NECESSARY (See Fig 2 & 3)



**Fig 2:** UltraSOLV® Sponge, ScrubPAD and Small Amount of DI Water

**Fig 3:** Dampening UltraSOLV® Sponge with squirt bottle



**Step 3:** Wipe down and place protective cover over E-Chuck top surface to protect it (See Fig 4)

**Fig 4:** Protective cover on E-Chuck

