



On-Site Installation Guide

No heavy machinery, no long learning curve. A Smart Panel crew gets to work with five familiar tools.

The 5 Essential Tools

1

Cutting Machine

Trim panels cleanly to size on site.

2

Drill Machine

Set fixings quickly and securely.

3

Welding Machine

Secure the steel frame and joints.

4

Thread Hand Drill

Fine adjustments and finishing work.

5

Plumb Bob

Keep every panel true and vertical.

Why it matters

Tongue-and-groove edges let each panel lock into the next, so a small crew with basic tools can raise walls quickly, cutting labor time and bringing handover forward.

Installation Sequence at a Glance

1

Plan and set out

Finalize the design with an architect or structural engineer and mark wall lines on the prepared base.

Tool: Plumb Bob

2

Prepare the frame

Prepare the foundation and erect the steel framing and channels as per the approved design.

Tool: Welding Machine

3

Cut panels to size

Measure and trim panels for openings, corners and heights.

Tool: Cutting Machine

4

Fix and interlock

Set panels into the channels and lock tongue-and-groove edges. Secure fixings where required.

Tool: Drill Machine

5

Check and fine-tune

Check every panel is true and vertical, and make finishing adjustments before moving on.

Tool: Plumb Bob, Thread Hand Drill

6

Plaster and finish

For Smart Solid Panel, plaster both sides after installation, then paint and finish interiors.

Site Safety Checklist

- Wear hard hats, gloves and masks while cutting and drilling.
- Keep the cutting and welding areas clear and well ventilated.
- Follow the structural engineer's approved drawings for framing and fixings.
- Store panels flat and dry, and handle edges carefully to protect the tongue-and-groove joint.

Need on-site guidance?

Call +977-9851149804 / +977-9709084173 | info@prefabpanelnepal.com