F13-SR-004
415V RECYCLE CRUSHING SWITCHROOM

F13-SW-014
RECYCLE CRUSHING 415V MOTOR CONTROL CENTRE

CONTINUED ON SHT 1
2000-F13-SLD-EL-10401

CONTINUED ON SHT 3
2000-F13-SLD-EL-10403

415V 3NE~ 50Hz 4000A 65kA for 1sec

	4F-04	3R-12	4R-01	5R-01	4F-08	2R-13	2R-17	3F-13	3F-17	3R-01
	250A	100A	20A	20A	20A	32A	32A	32A	32A	20A
	2A 32A	2A 32A	2A 32A	2A 32A	2A 32A	2A 32A	2A 32A	2A 32A	2A 32A	2A 32A
	100/1A	70A	70A	70A	70A	70A	70A	70A	70A	100A
		EOL	EOL	EOL	EOL	EOL	EOL	EOL	EOL	NOTE 10
										JB
	M 3~	M 1~	M 3~	M 3~	M 3~	M 3~	M 3~	M 3~	M 3~	M 3~	M 3~
	90kW	0.7kW	30kW	0.55kW	0.55kW	0.55kW	7.5kW	7.5kW	7.5kW	7.5kW	4.8kW	4.8kW
	F13-FA-414 EMERGENCY FEEDER 2000-F13-SCM-EL-10205	F13-FN-586 EMERGENCY FEEDER MOTOR FORCED COOLING FAN 2000-F13-SCM-EL-10205	F13-FN-419 RECLAIM VAULT VENTILATION FAN 2000-F13-SCM-EL-10206	F13-FN-422 COARSE ORE RECLAIM FEEDER 1 GEARBOX COOLER FAN 2000-F13-SCM-EL-10429	F13-FN-423 COARSE ORE RECLAIM FEEDER 2 GEARBOX COOLER FAN 2000-F13-SCM-EL-10430	F13-FN-424 EMERGENCY FEEDER GEARBOX COOLER FAN 2000-F13-SCM-EL-10431	F13-FN-457 RECYCLE CRUSHER C LUBRICATION AIR COOLER 1 2000-F13-SCM-EL-10414	F13-FN-458 RECYCLE CRUSHER C LUBRICATION AIR COOLER 2 2000-F13-SCM-EL-10436	F13-FN-459 RECYCLED CRUSHER D LUBRICATION AIR COOLER 1 2000-F13-SCM-EL-10415	F13-FN-460 RECYCLED CRUSHER D LUBRICATION AIR COOLER 2 2000-F13-SCM-EL-10437	F13-FV-401 RECYCLE CRUSHER C FEEDER 2000-F13-SCM-EL-10416

NOTES

1. REFER TO SHEET 1.

LEGEND

1. REFER TO SHEET 1.

2000-F13-SLD-EL-10402_Rev2

Recycle crushing F13-SW-014 415V MCC single line diagram sheet 2