F16AG422-VS
VARIABLE SPEED DRIVE

RD WH BU
11,000V
FCF 100A
QAC 100A 100A 400A
BCT1 50 / 1A 2.5VA 5P20
BCT2 50 / 1A 2.5VA 5P20
BCT3 50 / 1A 2.5VA 5P20
BCN 50 / 1A 1.5VA 10P10
BAD
PFV1 RD RD RD
QCE 400A
EARTH BAR
X4-1 X4-2 X4-3 X4-4 X4-5 X4-6 X4-7 X4-8 X4-11 X4-12 X4-13
2000-EL003-F16-10016 SHEET 14

SYSTEM INTERCONNECTION DIAGRAM 2000-EL005-B02-10001
LINE SIDE INCOMING SUPPLY SHEET 6
OUTGOING MOTOR SUPPLY SHEET 6
CABLE SCREEN EARTHED
F16-AG-422
ROUGHER FLOTATION CELL 2 AGITATOR
3,300V
500 kW

F16-AG-422
MOTOR HEATER TERMINAL BOX
F16-HT-542
0.3kW
ANTI-CONDENSATION HEATER
F16HT542-L
F16HT542-N
MOTOR SPACE HEATER CIRCUIT SHEET 6

X81 (PART OF)
RTD TEMPERATURE MONITOR RELAY SHEET 6
PT100 RTD INPUT CH1
PT100 RTD INPUT CH2
PT100 RTD INPUT CH3
PT100 RTD INPUT CH4
PT100 RTD INPUT CH5
PT100 RTD INPUT CH6
PT100 RTD INPUT CH7
PT100 RTD INPUT CH8
F16AG422A-RD
F16AG422A-WH
F16AG422A-BK
F16AG422B-RD
F16AG422B-WH
F16AG422B-BK
F16AG422C-RD
F16AG422C-WH
F16AG422C-BK
F16AG422D-RD
F16AG422D-WH
F16AG422D-BK
F16AG422E-RD
F16AG422E-WH
F16AG422E-BK

F16-AG-422
MOTOR RTD TERMINAL BOX
RTD
MOTOR WINDING RTD (RD PHASE) (TD1)
MOTOR WINDING RTD (WH PHASE) (TD3)
MOTOR WINDING RTD (BU PHASE) (TD5)
MOTOR BEARING RTD (DRIVE END) (BD10)
MOTOR BEARING RTD (NON DRIVE END) (BD20)

F16-SW-011 11kV FEEDER START/STOP CONTROL 2000-EL003-F16-10016 SHEET 7 3A & 3B
MV CONTACTOR ENABLE CIRCUIT SHEET 6
F16-SW-011 11kV FEEDER VSD HEALTHY 2000-EL003-F16-10016 SHEET 10 4A
MV INPUT ENABLE CIRCUIT SHEET 6
F16-SW-011 11kV FEEDER VSD TRIP 2000-EL003-F16-10016 SHEET 10 3A
MV INPUT TRIP CIRCUIT SHEET 6
F16-SW-011 11kV FEEDER ARC FLASH TRIP 2000-EL003-F16-10016 SHEET 8 5A & 5D
A30 (PART OF) TRIP
ARC FLASH DETECTION TRIP SIGNAL SHEET 6

F16-DB-101
2000-F16-TLD-EL-10054
RD WH BU BK
R7 W7 B7
25A
EARTH BAR
415VAC
F16DB101-R7
F16DB101-W7
F16DB101-B7
F16DB101-BK7
VSD AUXILIARY POWER SUPPLY SHEET 6

F16-DB-201
2000-F16-TLD-EL-10057
WH BK
W1
10A
EARTH BAR
240VAC
F16DB201-W1
F16DB201-BK1
VSD UPS POWER SUPPLY SHEET 6

TO FLOTATION 11kV SWITCHROOM
F16-COM-001 COMMUNICATION RACK
MODBUS ETHERNET SWITCH
F16-ETH-001
2000-F16-TER-IC-10002
CAT6 — CAT6 — CAT6 — CAT6 — CAT6 — CAT6 — CAT6 — CAT6
X47 ETHERNET ADAPTOR RJ45
A2 (PART OF) DI-2B
24VDC CONTROL SHEET 6

F16AG422-LCS
LOCAL CONTROL STATION
LOS
START
SAFE TORQUE OFF CIRCUIT SHEET 6
F16AG422VS-1409
F16AG422VS-1419
F16AG422VS-1429
F16AG422VS-1439
F16AG422VS-1459
F16AG422VS-1469

NOTES

1. WIRE NUMBER FERRULES ON TERMINAL STRIP SHALL BE PREFIXED WITH EQUIPMENT NUMBER e.g. F16AG422-1200, UNLESS OTHERWISE NOTED.
2. EACH WIRE SHALL BE IDENTIFIED AT BOTH ENDS WITH FERRULES.

LEGEND

- 11kV SWITCHBOARD TERMINAL
- VSD TERMINAL
- FIELD TERMINAL
- DCS OR I/O TERMINAL
- MARSHALLING TERMINAL
- DEVICE TERMINAL

PANEL A03

2000-F16-SCM-EL-10105_Rev1

Rougher & scavenger flotation F16-SW-011
F16-AG-422 rougher flot cell 2 agitator VSD feeder schematic diagram