F16AG423-VS
VARIABLE SPEED DRIVE

11,000V
RD WH BU
FCF 100A
QAC 100A 100A 400A
BCT1 50 / 1A 2.5VA 5P20
BCT2 50 / 1A 2.5VA 5P20
BCT3 50 / 1A 2.5VA 5P20
BCN 50 / 1A 1.5VA 10P10
BAD
PFV1 RD RD RD
QCE 400A
EARTH BAR
X4-1 X4-2 X4-3 X4-4 X4-5 X4-6 X4-7 X4-8 X4-11 X4-12 X4-13
2000-EL003-F16-10016 SHEET 14

SYSTEM INTERCONNECTION DIAGRAM 2000-EL005-B02-10001
LINE SIDE INCOMING SUPPLY SHEET 6
OUTGOING MOTOR SUPPLY SHEET 6
CABLE SCREEN EARTHED
F16-AG-423
ROUGHER FLOTATION CELL 3 AGITATOR
3,300V
500 kW

F16-AG-423
MOTOR HEATER TERMINAL BOX
F16-HT-543
0.3kW
ANTI-CONDENSATION HEATER
MOTOR SPACE HEATER CIRCUIT SHEET 6

X81 (PART OF)
RTD TEMPERATURE MONITOR RELAY SHEET 6
PT100 RTD INPUT CH1
PT100 RTD INPUT CH2
PT100 RTD INPUT CH3
PT100 RTD INPUT CH4
PT100 RTD INPUT CH5
PT100 RTD INPUT CH6
PT100 RTD INPUT CH7
PT100 RTD INPUT CH8

F16-AG-423
MOTOR RTD TERMINAL BOX
MOTOR WINDING RTD (RD PHASE) (TD1)
MOTOR WINDING RTD (WH PHASE) (TD3)
MOTOR WINDING RTD (BU PHASE) (TD5)
MOTOR BEARING RTD (DRIVE END) (BD10)
MOTOR BEARING RTD (NON DRIVE END) (BD20)

F16-SW-011 11kV FEEDER START/STOP CONTROL 2000-EL003-F16-10016 SHEET 7 3A & 3B
MV CONTACTOR ENABLE CIRCUIT SHEET 6
F16-SW-011 11kV FEEDER VSD HEALTHY 2000-EL003-F16-10016 SHEET 10 4A
MV INPUT ENABLE CIRCUIT SHEET 6
F16-SW-011 11kV FEEDER VSD TRIP 2000-EL003-F16-10016 SHEET 10 3A
MV INPUT TRIP CIRCUIT SHEET 6
F16-SW-011 11kV FEEDER ARC FLASH TRIP 2000-EL003-F16-10016 SHEET 8 5A & 5D
A30 (PART OF)
ARC FLASH DETECTION TRIP SIGNAL SHEET 6

F16-DB-101
2000-F16-TLD-EL-10054
RD WH BU BK
R9 W9 B9 25A
415VAC
EARTH BAR
F16DB101-R9 F16DB101-W9 F16DB101-B9 F16DB101-BK9
VSD AUXILIARY POWER SUPPLY SHEET 6

F16-DB-201
2000-F16-TLD-EL-10057
BU BK
B1 10A
240VAC
EARTH BAR
F16DB201-B1 F16DB201-BK1
VSD UPS POWER SUPPLY SHEET 6

TO FLOTATION 11kV SWITCHROOM
F16-COM-001 COMMUNICATION RACK
MODBUS ETHERNET SWITCH
F16-ETH-001
2000-F16-TER-IC-10002
CAT6 — CAT6 — CAT6 — CAT6 — CAT6 — CAT6 — CAT6 — CAT6
X47 ETHERNET ADAPTOR RJ45
A2 (PART OF) DI-2B
24VDC CONTROL SHEET 6

SAFE TORQUE OFF CIRCUIT SHEET 6
F16AG423VS-1409 F16AG423VS-1419 F16AG423VS-1429 F16AG423VS-1439
F16AG423-LCS
LOCAL CONTROL STATION
LOS
START
F16AG423VS-1459 F16AG423VS-1469

NOTES

1. WIRE NUMBER FERRULES ON TERMINAL STRIP SHALL BE PREFIXED WITH EQUIPMENT NUMBER e.g. F16AG423-1200, UNLESS OTHERWISE NOTED.
2. EACH WIRE SHALL BE IDENTIFIED AT BOTH ENDS WITH FERRULES.

LEGEND

- 11kV SWITCHBOARD TERMINAL
- VSD TERMINAL
- FIELD TERMINAL
- DCS OR I/O TERMINAL
- MARSHALLING TERMINAL
- DEVICE TERMINAL

PANEL A04

2000-F16-SCM-EL-10107_Rev1

F16-SW-011 F16-AG-423 rougher flot. cell 3 agi VSD feeder schematic diagram