F16-GE-001
FLOTATION EMERGENCY SUPPLY
11kV, 2500kVA GENERATOR

G
3~

F16GE001-NR
FLOTATION EMERGENCY SUPPLY
11kV GENERATOR
NEUTRAL EARTHING RESISTOR
2000-EL019-B02-10008

1

30/0.05A EFCT
1S1
1S2
25A FOR 10s
254Ω +/-5%
SENSING
ER-15kV
N
G
R
S1
S2
T1
T2
3

1156
1157
1159

F16-SW-011
FLOTATION 11kV SWITCHBOARD PANEL A15
2000-EL003-F16-10010

EARTH BAR
QCE
630A
M
X4-21
X4-22
X9
10
BCF2
(PART OF)
EF 8
11 COM
R 6
G 7

BAD
PFV1
RD

P2 P2 P2
P1 P1 P1

BCT1 200 / 1A 2.5VA SP20 — 2S1 / 2S2
BCT2 200 / 1A 2.5VA SP20 — 2S1 / 2S2
BCT3 200 / 1A 2.5VA SP20 — 2S1 / 2S2
SEL 700G

BCT1 200 / 1A 2.5VA 5P20 — 1S1 / 1S2
BCT2 200 / 1A 2.5VA 5P20 — 1S1 / 1S2
BCT3 200 / 1A 2.5VA 5P20 — 1S1 / 1S2
SEL 751

2000-EL003-F16-10010
SHEET 19

-QAB
630A
M

RD
WH
BU

11kV 1250A 3-E 25kA FOR 3s

1

F16-SW-011
FLOTATION 11kV SWITCHBOARD PANEL A15
2000-EL003-F16-10010

F16SR001-LCS
SWITCHROOM EMERGENCY SHUTDOWN
PUSHBUTTON (LOCATED IN AIR LOCK)

TO F16-TR-011 INCOMER 2000-F16-SCM-EL-10117
13
11
E-SHUT
12
14
NOTE 3
1

1B45
1B65
X3 22
X3 32
SWITCHROOM EMERGENCY SHUTDOWN PUSHBUTTON CONNECTION TO THE VCB 1st TRIP CIRCUIT
SHEET 8

F16-RIO-100
11kV SWITCHROOM RIO PANEL
2000-F16-TER-IC-10014

X2 3B — F16SR011OP2-48VDC+ — 23 — 3A — 18/03/03 — 3B
X2 8 — F16SR011OP2 — 23 — 14
DCS REMOTE CB OPEN

X2 39 — F16SR011CL2-48VDC+ — R4 — 4A — 18/03/04 — 4B
X2 9 — F16SR011CL2 — R4 — 14
DCS REMOTE CB CLOSE

NOTES

1. WIRE NUMBER FERRULES ON TERMINAL STRIP SHALL BE PREFIXED WITH EQUIPMENT NUMBER e.g. F16SW011-1200, UNLESS OTHERWISE NOTED.
2. EACH WIRE SHALL BE IDENTIFIED AT BOTH ENDS WITH FERRULES.
3. E-SHUT CIRCUIT IS FAIL SAFE. NORMALLY CLOSED CONTACTS WILL BE OPEN WHEN THE E-SHUT BUTTON IS UN-ACTIVATED AND THE CIRCUIT HEALTHY.

LEGEND

- xx/xx/xx — DCS DIGITAL INPUT
- xx/xx/xx — DCS DIGITAL OUTPUT
- xx/xx/xx — DCS ANALOGUE INPUT
- xx/xx/xx — DCS ANALOGUE OUTPUT
- xx/xx/xx — DCS ANALOGUE RTD INPUT
- ⊗ — MCC TERMINAL
- ◓ — VSD TERMINAL
- ◒ — FIELD TERMINAL
- ◑ — DCS OR I/O TERMINAL
- ◧ — MARSHALLING TERMINAL
- (x) — DEVICE TERMINAL

1

PANEL A15

2000-F16-SCM-EL-10129_Rev1

Generator schematic diagram