F16-HF-004
SCHNEIDER ACCUSINE
PCSP3005DIPS4

R W B N
Q102
400A
TOROID
NOTE 5
A B
C70 C71
LINE 142
F106
2A
32A
1061
1062
1063
N
L1
L2
L3
PE
LLI
RD
XC-PE
L1
L2
L3

CT BOARD
D16
D17
D36
D37
D56
D57
X1
X2
IN
OUT
CH1
CH2
CH3
TO F16-SW-004 MCC INCOMER MODULE
2000-F16-SCM-EL-10221

24VDC
CONTROL
TO NEXT
MODULE
Q120
4A
1200

0VDC
CONTROL
TO NEXT
MODULE
1
2
0VDC

CONTROL BOARD
1P
2P
NOTE 4
ETH
CAT6 — CAT6 — CAT6 —
TO SWITCHROOM
COMMUNICATION
RACK ETHERNET SWITCH
2000-F16-TER-IC-10043

(DOOR MOUNTED)
K142
TEST
RESET
TRIP
2
3
18
17
20
21
C70
C71
LINE 106
Q102
1453
NHP RD1EP21H (IME DELTA 72-S)
NOTE 6
MCCB SHUNT TRIP COIL
102
EARTH LEAKAGE RELAY

F16-HF-004
F16-SW-004
415V MCC ACTIVE
HARMONIC FILTER
300 A

AHF
ENCLOSURE TERMINALS

L1	F16HF004-RD	RD
L2	F16HF004-WH	WH
L3	F16HF004-BU	BU
⏚	F16HF004-GNYE	GNYE

POWER

CT BOARD

CH1 IN	X1	F16SW004-D16	1
	X2	F16SW004-D17	2
CH1 OUT	X1		
	X2		
CH2 IN	X1	F16SW004-D36	3
	X2	F16SW004-D37	4
CH2 OUT	X1		
	X2		
CH3 IN	X1	F16SW004-D56	5
	X2	F16SW004-D57	6
CH3 OUT	X1		
	X2		

F16HF004-P1
95 mm² 4C+E
FROM F16-HF-004 FEEDER
MODULE CIRCUIT BREAKER
F16HF004-P2
95 mm² 4C+E
F16HF004-C1
6 mm² 6C+E
TO MCC INCOMER TIER
2000-F16-TER-EL-10221

CABLE ZONE
24VDC TERMINALS

24VDC
LOOPED POWER
NEXT MODULE
PREV MODULE

Q120	4A	2740
1		2750
2		2750
3		
4		
5		
6		
7		
8	⏚	EARTH

NOTE 2

NOTES

1. TERMINALS ON TERMINAL STRIPS ABOVE 50VAC SHALL HAVE A SEPARATE PERSPEX SHROUD AND SHALL BE LABELLED "DANGER xxxVAC".
2. WIRE NUMBER FERRULES ON TERMINAL STRIP SHALL BE PREFIXED WITH EQUIPMENT NUMBER e.g. F16HF004-1200, UNLESS OTHERWISE NOTED.
3. EACH WIRE SHALL BE IDENTIFIED AT BOTH ENDS WITH FERRULES.
4. P1 & P2 PORTS ARE FACTORY FITTED WITH RJ45 TERMINATOR.
5. NHP TDGB2
   IN:70A IΔN MIN:0.03A TOROID TO SUIT CABLE DIAMETER.
6. EARTH LEAKAGE RELAY (ELV) USER INTERFACE TO BE MOUNTED ON MCC MODULE DOOR. RELAY ENERGISED (NORMALLY CLOSED CONTACT OPEN) IN NORMAL OPERATION.

LEGEND

- 00/01/00 — DCS DIGITAL INPUT
- 00/02/00 — DCS DIGITAL OUTPUT
- ⊗ — MCC TERMINAL
- ◓ — VSD TERMINAL
- ◒ — FIELD TERMINAL
- ◑ — DCS OR I/O TERMINAL
- ◧ — MARSHALLING TERMINAL
- (x) — DEVICE TERMINAL
- ⊗cc — INDICATION LAMP, cc = COLOUR

TERMINATION LEGEND

Q120	4A	F16SW004-2xxx
1		F16SW004-2xxx
2		F16SW004-2xxx
3		F16HF004-1200
4		F16HF004-1230
5		F16HF004-1230
6	⏚	EARTH

RD
BK
GNYE

CORE COLOUR/ IDENTIFIER
BARRIER
FERRULE
JUMPER/DISCONNECT/ FUSE/EARTH
TERMINAL No.
DESTINATION

2000-F16-SCM-EL-10206_Rev2

F16-SW-004 F16-HF-004 active harmonic filter - schematic and termination diagram