



PANEL A01	
BUS VT & EARTH SWITCH	
2000-EL003-F16-10001	
VT RACKED OUT INDICATION	
VT RACKED IN INDICATION	
EARTH SWITCH OPEN INDICATION	
EARTH SWITCH CLOSED INDICATION	
EARTH SYMBOL INDICATION	
CLOSE EARTH SWITCH COMMAND	
OPEN EARTH SWITCH COMMAND	
MOTOR RESET	
PANEL A02	
F23PP466-VS FEEDER	
2000-EL003-F16-10011	
CONTACTOR OPEN INDICATION	
CONTACTOR CLOSED INDICATION	
CONTACTOR RACKED OUT INDICATION	
CONTACTOR RACKED IN INDICATION	
EARTH SWITCH OPEN INDICATION	
EARTH SWITCH CLOSED INDICATION	
EARTH SYMBOL INDICATION	
CLOSE CONTACTOR COMMAND	
OPEN CONTACTOR COMMAND	
RACK IN CONTACTOR COMMAND	
RACK OUT CONTACTOR COMMAND	
CLOSE EARTH SWITCH COMMAND	
OPEN EARTH SWITCH COMMAND	
MOTOR RESET	



PANEL A03	
F23PP467-VS FEEDER	
2000-EL003-F16-10011	
CONTACTOR OPEN INDICATION	
CONTACTOR CLOSED INDICATION	
CONTACTOR RACKED OUT INDICATION	
CONTACTOR RACKED IN INDICATION	
EARTH SWITCH OPEN INDICATION	
EARTH SWITCH CLOSED INDICATION	
EARTH SYMBOL INDICATION	
CLOSE CONTACTOR COMMAND	
OPEN CONTACTOR COMMAND	
RACK IN CONTACTOR COMMAND	
RACK OUT CONTACTOR COMMAND	
CLOSE EARTH SWITCH COMMAND	
OPEN EARTH SWITCH COMMAND	
EARTH SWITCH MOTOR RESET	

NOTES

1. WIRE NUMBER FERRULES ON TERMINAL STRIP SHALL BE PREFIXED WITH EQUIPMENT NUMBER e.g. FxxPPxxx-1200, UNLESS OTHERWISE NOTED.
2. EACH WIRE SHALL BE IDENTIFIED AT BOTH ENDS WITH FERRULES.

LEGEND

- RSP TERMINAL
- HV SWITCHBOARD TERMINAL
- DEVICE TERMINAL

2000-F23-SCM-EL-10171_Rev1

F23SW016-LCS - 11kV SWITCHBOARD REMOTE SWITCHING PANEL - SCHEMATIC DIAGRAM SHEET 1