TO 33kV SWITCHBOARD F00-SW-010 PANEL B04
REFER 2000-F00-SLD-EL-10002

F28-TR-013
33 /11 kV
12500 kVA
Dyn11
z=8%
KNAN

300/1A
2.5VA
5P20

F28-NR-013
ULTRAFINE GRINDING 2/3 TRANSFORMER
F28-TR-013 NEUTRAL EARTHING CUBICLE

254Ω +/-5%
30/0.05A 25A FOR 10s
SENSING
ER-15kV

INTERTRIPS
TO SIGNALS

TRANSFORMER
PROTECTION
DEVICES
TERMINAL BOX

F28-SR-001
ULTRAFINE GRINDING 11kV SWITCHROOM

NOTE 4

E-SHUT
F28SR001-LCS
NOTE 5

F28-SW-013
ULTRAFINE GRINDING 2/3 11kV SWITCHBOARD

TEST
TEST

900/1A
2.5VA
Cl 0.2

PQM
SEL735

900/1A
2.5VA
5P20

50
51
PR
NOTE 2
SEL 751
AFD

900/1A
2.5VA
5P20

PR
50G
SE-330AU

FAULT
EARTH FAULT INDICATION
TRANSFORMER INSTRUMENTATION ALARM & TRIP CONTACTS (NOTE 6)
UPSTREAM TRIPS

CLOSE
TRIP
1250A

87T
26Q
49W
63
71
PR
SEL 787

2000-F28-SCM-EL-10011
NOTE 2
A01

2000-F28-SCM-EL-10103
A02

2000-F28-SCM-EL-10107
A04

2000-F28-SCM-EL-10019
A05
11kV 1250A 3-E 25kA FOR 3s

NOTE 3

2A
630A
NOTE 2

VT
11kV/√3 / 0.11kV/√3 / 0.11kV/√3
15VA CLASS 0.2
20VA CLASS 3P

A03
2000-F28-SCM-EL-10015

CLOSE
TRIP
630A

50
50G
27
AFD
46
38
51
66
49
49R
PR
SEL 710-5

300/1A
2.5VA
5P20
TEST

50/1A
1.5VA
10P10
TEST

CLOSE
TRIP
630A

50
50G
27
AFD
38
51
51G
81
66
49R
PR
SEL 710

300/1A
2.5VA
5P20
TEST

50/1A
1.5VA
10P10
TEST

CLOSE
TRIP
630A

50
50G
27
AFD
51
51G
81
PR
SEL 751

250/1A
2.5VA
5P20
TEST

50/1A
1.5VA
10P10
TEST

UFG MILL PACKAGE
SEL 2600
MILL MOTOR
RTD
M
3~
3800 kW
LRS I/O TO DCS
RIO PANEL

F28-MUF-402
ULTRAFINE
GRINDING MILL 2
2000-F28-SCM-EL-10013

UFG MILL PACKAGE
SEL 2600
MILL MOTOR
RTD
M
3~
3800 kW
LRS I/O TO DCS
RIO PANEL

F28-MUF-403
ULTRAFINE
GRINDING MILL 3
2000-F28-SCM-EL-10017

11kV SPARE
FULLY EQUIPPED
-

NOTES

1. THE SWITCHBOARD SHALL BE EXTENSIBLE ONE END FOR FUTURE EXPANSION AND SUPPLIED WITH ONE SPARE TIER AS SHOWN.
2. ARC FLASH IN INCOMER CB COMPARTMENT IS NOT CURRENT SUPERVISED. TRIPPING OF BUS AND DOWNSTREAM CB/FC COMPARTMENTS IS CURRENT SUPERVISED.
3. ARC FLASH POINT DETECTORS SHALL BE PLACED IN THE CABLE ZONE, CIRCUIT BREAKER CHAMBER OR FUSE CONTACTOR CHAMBER AND THE BUSBAR CHAMBER. THE DETECTORS SHALL BE CONNECTED DIRECTLY TO THE PROTECTION RELAY IN EACH PANEL.
4. ONE OFF 30/0.05A PROTECTION CT SHALL BE INSTALLED IN THE NER CUBICLE AND CONNECTED TO THE INCOMER PROTECTION RELAY TO MONITOR FOR EARTH FAULT DETECTION .
5. SWITCHROOM EMERGENCY SHUTDOWN (E-SHUT) PUSHBUTTON IS HARDWIRED DIRECT TO THE SHUNT TRIP OF THE INCOMER CIRCUIT BREAKER AND UPSTREAM 33kV FEEDER.
6. 33/11kV TRANSFORMER INSTRUMENTATION TRIP CONTACTS SHALL BE HARDWIRED TO THE 11kV SWITCHBOARD INCOMER PROTECTION RELAY WHICH SHALL INTERTRIP THE UPSTREAM 33kV FEEDER.
7. UPSTREAM 33kV FEEDER SHALL BE TRIPPED ON THE EARTH & ARC FAULT DETECTION OF THE DOWNSTREAM INCOMER ACB.

LEGEND

PR	INCOMER / FEEDER PROTECTION RELAY
PQM	POWER QUALITY METER
	ARC FLASH SENSOR (POINT TYPE) NOTES 2 & 3
	CAPACITIVE VOLTAGE INDICATION
	MECHANICAL INTERLOCK DEVICE
E-SHUT	SWITCHROOM EMERGENCY SHUTDOWN
M	MOTOR OPERATOR
26Q	TRANSFORMER PROTECTION DEVICES
27	UNDER VOLTAGE
38	BEARING RTD TEMPERATURE
46	CURRENT IMBALANCE
49	THERMAL OVERLOAD
49R	RTD BIASED THERMAL OVERLOAD
50	INSTANTANEOUS OVERCURRENT
50SG	INSTANTANEOUS OVERCURRENT SENSITIVE GROUND
50G 50N	INSTANTANEOUS EARTH/NEUTRAL OVERCURRENT
51	TIMED OVER-CURRENT
51G 51N	TIMED EARTH/NEUTRAL OVERCURRENT
59	OVER VOLTAGE
63	TRANSFORMER PRESSURE / BUCCHOLZ
64	EARTH FAULT
66	NOTCHING OR JOGGING DEVICE / MAXIMUM STARTS PER HOUR / TIME BETWEEN STARTS
71	TRANSFORMER LIQUID / GAS LEVEL
81	FREQUENCY
87T	TRANSFORMER DIFFERENTIAL
AFD	ARC FLASH DETECTION

2000-F28-SLD-EL-10001_Rev2

Single line diagram