F28GE109-CB

400A

4 POLE

F28-GE-109
415V
250kVA

F28-SR-002
415V ULTRA FINE GRINDING SWITCHROOM

SWR EARTH BAR

FEEDER FROM F28-SW-009
2000-F28-SLD-EL-10201

TO F28-SW-009
2000-F28-SLD-EL-10201

F28-SW-109
ULTRA FINE GRINDING 415V ESSENTIAL SWITCHBOARD

EARTH BAR

NEUTRAL BAR
NOTE 1

AFD

125A
160A

SD
NOTE 3

2A
63A

2A
63A

PFR

00F-05

2A
63A

MANUAL
MCCB CHANGEOVER
SWITCH 3 POLE 400A

415V 3NE~ 50Hz 400A 65kA for 1sec

INC

01F-17

250A

2A
32A

90A

250A
250A

TEMPORARY
GENERATOR

1F-01

32A

2A
32A

70A

32A
32A

01F-09

250A

2A
32A

90A

69kW

F28-DB-301
ULTRA FINE GRINDING AREA
L&SP DB

2000-F28-SCM-EL-10207

01F-07

63A

2A
32A

70A

63A

SPARE FEEDER

01F-05

63A

2A
32A

70A

F28CR430-JB02
UFG AREA
CRANE

JB

CR

63A

F28-CR-430
UFG AREA
CRANE

2000-F28-SCM-EL-10209

1F-05

250A

2A
32A

90A

JB

F72DB302-JB
REAGENTS MIXING &
STORAGE AREA L&SP DB 2
JUNCTION BOX

69kW

F72-DB-302
REAGENTS MIXING & STORAGE AREA
L&SP DB 2

2000-F72-SCM-EL-10406

F28-SR-001
11kV ULTRA FINE
GRINDING
SWITCHROOM

BC

3.6kW

F28-BC-001
ULTRA FINE GRINDING
11kV SWITCHROOM
48V CHARGER
2000-F28-TLD-EL-10051

69kW

F28-DB-001
ULTRA FINE GRINDING
11kV / 415V SWITCHROOM
L&SP DB
2000-F28-SCM-EL-10205

ISL

32A

F28UPS002-ISL
ULTRA FINE GRINDING
415V/240VAC UPS
BYPASS SWITCH
2000-F28-SCM-EL-10206

10kW

F28-DB-201
ULTRA FINE GRINDING
415V SWITCHROOM
240VAC UPS DB
2000-F28-TLD-EL-10054

UPS

10kW

F28-UPS-002
ULTRA FINE GRINDING
415V SWITCHROOM
240VAC UPS
2000-F28-TLD-EL-10054

NOTES

1. EARTH-NEUTRAL LINK INSTALLED IN UPSTREAM F28-SW-009 INCOMER TIER. SIGNAGE SHALL BE PLACED ON F28-SW-109 SWITCHBOARD AND ON GENERATOR READING "M.E.N. LINK LOCATED IN F28-SW-109 INCOMER TIER"
2. SWITCHBOARD SHALL BE EXTENSIBLE AND BE PROVIDED WITH THE FACILITY TO EXTEND THE MAIN BUSBAR AND APPEND ADDITIONAL TIERS AT ONE END WITHOUT MAJOR STRUCTURAL DISASSEMBLY.
3. SURGE DIVERTERS SHALL PROVIDE FEEDBACK TO DCS VIA VOLT-FREE CONTACTS. SURGE DIVERTER FUSES SHALL BE SIZED BY VENDOR TO SUIT DUTY.
4. MINIATURE CIRCUIT BREAKERS SHALL BE SIZED AND RATED TO SUIT ACB AND INCOMER REQUIREMENTS.
5. CIRCUIT BREAKER TO BE SUBSTITUTED FOR FUSED-SWITCH WHERE REQUIRED BY EQUIPMENT MANUFACTURERS GUIDELINES.

LEGEND

PFR	PHASE FAILURE RELAY
/ >	EARTH LEAKAGE RELAY
xxxA / xxxA	ST TRIP SET POINT / CB SIZE
AFD	ARC FLASH DETECTION
ECR	EARTH CONTINUITY RELAY

2000-F28-SLD-EL-10211_Rev2

F28-SW-109 415V essential switchboard - single line diagram