NOTES:

1. 3" SS MALE CAMLOCK FITTING
2. 2" POLYETHYLENE MALE CAMLOCK FITTING.
3. PRESSURE RELIEF VALVE KCGM SUPPLY.
4a. TBA
4b. TBA
5. TBA

REFER NOTE 2
50V303
71-113-HCL-PE8-63
25V303
71-115-HCL-PE8-32
LI 71211
LAH 71211
LAL 71211
LIT 71211
LE 71211
ACID DOSING PUMPS
2000-F00-PID-PR-10101
HYDROCHLORIC ACID
00-4108-HCL-PE8-63
UA 71422A
UA 71422B
NOTE 4 (A)
NOTE 4 (B)
71-121-HCL-PE8-50
71-122-HCL-PE8-50
LI 71221
LAH 71221
LAL 71221
LIT 71221
LE 71221
UA 71221A
NOTE 4 (A)
REFER NOTE 3
0-600kPaG
PI
25V303
50V
50V
TI 15
71-120-HCL-PE8-63
50V303
25V303
71-165-HCL-PE8-32
50V303
71-129-HCL-PE8-32
50VBD1T1 F00-13114
25VBD1T1 F00-13115
TIP 2059
50VBD1T1 F00-13116
REFER NOTE 2
50V303
71-112-HCL-PE8-63
25V303
71-114-HCL-PE8-32
SIC
ACID DOSING PUMP
F71-PP-02A
SIC
ACID DOSING PUMP
F71-PP-02B
REFER NOTE 3
71-117-HCL-PE8-90
71-119-HCL-PE8-63
50VBD1T1 F00-13106
25VBD1T1 F00-13107
50VBD1T1 F00-13108
50VBD1T1 F00-13122
TIP 2071
25VBD1T1 F00-13123
50VBD1T1 F00-13124
63x40
72-4076-HCL-PE8-40
ACID COLUMN 2 - PR62
2000-F65-PID-PR-10002
HYDROCHLORIC ACID
ACID WASH COLUMNS
ACID COLUMN 1 - PR61
2000-F65-PID-PR-10001
ACID COLUMN 2 - PR62
2000-F65-PID-PR-10002
ACID STORAGE TANK F71-TK-02A
ACID STORAGE TANK F71-TK-02B
71-124-HCL-PE8-110
71-123-HCL-PE8-110
100V304
100V304
110x90CR
80V304
25V303
71-163-HCL-PE8-32
71-118-HCL-PE8-90
80V304
71-125-HCL-PE8-90
80V304
71-126-HCL-PE8-90
100V304
110x90CR
80V304
25V303
71-127-HCL-PE8-32
71-116-HCL-PE8-110
25V303
71-164-HCL-PE8-32
71-128-HCL-PE8-32
71-130-HCL-PE8-32
LAH 71201
LT 71201
PE=8-90
32x63CR
50V303
50V303
71-132-HCL-PE8-90
50V702
25V303
63x90CR
71-134-HCL-PE8-25
71-146-PSW-PE8-25
25V302
71-145-PSW-PE8-63
71-PI-1002
SEALED POT
71-131-HCL-PE8-160
ACID AREA SUMP PUMP
F71-PS-02
TI 19
PROCESS SCHEME WATER
BY HCL UNLOADING SLAB
25V302
63x25CR
71-144-PSW-PE8-63
50V303
30\PI\1000
CIL 03 - TAILS HOPPER

HYDROCHLORIC ACID

FROTHER AGENT

0-600kPaG
PI
25V302
71-086-TE-PE8-63
25-PI-1000
71-162-TE-PE8-63
50V302
50V401
71-085-TE-MS-50
90x50CR
71-083-TE-MS-80
1
100
SV 71510
KV 71510
ZSC 71512
71-093-TE-MS-25
25V302
50x32CR
71-088-FR-MS-50
FILL POINT
REFER NOTE 1.
80V101
80V101
FROTHER AGENT STORAGE VESSEL, 55m³
F71-TK-05
71-157-TE-MS-25
71-156-TE-MS-50
71-135-TE-MS-25
50V101
REFER NOTE 5.
50V101
50V101
25V302
71-094-TE-MS-25
71-092-TE-MS-25
25V302
FROTHER TRANSFER PUMP
F71-PP-05A
EXISTING RING MAIN
71-091-TE-MS-25
MS | PE80B PN8
71-086-FR-PE8-63
71-PI-1002
25V302
50x32CR
71-084-TE-MS-25
71-087-TE-MS-25
PIVOT POINT
25V302
WIT 71511
WE 71511
PI 71513
WAH 71511
WAL 71511
50V101
REFER NOTE 5.
50V101
50V101
25V302
71-090-TE-MS-25
71-089-TE-MS-25
FROTHER TRANSFER PUMP
F71-PP-05B
TO SPOON DRAIN
AU 71910
AU 71911
UA 71900
TO XANTHATE TANK F71-TK-06
25V302
71-099-TE-PE8-32
71-147-TE-PE8-50
OVERFLOW
50V×
50V301
TO SPOON DRAIN
0-400kPaG
PI
25V302
MS | PE80B PN16
50x25CR
71-106-CA-PE16-63
50V302
TI 20
PLANT AIR
BY TRUCK UNLOADING SLAB
25V302
BY PIPE SUPPORT ON SOUTHERN OF VESSELS
71-110-CA-MS-25
25V302

NOTE:
× DENOTES POLY VALVES

LEGEND
- EXISTING
- NON-EXISTENT
- STAGE 1 - NEW
- STAGE 1 - REMOVE
- STAGE 1 - DECOMMISSIONED (OTHERS)
- STAGE 2 - NEW
- STAGE 2 - REMOVE
- STAGE 2 - DECOMMISSIONED (OTHERS)