NOTES:

1. CALCULATION WILL CONVERT FRESH SOLIDS RATE TO A REAGENT FLOWRATE.
2. FLANGED ASME B16.5 CLASS 150.
3. SPARE NOZZLE.
4. FROTHER DELIVERY TRUCK COMES WITH REAGENT TRANSFER PUMP AND 6m HOSE. NATO/CAMLOCK MALE COUPLING IS REQUIRED ON CUSTOMER'S FIXED DELIVERY POINT.
5. CUSTOMER TO PROVIDE A 20A 3 PHASE GPO FOR ON TRUCK DELIVERY PUMP.
6. THE SIREN WILL ACTIVATE UPON A HIGH-HIGH LEVEL TO INDICATE NEAR OVERFLOW LEVEL IN THE STORAGE TANK.

W113121B
2000-F16-PID-PR-10001
SIGNAL

FROTHER DELIVERY
NOTE 5

SP MC-005

NOTE 4

72-1160-FR-SS1-80

80VBD1S1 F72-12237

25VB03S1 F72-12238

TO GRADE

80VBD1S1 FC

25VB03S1 F72-12239

TO GRADE

DETAIL 8

HS 72110

XV 72110

NOTE 6

YA 72112

YA 72112

LI 72111

HH H L LL

LI 72111

f(x) WI 72111

LIT 72111

72-2212-FR-SS1-50

15VB03S1 F72-12385

TO GRADE

50VBD1S3 F72-12245

O/F

F72-TK-432
FROTHER STORAGE TANK

80VBD1S3 F72-12244

50VBD1S3 F72-12246

25VB03S1 F72-12247

TO GRADE

72-1178-FR-SS1-80

150-MECH-SS1

72-2211-FR-SS1-80

TO GRADE

72-1163-FR-SS1-50

SP MC-001

25VB03S1 F72-12241

80VBD1S1 F72-12240 NC

100x80

100VBD1S1 F72-12242 NO

LI 72121 H

LIT 72121

LE 72121

72-0654-FR-SS1-100

100x65

NOTE 2

F72-PS-425
FROTHER AREA SUMP PUMP

SP MC-001

25VB03S1 F72-12243

HS 72121

NOTE 1 FIC 72122 f(x) L LL

PRV 72115 SET AT 600 kPag

72-2213-FR-SS1-15

TO GRADE

SP MC-001

25VB03S1 F72-12251

NOTE 3 DN25

VSD M

NOTE 2 NOTE 2

72-1449-FR-SS1-25

25VBD1S1 F72-12248

15VB03S1 F72-12249

TO GRADE

25VBD1S1 F72-12250

25x15

F72-PP-666
FROTHER DOSING PUMP 1

15VCD1S4 F72-12253

15VBD1S1 F72-12254

15VB03S1 F72-12255

TO GRADE

15VBD1S1 F72-12256

FIT 72122

FE 72122

15VBD1S1 F72-12273

15VB03S1 F72-12275

15VBD1S1 F72-12276

TO GRADE

15VB03S1 F72-12272

TO GRADE

72-1450-FR-SS1-15

FLOTATION FEED BOX FROTHER TUNDISH
2000-F16-PID-PR-10001
FROTHER

NOTE 1 FIC 72117 f(x) L LL

PRV 72117 SET AT 600 kPag

72-2214-FR-SS1-15

TO GRADE

SP MC-001

25VB03S1 F72-12260

NOTE 3 DN25

VSD M

NOTE 2 NOTE 2

72-1453-FR-SS1-25

25VBD1S1 F72-12257

15VB03S1 F72-12258

TO GRADE

25VBD1S1 F72-12259

25x15

F72-PP-668
FROTHER DOSING PUMP 3

72-1459-FR-SS1-15

15VCD1S4 F72-12270

15VBD1S1 F72-12271

15VCD1S4 F72-12277

15VBD1S1 F72-12278

NOTE 1 FIC 72123 f(x) L LL

PRV 72116 SET AT 600 kPag

72-2215-FR-SS1-15

TO GRADE

SP MC-001

25VB03S1 F72-12265

NOTE 3 DN25

VSD M

NOTE 2 NOTE 2

72-1451-FR-SS1-25

25VBD1S1 F72-12262

15VB03S1 F72-12263

TO GRADE

25VBD1S1 F72-12264

25x15

F72-PP-667
FROTHER DOSING PUMP 2

15VCD1S4 F72-12266

15VBD1S1 F72-12267

15VB03S1 F72-12268

TO GRADE

15VBD1S1 F72-12269

15VB03S1 F72-12279

TO GRADE

FIT 72123

FE 72123

15VBD1S1 F72-12280

15VBD1S1 F72-12281

15VB03S1 F72-12282

15VBD1S1 F72-12283

TO GRADE

72-1452-FR-SS1-15

SCAVENGER FLOTATION CELL 1
2000-F16-PID-PR-10003
FROTHER

NOTE 1 FIC 72124 f(x) L LL

PRV 72118 SET AT 600 kPag

72-2216-FR-SS1-15

TO GRADE

SP MC-001

25VB03S1 F72-12287

NOTE 3 DN25

VSD M

NOTE 2 NOTE 2

72-1455-FR-SS1-25

25VBD1S1 F72-12284

15VB03S1 F72-12285

TO GRADE

25VBD1S1 F72-12286

25x15

F72-PP-669
FROTHER DOSING PUMP 4

15VBD1S1 F72-12292

15VB03S1 F72-12293

TO GRADE

15VBD1S1 F72-12294

FIT 72124

FE 72124

72-1456-FR-SS1-15

CLEANER-SCAVENGER FLOTATION CELL FEED HOPPER
2000-F18-PID-PR-10003
FROTHER

NOTE 1 FIC 72125 f(x) L LL

PRV 72119 SET AT 600 kPag

72-2217-FR-SS1-15

TO GRADE

SP MC-001

25VB03S1 F72-12291

NOTE 3 DN25

VSD M

NOTE 2 NOTE 2

72-1457-FR-SS1-25

25VBD1S1 F72-12288

15VB03S1 F72-12289

TO GRADE

25VBD1S1 F72-12290

25x15

F72-PP-670
FROTHER DOSING PUMP 5

15VBD1S1 F72-12295

15VB03S1 F72-12296

TO GRADE

15VBD1S1 F72-12297

FIT 72125

FE 72125

72-1458-FR-SS1-15

CLEANER FLOTATION CELL FEED HOPPER
2000-F18-PID-PR-10001
FROTHER

SS1 PE8

72-1179-FR-PE8-110

FLOTATION FEED BOX
2000-F16-PID-PR-10001
SPILLAGE