

- NOTES:
1.

TRUCK UNLOADING VIA COMPRESSED AIR DISPLACEMENT TRANSFER.
2.

TRUCK UNLOADING VIA ONBOARD TANKER PUMP.

- LEGEND:
- INTERMITTENT
- SP2 NEW
- SP2 DECOMMISSIONED

