

NOTES:

1. ALL SAMPLE POINTS TO HAVE MINIMAL STUB LENGTH TO SAMPLE VALVE.
2. VALVE IS ACTUATED VIA A MANUAL 4-WAY VALVE LOCATED IN CONTROL PANEL.
3. CURRENT SETPOINT AND VOLTAGE LIMIT INPUTS FOR RECTIFIER OPERATION WHEN IN REMOTE/AUTOMATIC MODE. RECTIFIER WILL OPERATE IN 'DC CURRENT CONTROL' MODE ONLY WHEN IN REMOTE/AUTOMATIC. COMMUNICATION TO AND FROM DCS IS VIA MODBUS.

