NOTES:

1. APRON FEEDER MOTOR INCLUDES GEARBOX WITH LUBE PUMP AND COOLING FAN, REFER TO 2000-ME004-C05-10001 FOR DETAILS.
2. FLANGE CONNECTION IS ANSI B16.5 CLASS 150.
3. FLANGE CONNECTION IS SAE CODE 61.
4. BEACONS IN TUNNEL TO ACTIVATE WHEN VENTILATION FAN IS NOT RUNNING OR FAULT STATUS ACTIVE.

RAW WATER BOOSTER PUMP 2000-F24-PID-PR-10020 RAW WATER — 12-0997-BW-PE16-32
RAW WATER BOOSTER PUMP 2000-F24-PID-PR-10020 RAW WATER — 12-1082-BW-SS1-80
SCHEME WATER DISTRIBUTION 2000-F24-PID-PR-10006 SCHEME WATER — 12-1472-PSW-PE16-90
PRIMARY CRUSHER 2 CHILLER 2000-F12-PID-PR-10003 COOLING WATER — 12-0159-COW-SS3-50-TI
YIC12523 2000-F12-PID-PR-10002 SIGNAL — 12-2049-LO-SS8-12-ET
WIC12557 2000-F12-PID-PR-10002 SIGNAL

PE16 SS2 — 80VBFE1S2 F12-10030 — 80VBFE1S1 FC — 80VBFDIS1 F12-10001 — 80VBFDIS1 FC

CCTV F12-CAM-001 — DIRECT DUMP — DIRECT DUMP — DIRECT DUMP

XI 12000 — YI 12000 — YI 12001 — XI 12001 — ZT 12005A — ZI 12005A — ZI 12005A — HS 12005 — DETAIL 7 — HS 12006 — DETAIL 7
XI 12002 — YI 12002 — YI 12003 — XI 12003 — ZT 12005B — ZI 12005B — ZI 12005B — LI 12004A H — LI 12004B H — LI 12004A — LI 12004B — LT 12004A — LT 12004B
RED GREEN — RED GREEN — RED GREEN — RED GREEN

XV 12005 — XV 12006 — 12-0002-PSW-SS2-80

CCTV F12-CAM-002 — CCTV F12-CAM-003

F12-CR-401 PRIMARY CRUSHER OVERHEAD CRANE

F12-HU-402 ROCKBREAKER HYDRAULIC POWER UNIT
F12-FN-409 ROCKBREAKER HPU COOLING FAN & HEATING COIL
VENDOR PACKAGE

HS 12019A RUN ENABLE — PDAH 12019B HPU BLOCKED FILTER — XI 12019C MAINTENANCE POSITION — XI 12019D HOME POSITION — XI 12019E SYSTEM READY — XI 12019F SYSTEM RUNNING — XI 12019G SYSTEM FAULT — HS 12019H RUN ENABLE

SP SP-005 10 OFF — F12-RB-401 ROCK BREAKER — F12-BN-401 PRIMARY CRUSHER 2 ROM BIN

MANTLE CONTROL — ZIC 12062 HH H L LL — f(x)
AIR BLOWER — FI 12079 L LL
MANTLE POSITION — ZI 12061 H
COUNTER SHAFT 2 — VI 12070
COUNTER SHAFT 1 — VI 12069
MAIN SHAFT — SI 12060 H
COUNTER SHAFT — SI 12059 LL
START — YA 12050 — YA 12050 0 — VSD

F12-CG-401 PRIMARY CRUSHER 2 — 12-2161-CA-MSG3-50 — 50x40 — F12-CH-417 PRIMARY CRUSHER 2 DISCHARGE CHUTE
F12-BW-401 PRIMARY CRUSHER 2 DUST SEAL BLOWER
VENDOR PACKAGE 2000-ME001.1-E02-50001

NOTE 2 — 12-0906-LO-SS2-150

FIT 12075 — 12-1118-LO-SS9-50
FIT 12071 — 12-1119-LO-SS9-50
FIT 12072 — 12-1123-LO-SS9-25
FIT 12073 — 12-1152-LO-SS9-25
FIT 12074 — 12-1153-LO-SS9-25
12-0903-LO-SS10-80-ET

SP MS-005 — 12-0905-HO-SS8-20

HEAT EXCHANGER — 12-2105-COW-SS10-50 — 12-2104-COW-SS10-50

DETAIL 1 — TIC 12127 HH H — TCV 12127 — VTWD1C1 — 12-0036-COW-SS10-50

COOLING WATER RETURN FAL 12145 — HYDRAULIC FILTER PDAH 12088 PDAHH 12088 — LOWER MANTLE SOLENOID HS 12090 — RAISE MANTLE SOLENOID HS 12089 — LUBE PUMP DISCHARGE PI 12118 H — HYDRAULIC OIL RESERVOIR LAL 12081 LALL 12081 — LUBRICATION FILTER PDAH 12121 PDAHH 12121 — TDI 12128

SS10 SS3 — 50VB03S1 F12-10004 — 12-0158-COW-SS3-50 — PRIMARY CRUSHER 2 COOLING WATER TANK 2000-F12-PID-PR-10003 COOLING WATER RETURN

TI 12128 HH H RETURN LUBE OIL
TI 12110 HH H L LL LUBE TANK
LAL 12111 — LALL 12111 LUBRICATION RESERVOIR

F12-LU-401 PRIMARY CRUSHER 2 LUBRICATION SYSTEM
LUBRICATION
HYDRAULIC
NOTE 3

ZIO 12122 — ZIC 12122 LUBRICATION OIL DRAIN VALVE
AAH 12125 LUBRICATION OIL MOISTURE
TI 12080 HH L LL HYDRAULIC OIL RESERVOIR

HS 12130 E-STOP
HS 12131A HS 12131B
HS 12132A HS 12132B
HS 12133A HS 12133B
HS 12134A HS 12134B
F12-LU-401 PUMP START/STOP LOCAL PUSH BUTTONS

F12-PO-404 PRIMARY CRUSHER 2 LUBRICATION PUMP 1 — F12-PO-403 PRIMARY CRUSHER 2 HYDRAULIC PUMP 1 — F12-HT-407 PRIMARY CRUSHER 2 LUBRICATION RESERVOIR HEATER 1 — F12-HT-409 PRIMARY CRUSHER 2 LUBRICATION RESERVOIR HEATER 3 — F12-HT-417 PRIMARY CRUSHER 2 HYDRAULIC RESERVOIR HEATER 1
F12-PO-405 PRIMARY CRUSHER 2 LUBRICATION PUMP 2 — F12-PO-410 PRIMARY CRUSHER 2 HYDRAULIC PUMP 2 — F12-HT-408 PRIMARY CRUSHER 2 LUBRICATION RESERVOIR HEATER 2 — F12-HT-410 PRIMARY CRUSHER 2 LUBRICATION RESERVOIR HEATER 4 — F12-HT-418 PRIMARY CRUSHER 2 HYDRAULIC RESERVOIR HEATER 2
VENDOR PACKAGE 2000-ME001.1-E02-50001

END CYCLE XA 12100 — REMOTE RUN XC 12103 — START HS 12101
F12-LU-402 PRIMARY CRUSHER 2 SPIDER LUBRICATION SYSTEM
VENDOR PACKAGE

XI 12104 READY — XI 12105 RUNNING — WI 12097 L GREASE DRUM

F12-LE-401 PRIMARY CRUSHER 2 INSPECTION TROLLEY

F12-HU-401 F12-PO-420 CRUSHING VAULT LOWER DOOR HPU & HYDRAULIC PUMP VENDOR PACKAGE — LAL 12202

HS 12062 HS 12063 MANTLE RAISE/LOWER
TI 12064 HH H OUTER ECCENTRIC UPPER
TI 12065 HH H OUTER ECCENTRIC WEAR RING
TI 12066 HH H OUTER ECCENTRIC LOWER
TI 12067 HH H COUNTER SHAFT O/B BEARING
TI 12068 HH H COUNTER SHAFT I/B BEARING
FI 12071 L LL OUTER ECCENTRIC LUBE
FI 12072 L LL UPPER ECCENTRIC LUBE
FI 12073 LL PINION LUBE
FI 12074 LL C/SHAFT LUBE
FI 12075 L LL INNER ECCENTRIC LUBE
LI 12200 HH H L LL — LIT 12200 — LI 12199 L LL — LT 12199

LSH 12201 — LAH 12201 — F12-BN-405 PRIMARY CRUSHER 2 DISCHARGE CHAMBER
F12-CH-415 PRIMARY CRUSHER 2 DISCHARGE APRON FEEDER FEED CHUTE CAST-IN

SP SP-005 10 OFF — VI 12057 HH H MAIN DRIVE BEARING DE — VI 12058 HH H MAIN DRIVE BEARING NDE

F12-AV-401 PRIMARY CRUSHER 2 ACCUMULATOR — VENDOR PACKAGE 2000-ME001.1-E02-50001 — PI 12091

12-0908-HO-SS10-80 — 12-0907-HO-SS10-80

F12-XM-578 PRIMARY CRUSHER 2 LUBRICATION UNIT CONTAINMENT BUND
12-0145-FD-SS3-50 — 12-0155-FD-SS3-100 — TO GRADE
100VBFDIS2 F12-10005 LC — 50VB03S1 F12-10006 LC — 12-0144-FD-SS3-50

SP HS-071 — SP HS-078 — TO GRADE TO GRADE

12-0003-BW-SS3-25 — SS3 PE16 — 25VB03S1 F12-10002

PRIMARY CRUSHER DUST COLLECTOR 2000-F12-PID-PR-10002 DUST
PRIMARY CRUSHER DISCHARGE CONVEYOR 2000-F12-PID-PR-10002 COARSE ORE
PRIMARY CRUSHER DISCHARGE CONVEYOR 2000-F12-PID-PR-10002 COARSE ORE

F12-XM-408 PRIMARY CRUSHER BURIED VAULT DUST COLLECTOR DUCTING

F12-CH-401 PRIMARY CRUSHER 2 DISCHARGE APRON FEEDER FEED CHUTE
YA 12223 — F12-CH-412 APRON FEEDER SKIRTS
F12-LU-441 APRON FEEDER AUTO GREASE SYSTEM
F12-FA-401 PRIMARY CRUSHER 2 DISCHARGE APRON FEEDER
START — NOTE 1 — VSD
VENDOR PACKAGE

LI 12226 — LT 12226 — DETAIL 11 — HS 12220 — SV 12220 — 25VD01S1 F12-10003 FC
F12-CH-402 PRIMARY CRUSHER 2 DISCHARGE APRON FEEDER HEAD CHUTE
LSH 12227 — LAH 12227
F12-CH-404 PRIMARY CRUSHER 2 DISCHARGE CONVEYOR FEED CHUTE
SP SP-005

LAL 12225 LUBE LEVEL LOW — XA 12224 GREASE CYCLE SWITCH — PDAH 12230 GEARBOX FILTER — TSH 12237 GEARBOX — PAL 12231 ENCODER — SAL 12222
PWA 12221A — PWA 12221B

F12-CH-403 PRIMARY CRUSHER 2 DISCHARGE APRON FEEDER DRIBBLE CHUTE 1
F12-CH-416 PRIMARY CRUSHER 2 DISCHARGE APRON FEEDER DRIBBLE CHUTE 2

ROM ENTRANCE YI 12234A — CONVEYOR ENTRANCE 1 YI 12234B — CONVEYOR ENTRANCE 2 YI 12234C
NOT RUNNING — YA 12234A YA 12234B YA 12234C — NOTE 4
ATMOSPHERE — CRUSHER CHAMBER
F12-FN-410 PRIMARY CRUSHER 2 BURIED VAULT VENTILATION FAN
F12-XM-414 PRIMARY CRUSHER 2 BURIED VAULT VENTILATION FAN DUCTING
F12-CH-406 PRIMARY CRUSHER 2 VAULT CLEANUP CHUTE

LAH 12370 — LSH 12370 — 12-0007-FD-PE10-110
RAW WATER BOOSTER PUMP 2000-F24-PID-PR-10020 RAW WATER — 12-0008-BW-PE16-63 — PE16 SS3 — 12-0009-BW-SS3-50 — 50VB03S1 F12-10007
SP HS-002
F12-PS-401 PRIMARY CRUSHING 2 AREA SUMP PUMP
PRIMARY CRUSHING 2 DRIVE-IN SUMP