NOTES:

1. AIR SUPPLY TO DART VALVES, REFER TO DART VALVE PNEUMATIC SCHEMATIC 2000-ME001.4-D02-50001 FOR DETAILS.

FLOTATION/
THICKENER AIR SERVICES
2000-F24-PID-PR-10008

PLANT AIR

16-0683-IA-MSG2-100

XV 16080 (1) | XV 16123 | XV 16122 | XV 17007 | XV 17006 | XV 17005

F17-CP-404
FLOTATION TAILINGS THICKENER
FINAL TAIL SAMPLE PUMP
VALVE CONTROL PANEL

17-0319-IA-MSG3-25
25VB03S1 F17-11479

SP@ F18-PP-501 AT GRADE — SP MC-001
16-2250-IA-MSG3-25
25VB03S1 F16-10740

F16GA425-CP01
ROUGHER CONCENTRATE LAUNDER
VALVE CONTROL PANEL
XV 16025 | XV 16026
16-2131-IA-MSG3-50
25VB03S1 F16-11676

SP@ F16-ST-10204 TOS RL 382.780 — SP MC-001
16-2109-IA-MSG3-25
25VB03S1 F16-10742

SP@ F16-ST-10204 AT GRADE — SP MC-001
16-2108-IA-MSG3-25
25VB03S1 F16-10741

SP@ F18-HP-511 AT GRADE — SP MC-001
18-1584-IA-MSG3-25 (1)
25VB03S1 F18-11492

F18-CP-407
CLEANER FLOTATION CELL
RECIRCULATION PUMPS
VALVE CONTROL PANEL
XV 18031 | XV 18032 | XV 18033 | XV 18034 | XV 18035 | XV 18036
18-0692-IA-MSG3-25
25VB03S1 F18-11488
50x25

18-0691-IA-MSG3-50

SP@ F18-CF-501 TOS RL 387.000 — SP MC-001
18-1579-IA-MSG3-25
25VB03S1 F18-11487

SP@ F18-PP-408 AT GRADE — SP MC-001
18-1580-IA-MSG3-25
25VB03S1 F18-11486

F18-CP-406
FINAL CONCENTRATION PUMPS
VALVE CONTROL PANEL
XV 18021 | XV 18022 | XV 18023 | XV 18024 | XV 18025 | XV 18026 | XV 18028 | XV 18029
18-0693-IA-MSG3-25
25VB03S1 F18-11485

F18-CP-410
FINAL CONCENTRATE
VALVE CONTROL PANEL
XV 18013 | XV 18012 | XV 18039 | XV 18038 | LCV 18011A | LCV 18001
50x25
25VB03S1 F18-11483

16-2130-IA-MSG2-100
18-1078-IA-MSG2-100
18-0270-IA-MSG3-50

MSG2 MSG3 (1)

18-0269-IA-MSG3-50
50x25
25VB03S1 F18-11480

F18-CP-409
CLEANER SCAVENGER TAILS DISCHARGE
VALVE CONTROL PANEL
XV 18229 | XV 18239 | XV 18241 | XV 18242 | XV 18243 | XV 18244

18-1583-IA-MSG3-50
50x25
25VB03S1 F18-11494

SP@ F18-CF-511 TOS RL 387.000 — SP MC-001

F18-CP-403
CLEANER SCAVENGER CELL
RECIRCULATION PUMPS
VALVE CONTROL PANEL
XV 18221 | XV 18222 | XV 18223 | XV 18224 | XV 18225 | XV 18226

18-0318-IA-MSG3-50
50x25
25VB03S1 F18-11490

F18-CP-408
CLEANER SCAVENGER CELL FEED
HOPPER PROCESS WATER
VALVE CONTROL PANEL
XV 18014 | LCV 18201A

18-0966-IA-MSG3-25 (1)
50x25
25VB03S1 F18-11484

F18-CP-404
CLEANER SCAVENGER CELL TAILS
HOPPER PROCESS WATER
VALVE CONTROL PANEL
XV 18015 | LCV 18211

18-0715-IA-MSG3-25 (1)
25VB03S1 F18-11489

F18-CP-405
CLEANER SCAVENGER CELL TAILS PUMPS
VALVE CONTROL PANEL
XV 18231 | XV 18232 | XV 18233 | XV 18234 | XV 18235 | XV 18236

18-0274-IA-MSG3-50
50x25
25VB03S1 F18-11491

18-1585-IA-MSG3-25
25VB03S1 F18-11493

SP@ F18-CF-511 TOS RL 381.000 — SP MC-001

F18-CP-402
CLEANER SCAVENGER FLOTATION CELL
VALVE CONTROL PANEL
FCV 18256 | FCV 18257 | LCV 18201B | LCV 18251

18-0256-IA-MSG3-25
50x25
25VB03S1 F18-11481

F18-CP-401
CLEANER FLOTATION CELL
VALVE CONTROL PANEL
FCV 18056 | FCV 18057 | LCV 18011B | LCV 18051

18-0255-IA-MSG3-25
50x25
25VB03S1 F18-11482

17-0688-IA-MSG2-80

MSG2 MSG3

17-1577-IA-MSG3-25
25VB03S1 F17-11498
SP@ ST-10401 COLUMN F4 AT GRADE — SP MC-001

F17-CP-403
FLOTATION TAILINGS THICKENER
UNDERFLOW PUMPS
VALVE CONTROL PANEL
XV 17123 | XV 17124 | XV 17125 | XV 17126 | XV 17131

17-0322-IA-MSG3-25
25VB03S1 F17-11497

17-1612-IA-MSG3-25
25VB03S1 F17-11495
SP@ F17-PP-634 AT GRADE — SP MC-001

F17-CP-402
FLOTATION TAILINGS THICKENER
UNDERFLOW PUMPS
VALVE CONTROL PANEL
XV 17101 | XV 17102 | XV 17103 | XV 17111 | XV 17112 | XV 17113

17-0689-IA-MSG3-25
25VB03S1 F17-11499

17-1716-IA-MSG3-25
25VB03S1 F17-11473
SP@ F16-RA-402 AT GRADE — SP MC-001

F17-CP-401
FLOTATION TAILINGS
THICKENER DISCHARGE
VALVE CONTROL PANEL
XV 17091 | XV 17092 | XV 17093 | XV 17094 | XV 17095 | XV 17096

17-0935-IA-MSG3-25
25VB03S1 F17-11500

17-1614-IA-MSG3-25
25VB03S1 F17-11501
SP@ F17-TH-401 AT GRADE — SP MC-001

200x100

VENDOR PACKAGE
REFER DRAWING
2000-ME001-4-E02-50004

NOTE 1

FCV 16011 | LCV 16013A | LCV 16013B
SP MS-001 (F R)
25VB03S1 F16-10642 | 25VB03S1 F16-10643 | 25VB03S1 F16-10644
16-0410-IA-MSG3-25
25VB03S1 F16-11508
SP@ F16-CF-411 TOS RL 396.713 — SP MC-001

FCV 16051 | LCV 16053A | LCV 16053B
SP MS-001 (F R)
25VB03S1 F16-11067 | 25VB03S1 F16-11068 | 25VB03S1 F16-11069
16-0470-IA-MSG3-25
25VB03S1 F16-11507
SP@ F16-CF-412 TOS RL 395.413 — SP MC-001

FCV 16061 | LCV 16063A | LCV 16063B
SP MS-001 (F R)
25VB03S1 F16-10755 | 25VB03S1 F16-10756 | 25VB03S1 F16-10758
16-0542-IA-MSG3-25
25VB03S1 F16-11506
SP@ F16-CF-413 TOS RL 394.113 — SP MC-001

FCV 16081 | LCV 16083A | LCV 16083B
SP MS-001 (F R)
25VB03S1 F16-10752 | 25VB03S1 F16-10753 | 25VB03S1 F16-10754
16-0664-IA-MSG3-25
25VB03S1 F16-11505
SP@ F16-CF-414 TOS RL 392.813 — SP MC-001

FCV 16091 | LCV 16093A | LCV 16093B
SP MS-001 (F R)
25VB03S1 F16-10749 | 25VB03S1 F16-10750 | 25VB03S1 F16-10751
16-0708-IA-MSG3-25
25VB03S1 F16-11504
SP@ F16-CF-415 TOS RL 391.513 — SP MC-001

FCV 16101 | LCV 16103A | LCV 16103B
SP MS-001 (F R)
25VB03S1 F16-10746 | 25VB03S1 F16-10747 | 25VB03S1 F16-10748
16-0712-IA-MSG3-25
25VB03S1 F16-11503
SP@ F16-CF-416 TOS RL 390.213 — SP MC-001

FCV 16111 | LCV 16113A | LCV 16113B | LCV 16103A | LCV 16103B
SP MS-001 (F R)
25VB03S1 F16-10743 | 25VB03S1 F16-10744 | 25VB03S1 F16-10745 | 25VB03S1 F16-10643 | 25VB03S1 F16-10644
16-0920-IA-MSG3-25
25VB03S1 F16-11502
SP@ F16-CF-417 TOS RL 388.913 — SP MC-001