

- NOTES:
1. SPIGOTS PLACED AT 40m CENTRES ON TSF EMBANKMENT.
 2. SPIGOTS PLACED AT 15m CENTRES ON THE CAUSEWAYS.
 3. PIPING ON TSF EMBANKMENT TO BE FLANGED EVERY 40m.
 4. PIPING ON CAUSEWAY TO BE FLANGED EVERY 15m.
 5. REFER TO DRAWING 2000-T02-DRG-GE-40002 FOR SPIGOT DETAILS A TOTAL OF 166 SPIGOTS REQUIRED WITH UNIQUE VALVE NUMBERS 44204 TO 44369.

- LEGEND:
- EXISTING
 - NEW
 - FUTURE
 - DECOMMISSIONED

