# Reset Release IP V1.0

IP User Guide(Beta Release)



February 2, 2023





# **Contents**

Overview	2
Reset Release IP	
Licensing	3
IP Specification	4
Overview	
IP Support Details	
Resource Utilization	5
Port List	
Parameters	6
Design Flow	7
IP Customization and Generation	7
Example Design	9
Overview	9
Synthesis and PnR	9
Test Bench	10
	11
Revision History	11



## **Overview**

#### **Reset Release IP**

Reset Release is added as a processor reset release IP in IP Catalog. It is designed to generate customized resets for a processor based SoC, namely processor, peripherals, buses and interconnects. This offers user access to parameterize the system resets as per his feature needs.




Figure 1. Reset Release IP Block

#### **Features:**

- Asynchronous external reset
- Parameterizable pulse width of input resets
- Locked Input
- Reset generation on power up
- Parameterized active-Low reset signal generation for peripherals and interconnects



### Licensing

#### **COPYRIGHT TEXT:**

Copyright (c) 2022 RapidSilicon

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions: The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.



# **IP Specification**

#### Overview

Reset Release IP is a soft IP that offers reset handling mechanism for a processor based system. It generates output resets based upon external resets and lock.

### **Core Description**

The reset release Core has 4 input and 5 output signals. User can configure the core using 5 parameters controlling the outputs. **EXTERNAL RESET WIDTH** tells the window of external reset, number of active Low Peripheral Resets, **PERIPHERAL ARESETN**, number of Interconnects **INTERCONNECTS**, number of bus resets **BUS RESET**, number of Peripheral Resets Active High **PERIPHERAL RESET**.

The reset becomes active six or seven clocks after the input is activated and remains active for five clocks. After ext\_reset is inactive for five clocks, the process of exiting the reset begins. If, during this process, ext\_reset becomes active for five or more clocks, all outputs will become active again. The External Reset Active Polarity is used to set the logic level that triggers a reset when ext\_reset is high on a rising edge of the clock. The Auxiliary Reset Active Polarity is used to set the logic level that triggers a reset when aux\_reset is low. The No. of Bus Reset (active-High) and No. of Interconnect Reset (active-Low) are used to generate additional bus\_struct\_reset and Interconnect Structure Reset signals, which assist with signal loading and routing.

#### **Output reset sequence**

- 1. Interconnects and Bridges(Bus Structures) come out of reset first.
- 2. After 12 clock cycles Peripherals come out of reset.
- 3. CPU comes out of reset after 12 more cycles of the peripherals.



### **IP Support Details**

Comp	oliance	IP Resources				Tool Flow			
Device	Interface	Source Files	Constraint File	Testbench	Simulation Model	Software Driver	Analyze and Elaboration	Simulation	Synthesis
GEMINI	AXI4-lite	Verilog	-	<verilog< td=""><td>-</td><td>-</td><td>Raptor</td><td>Raptor</td><td>Raptor</td></verilog<>	-	-	Raptor	Raptor	Raptor

### **Resource Utilization**

Please note that the utilization and timing figures provided in this section for the Processor System Reset IP core should be considered as estimates, as they are based on its usage in conjunction with other design modules in the FPGA. Once integrated with other designs in the system, the FPGA resource utilization and core timing may differ from the reported results.

Tool	Raptor Design Suite				
FPGA Device	GEMINI				
	Configuration	Resource Utilization			
	Options	Configuration	Resources	Utilized	
	EXT_RESET_WIDTH	5	LUT	31	
Minimum	PERIPHERAL_ARESETN	1	Registers	19	
Resource	INTERCONNETS	1	BRAM	0	
	BUS_RESET	1	DSP	0	
	Options	Configuration	Resources	Utilized	
Maximum Resource	EXT_RESET_WIDTH	10	LUT	31	
	PERIPHERAL_ARESETN	10	Registers	19	
	INTERCONNETS	10	BRAM	0	
Resource	BUS_RESET	10	DSP	0	



### **Ports**

Table 2 lists the top interface ports of the Reset Release Core.

Signal Name	I/O	Description
slow_clk	I	Slowest clock of the system
ext_rst	I	External reset of the system
cpu_dbg_rst	I	Processor debug reset
pll_lock	I	Pll Lock
cpu_rst	О	Processor reset generated by IP
periph_aresetn	О	RESETNs for system peripherals
interconnect_aresetn	О	Resets generated for the interconnects used in the system
bus_reset	О	Resets for the buses
periph_reset	O	Resets for system peripherals

#### Reset Release Interface

### **Parameters**

Table 3 lists the parameters of the Reset Release Core.

Parameter	Values	Default Value	Description
EXTERNAL RESET WIDTH	4-10	5	External reset window.
PERIPHERAL ARESETN	1-10	1	Number of peripheral resets N.
INTERCONNECTS	1-10	1	Number of Interconnects.
BUS RESET	1-10	1	Number of bus resets.
PERIPHERAL RESET	1-10	1	Probe width in case of value compare mode


Parameters



# **Design Flow**

#### **IP Customization and Generation**


OCLA IP core is a part of the Raptor Design Suite Software. A customized ocla can be generated from the Raptor's IP configurator window.



IP list



**Parameters Customization:** From the IP configuration window, the parameters of the OCLA can be configured and OCLA features can be enabled for generating a customized OCLA IP core that suits the user application requirment.




**IP** Configuration



# **Example Design**

#### Overview

Reset release IP is an integral part of a processor based SoC. Below shows an example design employing the reset release IP. The reset release IP takes its input from external reset and/or a clock generator. The cpu\_reset is fed to Vexriscv cpu, bus\_struct\_reset is fed to the AXILAXILite bridge, interconnect\_aresetn is fed to the AXILite Interconnect and peripheral resets are fed to AXIL\_UART and AXIL\_RAM.



Example design employing Reset Realease IP

### Synthesis and PnR

Raptor Suite is armed with tools for Synthesis along with Post and Route capabilities and the generated post-synthesis and post-route and place netlists can be viewed and analyzed from within the Raptor. The generated bitstream can then be uploaded on an FPGA device to be utilized in hardware application.



# **Test Bench**

The IP package hosts a simple Verilog based test bench that validates design functionality. It can be simulated using Iverilog, Verilator or other simulators.



# **Revision History**

Date	Version	Revisions
February 2, 2023	0.01	Initial version Reset Release IP User Guide