

Alignment PADs positioning in red (dotted areas is the clearance, gray line is the IC dimension)

Pad A ) Top Right is located exactly on the BGA corner

Pad B ) Bottom Left corner is located exactly 10 mil up with respect to the BGA corner