
Before Update Firmware

- Disconnect USB cable from motor test kit
- Connect GPIO1 to GND
- Connect the USB cable to motor test kit
- 4. Follow the next page steps to upgrade the firmware


After Update Firmware

- Disconnect USB cable from motor test kit
- Disconnect GPIO1 to GND
- Connect the USB cable to motor test kit



Firmware UpGrade

1.Utility->Firmware




4.Press 確定




2.Press Update



5.Firmware upgrade OK



3.Select file...



6.Re-plug the USB and re-start the APP

