We are almost done with creating our FlexBE behavior. In this video lecture, we will learn step by step how to define the data for our behavior.

Important Note:

You may note minor differences in the hrwros.srdf file displayed in the video around min 3:30 and your hrwros.srdf (e.g. group_state name is now "R1Home").

Do not worry, use the values in your hrwros.srdf file, the same ones that you use in week 4, we have adjusted them for this edition of the MOOC.

Configure a 6.3.2 behavior Carlos Hernandez 1.0x Subtitles • **▼** Video Other

Configure a behavior

© (§ (§ (§ Some Rights Reserved)

- Behavior data will be defined in the behavior overview panel.
- · Constants are useful for data that will never change during operation, but that you might want to change between versions. They are defined by using literals.
- Other data can changed during the behavior. Data like this is called userdata in FlexBE. They will need to have default values. You can use defined constants as the default value.

Question	า 1

1 point possible (ungraded) Which of the following statements about *Userdata Variables* are true? More then one statement is true

1. They are used for constant values in a behavior.
2. They are used for information that can change at runtime during the behavior execution.
3. They can be passed as input to states.
4. They do not require a default value in FlexBE.

Submit