

## 硬件连接:



## 下载烧写软件:

https://content.elprotronic.ca/downloads/M-win.zip

## 软件配置:



## 烧写步骤:

- 1. 点击 'Power ON/OFF' 按钮.
- 2. 检查回读电压,应为3.3V.
- 3. 点击 'AUTO PROG', 开始自动烧写.

