

FINAL ASSEMBLY



ASSEMBLY

- Connect the wires from the Sensor Holder Assembly to the appropriate pins on the MotorHat(See Previous Page or Schematics File)
- Connect the Micro USB to the Raspberry Pi and the USB to the PowerBoost
- Orient the Sensor Holder so that the three holes align to the Frame Spacers(The three 2 1/2in spacers on the Chassis) Be sure that no wires are being crimped and that no pins are being bent
- Screw in the 1/2in hex screws through the Sensor Holder, into the Frame Spacers



DO NOT CHARGE THE BATTERIES WITHOUT
ENSURING THEY ARE ALL AT THE SAME VOLTAGE
AND CAPACITY! THIS CAN RESULT IN FIRE!!
FOLLOW ALL PRECAUTIONARY STEPS WHEN
USING LITHIUM ION BATTERIES

PARTS

- Chassis Assembly x 1
- Sensor Holder Assembly x 1
- 1/2in x 3/32in hex x 3
- 6in Micro USB to USB Cord x 1

