

Product Name: SmartHome WiFi Router X100

1. Installation

To install the router, connect the power adapter and plug in the WAN cable. Wait for the power LED to turn solid green.

2. Configuration

Press the RESET button for 3 seconds to start configuration. Connect your device to the default SSID "X100_Default" and open the browser to 192.168.0.1.

3. Default Credentials

Username: admin

Password: password123

4. Troubleshooting

If the internet does not work, restart the device and check the WAN cable connection. You can also reset the router.

5. Safety Guidelines

Keep the router in a ventilated area. Do not expose it to water or high temperatures.

6. Warranty

This product comes with a 1-year limited warranty covering manufacturing defects only.