

Summary report

Wellbore: 15/9-F-7

Period: 2007-10-07 00:00 - 2007-10-08 00:00

Status:	normal
Report creation time:	2018-05-03 13:53
Report number:	24
Days Ahead/Behind (+/-):	
Operator:	StatoilHydro
Rig Name:	MÆRSK INSPIRER
Drilling contractor:	Mærsk Contractors
Spud Date:	2007-05-01 00:00
Wellbore type:	
Elevation RKB-MSL (m):	54.9
Water depth MSL (m):	91
Tight well:	Y
HPHT:	Y
Temperature (I):	
Pressure (I):	
Date Well Complete:	2007-10-04

Dist Drilled (m):	-999.99
Penetration rate (m/h):	-999.99
Hole Dia (I):	
Pressure Test Type:	
Formation strength (g/cm3):	0
Dia Last Casing (I):	

Depth at Kick Off mMD:	
Depth at Kick Off mTVD:	
Depth mMd:	1085
Depth mTVD:	1077
Plug Back Depth mMD:	
Depth at formation strength mMD:	0
Depth At Formation Strength mTVD:	0
Depth At Last Casing mMD:	1062
Depth At Last Casing mTVD:	1056.7

Summary of activities (24 Hours)

POOH with the Swab assembly. RIH with Swab new assemblee. Pumped 14,5 m³ of Citric acid (1,06 SG). Displaced Citric acid with 8,6 m³ 1.03 SG NaCl. Let Citric acid soak. Lined up to trip tank and established loss rate, loss rate 450 lpm. Pulled the string up to 840 m above the PBR. Lined up to trip tank and established loss rate, loss rate 400 lpm. POOH with the swabbing assemblee from 840 m to 530 m.

Summary of planned activities (24 Hours)

POOH with the swabbing assemblies and LD same. Retrieve bore protector. RIH jetting tool for Riser/Well head. Prepare to run ESP assembly. Spot equipment on deck and on drillfloor. MU ESP assemblies and connect cable. Run in with ESP on 7 5/8" tubing.

Operations

Start time	End time	End Depth mMD	Main - Sub Activity	State	Remark
00:00	02:45	888	completion -- circulatin g conditioning	ok	Continued swabbing the well 3 times using 3 strokes at the time with stroke length of 35 m. Swabbing speed 40 and 50 m/min. Losses 1200, 700 and 600 lpm. Filled up t rip tank and observed final loss rate of 300 lpm.
02:45	03:00	888	completion -- circulatin g conditioning	ok	Pressured up the string and bursted the burst disk sub at 250 bars.
03:00	03:30	1050	completion -- circulatin g conditioning	ok	RIH with Swab assembly from 888 m to 1050 m.
03:30	05:00	918	completion -- circulatin g conditioning	ok	Connected up to TDS POOH pumping 1000 lpm, 10 m/min, 8 bars SSP, 1.03 SG NaCl.
05:00	06:00	829	completion -- circulatin g conditioning	ok	Pulled the swab assembly above the PBR. Established a loss rate of 150 lpm.
06:00	06:30	888	completion -- circulatin g conditioning	ok	Prepared for POOH with the Swab assembly.
06:30	06:45	835	completion -- circulatin g conditioning	ok	Started to POOH with the Swab assembly from 888 m to 835 m.
06:45	07:00	835	completion -- circulatin g conditioning	ok	Stopped POOH with the Swab assembly. Evaluated situation.
07:00	08:15	835	completion -- circulatin g conditioning	ok	Held tool box talk with day shift. evaluated situation. Meanwhile greased drilling equipment, installed TIW.
08:15	12:00	835	completion -- circulatin g conditioning	ok	Slip and cut drill line.
12:00	12:45	835	completion -- circulatin g conditioning	ok	Calibrated TDS height for Geoservices.
12:45	14:15	112	completion -- circulatin g conditioning	ok	Started to POOH with 5½" DP and Swab assembly from 835 m to 112 m.
14:15	15:30	112	completion -- circulatin g conditioning	ok	Picked and made up second Swab assembly.
15:30	17:30	849	completion -- circulatin g conditioning	ok	RIH with Swab assemblee from 112 m to 849 m.
17:30	18:15	1050	completion -- circulatin g conditioning	ok	Continued to RIH with Swab assemblee at 2 min/std to 1050 m.
18:15	20:30	1050	completion -- circulatin g conditioning	ok	Pumped 14,5 m³ of Citric acid (1,06 SG) with 1500 lpm. Displaced Citric acid with 8,6 m³ 1.03 SG NaCl brine at 1500 lpm. Closed DP on stand pipe valve, locked in fluid in DP. Let Citric acid soak.
20:30	21:30	1050	completion -- circulatin g conditioning	ok	Pulled the upper cup into the blank pipe and swabbed the well 2 times with 10 m strokes 30 m/min. Ran back to 1050 m. Opened the stand pipe valve. Pumped 0.5 m³ d own DP and displaced clean acid into well bore. Closed stand pipe valve. Let Citric acid soak.
21:30	22:15	1050	completion -- circulatin g conditioning	ok	Pulled the upper cup into the blank pipe and swabbed the well 2 times with 10 m strokes 30 m/min. Ran back to 1050 m. Opened the stand pipe valve. Pumped 0.5 m³ d own DP and displaced clean acid into well bore. Closed stand pipe valve. Let Citric acid soak.
22:15	23:00	1050	completion -- circulatin g conditioning	ok	Pulled the upper cup into the blank pipe and swabbed the well 2 times with 10 m strokes 30 m/min. Ran back to 1050 m. Opened the stand pipe valve. Pumped 0.5 m³ d own DP and displaced clean acid into well bore. Closed stand pipe valve. Let Citric acid soak.
23:00	23:15	1050	completion -- circulatin g conditioning	ok	Pulled the upper cup into the blank pipe and swabbed the well 2 times with 10 m strokes 30 m/min. Ran back to 1050 m. Opened the stand pipe valve. Pumped 0.5 m3 d own DP and displaced clean acid into well bore.
23:15	00:00	1050	completion -- circulatin g conditioning	ok	Lined up to trip tank and established loss rate, loss rate 450 lpm.

Drilling Fluid

Sample Time	15:00
Sample Point	Reserve pit
Sample Depth mMD	1083
Fluid Type	Packer fluid
Fluid Density (g/cm3)	1.03
Funnel Visc (s)	-999.99
Mf (I)	
Pm (I)	
Pm filtrate (I)	
Chloride (I)	

Calcium ()	
Magnesium ()	
Ph	
Excess Lime ()	
Solids	
Sand ()	
Water ()	
Oil ()	
Solids ()	
Corrected solids ()	
High gravity solids ()	
Low gravity solids ()	
Viscometer tests	
Plastic visc. (mPa.s)	-999.99
Yield point (Pa)	-999.99
Filtration tests	
Pm filtrate ()	
Filtrate Lthp ()	
Filtrate Hthp ()	
Cake thickn API ()	
Cake thickn HPHT ()	
Test Temp HPHT ()	
Comment	