

Summary report

Wellbore: 15/9-F-7

Period: 2007-10-08 00:00 - 2007-10-09 00:00

Status:	normal
Report creation time:	2018-05-03 13:53
Report number:	25
Days Ahead/Behind (+/-):	
Operator:	StatoilHydro
Rig Name:	MÆRSK INSPIRER
Drilling contractor:	Mærsk Contractors
Spud Date:	2007-05-01 00:00
Wellbore type:	
Elevation RKB-MSL (m):	54.9
Water depth MSL (m):	91
Tight well:	Y
HPHT:	Y
Temperature (I):	
Pressure (I):	
Date Well Complete:	2007-10-04

Dist Drilled (m):	-999.99
Penetration rate (m/h):	-999.99
Hole Dia (I):	
Pressure Test Type:	
Formation strength (g/cm3):	0
Dia Last Casing (I):	

Depth at Kick Off mMD:	
Depth at Kick Off mTVD:	
Depth mMd:	1085
Depth mTVD:	1077
Plug Back Depth mMD:	
Depth at formation strength mMD:	0
Depth At Formation Strength mTVD:	0
Depth At Last Casing mMD:	1062
Depth At Last Casing mTVD:	1056.7

Summary of activities (24 Hours)

POOH with the Swabbing assemblies from 530 m to surface. RIH and retrieved the bowl protector at 20.61 m. Jet washed the surface well head. Perform dummy run with the tubing hanger, landed same and documented orientation. Racked tubing hanger back in the derrick. Rigged up surface equipment for handling the ESP equipment. Made up ESP assemblies and tested same.

Summary of planned activities (24 Hours)

Complete making up the ESP pump equipment. Run in with ESP on 7 5/8" tubing, MU hanger FAST swivel assembly. Orient hanger and lock quick connector. Space out penetrator cable. Cut cable. Make splice. Install penetrator in hanger. Leak test between seals on penetrator. MU tubing hanger running tool. Prepare to land hanger. Run in and land hanger. Leak test. Nipple down diverter and surface riser. Install tubing bonnet, spacer spool and ball valve assembly. Leak test. Terminate cable. Install XMT

Operations

Start time	End time	End Depth mMD	Main - Sub Activity	State	Remark
00:00	01:30	1026	completion -- circulating conditioning	ok	Pulled the string up to 1026 m, having the upper swab cup inside the 9 5/8" blank pipe. Opened stand pipe valve. Pumped 30 m³ 1.03 SG brine, to ensure that the rema ining Citric acid was bull headed into the formation. Pumping rate 420 lpm 5 bars SPP.
01:30	03:15	900	completion -- circulating conditioning	ok	Pulled the string to 900 m having the bottom swab cup inside the 9 5/8" blank pipe. Displaced the remaining citric acid into the formation by pumping 20 m³ 1.03 SG packer fluid.
03:15	04:30	840	completion -- circulating conditioning	ok	Pulled the string up to 840 m above the PBR. Lined up to trip tank and established loss rate, loss rate 400 lpm.
04:30	05:15	731	completion -- circulating conditioning	ok	POOH with the Swabbing assemblies from 840 m to 731 m. As POOH filled the well with 1.03 SG packer fluid.
05:15	05:45	731	interruption -- maintain	ok	Stand threads got caught in box, when picking up with PRS. Freed the stand from box. Inspected the dies and the rollers on PRS head.
05:45	06:00	530	completion -- circulating conditioning	ok	Continued POOH with the Swabbing assemblies from 731 m to 530 m. As POOH filled the well with 1.03 SG packer fluid.
06:00	08:15	0	completion -- circulating conditioning	ok	Continued POOH with the Swabbing assemblies from 530 m to surface. Laid out the two Swabbing assemblies.
08:15	08:45	0	drilling -- bop/wellhead equipment	ok	Held tool box talk prior to retrieving the bowl protector. Removed master bushing and pulled 18" diverter inserts.
08:45	09:00	0	drilling -- bop/wellhead equipment	ok	RIH and retrieved the bowl protector at 20.61 m. POOH and laid out same. Installed the master bushing.
09:00	10:30	0	drilling -- bop/wellhead equipment	ok	Made up the jetting tool. Ran in and washed the surface well head area (1500 lpm/5 rpm) total pumped 8 m³ packer fluid. Pulled out and laid out jetting tool.
10:30	12:45	0	completion -- completion string	ok	Held tool box talk prior to perform dummy run with the tubing hanger. Cleared rig floor and picked up and made up tubing hanger. Ran in and landed the tubing hanger, documented the orientation. Pulled out with tubing hanger and racked back in the derrick.
12:45	19:00	0	completion -- completion string	ok	Held tool box talk prior to rig up. Rigged up surface equipment for handling the ESP equipment, casing tong, goose neck and cable.
19:00	20:30	0	completion -- completion string	ok	Held tool box talk prior to picking up the ESP motor. Picked up same.
20:30	21:15	0	completion -- completion string	ok	Serviced the motor and evacuated the air
21:15	00:00	0	completion -- completion string	ok	Installed protector joint, ESP pump, discharge pressure assembly and x-o 9 5/8" x 7 5/8".

Drilling Fluid

Sample Time	15:00
Sample Point	Reserve pit
Sample Depth mMD	1083
Fluid Type	Packer fluid
Fluid Density (g/cm3)	1.03
Funnel Visc (s)	-999.99
Mf ()	
Pm ()	
Pm filtrate ()	
Chloride ()	
Calcium ()	
Magnesium ()	
Ph	
Excess Lime ()	
Solids	
Sand ()	
Water ()	
Oil ()	

Solids ()	
Corrected solids ()	
High gravity solids ()	
Low gravity solids ()	
Viscometer tests	
Plastic visc. (mPa.s)	-999.99
Yield point (Pa)	-999.99
Filtration tests	
Pm filtrate ()	
Filtrate Lthp ()	
Filtrate Hthp ()	
Cake thickn API ()	
Cake thickn HPHT ()	
Test Temp HPHT ()	
Comment	