Service protocol packet examples

Device reset

transmit: addr:AB

cmd:Reset
size:0000
crc:ABA0
num:0000


Data transmission request

transmit: addr:AB

cmd:Send
size:0008
crc:5D15
num:0000

data: WSERV 0001, WDATA 0002, WDATA AB45, WDATA FFA1

The transmission of 4 MIL words as the result of this request:



Data receive request

transmit: addr:AC

cmd:Receive
size:0008
crc:B4BA
num:0001

Data receive reply

receivedRaw: 000000000000AC0008B2<mark>FFA1</mark>0001<mark>FFA3</mark>0002<mark>FFA3</mark>AB45<mark>FFA3</mark>FFA15E250001

received: addr:AC

cmd:Receive
size:0008
crc:5E25
num:0001

data: WSERV 0001, WDATA 0002, WDATA AB45, WDATA FFA1

Status request

transmit: addr:AB

cmd:Status
size:0000
crc:ABB0
num:0000

Status reply

receivedRaw: 000000000000003B00000000000001AEB10001

received: addr:AB

cmd:Status
size:0003
crc:AEB1
num:0001

ReceivedQueueSize:0000 TransmitQueueSize:0000 SpiErrorCount:0001

Available packet headers

FFA0 - WSERVERR - service word that was received with error (data receive only)

FFA1 - WSERV - service word

FFA2 - WDATAERR - data word that was received with error (data receive only)

FFA3 - WDATA - data word

Available commands

A0 - device reset

A2 - send data to mil

B0 - status request

B2 - data request