Export: One Company Header with Compound Meters (continued)

RDGDT

MTRDT

ORDST

RDGDT

VHLDT

RTETR

COMTR

Record Formats

Header Formats

The following tables represent the format for the record layouts used by $N_SIGHT\ R900$.

Table 4.5 Company Record Format

Column	Use	Source	Offset	Length	Туре	Comment
Record ID	Req	UB	1-5	5	A/N	'COMHD'
Company Code	Req	UB	6-9	4	A/N	
Create Date	Req	UB	10-17	8	NUM	YYYYMMDD
Description	Opt	UB	18-57	40	A/N	
File Version	Req	UB	58	1	NUM	'4'
Service Orders	Req	UB	59	1	воо	Y or N
CRLF	Req	UB	60-61	2		

Table 4.6 Route Record Format

Column	Use	Source	Offset	Length	Туре	Comment
Record ID	Req	UB	1-5	5	A/N	'RTEHD'
Office	Req	UB	6-9	4	A/N	
Cycle	Req	UB	10-13	4	A/N	
Route	Req	UB	14-23	10	A/N	
Read Date	Req	UB	24-31	8	NUM	YYYYMMDD; 00000000 if not used.
Deactivate Date	Req	UB	32-39	8	NUM	YYYYMMDD; 00000000 if not used.
Route Message	Opt	UB	40-119	80	A/N	
CRLF	Req	UB	120-121	2		



The Route ID in N_SIGHT R900 is a combination of the Company Code, Office, Cycle, and Route fields.

Table 4.7 Premise Details Record Format

Column	Use	Source	Offset	Length	Туре	Comment
Record ID	Req	UB	1-5	5	A/N	'PRMDT'
Address 1	Req	UB	6-31	26	A/N	
Address 2	Opt	UB	32-57	26	A/N	
Customer Name	Req	UB	58-83	26	A/N	

 Table 4.7 Premise Details Record Format (continued)

Column	Use	Source	Offset	Length	Туре	Comment
Premise Key	Req	UB	84-103	20	A/N	Uniquely identifies the premise. Use account number, unless the billing system has a better key.
Account Number	Req	UB	104-123	20	A/N	
Account Status	Req	UB	124-127	4	A/N	Account status codes
Premise Custom 1	Opt	UB	128-153	26	A/N	Custom display fields for premise screen.
Premise Custom 2	Opt	UB	154-179	26	A/N	
Utility Pass Through	Opt	UB	180-307	128	A/N	Any utility-defined information.
CRLF	Req	UB	308-309	2		

Table 4.8 Alternate Premise Detail Record Format¹

Column	Use	Source	Offset	Length	Туре	Comment
Record ID	Req	UB	1-5	5	A/N	'PRMD2'
Premise Key	Req	UB	6-25	20	A/N	
Customer Name 1	Req	UB	26-51	26	A/N	
Customer Name 2	Opt	UB	52-77	26	A/N	
Customer Contact	Opt	UB	78-103	26	A/N	
Account Number	Req	UB	104-123	20	A/N	
Account Status	Req	UB	124-127	4	A/N	Account status codes

^{&#}x27;Reserved for future use

Table 4.8 Alternate Premise Detail Record Format¹ (continued)

Column	Use	Source	Offset	Length	Туре	Comment
Customer Address House Number	Req	UB	128-134	7	A/N	
Customer Address HSuffix	Req	UB	135-141	7	A/N	
Customer Address Unit	Req	UB	142-156	15	A/N	
Customer Address Predir	Req	UB	157-158	2	A/N	
Customer Address Street	Req	UB	159-183	25	A/N	
Customer Address Suffix	Req	UB	184-187	4	A/N	
Customer Address Postdir	Req	UB	188-189	2	A/N	
Customer Address City	Req	UB	190-215	26	A/N	
Customer Address State	Req	UB	216-217	2	A/N	
Customer Address Zip	Req	UB	218-228	11	A/N	ZZZZZ-ZZZZ
Customer Phone 1	Opt	UB	229-238	10	A/N	
Customer Phone 2	Opt	UB	239-248	10	A/N	
Mail Name 1	Opt	UB	249-274	26	A/N	
Mail Name 2	Opt	UB	275-300	26	A/N	
Mail Address 1	Opt	UB	301-326	26	A/N	
Mail Address House Number	Opt	UB	327-333	7	A/N	

¹Reserved for future use

Table 4.8 Alternate Premise Detail Record Format¹ (continued)

Column	Use	Source	Offset	Length	Туре	Comment
Mail Address HSuffix	Opt	UB	334-340	7	A/N	
Mail Address Unit	Opt	UB	341-355	15	A/N	
Mail Address Predir	Opt	UB	356-357	2	A/N	
Mail Address Street	Opt	UB	358-382	25	A/N	
Mail Address Suffix	Opt	UB	383-386	4	A/N	
Mail Address Postdir	Opt	UB	387-388	2	A/N	
Mail City	Opt	UB	389-414	26	A/N	
Mail State	Opt	UB	415-416	2	A/N	
Mail Zip	Opt	UB	417-427	11	A/N	ZZZZZ-ZZZZ
Mail Phone	Opt	UB	428-437	10	A/N	
Permit	Opt	UB	438	1	воо	Y/N
Premise Custom 1	Opt	UB	439-464	26	A/N	
Premise Custom 2	Opt	UB	465-490	26	A/N	
Utility Pass Through	Opt	UB	491-618	128	A/N	
Email Address	Opt	UB	619-668	50	A/N	
CRLF	Req	UB	699-670	2	A/N	

'Reserved for future use

Table 4.9 Premise Notes Record Formats - Optional

Column	Use	Source	Offset	Length	Туре	Comment
Record ID	Req	UB	1-5	5	A/N	'PRMNT'
Hazard Code	Opt	UB	6-9	4	A/N	
Changed Hazard Code	Opt	НН	10-13	4	A/N	Changed value coming back from field
Hazard Text	Opt	UB	14-39	26	A/N	Freeform hazard text
Changed Hazard Text	Opt	НН	40-65	26	A/N	
Special Instruction	Opt	UB	66-365	300	A/N	
Special Instruction 2	Opt	UB	366-665	300	A/N	
Changed Special Instruction	Opt	НН	666-965	300	A/N	
Changed Special Instruction 2	Opt	НН	966- 1,265	300	A/N	
Force Special Instruction	Req	UB	1,266	1	воо	'Y' or 'N'
Force Special Instruction 2	Req	UB	1,267	1	воо	'Y' or 'N'
Changed Force Special Instruction	Req	НН	1,268	1	воо	'Y' or 'N'
Changed Force Special Instruction 2	Req	НН	1,269	1	воо	'Y' or 'N'
CRLF	Req	UB	1,270- 1,271	2		

Table 4.10 Meter Detail Record Formats

Column	Use	Source	Offset	Length	Туре	Comment
Record ID	Req	UB	1-5	5	A/N	'MTRDT'
Read Sequence	Req	UB	6-11	6	NUM	Right-justify, zero-fill
Changed Read Sequence	Opt	НН	12-17	6	NUM	Changed value coming back from field.
Meter Key	Req	UB	18-37	20	NUM	Key to identify the meter within the premise_key. Use meter number for this unless the billing system has a better key.
Meter Number	Req	UB	38-57	20	NUM	
Changed Meter Number	Opt	нн	58-77	20	NUM	Actual meter number found in field.
Meter Type	Req	UB	78-81	4	A/N	
Changed Meter Type	Opt	НН	82-85	4	A/N	
Meter Size	Opt	UB	86-93	8	A/N	
Changed Meter Size	Opt	НН	94-101	8	A/N	
Meter Manufacturer	Opt	UB	102-104	3	A/N	Three-character code for the meter manufacturer.
Changed Meter Manufacturer	Opt	НН	105-107	3	A/N	
Meter UOM	Opt	UB	108-110	3	A/N	Unit Of Measure - for display purpose only. Example: CF = cubic feet.

Table 4.10 Meter Detail Record Formats (continued)

Column	Use	Source	Offset	Length	Туре	Comment
Changed Meter UOM	Opt	НН	111-113	3	A/N	
Meter Location	Opt	UB	114-117	4	A/N	
Changed Meter Location	Opt	НН	118-121	4	A/N	
Meter Location 2	Opt	UB	122-125	4	A/N	
Changed Meter Location 2	Opt	НН	126-129	4	A/N	
Read Instruction 1	Opt	UB	130-133	4	A/N	
Changed Read Instruction 1	Opt	НН	134-137	4	A/N	
Read Instruction 2	Opt	UB	138-141	4	A/N	
Changed Read Instruction 2	Opt	НН	142-145	4	A/N	
Seal Number	Opt	UB	146-155	10	A/N	
Changed Seal Number	Opt	НН	156-165	10	A/N	
Meter Install Date	Opt	UB	166-173	8	N	YYYYMMDD. Optional; from billing system.
Meter Custom 1	Opt	UB	174-199	26	A/N	
Meter Custom 2	Opt	UB	200-225	26	A/N	
Meter Condition Code 1	Opt	НН	226-229	4	A/N	
Meter Condition Code 2	Opt	НН	230-233	4	A/N	
Must Read Code	Opt	UB	234	1	воо	'Y' or 'N' Must read if 'Y'.

Table 4.10 Meter Detail Record Formats (continued)

Column	Use	Source	Offset	Length	Туре	Comment
Collector Error	Opt	НН	235-244	10	A/N	Values it contains will change based upon the collector type used.
Prev Read Date	Opt	UB	245-252	8	A/N	YYYYMMDD
Constant / Multiplier	Opt	UB	253-258	6	A/N	Data for electric meters.
Changed Constant / Multiplier	Opt	НН	259-264	6	A/N	
Xcoord	Opt	UB	265-276	12	A/N	Longitude
Ycoord	Opt	UB	277-288	12	A/N	Latitude
Xcoord2	Opt	UB	289-300	12	A/N	For future use
Ycoord2	Opt	UB	301-312	12	A/N	For future use
Xcoord3	Opt	UB	313-324	12	A/N	For future use
Ycoord3	Opt	UB	325-336	12	A/N	For future use
CRLF	Req	UB	337-338	2		

Table 4.11 Order Status Record Formats – Export file only

Column	Use	Source	Offset	Length	Туре	Comment
Record ID	Req	HS	1-5	5	A/N	'ORDST'
Completion Date	Req	НН	6-13	8	NUM	YYYYMMDD
Time Stamp	Req	НН	14-19	6	NUM	HHMMSS
Elapsed Time	Req	НН	20-24	5	NUM	Elapsed time in Seconds

Table 4.11 Order Status Record Formats – Export file only (continued)

Column	Use	Source	Offset	Length	Туре	Comment
Reader ID	Req	нн	25-44	20	A/N	
Order Status	Req	НН	45-46	2	A/N	IN - incomplete CO - complete SK - skipped
Skip Code	Req	НН	47-50	4	A/N	Only if order_status = 'SK'
Comment Code 1	Req	нн	51-54	4	A/N	
Comment Code 2	Req	НН	55-58	4	A/N	
Notes Back	Req	НН	59-186	128	A/N	
CRLF	Req	HS	187-188	2		

Table 4.12 Read Detail Record Formats

Column	Use	Source	Offset	Length	Туре	Comment
Record ID	Req	UB	1-5	5	A/N	'RDGDT'
Read Type	Req	UB	6-9	4	A/N	Details of a particular register, for example: • HIGH • LOW • KVAR • KW • KWH • WTR
Collection ID	Req	UB	10-22	13	A/N	Use 'spaces' if device provides no ID value.
For Future Use		UB	23-29	7	A/N	
Changed Collection ID	Opt	нн	30-49	20	A/N	

Table 4.12 Read Detail Record Formats (continued)

Column	Use	Source	Offset	Length	Туре	Comment
Dials	Req	UB	50-51	2	NUM	
Changed Dials	Opt	НН	52-453	2	NUM	
Decimals	Req	UB	54-55	2	NUM	
Changed Decimals	Opt	нн	56-57	2	NUM	
Read Direction	Opt	UB	58	1	A/N	R, L, C, or blank only
Hi Limit	Req	UB	59-68	10	NUM	
Low Limit	Req	UB	69-78	10	NUM	
Prev Read	Req	UB	79-88	10	NUM	
Reading	Req	НН	89-98	10	A/N	
Collector Reading	Req	НН	99-108	10	A/N	Actual reading that came from collector, before truncation
Read Code	Req	НН	109-110	2	A/N	
Re-entry Count	Req	НН	111-112	2	NUM	
Water No Flow 35 Days	Req	нн	113	1	NUM	Number of Days
Peak Backflow	Req	HH	114	1	NUM	Reverse Flow Event
Leak 35 Days	Req	НН	115	1	NUM	Number of Days
Current Leak	Req	НН	116	1	NUM	Leak Status
Previous Error Count	Opt	UB	117	1	NUM	R900 Electric or Gas tamper. Use '8' to suppress tamper check.

Table 4.12 Read Detail Record Formats (continued)

Column	Use	Source	Offset	Length	Туре	Comment
Current Error Count	Req	НН	118	1	NUM	Current error/tamper count for R900 Electric or Gas
Fatal Error	Req	НН	119	1	NUM	Fatal error flag for R900 Electric
Non-Fatal Error/Flags	Req	НН	120	1	NUM	Non-fatal error flag for R900 Electric or Gas
Voltage	Req	НН	121-123	3	NUM	Operating meter voltage for R900 Electric
MIU Type	Req	НН	124-125	2	NUM	Utility meter type
AMR Read Type	Req	НН	126-127	2	NUM	AMR reading type
High Power	Req	НН	128	1	NUM	High versus low power indicator for all R900s
R900 Format	Req	НН	129-130	2	NUM	The R900 reading format: 0 - Binary 1 - BCD 2 - "Data Stream" (not used) 3 - E-Coder 4 - Mlog
Display Digits	Req	НН	131	1	NUM	Number of digits in main reading display
Multiplier Applied	Req	НН	132	1	NUM	
Gas No Flow	Req	НН	133	1	NUM	Period for which there has been no gas flow
Current Gas Backflow Tamper	Req	нн	134	1	NUM	

Table 4.12 Read Detail Record Formats (continued)

Column	Use	Source	Offset	Length	Туре	Comment
Current Gas Removal Tamper	Req	НН	135	1	NUM	
Current Gas Magnetic Tamper	Req	НН	136	1	NUM	
ERT Inversion Tamper	Req	HH	137	1	NUM	
ERT Reverse Tamper	Req	нн	138	1	NUM	
35-Day Gas Backflow Tamper	Req	нн	139	1	NUM	
35-Day Gas Removal Tamper	Req	НН	140	1	NUM	
35-Day Gas Magnetic Tamper	Req	НН	141	1	NUM	
35-Day Program Flag	Req	НН	142	1	NUM	R900G only
Reed Switch Failure Flag	Req	нн	143	1	NUM	R900G only
Additional Flags	Req	НН	144-212	69		For future use
Register Manufacturer	Req	НН	213-237	25	A/N	
Register Install Date	Req	НН	238-245	8	NUM	YYYYMMDD
Register ID	Req	нн	246-255	10	A/N	
CRLF	Req	UB	256-257	2		

Table 4.13 ERT Detail Record Formats - Optional

Column	Use	Source	Offset	Length	Туре	Comment
Record ID	Req	UB	1-5	5	A/N	'ERTDT'
Tone	Req	UB	6-7	2	NUM	
Freq Channel	Req	UB	8-11	4	NUM	
Prev Tamper 1	Req	UB	12	1	A/N	Use '8' to suppress tamper check.
New Tamper 1	Req	нн	13	1	A/N	
Prev Tamper 2	Req	UB	14	1	A/N	Use '8' to suppress tamper check.
New Tamper 2	Req	НН	15	1	A/N	
ERT Type	Req	НН	16-17	2	A/N	
CRLF	Req	UB	18-19	2		

Table 4.14 Route Trailer Record Format

Column	Use	Source	Offset	Length	Туре	Comment
Record ID	Req	UB	1-5	5	A/N	'RTETR'
Office	Req	UB	6-9	4	A/N	
Cycle	Req	UB	10-13	4	A/N	
Route	Req	UB	14-23	10	A/N	
# Premises	Req	UB	24-29	6	A/N	One input field may be blank if total is unavailable.
# Meters	Req	UB	30-35	6	A/N	One input field may be blank if total is unavailable.
CRLF	Req	UB	36-37	2		

Table 4.15 Vehicle Detail Record Format – Export file only

Column	Use	Source	Offset	Length	Туре	Comment
Record ID	Req	HS	1-5	5	A/N	'VHLDT'
Reader ID	Req	НН	6-25	20	A/N	
Vehicle ID	Req	НН	26-45	20	A/N	
Date	Req	НН	46-55	10	NUM	YYYYMMDD
Start Time	Req	НН	56-59	4	NUM	ННММ
End Time	Req	НН	60-63	4	NUM	ННММ
Start Miles	Req	НН	64-73	10	A/N	
End Miles	Req	НН	74-83	10	NUM	
CRLF	Req	HS	84-85	2		

Table 4.16 Company Trailer Record Format - Optional

Column	Use	Source	Offset	Length	Туре	Comment
Record ID	Opt	UB	1-5	5	A/N	'COMTR'
Company Code	Req	UB	6-9	4	A/N	
# Routes	Req	UB	10-15	6	A/N	One input field may be blank if total is unavailable
CRLF	Req	UB	16-17	2		