Enclosure design for 3D Printing: A step-by-step gui

Written by John Wall

Learn how to optimize the design of your enclosure for 3D printing, follow a step by step guide on the design process and review the most common enclosure materials.

Table of contents

Introduction	
3D printed enclosure technologies	
Securing enclosure assemblies	
Designing 3D printed enclosures	
Rules of thumb	

Introduction

3D printing of enclosures allows design freedom, lets a designer print a prototype or final part in a matter of hours and is much cheaper when compared to traditional manufacturing methods. 3D printed enclosures offer an effective method of confirming form and fit and several of the materials that can be used for printing enclosures are suitable for end use applications.



This article will discuss the most common 3D printing technologies that are used to print enclosures, methods for securing printed

Assembled 3D printed enclosure for a DIY loudspeaker

enclosures together and introduce some design considerations to help optimize enclosure design for 3D printing.

The table below discuss the main 3D printing technologies and whether they are appropriate for a range of enclosure applications.

3D printed enclosure technologies

Application	Description	Printing Technology
Rapid prototyping	<u>Prototyping plastics</u> are a cost effective and quick method of printing enclosures.	FDM
High Temperature	Heat resistant plastics are rated to remain stable up to temperatures as high as 80°C after thermal post treatment.	Material jetting
High quality surface finish	The selection of surface finish is usually governed by cost and time. <u>SLS</u> <u>nylon</u> results in a satin-like matte finish that is slightly grainy to the touch while <u>material jetting</u> and <u>SLA</u> offer fine-detail models with very smooth surfaces.	SLA or material jetting
High accuracy	SLS nylon, SLA and material jetting printed parts are highly accurate and are capable of printing to within 0.2 - 0.5 mm. They give an excellent surface finish. SLS nylon does no require any support while the support used for material jetting is typically dissolvable and easy to remove resulting in an smooth surface after post processing.	SLA, SLS or material jetting
Transparent	3D printed <u>transparent plastics</u> allow for inspection or verification of internal components and are often applied to applications where fluids are being employed.	SLA or material jetting
Flexible material	Flexible enclosures allow the pressing of buttons or motion of switches through the sealed case.	Rubber-Like plastics or SLA flexible resin


wear-resistant. For quick prototypes adhesives are a quick and easy method to permanently fasten the enclosure.

Securing enclosure assemblies

Snap fits, interlocking joints, threaded fasteners and adhesives are all viable options for 3D printed enclosure connections. Designing

snap-fits and push-fits for an enclosure that does not require repeated opening is much easier because the joint does not have to be as





1. Enclosure planning and component measurement

2. Designing the structure

It can be useful to 3D model the internal enclosure components along with the enclosure to allow for easy clearance checks and to help determine the optimal component positions.

While tolerance and clearance recommendations will vary with printer technology and calibration the bullet points below offer a set of design guideline to use:

- · A minimum wall thickness of 2 mm. Reduce stress concentrations by including radii or fillets in corner and edges. Even a small radius can make a big difference.
- Subtract 0.25 mm from the diameter of holes if you are wanting the screw or fastener to bite into the case. Allow 2 mm clearance around ports (1mm each side).

Add 0.25 mm to the diameter of screw and fastener clearance holes.

 If your enclosure design is eventually going to be injection molded remember to use uniform wall thickness in you design. Add lugs and cut outs to assist with assembly/disassembly and alignment if the enclosure with multiple parts (base & lid).

Allow 0.5 mm around internal components to compensate for distortion, shrinkage and printer tolerances.

- While ribs and gussets are critical design features of injection molding and not essential for 3D printing their inclusion can help reduce and distribute stresses throughout the part and improve rigidity. To save on material ribs and gussets can be designed to 75-
- 80% of wall thickness. Include bosses around holes in locations where threaded fasteners will be used to reduce the likelihood of bulging, distortion and

- potential fracture. A minimum of 5mm wall thickness around the hole is a good starting point.
- Rules of thumb

If the enclosure will be subjected to loads include gussets, ribs and bosses to improve strength

· For enclosures that will experience repeated opening and closing a wear-resistant material such as sls nylon. For rapid prototypes where form or fit are being tested FDM provides a fast low cost method of production.

 A minimum wall thickness of 2mm, 0.5mm tolerance around internal components and ±0.25mm for clearance/bite holes are good start points to consider when designing a 3D printed enclosure.