

31	27	26	25	24	20	19	15	14	12	11	7	6	0	
funct7				rs2		rs1		funct3		rd		opcode		R-type
rs3		funct2		rs2		rs1		funct3		rd		opcode		R4-type
imm[11:0]						rs1		funct3		rd		opcode		I-type
imm[11:5]				rs2		rs1		funct3		imm[4:0]		opcode		S-type

RV32F Standard Extension							
imm[11:0]			rs1	010	rd	0000111	FLW
imm[11:5]		rs2	rs1	010	imm[4:0]	0100111	FSW
rs3	00	rs2	rs1	rm	rd	1000011	FMADD.S
rs3	00	rs2	rs1	rm	rd	1000111	FMSUB.S
rs3	00	rs2	rs1	rm	rd	1001011	FNMSUB.S
rs3	00	rs2	rs1	rm	rd	1001111	FNMADD.S
0000000		rs2	rs1	rm	rd	1010011	FADD.S
0000100		rs2	rs1	rm	rd	1010011	FSUB.S
0001000		rs2	rs1	rm	rd	1010011	FMUL.S
0001100		rs2	rs1	rm	rd	1010011	FDIV.S
0101100		00000	rs1	rm	rd	1010011	FSQRT.S
0010000		rs2	rs1	000	rd	1010011	FSGNJ.S
0010000		rs2	rs1	001	rd	1010011	FSGNJN.S
0010000		rs2	rs1	010	rd	1010011	FSGNJX.S
0010100		rs2	rs1	000	rd	1010011	FMIN.S
0010100		rs2	rs1	001	rd	1010011	FMAX.S
1100000		00000	rs1	rm	rd	1010011	FCVT.W.S
1100000		00001	rs1	rm	rd	1010011	FCVT.WU.S
1110000		00000	rs1	000	rd	1010011	FMV.X.W
1010000		rs2	rs1	010	rd	1010011	FEQ.S
1010000		rs2	rs1	001	rd	1010011	FLT.S
1010000		rs2	rs1	000	rd	1010011	FLE.S
1110000		00000	rs1	001	rd	1010011	FCLASS.S
1101000		00000	rs1	rm	rd	1010011	FCVT.S.W
1101000		00001	rs1	rm	rd	1010011	FCVT.S.WU
1111000		00000	rs1	000	rd	1010011	FMV.W.X

RV64F Standard Extension (in addition to RV32F)														
1100000			00010	rs1	rm	rd		1010011		FCVT.L.S				
1100000			00011	rs1	rm	rd		1010011		FCVT.LU.S				
1101000			00010	rs1	rm	rd		1010011		FCVT.S.L				
1101000			00011	rs1	rm	rd		1010011		FCVT.S.LU				