

Embodme

Erae 2



Setup

This document gives you a brief overview of the functions of the Embodme Erae 2 with Bitwig Studio. For a detailed explanation of all controller functions, please read the Erae 2 user guide provided by Embodme.

Firmware Update

Before you start using Erae 2 with Bitwig Studio, please make sure that you have the latest firmware installed (minimum required version: 2.0). Go to embodme.com to download and install *Erae Lab*. Connect your Erae 2 to your computer, start *Erae Lab* and update to the latest firmware.

Setup in Bitwig Studio

The Erae 2 should be detected and set up automatically in Bitwig Studio when it is connected. If you add the device manually, make sure the correct MIDI ports are selected in the correct order.

Mac/Linux:

In 1: Erae 2 MIDI
In 2: Erae 2 MIDI (MPE)
Out: Erae 2 MIDI

Windows:

In 1: Erae 2 MIDI
In 2: Erae 2 MIDI (MPE)
Out: Erae 2 MIDI

Synchronization

To synchronize the arpeggiator or looper of the Erae 2 to Bitwig Studio:

- On the Erae 2 open *Settings*, select *Clock Source* and set it to *USB-dev*
- In Bitwig Studio go to *Dashboard > Settings > Synchronization* and activate the following settings for the Erae 2 MIDI port:



Playing MPE Instruments

Erae 2 provides two different MIDI ports that send data from the device to Bitwig Studio: *Erae 2 MIDI* and *Erae 2 MIDI (MPE)*. If you want to play an MPE-enabled device or VST-instrument with Erae 2:

- Select *Erae 2 MIDI (MPE)* in the input source drop-down menu of the track that contains the MPE instrument
- Make sure that the MIDI channel setting of the track is set to *ALL*

Controlling the Clip Launcher

Erae 2 can be used to control the Clip Launcher in Bitwig Studio. Open EraeLab on your computer and drag the *LivePad* element onto an empty layout. The whole surface of the Erae 2 will become a Clip Launcher control surface, allowing you to control the following functions:

- Trigger clips and scenes
- Change the volume of tracks
- Change the FX Send 1 and 2 levels
- Toggle Mute, Solo and Record Enable
- Stop all currently playing clips
- Toggle between three different layouts by pressing the Arpeggiator button
- Toggle between a small and large track layout by pressing the +/- octave button