FAQ's FOR CUSTOMERS, DOs and DONTs and Preventive Maintenance.

1. **How would I know if there is a leak in the battery?**
   There is a different rusting pattern for a battery electrolyte spill and a different rusting pattern for a water spill. It will take an expert to gauge the kind of leak and spot the reasons for it. Hence we advise you to kindly contact the nearest Maruti Suzuki dealer or Maruti Suzuki service station and follow their advice. There are plenty of authorized dealers of new and Maruti Suzuki second hand cars throughout India.

2. **Drops of water come out of the exhaust pipe. Is it OK or abnormal?**
   There is a different rusting pattern for a battery electrolyte spill and a different rusting pattern for a water spill. It will take an expert to gauge the kind of leak and spot the reasons for it. Hence, we advise you to kindly contact the nearest Maruti Suzuki dealer or Maruti Suzuki service station and follow their advice.

3. **When should I get the engine overhaul done?**
   The engine overhauling depends on the health of the engine, be it a petrol or diesel car. You may need an engine overhaul when you see one or more of the following indications-

- Excessive engine oil consumption.
- Engine bearing noise.
- Piston slap noise.
- Piston slap noise.
- Excessive fuel consumption.

   Except engine oil consumption, other parameters given above are difficult to monitor by the customers and it is best you consult the service manager at the Maruti Suzuki service station. There are other parameters to be checked too, such as engine compression pressure, engine vacuum etc. But most of the time, engine oil consumption provides a very good reference to the health of the engine. Once you have problem with that, do not delay sending your car, whether it is a petrol or diesel car, for assessment and appropriate service. It is best to contact one of our dealers to get the vehicle checked for engine health. You have to mention the amount of topping up required over a distance of 5000 kms or 10,000 kms for them to judge the extent of tests they should carry out.

4. **What should I do when the car overheats?**

   If the High Engine Coolant Temperature Warning Light (if equipped) on instrument panel comes ON or the Temperature Gauge needle (if equipped) on instrument panel reaches near "H" mark then:

   Turn off the air conditioner, if equipped.

   Take the vehicle to a safe place and park.

   Let the engine run at normal idle speed for a few minutes until the high engine coolant temperature light goes OFF (OR).

   The indicator returns to the normal range, between the H and the C mark.

If you see or hear steam escaping from under the bonnet, immediately park the vehicle in a safe place and switch off the engine immediately. Do not open the bonnet until hissing sound or steam emission has stopped. Get in touch with nearest Maruti Suzuki service centre immediately.

Once the steam is no longer heard or visible, open the bonnet and check the water pump belt for any slippage or damage.

Check the coolant level in the reservoir. If it is below the low mark, check for leakage from the hose, water pump or radiator. If any leaks are located, do not start the engine till the time the leakage has been rectified.

If you do not find any leakage then slowly add coolant to the reservoir. Never add coolant to the radiator.

It is dangerous to remove the radiator cap when the temperature is high. It may cause serious burn injuries.

Consult your authorised service workshop for further advice.

5. **When do I need to get wheel balancing done?**
   For Indian road conditions, wheel balancing becomes necessary whenever the wheel suffers a puncture and as per the mileage recommended in the periodic maintenance schedule in the Owners' Type.

Daily Do's

- Maruti Suzuki's Daily Do's Before starting your vehicle, just briefly walk around to visually check:
- Tyre pressure and condition:
- Any oil leaks:
- Any coolant leaks:
- Wiper blade condition:
- Body scratches deep enough to cause rust:
- Rear view mirror condition:
- Top wash:
- Remove any leaves, dirt, etc.

Daily Don’t

- While doing the inspection, please ensure the following:
- Do not touch or open radiator cap when engine is hot.
- Do not fit non-genuine accessories that may affect performance.
- Do not use non genuine spares. Use only maruti's genuine parts.
- Do not park in sun for too long. Park under shade.
- Start vehicle periodically if parked /unused for long.
- Do not keep your engine idle.

Preventive Maintenance

1. When should the air filter be replaced?

Road Condition	Variant	Preventive Maintenance
Paved-road	Petrol	Clean after every 5,000 km and replace after every 40,000 km.
	Diesel	Replace after every 20,000 km as cleaning is not required.
Dusty	Petrol	Clean after every 5,000 km and replace after every 40,000 km.
	Diesel	Replace after every 20,000 km as cleaning is not required.

2. In what frequency should the fuel filter be changed?

The fuel filter should be changed at intervals of 20000 kms for carburettor vehicles. In case of MPFI vehicles, the interval is 40000 kms. However, if quality of fuel has been poor, it is recommended that you change the filter at earlier intervals as prescribed by the service manager of the Maruti Suzuki service station. You will find plenty of Maruti Suzuki service centres across India.

3. How important is preventive maintenance? Where can I get it done?

In your owner's Type, you will find "Periodic Maintenance Schedule" under the "Inspection and maintenance" section. This will guide you on how often you must send your car to a Maruti Suzuki service centre for check up and maintenance service. If you have bought a second hand car, you will have to do the maintenance check on a more frequent basis. Doing so will not only prolong the life of your vehicle, but will also reduce maintenance costs. The car will be trouble free and completely safe for use. We urge you to carry out your car maintenance services only at a Maruti Suzuki service station.

4. Do I need to strictly follow the schedule in the owner's handbook?

Yes, it is imperative that you follow the regular periodic maintenance schedule as listed in the owner's Type, especially if you have bought a used car. This will ensure trouble free operation of the vehicle and enhance the life of the engine. In addition, this is a pre requisite for any warranty claims to be processed, should any part fail within the warranty period.

5. How do I know if gas is less than normal in the AC system?

If cooling efficiency of the AC is less than satisfactory, do check for gas leakage. There are various methods to check whether the quantity of gas is adequate. However, it is best that you rely on the AC maintenance experts at your nearest Maruti Suzuki service station to do the checking. They will have the right instruments and expertise to assess if gas in the AC system of your vehicle is below norms. Get your car’s AC serviced every year and do it around Feb - March so that you may enjoy best cooling during summer. Gas checking and topping is part of the service.

6. In the AC system, what are the functions of coil, condenser, and blower?

The cooling coil performs the function of evaporation of the refrigerant inside the coil. The air blows over these coils and emerges cooled. The condenser does the reverse work of the cooling unit, i.e. the condensation of the refrigerant and its cooling. The blower works like a fan by drawing in the air and circulating it inside the cabin.

7. Which parts /joints are the main sources of gas leakage?

The AC gas in cars reduces over time due to various factors like- leakage from the joints, o-rings etc., if they were not properly tightened during service. Leakage from the hose rubber may happen due to the natural permeability of the hose. However, this is extremely slow and is very difficult to detect, even with sophisticated equipment. The AC gas may need to be refilled during servicing of the AC, if it is found that the AC system is undercharged.

Fuel Efficiency

Better driving habits for fuel saving

- Drive between 45-55 km/h
- Drive slow and steady. The faster you go, the more the wind resistance your vehicle will face. It has been established by trials that you can get upto 40% extra mileage at 40 km/h as compared to 80 km/h.
- Avoid accelerating or decelerating unnecessarily.

Always drive in the correct gear

- Incorrect gear shifting can lead to as much as 20% increase in fuel consumption.
- Remember : For city driving, change to a higher gear when you are sure that the engine will not have to struggle.
- Get into top gear as soon as possible.

While braking, anticipate stops

- Stop-and-go driving wastes fuel. When you slam on the brakes, a lot of useful energy is wasted in the form of heat.
- Proper synchronization of gear and accelerator is necessary for better mileage.
- Remember: check wheels for free rotation when your car is being serviced. Binding brakes restrict free wheel movement and the engine consumes more petrol in order to overcome resistance.

Keep your foot off the clutch

- Use your clutch only when you change gears. Riding the clutch causes loss of energy and damages clutch lining.
- Remember: Use your hand brakes when stopping on up gradient. Don't manipulate the clutch and accelerator while stationary because it wastes fuel, even if the car you are driving is the most fuel efficient petrol car in India.

Periodic servicing

Servicing of your vehicle must be carried out as specified in user's Type.

Use the recommended spares & lubricants

- Always use recommended spares and lubricants.
- Engine oil that is thicker than recommended can cause a 2% increase in fuel consumption. If you have bought a second hand car, be extra careful.
- Remember: Check the car Type and the oil manufacturer's recommendations, before using any particular grade of oil.

Clean your air filter regularly

- Your air filter prevents air from fouling the engine. Dust causes rapid wear of engine components and increases fuel consumption.
- Remember: Cylinder bores and piston rings wear out faster in engines with dirty air cleaners.
- Clean air filters at every tune up for both petrol cars and diesel cars.

Do not allow leakage or spillage

- Loss of one drop of petrol per second can amount to loss of 2000 litres per year.
- Make sure that the fuel tank cap has a good rubber seal.

Do not wait for your car to warm up

- Instead, drive in low gear till the engine warms up.

Reduce loads

- Unnecessary loads increase fuel consumption.
- Remember: A reduction of weight by about 50 kg can lead to a 2% saving in fuel, when driving in city.

Check your tyre pressure regularly

- Under inflated tyres increase rolling resistance, leading to higher petrol consumption and faster wear out of tyres at sides.
- Remember: A 25% decrease in tyre pressure can cost you 5 -10% more on petrol and 25% on tyre life.

When you stop your car, stop your engine

- Idling for an hour costs one litre of petrol - Always keep your car ready for starting quickly. Keep the battery, alternator and fan belt in good condition. This will ensure a good start whenever you need it.
- Remember: Switch off the engine at stops of over 2 minutes.

Plan your route

- Fuel consumption on a highly congested road can be double the normal.
- Rush hour or stop-and-go traffic can waste fuel excessively.
- Remember: You will get more mileage from each litre if you take a less congested route.

Tips for Road Trips

Driving during fog

- Start little early. This can help avoid delays due to fog.
- Be patient and calm. Familiarize yourself with the vehicle. Know the position of all switches before you start driving.
- Drive at low speeds and watch your speedometer. Maintain safe distance from other vehicles. Maintain greater distance between your vehicle and the vehicle ahead. Do not accelerate to get away from a vehicle that is too close behind you.
- Drive with lights on low beam. High beams direct light up into the fog, making it difficult for you to see.
- Dipped headlights direct light down onto the road and help other drivers see you. Use fog lights.
- Listen for traffic you cannot see. Beware of other cars, and drivers not using headlights. Open your window a little, to hear better.
- Use wipers and demisters necessary for maximum visibility. Use painted road markings as a guide. If your car breaks down, park your car on the farthest corner of the road. Switch on your hazard warning lights. Place a reflective warning triangle at a safe distance. Watch out for traffic that might not be able to spot you.

Driving on hills

- When driving down a hill, do not switch off the engine. Shift to a lower gear for reducing speed and by shifting to lower gear you will save fuel.
- When climbing steep hills, the car may begin to slow down and show a lack of power. If this happens, you should change to a lower gear so that the engine will again be operating in its normal power range.

More Mileage, More Fun

- Drive between 45 and 55 km/h.
- It has been established by trials that you can get up to 40% extra mileage at 40 km/h as compared to 80 km/h.
- Avoid accelerating or decelerating unnecessarily.
  Incorrect gearshifts can lead to as much as 20% increase in fuel consumption. It does not matter whether it is a petrol or diesel car.
- For city driving, change to a higher gear when you are sure that the engine will not have to struggle.
- Get into top gear as soon as possible.
- Check wheels for free rotation when your car is being serviced. Binding brakes restrict free wheel movement and the engine consumes more petrol in order to overcome resistance. The law applies even if you compare petrol cars vs diesel cars.
- Riding the clutch causes loss of energy and damages the clutch lining.

- You can save as much as 6% fuel by regularly tuning your car. If your engine emits black or dark grey smoke, it has poor pulling power or consumes large quantities of oil. Have it checked immediately at an authorized service station.
- Your air filter prevents air from fouling the engine. Dust causes rapid wear of engine components and increases fuel consumption.
- Make sure that the fuel tank cap has a good rubber seal.
- Unnecessary loads increase fuel consumption. A reduction of weight by about 50 kg can lead to a 2% saving in fuel, when driving in the city. Lighten your load even if your car is claimed to be the most fuel efficient petrol car in India.
- Under inflated tyres increase rolling resistance, this leads to higher fuel consumption faster wears of tyres at the sides, whether it is a petrol or diesel car.

High Speed watch-outs

- Stopping distance progressively increases with vehicle speed. Apply the brakes far before of the stopping point to allow for the extra stopping distance.
- At high speeds, the vehicle may be affected by side winds. Therefore, reduce speed and be prepared for unexpected buffeting, which can occur at the exits of tunnels, when passing by a cut of a hill, or when being overtaken by large vehicles etc.

Better Maintenance, Long Drives

- Do all preventive maintenance of your vehicle and stick to the maintenance schedule.
- If you notice any fault, consult your service station.
- All drivers must carry out daily pre-driving checks both inside the vehicle and outside.

ग्राहकांसाठी वारंवार विचारले जाणारे प्रश्न, काय करावे आणि काय करू नये आणि प्रतिबंधात्मक देखभाल.

1. **बॅटरीमध्ये गळती झाली आहे हे मला कसे कळेल?**
   बॅटरी इलेक्ट्रोलाइट गळतीसाठी गंजण्याचा पॅटर्न वेगळा असतो आणि पाणी गळतीसाठी गंजण्याचा पॅटर्न वेगळा असतो. गळतीचा प्रकार मोजण्यासाठी आणि त्याची कारणे शोधण्यासाठी तज्ञांची आवश्यकता असेल. म्हणून आम्ही तुम्हाला जवळच्या मारुती सुझुकी डीलर किंवा मारुती सुझुकी सर्व्हिस स्टेशनशी संपर्क साधण्याचा आणि त्यांच्या सल्ल्याचे पालन करण्याचा सल्ला देतो. संपूर्ण भारतात नवीन आणि मारुती सुझुकी सेकंड हँड कारचे बरेच अधिकृत डीलर आहेत.

2. **एक्झॉस्ट पाईपमधून पाण्याचे थेंब बाहेर पडतात. ते ठीक आहे की असामान्य?**
   बॅटरी इलेक्ट्रोलाइट गळतीसाठी गंजण्याचा पॅटर्न वेगळा असतो आणि पाणी गळतीसाठी गंजण्याचा पॅटर्न वेगळा असतो. गळतीचा प्रकार मोजण्यासाठी आणि त्याची कारणे शोधण्यासाठी तज्ञाची आवश्यकता असेल. म्हणून, आम्ही तुम्हाला जवळच्या मारुती सुझूकी डीलर किंवा मारुती सुझूकी सर्व्हिस स्टेशनशी संपर्क साधण्याचा आणि त्यांच्या सल्ल्याचे पालन करण्याचा सल्ला देतो.

3. **मी इंजिनची दुरुस्ती कधी करावी?**
   इंजिन ओव्हरहॉलिंग हे इंजिनच्या आरोग्यावर अवलंबून असते, मग ते पेट्रोल असो वा डिझेल कार. जेव्हा तुम्हाला खालीलपैकी एक किंवा अधिक संकेत दिसतात तेव्हा तुम्हाला इंजिन ओव्हरहॉलची आवश्यकता असू शकते-

- जास्त इंजिन तेलाचा वापर.
- इंजिन बेअरिंगचा आवाज.
- पिस्टनच्या थप्पडाचा आवाज.
- पिस्टनच्या थप्पडाचा आवाज.
- जास्त इंधन वापर.

   इंजिन ऑइलचा वापर वगळता, वर दिलेले इतर पॅरामीटर्स ग्राहकांसाठी निरीक्षण करणे कठीण आहे आणि तुम्ही मारुती सुझुकी सर्व्हिस स्टेशनवरील सर्व्हिस मॅनेजरचा सल्ला घेणे चांगले. इंजिन कॉम्प्रेशन प्रेशर, इंजिन व्हॅक्यूम इत्यादी इतर पॅरामीटर्स देखील तपासायचे आहेत. परंतु बहुतेक वेळा, इंजिन ऑइलचा वापर इंजिनच्या आरोग्याचा एक चांगला संदर्भ देतो. एकदा तुम्हाला त्यात समस्या आली की, तुमची कार, ती पेट्रोल किंवा डिझेल कार असो, मूल्यांकन आणि योग्य सेवेसाठी पाठवण्यास उशीर करू नका. इंजिनच्या आरोग्याची तपासणी करण्यासाठी आमच्या डीलरपैकी एकाशी संपर्क साधणे चांगले. त्यांनी किती चाचण्या कराव्यात हे ठरवण्यासाठी तुम्हाला ५००० किमी किंवा १०,००० किमी अंतरावर किती टॉपिंग अप करावे लागेल ते नमूद करावे लागेल.

4. **गाडी जास्त गरम झाल्यावर मी काय करावे?**

   जर इन्स्ट्रुमेंट पॅनलवरील उच्च इंजिन कूलंट तापमान चेतावणी दिवा (जर सुसज्ज असेल) चालू झाला किंवा इन्स्ट्रुमेंट पॅनलवरील तापमान गेज सुई (जर सुसज्ज असेल) "H" चिन्हाजवळ पोहोचली तर:

   जर एअर कंडिशनर सुसज्ज असेल तर ते बंद करा.

   गाडी सुरक्षित ठिकाणी घेऊन जा आणि पार्क करा.

   उच्च इंजिन शीतलक तापमानाचा दिवा बंद होईपर्यंत (OR) काही मिनिटे इंजिनला सामान्य निष्क्रिय गतीने चालू द्या.

   निर्देशक H आणि C चिन्हाच्या दरम्यान सामान्य श्रेणीत परत येतो.

जर तुम्हाला बोनेटच्या खालून वाफ बाहेर पडताना दिसली किंवा ऐकू आली तर ताबडतोब गाडी सुरक्षित ठिकाणी पार्क करा आणि ताबडतोब इंजिन बंद करा. फुसफुसणारा आवाज किंवा वाफेचे उत्सर्जन थांबेपर्यंत बोनेट उघडू नका. जवळच्या मारुती सुझुकी सेवा केंद्राशी त्वरित संपर्क साधा.

एकदा वाफ ऐकू आली नाही किंवा दिसत नाही, तर बोनेट उघडा आणि पाण्याच्या पंपाचा पट्टा घसरला आहे की नाही किंवा नुकसान झाले आहे का ते तपासा.

जलाशयातील शीतलक पातळी तपासा. जर ती कमी पातळीपेक्षा कमी असेल तर नळी, पाण्याचा पंप किंवा रेडिएटरमधून गळती तपासा. जर काही गळती आढळली तर, गळती दुरुस्त होईपर्यंत इंजिन सुरू करू नका.

जर तुम्हाला गळती आढळली नाही तर हळूहळू जलाशयात शीतलक घाला. रेडिएटरमध्ये कधीही शीतलक घालू नका.

तापमान जास्त असताना रेडिएटर कॅप काढणे धोकादायक असते. त्यामुळे गंभीर भाजण्याच्या जखमा होऊ शकतात.

अधिक सल्ल्यासाठी तुमच्या अधिकृत सेवा कार्यशाळेचा सल्ला घ्या.

5. **मला चाकांचे संतुलन कधी करावे लागेल?**
भारतीय रस्त्यांच्या परिस्थितीसाठी, जेव्हा जेव्हा चाक पंक्चर होते तेव्हा आणि मालकांच्या प्रकारातील नियतकालिक देखभाल वेळापत्रकात शिफारस केलेल्या मायलेजनुसार चाकांचे संतुलन आवश्यक होते.

रोजच्या करावयाच्या गोष्टी

- मारुती सुझुकीच्या दैनंदिन करावयाच्या गोष्टी तुमचे वाहन सुरू करण्यापूर्वी, थोडेसे फिरून पहा आणि दृश्यमानपणे तपासा:
- टायरचा दाब आणि स्थिती:
- कोणतेही तेल गळती:
- कोणत्याही शीतलक गळती:
- वायपर ब्लेडची स्थिती:
- शरीरावर गंज येण्याइतके खोलवर ओरखडे:
- मागील दृश्य आरशाची स्थिती:
- वरचे धुणे:
- पाने, घाण इत्यादी काढून टाका.

दैनिक करू नका

- तपासणी करताना, कृपया खालील गोष्टींची खात्री करा:
- इंजिन गरम असताना रेडिएटर कॅपला स्पर्श करू नका किंवा उघडू नका.
- कामगिरीवर परिणाम करू शकतील अशा अस्सल नसलेल्या ॲक्सेसरीज बसवू नका.
- खऱ्या नसलेल्या सुटे भागांचा वापर करू नका. फक्त मारुतीचेच खरे सुटे भाग वापरा.
- जास्त वेळ उन्हात गाडी पार्क करू नका. सावलीत गाडी पार्क करा.
- जर वाहन बराच काळ पार्क केलेले/वापरलेले नसेल तर वेळोवेळी सुरू करा.
- तुमचे इंजिन निष्क्रिय ठेवू नका.

प्रतिबंधात्मक देखभाल

1. एअर फिल्टर कधी बदलावा?

रस्त्याची स्थिती	प्रकार	प्रतिबंधात्मक देखभाल
पक्के रस्ते	पेट्रोल	दर ५,००० किमी नंतर स्वच्छ करा आणि दर ४०,००० किमी नंतर बदला.
	डिझेल	साफसफाईची आवश्यकता नसल्यामुळे दर २०,००० किमी नंतर बदला.
धुळीने माखलेला	पेट्रोल	दर ५,००० किमी नंतर स्वच्छ करा आणि दर ४०,००० किमी नंतर बदला.
	डिझेल	साफसफाईची आवश्यकता नसल्यामुळे दर २०,००० किमी नंतर बदला.

2. इंधन फिल्टर किती वारंवारतेने बदलावे?

कार्बोरेटर वाहनांसाठी इंधन फिल्टर २०००० किमीच्या अंतराने बदलले पाहिजे. एमपीएफआय वाहनांच्या बाबतीत, हा अंतराल ४०००० किमी आहे. तथापि, जर इंधनाची गुणवत्ता खराब असेल, तर मारुती सुझुकी सर्व्हिस स्टेशनच्या सर्व्हिस मॅनेजरने सांगितल्याप्रमाणे आधीच्या अंतराने फिल्टर बदलण्याची शिफारस केली जाते. तुम्हाला संपूर्ण भारतात भरपूर मारुती सुझुकी सर्व्हिस सेंटर सापडतील.

3. प्रतिबंधात्मक देखभाल किती महत्त्वाची आहे? मी ते कुठे करू शकतो?

तुमच्या मालकाच्या प्रकारात, "तपासणी आणि देखभाल" विभागाखाली तुम्हाला "नियतकालिक देखभाल वेळापत्रक" मिळेल. हे तुम्हाला तुमची कार किती वेळा मारुती सुझुकी सेवा केंद्रात तपासणी आणि देखभाल सेवेसाठी पाठवावी हे मार्गदर्शन करेल. जर तुम्ही सेकंड हँड कार खरेदी केली असेल, तर तुम्हाला देखभाल तपासणी अधिक वारंवार करावी लागेल. असे केल्याने तुमच्या वाहनाचे आयुष्य वाढेलच, परंतु देखभाल खर्चही कमी होईल. कार त्रासमुक्त आणि वापरासाठी पूर्णपणे सुरक्षित असेल. आम्ही तुम्हाला तुमच्या कार देखभाल सेवा फक्त मारुती सुझुकी सेवा केंद्रावरच करण्याचा आग्रह करतो.

4. मालकाच्या हँडबुकमधील वेळापत्रक मला काटेकोरपणे पाळावे लागेल का?

हो, मालकाच्या प्रकारात सूचीबद्ध केलेल्या नियमित नियतकालिक देखभाल वेळापत्रकाचे पालन करणे अत्यावश्यक आहे, विशेषतः जर तुम्ही वापरलेली कार खरेदी केली असेल. यामुळे वाहनाचे त्रासमुक्त ऑपरेशन सुनिश्चित होईल आणि इंजिनचे आयुष्य वाढेल. याव्यतिरिक्त, वॉरंटी कालावधीत कोणताही भाग निकामी झाल्यास, कोणत्याही वॉरंटी दाव्यांवर प्रक्रिया करण्यासाठी ही एक पूर्व आवश्यकता आहे.

5. एसी सिस्टीममध्ये गॅस सामान्यपेक्षा कमी आहे हे मला कसे कळेल?

जर एसीची कूलिंग कार्यक्षमता समाधानकारक पेक्षा कमी असेल तर गॅस गळती तपासा. गॅसचे प्रमाण पुरेसे आहे की नाही हे तपासण्यासाठी विविध पद्धती आहेत. तथापि, तपासणी करण्यासाठी तुमच्या जवळच्या मारुती सुझुकी सर्व्हिस स्टेशनवरील एसी देखभाल तज्ञांवर अवलंबून राहणे चांगले. तुमच्या वाहनाच्या एसी सिस्टममध्ये गॅस मानकांपेक्षा कमी आहे की नाही हे तपासण्यासाठी त्यांच्याकडे योग्य उपकरणे आणि कौशल्य असेल. दरवर्षी तुमच्या कारच्या एसीची सर्व्हिसिंग करा आणि फेब्रुवारी-मार्चच्या सुमारास ते करा जेणेकरून तुम्हाला उन्हाळ्यात सर्वोत्तम कूलिंगचा आनंद घेता येईल. गॅस तपासणी आणि टॉपिंग ही सेवेचा एक भाग आहे.

6. एसी सिस्टीममध्ये, कॉइल, कंडेन्सर आणि ब्लोअरची कार्ये काय आहेत?

कूलिंग कॉइल कॉइलच्या आत रेफ्रिजरंटचे बाष्पीभवन करण्याचे काम करते. या कॉइल्सवरून हवा वाहते आणि थंड होते. कंडेन्सर कूलिंग युनिटचे उलट काम करतो, म्हणजेच रेफ्रिजरंटचे कंडेन्सेशन आणि त्याचे कूलिंग. ब्लोअर हवेत ओढून आणि केबिनच्या आत फिरवून पंख्यासारखे काम करतो.

7. कोणते भाग/सांधे वायू गळतीचे मुख्य स्रोत आहेत?

कारमधील एसी गॅस कालांतराने कमी होतो कारण जॉइंट्समधून गळती, ओ-रिंग्ज इत्यादी विविध कारणांमुळे, जर सर्व्हिसिंग दरम्यान ते योग्यरित्या घट्ट केले गेले नाहीत. होज रबरमधून गळती होजच्या नैसर्गिक पारगम्यतेमुळे होऊ शकते. तथापि, हे अत्यंत मंद आहे आणि अत्याधुनिक उपकरणांसह देखील ते शोधणे खूप कठीण आहे. जर एसी सिस्टम कमी चार्ज असल्याचे आढळले तर एसीच्या सर्व्हिसिंग दरम्यान एसी गॅस पुन्हा भरावा लागू शकतो.

इंधन कार्यक्षमता

इंधन बचतीसाठी चांगल्या ड्रायव्हिंग सवयी

- ४५-५५ किमी/ताशी वेगाने गाडी चालवा
- हळू आणि स्थिरपणे गाडी चालवा. तुम्ही जितक्या वेगाने जाल तितके तुमच्या वाहनाला वाऱ्याच्या प्रतिकाराचा सामना करावा लागेल. चाचण्यांद्वारे हे सिद्ध झाले आहे की तुम्ही ८० किमी/ताशीच्या तुलनेत ४० किमी/ताशी वेगाने ४०% पर्यंत अतिरिक्त मायलेज मिळवू शकता.
- अनावश्यकपणे वेग वाढवणे किंवा कमी करणे टाळा.

नेहमी योग्य गियरमध्ये गाडी चालवा

- चुकीच्या पद्धतीने गियर बदलल्याने इंधनाचा वापर २०% पर्यंत वाढू शकतो.
- लक्षात ठेवा: शहरी ड्रायव्हिंगसाठी, इंजिनला त्रास होणार नाही याची खात्री झाल्यावर जास्त गियरवर बदला.
- शक्य तितक्या लवकर टॉप गियरमध्ये जा.

ब्रेक लावताना, थांबण्याचा अंदाज घ्या

- थांबा-थांबून गाडी चालवल्याने इंधन वाया जाते. जेव्हा तुम्ही ब्रेक दाबता तेव्हा उष्णतेच्या स्वरूपात बरीच उपयुक्त ऊर्जा वाया जाते.
- चांगल्या मायलेजसाठी गीअर आणि ॲक्सिलरेटरचे योग्य सिंक्रोनाइझेशन आवश्यक आहे.
- लक्षात ठेवा: तुमच्या गाडीची सर्व्हिसिंग सुरू असताना चाके मोकळी फिरत आहेत का ते तपासा. बाइंडिंग ब्रेकमुळे चाकांची मोकळी हालचाल मर्यादित होते आणि इंजिन प्रतिकारावर मात करण्यासाठी जास्त पेट्रोल वापरते.

तुमचा पाय क्लचपासून दूर ठेवा.

- गिअर्स बदलतानाच क्लच वापरा. क्लच चालवल्याने ऊर्जा कमी होते आणि क्लचच्या अस्तराचे नुकसान होते.
- लक्षात ठेवा: अप ग्रेडियंटवर थांबताना हँडब्रेक वापरा. तुम्ही चालवत असलेली कार भारतातील सर्वात इंधन कार्यक्षम पेट्रोल कार असली तरीही, स्थिर असताना क्लच आणि ॲक्सिलरेटरमध्ये फेरफार करू नका कारण त्यामुळे इंधन वाया जाते.

नियतकालिक सर्व्हिसिंग

तुमच्या वाहनाची सर्व्हिसिंग वापरकर्त्याच्या प्रकारात नमूद केल्याप्रमाणे केली पाहिजे.

शिफारस केलेले सुटे भाग आणि स्नेहक वापरा

- नेहमी शिफारस केलेले स्पेअर्स आणि ल्युब्रिकंट वापरा.
- शिफारस केलेल्यापेक्षा जास्त जाड इंजिन ऑइलमुळे इंधनाचा वापर २% वाढू शकतो. जर तुम्ही सेकंड हँड कार घेतली असेल तर जास्त काळजी घ्या.

- लक्षात ठेवा: कोणत्याही विशिष्ट दर्जाचे तेल वापरण्यापूर्वी, कारचा प्रकार आणि तेल उत्पादकाच्या शिफारशी तपासा.

तुमचा एअर फिल्टर नियमितपणे स्वच्छ करा

- तुमचे एअर फिल्टर इंजिनमध्ये हवा खराब होण्यापासून रोखते. धुळीमुळे इंजिनचे घटक जलद झीज होतात आणि इंधनाचा वापर वाढतो.
- लक्षात ठेवा: गलिच्छ एअर क्लीनर असलेल्या इंजिनमध्ये सिलेंडर बोअर आणि पिस्टन रिंग्ज लवकर खराब होतात.
- पेट्रोल आणि डिझेल दोन्ही कारसाठी प्रत्येक ट्यून अपवर एअर फिल्टर स्वच्छ करा.

गळती किंवा गळती होऊ देऊ नका

- दर सेकंदाला एक थेंब पेट्रोल वाया गेल्यास दरवर्षी २००० लिटर पेट्रोल वाया जाऊ शकते.
- इंधन टाकीच्या टोपीला चांगला रबर सील असल्याची खात्री करा.

तुमची गाडी गरम होण्याची वाट पाहू नका.

- त्याऐवजी, इंजिन गरम होईपर्यंत कमी गियरमध्ये गाडी चालवा.

भार कमी करा

- अनावश्यक भारांमुळे इंधनाचा वापर वाढतो.
- लक्षात ठेवा: शहरात गाडी चालवताना सुमारे ५० किलो वजन कमी केल्याने इंधनात २% बचत होऊ शकते.

तुमच्या टायरचा दाब नियमितपणे तपासा.

- फुगवलेल्या टायर्समुळे रोलिंग रेझिस्टन्स वाढतो, ज्यामुळे पेट्रोलचा वापर जास्त होतो आणि बाजूचे टायर जलद खराब होतात.
- लक्षात ठेवा: टायर प्रेशरमध्ये २५% घट झाल्यास पेट्रोलवर ५-१०% जास्त आणि टायरच्या आयुष्यावर २५% जास्त खर्च येऊ शकतो.

जेव्हा तुम्ही तुमची गाडी थांबवता तेव्हा तुमचे इंजिन थांबवा.

- तासभर निष्क्रिय राहिल्याने एक लिटर पेट्रोल खर्च होते - तुमची गाडी नेहमी लवकर सुरू होण्यासाठी तयार ठेवा. बॅटरी, अल्टरनेटर आणि फॅन बेल्ट चांगल्या स्थितीत ठेवा. यामुळे तुम्हाला गरज पडल्यास चांगली सुरुवात होईल.
- लक्षात ठेवा: २ मिनिटांपेक्षा जास्त थांबल्यावर इंजिन बंद करा.

तुमचा मार्ग आखा

- जास्त गर्दी असलेल्या रस्त्यावर इंधनाचा वापर सामान्यपेक्षा दुप्पट असू शकतो.
- गर्दीच्या वेळी किंवा थांबे-थांबे वाहतूक यामुळे इंधनाचा अतिरेकी अपव्यय होऊ शकतो.

- लक्षात ठेवा: जर तुम्ही कमी गर्दीचा मार्ग निवडलात तर तुम्हाला प्रत्येक लिटरमधून जास्त मायलेज मिळेल.

रोड ट्रिपसाठी टिप्स

धुक्यात गाडी चालवणे

- थोडे लवकर सुरुवात करा. यामुळे धुक्यामुळे होणारा विलंब टाळता येईल.
- धीर धरा आणि शांत रहा. वाहनाची ओळख करून घ्या. गाडी चालवायला सुरुवात करण्यापूर्वी सर्व स्विचची स्थिती जाणून घ्या.
- कमी वेगाने गाडी चालवा आणि तुमचा स्पीडोमीटर पहा. इतर वाहनांपासून सुरक्षित अंतर ठेवा. तुमचे वाहन आणि समोरील वाहन यांच्यात जास्त अंतर ठेवा. तुमच्या मागे खूप जवळ असलेल्या वाहनापासून दूर जाण्यासाठी वेग वाढवू नका.
- कमी बीमवर लाईट्स लावून गाडी चालवा. जास्त बीम धुक्यात प्रकाश टाकतात, ज्यामुळे तुम्हाला दिसणे कठीण होते.
- बंद हेडलाइट्स रस्त्यावर प्रकाश टाकतात आणि इतर वाहनचालकांना तुम्हाला पाहण्यास मदत करतात. फॉग लाईट्स वापरा.
- तुम्हाला दिसत नसलेल्या ट्रॅफिककडे लक्ष द्या. इतर गाड्या आणि ड्रायव्हर हेडलाइट्स वापरत नाहीत याची काळजी घ्या. चांगले ऐकण्यासाठी तुमची खिडकी थोडी उघडा.
- जास्तीत जास्त दृश्यमानतेसाठी आवश्यक असलेले वायपर आणि डेमिस्टर वापरा. रस्त्यांवर रंगवलेल्या खुणा मार्गदर्शक म्हणून वापरा. जर तुमची गाडी बिघडली तर रस्त्याच्या सर्वात दूरच्या कोपऱ्यावर तुमची गाडी पार्क करा. तुमचे धोक्याचे इशारा देणारे दिवे चालू करा. सुरक्षित अंतरावर परावर्तक इशारा त्रिकोण लावा. तुम्हाला दिसणार नाही अशा वाहतुकीकडे लक्ष ठेवा.

टेकड्यांवर गाडी चालवणे

- डोंगरावरून गाडी चालवताना, इंजिन बंद करू नका. वेग कमी करण्यासाठी कमी गिअरवर जा आणि कमी गिअरवर जाण्याने तुम्ही इंधन वाचवू शकाल.
- उंच टेकड्या चढताना, गाडीचा वेग कमी होऊ शकतो आणि त्यात पॉवरची कमतरता दिसून येऊ शकते. जर असे झाले तर, तुम्ही कमी गियरमध्ये बदलले पाहिजे जेणेकरून इंजिन पुन्हा त्याच्या सामान्य पॉवर रेंजमध्ये चालू होईल.

अधिक मायलेज, अधिक मजा

- ४५ ते ५५ किमी/ताशी वेगाने गाडी चालवा.
- चाचण्यांमधून असे सिद्ध झाले आहे की तुम्ही ८० किमी/ताशीच्या तुलनेत ४० किमी/ताशी वेगाने ४०% पर्यंत अतिरिक्त मायलेज मिळवू शकता.
- अनावश्यकपणे वेग वाढवणे किंवा कमी करणे टाळा. चुकीच्या गीअर शिफ्टमुळे इंधनाचा वापर २०% पर्यंत वाढू शकतो. ती पेट्रोल कार आहे की डिझेल कार आहे हे महत्त्वाचे नाही.
- शहरात गाडी चालवताना, इंजिनला अडचण येणार नाही याची खात्री झाल्यावर जास्त गियरवर बदला.
- शक्य तितक्या लवकर टॉप गियरमध्ये जा.

- तुमच्या गाडीची सर्व्हिसिंग सुरू असताना चाके मोकळी फिरत आहेत का ते तपासा. बाइंडिंग ब्रेकमुळे चाकांची मोकळी हालचाल मर्यादित होते आणि इंजिन प्रतिकारावर मात करण्यासाठी जास्त पेट्रोल वापरते. पेट्रोल कार आणि डिझेल कारची तुलना केली तरीही हा कायदा लागू होतो.
- क्लच चालवल्याने ऊर्जा कमी होते आणि क्लचच्या अस्तराचे नुकसान होते.
- तुमची कार नियमितपणे ट्यूनिंग करून तुम्ही ६% पर्यंत इंधन वाचवू शकता. जर तुमच्या इंजिनमधून काळा किंवा गडद राखाडी धूर निघत असेल, तर त्याची ओढण्याची शक्ती कमी आहे किंवा ते मोठ्या प्रमाणात तेल वापरते. अधिकृत सर्व्हिस स्टेशनवर त्वरित ते तपासा.
- तुमचे एअर फिल्टर इंजिनमध्ये हवा खराब होण्यापासून रोखते. धुळीमुळे इंजिनचे घटक जलद झीज होतात आणि इंधनाचा वापर वाढतो.
- इंधन टाकीच्या टोपीला चांगला रबर सील असल्याची खात्री करा.
- अनावश्यक भारांमुळे इंधनाचा वापर वाढतो. शहरात गाडी चालवताना सुमारे ५० किलो वजन कमी केल्याने इंधनात २% बचत होऊ शकते. तुमची कार भारतातील सर्वात इंधन कार्यक्षम पेट्रोल कार असल्याचा दावा केला जात असला तरीही तुमचा भार हलका करा.
- फुगवलेल्या टायर्समुळे रोलिंग रेझिस्टन्स वाढतो, ज्यामुळे इंधनाचा वापर जास्त होतो आणि बाजूचे टायर जलद खराब होतात, मग ते पेट्रोल असो वा डिझेल कार.

हाय स्पीड वॉच-आउट्स

- वाहनाच्या वेगानुसार थांबण्याचे अंतर हळूहळू वाढते. थांबण्याच्या ठिकाणाच्या खूप आधी ब्रेक लावा जेणेकरून जास्त थांबण्याचे अंतर मिळेल.
- जास्त वेगाने, बाजूच्या वाऱ्यांमुळे वाहनावर परिणाम होऊ शकतो. म्हणून, वेग कमी करा आणि बोगद्यांच्या बाहेर पडताना, टेकडीच्या टोकावरून जाताना किंवा मोठ्या वाहनांनी ओव्हरटेक केल्यावर होणाऱ्या अनपेक्षित धडकेसाठी तयार रहा.

चांगली देखभाल, लांब ड्राइव्ह

- तुमच्या वाहनाची सर्व प्रतिबंधात्मक देखभाल करा आणि देखभाल वेळापत्रकाचे पालन करा.
- जर तुम्हाला काही बिघाड आढळला तर तुमच्या सर्व्हिस स्टेशनचा सल्ला घ्या.
- सर्व चालकांनी वाहनाच्या आत आणि बाहेर दररोज वाहन चालवण्यापूर्वी तपासणी करणे आवश्यक आहे.