ASUSTeK	COMPUTER				
INC.					

# EAH6950 Date:Mar. 3, 2 Standard Operation Procedure Revision:1.01

Doc. No:
Date:Mar. 3, 2011

Page: 10 Grade:

Rev.	Modified Chapters	Modification Description	Issued Dept.	Issued by	Revised Date
1.00		First Release	GRMA	Ariel_wang	Jan.30,2011
1.01		Add new P/N(C1CQ85-A01)	GRMA	Ariel wang	Mar.3,2011

Authorize by		Review by		Originator By	Ariel
-----------------	--	--------------	--	------------------	-------

Form No: T2-009-01 Rev.01

EAH6950 Standard Operation Procedure

Doc. No:

Date: Mar. 3, 2011

Rev.: 1.01 Page: 1

## 1.Objectives

Create test procedure.

2.Scope

Model: EAH6950

PN: C1CQ80 (A01) C1CQ85(A01)

3.Test Item

3.1 Diagnostic test in 64-bit Linux

3.2 3DMark06(contain HDMI test)

3.3 Temperature test

### **4.Relevant Document**

None.

**5.Definition**: 1. If the model name contains P, please test HDCP function.

Ex: EAH\*\*\*/HTDP/512M/A

- 2. If you test HDMI already, it's unnecessary to test HDCP. The HDMI contains HDCP function.
- 3. System Memory: 1GB for a single GPU test station; please add an additional 512MB of system memory for each additional GPU used for the test configuration
- 4. EAH6950 Test Program in 64-bit Linux system.

ASUSTEK COMPUTER INC

EAH6950
Standard Operation Procedure

Doc. No:

Date: Mar. 3, 2011

Rev.: 1.01 Page: 2

## **6. Operation Procedures:**

#### 6.1 Attention

- 6.1.1 To avoid damaging devices or M/B, please turn off A/C power then unplug VGA card.
- 6.1.2 While unplugging the card, do it in upright direction to avoid damaging slot & golden finger.
- 6.1.3 If any problem happens, please inform test supervisor. Base on ATX power specification, +5V standby voltage is existed while AC power is connecting. For safety reason, please turn off main power during break time or idling test.
- 6.1.4 Some test items should be tested under Windows environment. (Please install windows test environment by yourself).

EAH6950 Standard Operation Procedure Doc. No:

Date: Mar. 3, 2011 Rev.: 1.01 Page: 3

#### **6.2** Fixture connect

- 6.2.1 Install Intel P5 CPU & CPU Fan.
- 6.2.2 Install DDR2 1GB Memory to DIMM1~4. (a minimum memory of 2GB for Linux test)
- 6.2.3 Plug USB Mouse and PS/2 Keyboard into MB.
- 6.2.4 Plug VGA Card EAH6950 into PCIEX16 1.
- 6.2.5 If this card has 6 PIN or 8 PIN of Power supply, please connect power con of VGA card & Power supply via bundled power cable.

(6 PIN of Power supply to 6 PIN of VGA card) (8 PIN of Power supply to 8 PIN of VGA card)





6.2.6 Connect SATA HDD & SATA con via SATA cable



- 6.2.7 Plug 4PIN 12V power(a minimum power of 1200W) cable into CON12V.
- 6.2.8 Plug ATX Power on Power(a minimum power of 1200W) Connector.



## EAH6950 Standard Operation Procedure

Doc. No:

Date: Mar. 3, 2011 Rev.: 1.01 Page: 4

#### 6.3 Certain test.

#### 6.3.1 Diagnostic test in 64-bit LINUX system

6.3.1.1 Please connect LCD monitor & card's DVI CON via a DVI cable.



- 6.3.1.2 Press Power Switch then turn on power button.
- 6.3.1.3 Press "Del" to enter CMOS setup menu while boot screen is displaying.

EXIT -> Load Setup Defaults. Advanced Power Exit Options Exit system setup Exit & Save Changes Exit & Discard Changes after saving the changes. Discard Changes F10 key can be used for this operation. Load Setup Defaults Select Screen Select Item Enter Go to Sub-screen General Help Save and Exit Exit (C)Copyright 1985-2002, American Megatrends

6.3.1.4 Run test program in 64-bit linux system.

Path:eah6950\c1cq80a0.sh

Path:eah6950\c1cq85a0.sh

Please enter into the file of eah6950 enter the following command: cd./eah6950

Then,please run ./c1cq80a0.sh or ./c1cq85a0.sh

6.3.1.5 Memory test

If you want to test memory, please run ./tserver -test=memfa

Path:eah6950\

6.3.1.6 BIOS Version

If you want to see the version of bios, please run ./atiflash -ai 0.

Path:eah6950\

6.3.1.7 BIOS flash

Please use the following command to flash bios and notice the size of character.

Path:eah6950\

Command:./atiflash -p -f 0 xxx.rom

Notice:

If you can not flash bios because of the bios locked, please use ./atiflash –unlockrom 0 to unlock bios. And then, please use ./atiflash –lockrom 0 to lock bios after updating latest bios.

# EAH6950 Standard Operation Procedure

Doc. No:

Date: Mar. 3, 2011 Rev.: 1.01 Page: 5

6.3.1.8 After finishing 64-bit Linux testing, please enter Windows environment to test 3DMark.


#### 6.3.2 3DMark test(contain HDMI test)

- 6.3.2.1 Please install 3DMark program by yourself.
- 6.3.2.2 Please connect VGA card to LCD via Display port cable.



#### Display Port CON(\*4)

- 6.3.2.3 Please install VGA card driver in Windows(You must use individual driver of this card).
- 6.3.2.4 Please run 3DMark06 base on this card (please test 1 cycle).
- 6.3.2.5 Press "Select" to enter Select test menu. You can choose "HDR1" for default setting.




6.3.2.6 Press "Demo" to enter Demo menu. You can choose "Sounds" for default setting.

# EAH6950 Standard Operation Procedure

Doc. No:

Date: Mar. 3, 2011 Rev.: 1.01 Page: 6



- 6.3.2.7 Please pay attention to check if there is flickering, discolor, crash and so on. If there's no problem, it can be judged OK!
- 6.3.2.8 Please listen to voice carefully to check whether it outputs sounds. If not, HDMI test fail.



6. 3.2.9 If test OK, please test temperature test.

EAH6950 Standard Operation Procedure


Doc. No:
Date: Mar. 3, 2011
Rev.: 1.01 Page: 7

## **6.4 Temperature test**

- 6.4.1 Please copy Thermaltool(1.0.05) to Windows by yourself.
- 6.4.2 Please run ThermalTest.exe.



6.4.3 If test ok, show pass.




6.4.4 If test fail, show fail.

# EAH6950 Standard Operation Procedure

Doc. No:

Date: Mar. 3, 2011 Rev.: 1.01 Page: 8



6.4.5 If test OK, please NTF test.

EAH6950 Standard Operation Procedure Doc. No:

Date: Mar. 3, 2011 Rev.: 1.01 Page: 9

# 7.Appendix

NO#	Equipment Description	ASUS Part#	Supplier	Quantity	Remarks
1	Dell 30 inches (3008WFP) (Buying a local LCD by yourself)			1	P. Sept III George and A. Sept St. St. St. St. St. St. St. St. St. St
2	USB MOUSE			1	
3	PS/2 KEYBOARD			1	
4	ATX POWER SUPPLY(a minimum power of 500W)			1	
5	INTEL Celeron E1200			1	61200
6	Heat sink + FAN	22-240000160		1	
7	DDR2(667/800) 1G	04G0016169A9NE /22-T00642404		4	
8	TEST HDD			1	
9	SATA HDD Cable	14-000107070	ASUS	1	
10	PCIEX16 VGA CARD			1	
11	Dual link DVI cable (Buying a local DVI cable by yourself)			1	O'
12	HDMI extend cable (Buying a local HDMI cable by yourself)			1	O
13	P5E MB	80- MBB7X0-*		1	
14	Display port cable (Buying a local Display port cable by yourself)			1	A city