GTX960 Standard Operation Procedure

Doc. No: Date: Apr. 15. 2016

Page: 12 Grade:

Revision:1.82

0Rev	Modified Chapters	Modification Description	Issued Dept.	Issued by	Revised Date
1.66		Add new PCBA(YV07N3-B02)	GRTD	Xiaoming Lu	Mar.18.1016
1.67		Add new PCBA(YV07N2-B01)	GRTD	Xiaoming Lu	Mar.18.1016
1.68		Add new PCBA(YV07NB-A02)	GRTD	Xiaoming Lu	Mar.18.1016
1.69		Add new PCBA(YV07N8-B12)	GRTD	Xiaoming Lu	Mar.25.1016
1.70		Add new PCBA(YV07N9-B12)	GRTD	Xiaoming Lu	Mar.25.1016
1.71		Add new PCBA(YV08B3-A35)	GRTD	Xiaoming Lu	Mar.25.1016
1.72		Add new PCBA(YV07ND-B01)	GRTD	Xiaoming Lu	Mar.25.1016
1.73		Add new PCBA(YV07NE-A12)	GRTD	Xiaoming Lu	Apr.1.1016
1.74		Add new PCBA(YV07NA-A12)	GRTD	Xiaoming Lu	Apr.1.1016
1.75		Add new PCBA(YV07N1-B12)	GRTD	Xiaoming Lu	Apr.8.1016
1.76		Add new PCBA(YV07N0-C32)	GRTD	Xiaoming Lu	Apr.15.1016
1.77		Add new PCBA(YV07N2-B12)	GRTD	Xiaoming Lu	Apr.15.1016
1.78		Add new PCBA(YV07N3-B12)	GRTD	Xiaoming Lu	Apr.15.1016
1.79		Add new PCBA(YV07N7-A15)	GRTD	Xiaoming Lu	Apr.15.1016
1.80		Add new PCBA(YV07NC-A13)	GRTD	Xiaoming Lu	Apr.15.1016
1.81		Add new PCBA(YV08B5-A14)	GRTD	Xiaoming Lu	Apr.15.1016
1.82		Add new PCBA(YV07N0-A5E)	GRTD	Xiaoming Lu	Apr.15.1016

Authorize by	Review by	Originator By	Mao

Form No: T2-009-01 Rev.01

		Doc. No:
ASUSTEK COMPUTER INC		Date: Apr. 15. 2016
	Standard Operation Procedure	Rev.: 1.82 Page: 1

1.Objectives

Create test procedure.

2.Scope

Model: GTX960

PN: YV07N3(B02) YV07N2(B01) YV07NB(B02) YV07N8(B12) YV07N9(B12)

YV08B3(A35) YV07ND(B01) YV07NE(A12) YV07NA(A12) YV07N1(B12) YV07N0(C23) YV07N2(B12) YV07N3(B12) YV07N7(A15) YV07NC(A13)

YV08B5(A24) YV07N0(A5E)

3.Test Item

3.1 Diagnostic test in Tiny Linux

4.Relevant Document

None.

5.Definition: 1. If the model name contains P, please test HDCP function.

Ex: EAH***/HTDP/512M/A

2. If you test HDMI already, it's unnecessary to test HDCP. The HDMI contains HDCP function.

GTX960 Date: Apr. 15. 2016
Standard Operation Procedure Rev.: 1.82 Page: 2

Doc. No:
Date: Apr. 15. 2016

6. Operation Procedures:

6.1 Attention

- 6.1.1 To avoid damaging devices or M/B, please turn off A/C power then unplug VGA card.
- 6.1.2 While unplugging the card, do it in upright direction to avoid damaging slot & golden finger.
- 6.1.3 If any problem happens, please inform test supervisor. Base on ATX power specification, +5V standby voltage is existed while AC power is connecting. For safety reason, please turn off main power during break time or idling test.
- 6.1.4 Some test items should be tested under Windows environment. (Please install windows 7 test environment by yourself).

6.2 Fixture connect

- 6.2.1 Install Intel CPU & CPU Fan.
- 6.2.2 Install DDR3 Memory to DIMM1~4...
- 6.2.3 Plug USB Mouse and PS/2 Keyboard into MB.
- 6.2.4 Plug VGA Card GTX960 into PCIEX16.
- 6.2.5 Connect power con of VGA card & Power supply via bundled power cable.
- 6.2.6 Connect SATA HDD with SATA CON.




GTX960 Standard Operation Procedure Rev.: 1.82 Page: 3

Doc. No:

Date: Apr. 15. 2016

6.2.7 Plug 4PIN 12V (1200W) power cable into CON12V.

6.2.8 Plug ATX Power (1200W) on Power Connector.



6.3 Diagnostic test in Tiny Linux.

6.3.1Please connect LCD monitor & card's first DVI CON via a DVI cable.




6.3.2 Press Power Switch then turn on power button.

6.3.3 Press "Del" to enter CMOS setup menu while boot screen is displaying. EXIT -> Load Setup Defaults.

GTX960 Standard Operation Procedure | Rev.: 1.82 Page: 4

Doc. No:

Date: Apr. 15. 2016



6.3.4 System will reboot, select Linux to run test program.

Path: GTX960r\yv07n3b0.sh or yv07n2b0.sh or yv07nbb0.sh or yv07ndb0.sh or

yv07n2b1.sh or yv07n3b1.sh or yv07n7a1.sh or yv07nca1.sh

Path: GTX960s\yv07n8b1.sh or yv07n9b1.sh or yv07n1b1.sh

Path: GTX960t\yv08b3a3.sh

Path: GTX960u\yv07naa1.sh or yv07nea1.sh Path: GTX960v\yv07n0c2.sh or yv07n0a5.sh

Path: GTX960w\yv08b5a2.sh

Run the test program refer to the prompt.

6.3.5 Memory test

If you want to test memory, please run ./mats -e xx

Where,-c xx----- only xx% of frame buffer is detected.

Path: GTX960r\ Path: GTX960s\ Path: GTX960t Path: GTX960u\ Path: GTX960v\ Path: GTX960w\

6.3.7 BIOS flash

Please use the following command to flash bios and notice the size of character.

Path: Path: GTX960\

Command:nvflash xxx.rom -6 -A

Notice:

If you can not flash bios because of the bios locked, please use nvflash.exe /r or nvflash.exe –r to unlock bios. And then, please use nvflash.exe /w or nvflash.exe –w to lock bios after updating latest bios.

6.3.8 Please connect LCD monitor & card's the other DVI CON via a DVI cable.

(Please refer to step 6.3.2&6.3.4)

GTX960 Standard Operation Procedure Rev. : 1.82 Page: 5

Doc. No:

Date: Apr. 15. 2016



6.3.9 If test OK, NTF test.

7 Appendix

NO#	Equipment Description	ASUS Part#	Supplier	Quantity	Remarks
1	SAMSUNG 2232MW			1	
2	USB MOUSE			1	
3	PS/2 KEYBOARD			1	
4	ATX POWER SUPPLY(a minimum power of 500W)			1	
5	Intel CPU Intel(R) Core(TM)2 CPU		local	1	E11200
6	Heat sink + FAN	22-240000160		1	
7	DDR3 1333 2G	20-TT2605618	local	4	James Dr., Market
8	TEST HDD			1	
9	SATA HDD Cable	14-000107070	ASUS	1	
10	PCIEX16 VGA CARD			1	

GTX960 Standard Operation Procedure Rev. : 1.82 Page: 6

Doc. No:

Date: Apr. 15. 2016

11	Dual link DVI cable (Buying a local DVI cable by yourself)		1	
12	HDMI extend cable (Buying a local HDMI cable by yourself)		1	O
13	P7H55-M/USB3 MB	80- MIBBKA-*	1	
14	TV extend cable (Buying a local TV cable by yourself)		1	
15	LCD "Y" Cable	14-010230000	1	
16	HDMI to MINI HDMI cable (Buying a local cable by yourself)		1	