CORVETTE PCI-EXPRESS EDGE CONNECTOR +3.3V_BUS PCIe RESET Buffered +12<u>V_BUS</u> +3.3V_BUS +3.3V_BUS x16 PCle +3.3V_BUS PRSNT1#A1 +12V#A2 +12V#A3 GND#A4 JTAG2 JTAG3 JTAG4 JTAG5 +3.3V#A9 +3.3V#A10 PERST# R102 10K 6,15 1V_LDO_POK >> R103 0R PERST# GND#A12
REFCIAREFCIAREFCIAREFCIAREFCIAGND#A15
PERR0
PERR0
GND#A18
RSVD#A19
GND#A20
PERR1
PERR1
GND#A23
GND#A24
PERR2
PERR2
GND#A24
GND#A24
GND#A28
PERR4
GND#A38
PERR4
GND#A38
PERR5
GND#A38 GND#B16 PRSNT2#B17 GND#B18 PETp1 PETn1 GND#B21 GND#B22 BETp2 R104 OR DNI Place these caps as close to the PCIE Place R104 in U100 CAP CER 10UF 20% 16V X5R (1206)1.8MM H MAX U101C 74LCX125M 100pF_50V +12V BUS C151 C152 = 150nF_16V = 150nF_16V →>> PERST#_buf 2,18 C161 100pF_50V GND#B43 GND#B44 PERDIS
PE +3.3V_BUS CAP CER 10UF 10% 6.3V X5R +3.3V_BUS (0805)1.4MM MAX THICK +3.3V_BUS U101A 74LCX125M C162 100pF_50V C156 $\stackrel{\wedge}{\uparrow}$ BUO BRING UP **AMD** Commerce Valley Drive East Markham, Ontario et 1 of 21 RH JUNIPER LE GDDR5 1GB DP+DP/HDMI+2xDVI Doc No. 105-C012xx-00C







































