GTX780 (C2083X) Repair Guide

ASUS Model name	MATRIX-GTX780TI-P-3GD5-2DIS
ASUS P/N	60YV05G0-VG0A02
Graphics Engine	GF GTX770
GPU P/N	02004-00350200
Bus Standard	PCI Express 3.0
Video Memory	GDDR5 3GB
Memory Interface	256-bit

Page1. Basic Information about the Model


Page2. Block Diagram


Page3. Power Flow

Page4. Important Signal map (Top side)

Page U.3 as US MATRIX 4th - BIOCK Diagram: MELOCK-EDILA BY a MATRIX 4th - BIOCK Diagram: 01. NVVDD 12 Phase SAP (with dual EXT 8pin) 02. Triple Voltage Control: Digi VRM + up6262 (NVVDD+FBVDDQ + PLL)

- 03. Individual 3V3F (replace BUS 3V3)
- 04. Memory Heater (with HW switch EXT 4pin)
- 05. LN2 ROM/MODE (with HW switch)
- 06. Safemode BIOS switch Button
- 07. MCU GPU loading LED module 08. Analog VGA Hot Wire (connect to PWR IC)
- 09. MB SM BUS (via PCI-E slot) (connect to MCU)
- 10. MCU ADC Temp sensor(3 point) + Voltage sensor(5 point)





Power Flow

