ASUSTeK	COMPUTER				
INC.					

# ENG210 Date: AUG. 19, Standard Operation Procedure Revision: 1.00

Doc. No: Date: AUG. 19, 2009

Page: 8 Grade:

Rev.	Modified Chapters	Modification Description	Issued Dept.	Issued by	Revised Date
1.00		Frist release	GTC	Kelvin Cao	Aug.19,2009

Authorize by Review by Originator By Kelvin	
---	--

Form No: T2-009-01 Rev.01

## ENG210 Standard Operation Procedure

Doc. No:

Date: AUG.19, 2009 Rev.: 1.00 Page:1

## 1.Objectives

Create test procedure.

2.Scope

Model: ENG210 PN: C1CMY0

3.Test Item

3.1 Diagnostic test in DOS

3.2 3DMark05(contain HDMI test)

### **4.Relevant Document**

None.

**5.Definition**: 1. If the model name contains P, please test HDCP function.

Ex: EN\*\*\*/HTDP/512M/A

2. If you test HDMI already, it's unnecessary to test HDCP. The HDMI contains HDCP function.

## ENG210 Standard Operation Procedure

Doc. No:
Date: AUG. 19, 2009

Rev.: 1.00 Page: 2

## 6. Operation Procedures:

#### 6.1 Attention

- 6.1.1 To avoid damaging devices or M/B, please turn off A/C power then unplug VGA card.
- 6.1.2 While unplugging the card, do it in upright direction to avoid damaging slot & golden finger.
- 6.1.3 If any problem happens, please inform test supervisor. Base on ATX power specification, +5V standby voltage is existed while AC power is connecting. For safety reason, please turn off main power during break time or idling test.
- 6.1.4 Some test items should be tested under Windows environment. (Please install windows test environment by yourself).

ENG210 Standard Operation Procedure Doc. No:

Date: AUG. 19, 2009

Rev.: 1.00 Page: 3

#### **6.2** Fixture connect

- 6.2.1 Install Intel P5 CPU & CPU Fan.
- 6.2.2 Install DDR2 667/800M 1GB Memory to DIMM1~2.
- 6.2.3 Plug PS/2 Mouse and Keyboard into PS/2 port.
- 6.2.4 Plug VGA Card ENG210 into PCIEX16.
- 6.2.5 Connect power con of VGA card & Power supply via bundled power cable.



6.2.6 Connect SATA HDD with SATA CON.



- 6.2.7 Plug 4PIN 12V power cable into CON12V.
- 6.2.8 Plug ATX Power on Power Connector.



ENG210 Standard Operation Procedure

Doc. No:
Date: AUG. 19, 2009
Rev.: 1.00 Page: 4


#### 6.3 Certain test.

#### 6.3.1 Diagnostic test in DOS

6.3.1.1 Please connect LCD monitor & card's D-SUB CON via a D-SUB cable.



- 6.3.1.2 Press Power Switch then turn on power button.
- 6.3.1.3 Press "Del" to enter CMOS setup menu while boot screen is displaying. EXIT -> Load Setup Defaults.



6.3.1.4 System will reboot, select DOS to run test program.

Path: VBAT\ENG210\BATCH\

Run the test program refer to the prompt.

6.3.1.5 Memory test

If you want to test memory, please run Mats.exe.

Path: VBAT\ENG210\DIAG\185.17 (C1CMY0)

6.3.1.6 BIOS flash

Please use the following command to flash bios and notice the size of character.

Path: VBAT\ENG210\BIOS

Command: Nyflash -4 -5 -6 -A XXX.rom

6.3.1.7 After finish DOS testing, please enter Windows environment to test 3DMark.

ENG210 Standard Operation Procedure


Doc. No:
Date: AUG. 19, 2009
Rev.: 1.00 Page: 5

#### 6.3.2 3DMark test(contain HDMI test)

- 6.3.2.1 Please install 3DMark program by yourself.
- 6.3.2.2 Please connect LCD monitor & card's DVI CON via a DVI cable or Please connect VGA card to LCD via HDMI cable.



- 6.3.2.3 Please install VGA card driver in Windows(You must use individual driver of this card).
- 6.3.2.4 Please run 3DMark05 base on this card (please test 1 cycle).
- 6.3.2.5 Press "Select" to enter Select test menu. You can choose "HDR1" for default setting.




## ENG210 Standard Operation Procedure

Doc. No:

Date: AUG. 19, 2009 Rev.: 1.00 Page: 6

6.3.2.6 Press "Demo" to enter Demo menu. You can choose "Sounds" for default setting(for HDMI function).



- 6.3.2.7 Please pay attention to check if there is flickering, discolor, crash and so on. If there's no problem, it can be judged OK!
- 6.3.2.8 Please listen to voice carefully to check whether it outputs sounds. If not, HDMI test fail(for HDMI function).



6.3.2.9 If test OK, please NTF test.

ENG210 Standard Operation Procedure Doc. No:

Date: AUG. 19, 2009 Rev.: 1.00 Page: 7

# 7.Appendix

NC#   Equipment Description   ASUS Part#   Supplier   Quantity   Remarks				1		1
1	NO#	<b>Equipment Description</b>	ASUS Part#	Supplier	Quantity	Remarks
3	1	LCD MONITOR			1	
4 ATX POWER SUPPLY(600W)  5 INTEL P5 CPU  1  6 Heat sink + FAN  22-240000160  1  7 MEMORY DDR  APACER 400MHz 512M or 400MHz 1G  8 TEST HDD  1  1  9 40Pins IDE Cable ATA66  ASUS  1  10 PCIEX16 VGA CARD  11  11  12  13 Dual link DVI cable (Buying a local DVI cable by yourself)  12 (Buying alocal HDMI cable by yourself)  13 DVI-HDMI  14 TV extend cable (Buying a local IV cable by yourself)  15 ATI S CABLE  16 PSE  80-MBB7X0-G0A01  1  17  18  18  19  10  11  11  11  12  13  14  15  16 PSE  80-MBB7X0-G0A01  1  17  18  18  18  19  10  10  11  11  11  12  13  14  15  16 PSE  80-MBB7X0-G0A01  1  16 PSE  80-MBB7X0-G0A01  1  14  14  15  16 PSE  80-MBB7X0-G0A01  1  14  16 PSE  80-MBB7X0-G0A01  1  14  16 PSE  80-MBB7X0-G0A01  1  14  16 PSE  80-MBB7X0-G0A01	2	PS/2 MOUSE			1	
SUPPLY(600W)   1	3	PS/2 KEYBOARD			1	
6 Heat sink + FAN 22-240000160 1  7 MEMORY DDR APACER 400MHz 1  8 TEST HDD 1  9 40Pins IDE Cable ATA66 ASUS 1  10 PCIEX16 VGA CARD 1  11 Dual link DVI cable (Buying a local DVI cable by yourself) 1  12 (Buying a local DVI cable by hy yourself) 1  13 DVI-HDMI 04G460002400 1  14 (Buying a local TV cable by yourself) 1  15 ATI S CABLE 14G001801801 1  16 P5E 80-MBB7X0-G0A01 1	4				1	
Test Hdd	5	INTEL P5 CPU			1	
NEMORY DDR	6	Heat sink + FAN	22-240000160		1	
9 40Pins IDE Cable ATA66 ASUS 1  10 PCIEX16 VGA CARD  11 Dual link DVI cable (Buying a local DVI cable by yourself)  12 (Buying a local HDMI cable by yourself)  13 DVI-HDMI 04G460002400 1  14 (Buying a local TV cable by yourself)  15 ATI S CABLE 14G001801801 1  16 P5E 80-MBB7X0-G0A01 1	7	MEMORY DDR			1	
10	8	TEST HDD			1	
1	9	40Pins IDE Cable ATA66		ASUS	1	
11	10	PCIEX16 VGA CARD			1	
12   (Buying a local HDMI cable by yourself)   1   1   1   1   1   1   1   1   1	11	(Buying a local DVI cable by			1	O
13 DVI-HDMI 04G460002400	12	(Buying a local HDMI cable			1	
14     (Buying a local TV cable by yourself)     1       15     ATI S CABLE     14G001801801     1       16     P5E     80-MBB7X0-G0A01     1       17     Power Cable     14G000602510     1	13	DVI-HDMI			1	
16 P5E 80-MBB7X0-G0A01 1  17 Power Cable 14G000602510 1	14	(Buying a local TV cable by			1	
17 Power Cable 14G000602510						
	16	P5E	80-MBB7X0-G0A01		1	
	17	Power Cable			1	

ENG210 Standard Operation Procedure Doc. No:

Date: AUG. 19, 2009 Rev.: 1.00 Page: 8

18	LCD "Y" Cable	14-010230000	1	
19	D-SUB extend cable (Buying a local D-SUB cable by yourself)		1	